



2011 Harley-Davidson Softail Models Service Manual

©2010 H-D.
ALL RIGHTS RESERVED
99482-11

Printed in the U.S.A.

ABOUT THIS MANUAL

GENERAL

This Service Manual has been prepared with two purposes in mind. First, it will acquaint the user with the construction of the Harley-Davidson product and assist in the performance of basic maintenance and repair. Secondly, it will introduce to the professional Harley-Davidson Technician the latest field-tested and factory-approved major repair methods. We sincerely believe that this Service Manual will make your association with Harley-Davidson products more pleasant and profitable.

HOW TO USE YOUR SERVICE MANUAL

Refer to the table below for the content layout of this manual.

NO.	CHAPTER
1	Maintenance
2	Chassis
3	Engine
4	Fuel System
5	Drive
6	Transmission
7	Electrical
A	Appendix A Connector Repair
B	Appendix B Wiring
C	Appendix C ABS
D	Appendix D Conversions
E	Appendix E Glossary

Use the TABLE OF CONTENTS (which follows this FOREWORD) and the INDEX (at the back of this manual) to quickly locate subjects. Chapters and topics in this manual are sequentially numbered for easy navigation.

For example, a cross-reference shown as **2.2 SPECIFICATIONS** refers to chapter 2 CHASSIS, heading 2.2 SPECIFICATIONS.

For quick and easy reference, all pages contain a chapter number followed by a page number. For example, **page 3-5** refers to page 5 in Chapter 3.

A number of acronyms and abbreviations are used in this document. See the E.1 GLOSSARY for a list of acronyms, abbreviations and definitions.

PREPARATION FOR SERVICE

WARNING

Stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near gasoline. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00002a)

Good preparation is very important for efficient service work. A clean work area at the start of each job will allow you to perform the repair as easily and quickly as possible, and will reduce the incidence of misplaced tools and parts. A motorcycle that is excessively dirty should be cleaned before work starts. Cleaning will occasionally uncover sources of trouble. Tools, instruments and any parts needed for the job should be

gathered before work is started. Interrupting a job to locate tools or parts is a distraction and causes needless delay.

NOTES

- To avoid unnecessary disassembly, carefully read all relative service information before repair work is started.
- In figure legends, the number which follows the name of a part indicates the quantity necessary for one complete assembly.
- When servicing a vehicle equipped with the Harley-Davidson Smart Security System (H-DSSS), you must first disarm the security system. Either keep the fob in close proximity to the vehicle, or use Digital Technician II to disable the security system while the vehicle is being serviced and re-enable the system after service is completed.

SERVICE BULLETINS

In addition to the information presented in this manual, Harley-Davidson Motor Company will periodically issue service bulletins to Harley-Davidson dealers. Service bulletins cover interim engineering changes and supplementary information. Consult the service bulletins to keep your product knowledge current and complete.

USE GENUINE REPLACEMENT PARTS

WARNING

Harley-Davidson parts and accessories are designed for Harley-Davidson motorcycles. Using non-Harley-Davidson parts or accessories can adversely affect performance, stability or handling, which could result in death or serious injury. (00001b)

To achieve satisfactory and lasting repairs, carefully follow the service manual instructions and use only genuine Harley-Davidson replacement parts. Behind the emblem bearing the words GENUINE HARLEY-DAVIDSON stand more than 100 years of design, research, manufacturing, testing and inspecting experience. This is your assurance that the parts you are using will fit right, operate properly and last longer.

WARNINGS AND CAUTIONS

Statements in this manual preceded by the following words are of special significance.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. (00119a)

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. (00139a)

NOTICE

NOTICE indicates a potentially hazardous situation which, if not avoided, may result in property damage. (00140b)

NOTE

Refers to important information, and is placed in italic type. It is recommended that you take special notice of these items.

Proper service and repair is important for the safe, reliable operation of all mechanical products. The service procedures recommended and described in this manual are effective methods for performing service operations.

WARNING

Always wear proper eye protection when using hammers, arbor or hydraulic presses, gear pullers, spring compressors, slide hammers and similar tools. Flying parts could result in death or serious injury. (00496b)

Some of these service operations require the use of tools specially designed for the purpose. These special tools should be used when and as recommended. It is important to note that some warnings against the use of specific service methods, which could damage the motorcycle or render it unsafe, are stated in this manual. However, remember that these warnings are not all-inclusive. Inadequate safety precautions could result in death or serious injury.

Since Harley-Davidson could not possibly know, evaluate or advise the service trade of all possible ways in which service might be performed, or of the possible hazardous consequences of each method, we have not undertaken any such broad evaluation. Accordingly, anyone who uses a service procedure or tool which is not recommended by Harley-Davidson must first thoroughly satisfy himself that neither his nor the operator's safety will be jeopardized as a result. Failure to do so could result in death or serious injury.

PRODUCT REFERENCES

WARNING

Read and follow warnings and directions on all products. Failure to follow warnings and directions can result in death or serious injury. (00470b)

When reference is made in this manual to a specific brand name product, tool or instrument, an equivalent product, tool or instrument may be substituted.

Kent-Moore Products

All tools mentioned in this manual with an "HD", "J" or "B" preface must be ordered through SPX Kent-Moore. For ordering

information or product returns, warranty or otherwise, visit www.spx.com.

Loctite Sealing and Threadlocking Products

Some procedures in this manual call for the use of Loctite products. If you have any questions regarding Loctite product usage or retailer/wholesaler locations, please contact Loctite Corp. at www.loctite.com.

PRODUCT REGISTERED MARKS

Apple, Alcantara S.p.A., Allen, Amp Multilock, Bluetooth, Brembo, Delphi, Deutsch, Dunlop, Dynojet, Fluke, G.E. Versilube, Garmin, Gunk, Hydroseal, Hylomar, iPhone, iPod, Kevlar, Lexan, Loctite, Lubriplate, Keps, K&N, Magnaflux, Marson Thread-Setter Tool Kit, MAXI fuse, Molex, Michelin, MPZ, Multilock, nano, NGK, Novus, Packard, Pirelli, Permatex, Philips, PJ1, Pozidriv, Robinair, S100, Sems, Snap-on, Teflon, Threadlocker, Torca, Torco, TORX, Tufoil, Tyco, Ultratorch, Velcro, X-Acto, XM Satellite Radio, and zumo are among the trademarks of their respective owners.

H-D MICHIGAN, INC. TRADEMARK INFORMATION

Harley, Harley-Davidson, H-D, Bar & Shield, Cross Bones, Digital Tech, Digital Technician, Digital Technician II, Dyna, Electra Glide, Evolution, Fat Bob, Fat Boy, Glaze, Gloss, H-D, H-Dnet.com, HD, Harley, Harley-Davidson, Heritage Softail, Low Rider, Night Rod, Nightster, Night Train, Profile, Revolution, Road Glide, Road King, Road Tech, Rocker, Softail, Sportster, Street Glide, Street Rod, Sun Ray, Sunwash, Tech Link, Twin Cam 88, Twin Cam 88B, Twin Cam 96, Twin Cam 96B, Twin Cam 103, Twin Cam 103B, Twin Cam 110, Twin Cam 110B, Tour-Pak, Screamin' Eagle, Softail, Super Glide, SYN3, Ultra Classic, V-Rod, VRSC and Harley-Davidson Genuine Motor Parts and Genuine Motor Accessories are among the trademarks of H-D Michigan, Inc.

CONTENTS

All photographs, illustrations and procedures may not necessarily depict the most current model or component, but are based on the latest production information available at the time of publication.

Since product improvement is our continual goal, Harley-Davidson reserves the right to change specifications, equipment or designs at any time without notice and without incurring obligation.

MAINTENANCE

1.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....1-1

1.2 GENERAL

Servicing a New Motorcycle.....	1-4
Safe Operating Maintenance.....	1-4
Shop Practices.....	1-4
Repair Notes.....	1-4
Safety.....	1-4
Removing Parts.....	1-4
Cleaning.....	1-4
Disassembly and Assembly.....	1-5
Checking Torques on Fasteners.....	1-5
Magnetic Parts Trays.....	1-5
Repair and Replacement Procedures.....	1-5
Hardware and Threaded Parts.....	1-5
Threadlocking Agents.....	1-5
Wiring, Hoses and Lines.....	1-5
Instruments and Gauges.....	1-5
Bearings.....	1-5
Bushings.....	1-5
Gaskets.....	1-5
Lip-Type Seals.....	1-5
O-Rings (Pre-Formed Packings).....	1-5
Gears.....	1-6
Shafts.....	1-6
Part Replacement.....	1-6
Exhaust System Leakage.....	1-6
Cleaning.....	1-6
Part Protection.....	1-6
Cleaning Process.....	1-6
Rust or Corrosion Removal.....	1-6
Bearings.....	1-6
Tool Safety.....	1-6
Air Tools.....	1-6
Wrenches.....	1-6
Pliers/Cutters/Pry Bars.....	1-6
Hammers.....	1-6
Punches/Chisels.....	1-7
Screwdrivers.....	1-7
Ratchets and Handles.....	1-7
Sockets.....	1-7
Storage Units.....	1-7

1.3 FUEL AND OIL

Fuel.....	1-8
Gasoline Blends.....	1-8
Engine Lubrication.....	1-8
Winter Lubrication.....	1-9

1.4 BULB REQUIREMENTS

General.....1-10

1.5 MAINTENANCE SCHEDULE

General.....1-11

1.6 ENGINE OIL AND FILTER

Checking and Adding Oil.....	1-15
Type of Oil.....	1-15
Checking Oil Level.....	1-15
Changing Oil and Filter.....	1-15

1.7 AIR CLEANER AND EXHAUST SYSTEM

Removal.....	1-17
Installation.....	1-18
Exhaust System Leak Check.....	1-19

1.8 TIRES AND WHEELS

General.....	1-20
Tires.....	1-20
Tire Replacement.....	1-21
Inspection.....	1-21
When To Replace Tires.....	1-21
Wheel Bearings.....	1-21
Wheel Spokes.....	1-21
Identify Wheel Spoke Groups.....	1-21
Wheel Spoke Adjustment.....	1-21

1.9 PRIMARY CHAINCASE LUBRICANT

General.....	1-23
Changing Primary Chaincase Lubricant.....	1-23

1.10 TRANSMISSION LUBRICANT

Changing Transmission Lubricant.....1-25

1.11 CLUTCH

Adjustment.....1-27

1.12 DRIVE BELT AND SPROCKETS

General.....	1-29
Cleaning.....	1-29
Inspection.....	1-29
Sprockets.....	1-29
Drive Belt.....	1-29
Checking Belt Deflection.....	1-30
Adjusting Belt Deflection.....	1-31

1.13 THROTTLE CABLES

Cable Inspection, Lubrication and Adjustment.....	1-33
Inspection and Lubrication.....	1-33
Adjustment.....	1-33

1.14 CABLE AND CHASSIS LUBRICATION

General.....	1-34
Cables and Hand Levers.....	1-34
Jiffy Stand.....	1-34
Steering Head Bearings.....	1-34

1.15 BRAKES

Fluid Inspection.....	1-35
Rear Brake Pedal.....	1-35
Pedal Height.....	1-35
Pedal Lubrication.....	1-35
Pedal Pad.....	1-35

1.16 BRAKE PADS AND DISCS

Inspection.....	1-36
Brake Pads.....	1-36
Brake Disc.....	1-36
Brake Pad Replacement.....	1-36
Rear Brake Caliper.....	1-36
Front Brake Caliper.....	1-38

1.17 SPARK PLUGS

Inspection.....	1-40
Spark Plug Cable Inspection.....	1-40

TABLE OF CONTENTS

1.18 SUSPENSION ADJUSTMENTS	
Shock Absorbers.....	1-42
Calculate Number of Turns.....	1-42
Adjustment.....	1-42
1.19 STEERING HEAD BEARINGS: ALL BUT FLSTSB	
Adjustment: FLSTC, FLSTF/B, FLSTN.....	1-43
Bearing Adjustment (Fall-away).....	1-43
Adjustment: FXST, FXCWC.....	1-43
Bearing Adjustment (Fall-away).....	1-43
Lubrication.....	1-45
1.20 STEERING HEAD BEARINGS: FLSTSB	
General.....	1-46
Lubrication.....	1-46
Adjustment: FLSTSB.....	1-46
Bearing Adjustment (Fall-away).....	1-46
1.21 ROCKER BEARINGS: FLSTSB	
Inspection.....	1-48
1.22 HEADLAMP ALIGNMENT	
Headlamp Alignment.....	1-50
Headlamp Adjustment.....	1-50
1.23 CRITICAL FASTENERS	
Inspection.....	1-52
Checking Torques on Fasteners.....	1-52
1.24 BATTERY MAINTENANCE	
General.....	1-53
Cleaning and Inspection.....	1-54
Voltmeter Test.....	1-54
Voltmeter Test.....	1-54
Charging Battery.....	1-54
Safety Precautions.....	1-54
Using a Battery Charger.....	1-54
Disconnection and Removal.....	1-55
Storage.....	1-56
Installation and Connection.....	1-57
1.25 ENGINE MOUNTS	
Inspection.....	1-59
1.26 STORAGE	
General.....	1-60
Placing in Storage.....	1-60
Removal from Storage.....	1-60
1.27 TROUBLESHOOTING	
General.....	1-62
Engine.....	1-62
Starter Motor Does Not Operate or Does Not Turn Engine Over	1-62
Engine Turns Over But Does Not Start	1-62
Starts Hard.....	1-62
Starts But Runs Irregularly or Misses	1-62
A Spark Plug Fouls Repeatedly.....	1-63
Pre-Ignition or Detonation (Knocks or Pings).....	1-63
Overheating.....	1-63
Valve Train Noise.....	1-63
Excessive Vibration.....	1-63
Check Engine Light Illuminates During Operation.....	1-63
Lubrication System.....	1-63
Oil Does Not Return To Oil Tank.....	1-63
Engine Uses Too Much Oil Or Smokes Excessively.....	1-63
Engine Leaks Oil From Cases, Push Rods, Hoses, Etc.....	1-63
Low Oil Pressure.....	1-64
High Oil Pressure.....	1-64
Electrical System.....	1-64
Alternator Does Not Charge.....	1-64
Alternator Charge Rate Is Below Normal.....	1-64
Speedometer Operates Erratically.....	1-64
Transmission.....	1-64
Shifts Hard.....	1-64
Jumps Out Of Gear.....	1-64
Clutch Slips.....	1-64
Clutch Drags Or Does Not Release.....	1-64
Clutch Chatters.....	1-64
Handling.....	1-64
Irregularities.....	1-64
Brakes.....	1-64
Brake Does Not Hold Normally.....	1-64
CHASSIS	
2.1 FASTENER TORQUE VALUES	
Fastener Torque Values in this Chapter.....	2-1
2.2 SPECIFICATIONS	
Specifications.....	2-5
Chassis Specifications.....	2-5
Tire Specifications.....	2-6
2.3 VEHICLE IDENTIFICATION NUMBER (V.I.N.)	
Vehicle Identification Number.....	2-8
2.4 FRONT WHEEL: ALL BUT FLSTSB	
Removal.....	2-10
Disassembly.....	2-10
Disc Wheel.....	2-10
Laced Wheel.....	2-10
Cleaning and Inspection.....	2-12
Assembly.....	2-12
Disc Wheel.....	2-12
Laced Wheel.....	2-12
Installation.....	2-13
2.5 FRONT WHEEL: FLSTSB	
Removal.....	2-14
Disassembly.....	2-14
Cleaning and Inspection.....	2-14
Assembly.....	2-14
Installation.....	2-15
2.6 REAR WHEEL	
Removal.....	2-16
Disassembly.....	2-16

TABLE OF CONTENTS

Cleaning and Inspection.....	2-17	Disassembly.....	2-53
Assembly.....	2-17	Cleaning, Inspection and Repair.....	2-55
Installation.....	2-18	Assembly.....	2-56
2.7 SEALED WHEEL BEARINGS			
Inspection.....	2-19	Rear Brake Line Routing.....	2-56
Removal.....	2-19	Installation.....	2-56
Installation.....	2-20		
2.8 WHEEL LACING			
Wheel Lacing: Angle Flange Hub.....	2-22		
2.9 TRUING LACED WHEELS			
General.....	2-24	General.....	2-60
Laced Wheel Rim Offset.....	2-24	Removal.....	2-60
Truing Laced Wheels.....	2-25	Cleaning, Inspection and Repair.....	2-61
Radial Runout.....	2-25	Installation.....	2-61
Lateral Runout.....	2-26	Tube Type Tires.....	2-61
2.10 CHECKING CAST WHEEL RUNOUT			
General.....	2-28	Tubeless Tires.....	2-61
Checking Wheel Runout.....	2-28	Checking Tire Runout.....	2-62
Checking Lateral Runout.....	2-28	Lateral Runout.....	2-62
Checking Radial Runout.....	2-28	Radial Runout.....	2-62
Radial Runout.....	2-28	Wheel Balancing.....	2-63
2.11 VEHICLE ALIGNMENT			
Inspection.....	2-30	Weights.....	2-63
2.12 FRONT BRAKE MASTER CYLINDER			
General.....	2-31		
Removal and Disassembly.....	2-31		
Cleaning and Inspection.....	2-33		
Assembly and Installation.....	2-33		
2.13 FRONT BRAKE CALIPER: ALL BUT FLSTSB			
Removal.....	2-35		
Disassembly.....	2-35		
Cleaning, Inspection and Repair.....	2-37		
Assembly.....	2-38		
Installation.....	2-39		
2.14 FRONT BRAKE CALIPER: FLSTSB			
Removal.....	2-41		
Disassembly.....	2-42		
Cleaning and Inspection.....	2-43		
Assembly.....	2-44		
Installation.....	2-45		
2.15 REAR BRAKE MASTER CYLINDER			
General.....	2-47		
Removal.....	2-47		
Installation.....	2-47		
Disassembly.....	2-50		
Cleaning and Inspection.....	2-51		
Assembly.....	2-51		
2.16 REAR BRAKE CALIPER			
Removal.....	2-53		

TABLE OF CONTENTS V

TABLE OF CONTENTS

FLSTC, FLSTF/B, FLSTN Models.....	2-80
FXST Models.....	2-80
FXCWC Models.....	2-80
FLSTSB Models.....	2-80
2.22 BELT GUARD AND DEBRIS DEFLECTOR	
Removal.....	2-81
Belt Guard.....	2-81
Debris Deflector.....	2-81
Installation.....	2-81
Belt Guard.....	2-81
Debris Deflector.....	2-81
2.23 REAR SHOCK ABSORBERS	
General.....	2-82
Removal.....	2-82
Installation.....	2-82
Shock Disposal.....	2-83
2.24 REAR FORK	
Removal.....	2-85
Cleaning and Inspection.....	2-86
Pivot Bearing Replacement.....	2-86
Installation.....	2-87
2.25 THROTTLE CONTROL	
Removal/Disassembly.....	2-88
Cleaning and Inspection.....	2-88
Assembly/Installation.....	2-88
2.26 CLUTCH CONTROL	
Removal.....	2-90
Installation.....	2-90
2.27 HANDLEBARS: ALL BUT FLSTF, FLSTFB, FLSTSB, FXCWC	
Removal.....	2-92
Installation.....	2-92
2.28 HANDLEBARS: FLSTF/B	
Removal.....	2-94
Installation.....	2-95
2.29 HANDLEBARS: FLSTSB	
Removal.....	2-98
Installation.....	2-98
2.30 HANDLEBARS: FXCWC	
Removal.....	2-100
Installation.....	2-101
2.31 FRONT FENDER: ALL BUT FLSTSB	
Removal.....	2-104
Installation.....	2-104
2.32 FRONT FENDER: FLSTSB	
Removal.....	2-105
Installation.....	2-106
2.33 REAR FENDER: FLSTC	
Removal.....	2-107
Installation.....	2-107
2.34 REAR FENDER: FLSTF/B	
Removal.....	2-109
Installation.....	2-109
2.35 REAR FENDER: FXST, FLSTSB	
Removal.....	2-111
Installation.....	2-111
2.36 REAR FENDER: FXCWC	
Removal.....	2-113
Installation.....	2-113
2.37 REAR FENDER: FLSTN	
Removal.....	2-115
Disassembly.....	2-115
Assembly.....	2-117
Installation.....	2-117
2.38 REAR FENDER WIRE CONDUIT	
Installation.....	2-118
2.39 FOOTBOARDS AND FOOTRESTS	
Rider Footboards.....	2-120
Removal.....	2-120
Installation.....	2-120
Rider Footrest.....	2-120
Removal.....	2-120
Installation.....	2-120
Passenger Footrest.....	2-120
Removal.....	2-120
Installation.....	2-120
2.40 JIFFY STAND	
Cleaning.....	2-122
Sensor (HDI Models).....	2-122
Removal.....	2-123
Installation.....	2-123
2.41 FORK LOCK	
Removal.....	2-124
Installation.....	2-124
2.42 SEAT AND STRAP RETENTION NUT	
Replacement.....	2-125
2.43 SEAT: FXST	
Removal and Installation.....	2-126
Seat Strap.....	2-126
Seat.....	2-126
2.44 SEAT: FXCWC	
Removal and Installation.....	2-127
Rider Seat.....	2-127
Passenger Seat Support.....	2-127

TABLE OF CONTENTS

2.45 SEAT: FLSTN, FLSTF, FLSTFB, FLSTC		3-20
Removal and Installation.....	2-128	
2.46 SEAT: FLTSB		3-20
Seat: FLTSB.....	2-129	
Removal.....	2-129	
Installation.....	2-129	
Adjusting Seat Position.....	2-129	
2.47 LUGGAGE RACK: FLSTN		
Removal and Installation.....	2-131	
2.48 SADDLEBAGS: FLSTC		
Removal.....	2-132	
Installation.....	2-132	
2.49 WINDSHIELD: FLSTC		
Removal.....	2-133	
Installation.....	2-133	
ENGINE		
3.1 FASTENER TORQUE VALUES		
Fastener Torque Values in this Chapter.....	3-1	
3.2 SPECIFICATIONS		
Specifications.....	3-3	
3.3 SERVICE WEAR LIMITS		
General.....	3-5	
3.4 ENGINE OIL FLOW		
Oil Feed.....	3-7	
Top End.....	3-8	
Bottom End.....	3-9	
Chain Guide Bracket.....	3-11	
Oil Return.....	3-12	
3.5 OIL PUMP OPERATION		
General.....	3-13	
Operation.....	3-13	
3.6 BREATHER OPERATION		
General.....	3-15	
3.7 OIL PRESSURE		
Oil Pressure Indicator Lamp.....	3-16	
Checking Oil Pressure.....	3-16	
3.8 TROUBLESHOOTING		
Diagnosing Valve Train Noise.....	3-18	
Compression Test.....	3-18	
Cylinder Leakdown Test.....	3-18	
Diagnosing Smoking Engine or High Oil Consumption.....	3-19	
Check Prior To Cylinder Head Removal.....	3-19	
Check After Cylinder Head Removal.....	3-19	
3.9 HOW TO USE THIS SECTION		
Top End Repair.....	3-20	
Bottom End Repair.....	3-20	
3.10 TOP END SERVICE		
Engine in Chassis.....	3-21	
Engine Removed from Chassis.....	3-22	
3.11 CAM COMPARTMENT SERVICE		
Engine in Chassis.....	3-23	
Engine Removed From Chassis.....	3-24	
3.12 STRIPPING MOTORCYCLE FOR SERVICE		
Procedure.....	3-25	
3.13 ASSEMBLING MOTORCYCLE AFTER SERVICE		
Procedure.....	3-26	
3.14 REMOVING ENGINE FROM CHASSIS		
Procedure.....	3-27	
3.15 INSTALLING ENGINE IN CHASSIS		
Procedure.....	3-28	
3.16 TOP END OVERHAUL: DISASSEMBLY		
General.....	3-30	
Rocker Covers.....	3-30	
Rocker Arm Support Plate.....	3-30	
Push Rods, Lifters and Covers.....	3-32	
Cylinder Head.....	3-33	
Cylinder.....	3-34	
Piston.....	3-34	
3.17 BREATHER ASSEMBLY		
Disassembly.....	3-36	
Early Production.....	3-36	
Late Production.....	3-36	
Cleaning and Inspection.....	3-36	
Assembly.....	3-36	
Early Production.....	3-36	
Late Production.....	3-36	
3.18 ROCKER ARM SUPPORT PLATE		
Disassembly.....	3-38	
Cleaning and Inspection.....	3-38	
Inspection.....	3-38	
Rocker Shaft Fit.....	3-38	
Rocker Arm Shaft to Bushing.....	3-39	
Replace Rocker Arm Bushings.....	3-39	
Assembly.....	3-40	
3.19 PUSH RODS, LIFTERS AND COVERS		
Disassembly.....	3-41	
Cleaning and Inspection.....	3-41	
Lifter Inspection.....	3-42	
Assembly.....	3-42	
3.20 CYLINDER HEAD		
Disassembly.....	3-43	

TABLE OF CONTENTS VII

TABLE OF CONTENTS

Cleaning.....	3-44	Cleaning and Inspection.....	3-85
Inspection.....	3-44	Installation.....	3-86
Cylinder Head.....	3-44		
Valve Guides.....	3-45		
Valves.....	3-45		
Valve Springs.....	3-45		
Tapered Keepers.....	3-45		
Valve Seats.....	3-45		
Valve Guide Replacement.....	3-45		
Removal.....	3-45		
Installation.....	3-46		
Valve and Seat Refacing.....	3-49		
Assembly.....	3-51		
3.21 CYLINDER			
Cleaning.....	3-54		
Inspection.....	3-54		
Deglazing Cylinder.....	3-56		
Boring and Honing Cylinder.....	3-56		
3.22 PISTON			
Disassembly.....	3-58		
Piston Rings.....	3-58		
Cleaning.....	3-58		
Inspection.....	3-58		
Assembly.....	3-60		
Checking Piston Ring Gap.....	3-60		
Installing Piston Rings.....	3-60		
3.23 TOP END OVERHAUL: ASSEMBLY			
General.....	3-62		
Piston.....	3-62		
Cylinder.....	3-63		
Cylinder Head.....	3-65		
Push Rods, Lifters and Covers.....	3-69		
Rocker Arm Support Plate.....	3-70		
Breather and Rocker Cover.....	3-71		
3.24 CAM COMPARTMENT AND COMPONENTS			
Cam Support Plate and Cover Removal.....	3-73		
Prepare Engine.....	3-73		
Cam Chain and Sprockets Removal.....	3-73		
Cam Support Plate Removal.....	3-74		
Cam Support Plate Cleaning and Inspection.....	3-75		
Oil Pressure Valve.....	3-75		
Cam Support Plate.....	3-75		
Camshafts.....	3-75		
Removal.....	3-75		
Installation.....	3-76		
Oil Pressure Relief Valve.....	3-77		
Removal.....	3-77		
Inspection.....	3-77		
Installation.....	3-77		
Cam Needle Bearings.....	3-78		
Removal.....	3-78		
Installation.....	3-79		
Cam Support Plate and Cover Installation.....	3-81		
3.25 OIL PUMP			
Removal.....	3-85		
Cleaning and Inspection.....	3-85		
Installation.....	3-86		
3.26 CRANKCASE DISASSEMBLY AND REPAIR			
Crankcase Disassembly.....	3-87		
Counterbalancer Assembly.....	3-87		
Cleaning and Inspection.....	3-89		
Right Crankcase Half.....	3-90		
Chain Guide Screen.....	3-90		
Main Bearing Removal.....	3-90		
Main Bearing Installation.....	3-91		
Piston Jets Removal.....	3-91		
Piston Jets Installation.....	3-91		
Left Crankcase Half.....	3-92		
Main Bearing Removal.....	3-92		
Main Bearing Installation.....	3-93		
Sprocket Shaft Bearing Inner Race.....	3-93		
Removal.....	3-93		
Installation.....	3-94		
Cylinder Studs.....	3-96		
Removal.....	3-96		
Installation.....	3-96		
Pipe Plugs and Oil Fittings.....	3-96		
Removal/Installation.....	3-96		
3.27 FLYWHEEL AND CONNECTING RODS			
Inspection.....	3-97		
Measuring Crankshaft Runout.....	3-97		
Crankshaft Removed.....	3-97		
3.28 COUNTERBALANCER ASSEMBLY REPAIR			
Cleaning, Inspection, and Repair.....	3-99		
General.....	3-99		
Balance Shaft Removal.....	3-99		
Balance Shaft Installation.....	3-100		
Balance Shaft Support Bearings Removal.....	3-100		
Balance Shaft Support Bearings Installation.....	3-100		
Front and Rear Balance Sprockets.....	3-101		
Hydraulic Tensioners.....	3-101		
Chain Tensioner Guides.....	3-102		
Balance Shaft Support.....	3-102		
Balance Chain.....	3-102		
3.29 CRANKCASE ASSEMBLY			
Counterbalancer Assembly Installation.....	3-103		
Crankcase.....	3-106		
3.30 OIL TANK: ALL BUT FXCWC			
Removal and Disassembly.....	3-109		
Oil Tank.....	3-109		
Oil Line Fittings/Retainers.....	3-111		
Installation.....	3-112		
3.31 OIL TANK: FXCWC			
Removal and Disassembly.....	3-113		
Oil Tank.....	3-113		
Oil Line Fittings/Retainers.....	3-116		
Installation.....	3-117		

VIII TABLE OF CONTENTS

TABLE OF CONTENTS

FUEL SYSTEM	
4.1 FASTENER TORQUE VALUES	
Fastener Torque Values in this Chapter.....	4-1
4.2 SPECIFICATIONS: FUEL SYSTEM	
Specifications.....	4-3
4.3 ELECTRONIC FUEL INJECTION (EFI)	
Troubleshooting.....	4-4
4.4 IDLE SPEED	
General.....	4-5
4.5 AIR CLEANER ASSEMBLY	
Removal.....	4-6
Installation.....	4-6
Backplate Assembly: HDI Models.....	4-7
4.6 FUEL TANK	
General.....	4-8
Removal.....	4-8
Cleaning and Inspection.....	4-12
Installation.....	4-12
All But FXCWC.....	4-12
FXCWC.....	4-12
4.7 THROTTLE POSITION SENSOR (TPS)	
General.....	4-14
Removal.....	4-14
Installation.....	4-14
4.8 INTAKE AIR TEMPERATURE SENSOR (IAT)	
General.....	4-15
Removal.....	4-15
Installation.....	4-15
4.9 ENGINE TEMPERATURE SENSOR (ET)	
General.....	4-16
Removal.....	4-16
Installation.....	4-17
4.10 INDUCTION MODULE	
Removal.....	4-18
Installation.....	4-19
4.11 IDLE AIR CONTROL (IAC)	
General.....	4-20
Removal.....	4-20
Installation.....	4-20
4.12 MANIFOLD ABSOLUTE PRESSURE SENSOR (MAP)	
General.....	4-21
Removal.....	4-21
Installation.....	4-21
4.13 OXYGEN SENSOR	
General.....	4-22
Removal.....	4-22
Installation.....	4-22
4.14 FUEL INJECTORS	
General.....	4-24
Removal.....	4-24
Installation.....	4-24
4.15 FUEL PUMP AND FUEL GAUGE SENDING UNIT	
General.....	4-26
Removal.....	4-26
Vapor Valve.....	4-28
Disassembly/Assembly.....	4-28
Fuel Filter.....	4-28
Regulator.....	4-29
Inlet sock.....	4-29
Fuel Pump.....	4-30
Installation.....	4-30
4.16 FUEL PRESSURE TEST	
General.....	4-32
Testing.....	4-32
4.17 EXHAUST SYSTEM: ALL BUT FLSTF, FLSTFB, FLSTN, FLSTS	
Mufflers.....	4-35
Removal.....	4-35
Assembly.....	4-35
System.....	4-35
Removal.....	4-35
Installation.....	4-35
4.18 EXHAUST SYSTEM: FLSTF, FLSTFB, FLSTN, FLSTS	
Mufflers.....	4-37
Removal.....	4-37
Assembly.....	4-37
System.....	4-37
Removal.....	4-37
Installation.....	4-37
4.19 INTAKE LEAK TEST	
General.....	4-39
Leak Tester.....	4-39
Parts List.....	4-39
Tester Assembly.....	4-39
Tester Adjustment.....	4-39
Procedure.....	4-39
4.20 EVAPORATIVE EMISSIONS CONTROL SYSTEM	
General.....	4-41
Charcoal Canister.....	4-42
Removal.....	4-42
Installation.....	4-42
Purge Solenoid.....	4-42

TABLE OF CONTENTS

Removal.....	4-42
Installation.....	4-42
Hose Routing/Replacement.....	4-42
Fuel Tank Vent Hose.....	4-42
Purge Solenoid-to-Induction Module Tube.....	4-42
Charcoal Canister-to-Purge Solenoid Tube.....	4-43
Vent Tube-to-Charcoal Canister Tube.....	4-43
DRIVE	
5.1 FASTENER TORQUE VALUES	
Fastener Torque Values in this Chapter.....	5-1
5.2 SPECIFICATIONS: DRIVE	
Specifications.....	5-2
5.3 PRIMARY CHAINCASE COVER	
General.....	5-3
Removal.....	5-3
Installation.....	5-3
5.4 DRIVE COMPONENTS	
Removal.....	5-4
Installation.....	5-5
5.5 PRIMARY CHAINCASE HOUSING	
Removal.....	5-10
Inspection.....	5-10
Mainshaft Bearing and Lip Seal.....	5-10
Removal.....	5-10
Installation.....	5-10
Mainshaft Bearing Inner Race.....	5-11
Removal.....	5-11
Installation.....	5-12
Installation.....	5-12
5.6 CLUTCH	
Removal and Installation.....	5-14
Clutch Pack Only.....	5-14
Partial Disassembly.....	5-14
Cleaning And Inspection.....	5-14
Assembly.....	5-15
Clutch Pack and Bearing.....	5-16
Complete Disassembly.....	5-16
Assembly.....	5-17
5.7 TRANSMISSION SPROCKET	
Removal.....	5-19
Cleaning and Inspection.....	5-20
Installation.....	5-20
5.8 DRIVE BELT	
Removal.....	5-22
Inspection.....	5-22
Installation.....	5-22
TRANSMISSION	
6.1 FASTENER TORQUE VALUES	
Fastener Torque Values in this Chapter.....	6-1
6.2 SPECIFICATIONS: TRANSMISSION	
Specifications.....	6-2
Service Wear Limits.....	6-2
6.3 TRANSMISSION	
Power Flow.....	6-3
Neutral.....	6-3
1st Gear.....	6-3
2nd Gear.....	6-3
3rd Gear.....	6-3
4th Gear.....	6-3
5th Gear.....	6-3
6th Gear.....	6-3
6.4 SHIFTER LINKAGE	
Adjustment.....	6-5
Shifter Rod.....	6-5
6.5 CLUTCH RELEASE COVER	
Removal and Disassembly.....	6-6
Cleaning and Inspection.....	6-6
Assembly and Installation.....	6-7
6.6 TRANSMISSION ASSEMBLY	
Removal.....	6-8
Disassembly.....	6-9
Shifter Cam/Shifter Forks.....	6-9
Mainshaft.....	6-11
Countershaft.....	6-14
Removing Side Door Bearings.....	6-15
Cleaning and Inspection.....	6-16
Assembly.....	6-16
Installing Side Door Bearings.....	6-16
Countershaft.....	6-16
Mainshaft.....	6-17
Shifter Cam/Shifter Forks.....	6-17
Installation.....	6-19
6.7 MAIN DRIVE GEAR AND BEARING	
Removal.....	6-21
Cleaning and Inspection.....	6-22
Needle Bearing Replacement.....	6-23
Installation.....	6-24
Installing Main Drive Gear Bearing.....	6-24
Installing Main Drive Gear.....	6-25
Installing Main Drive Gear Large Seal.....	6-25
6.8 TRANSMISSION CASE	
Removal.....	6-28
Installation.....	6-28
Disassembly.....	6-29
Shifter Arm Assembly.....	6-29
Cleaning and Inspection.....	6-29
Assembly.....	6-30
Countershaft Needle Bearing Replacement.....	6-30
Shifter Pawl Lever Assembly.....	6-30

TABLE OF CONTENTS

ELECTRICAL

7.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....7-1

7.2 SPECIFICATIONS: ELECTRICAL

Specifications.....7-4

7.3 ELECTRICAL PANEL

General.....7-5
Removal: All But FXCWC.....7-5
Installation: All But FXCWC.....7-6
Removal: FXCWC.....7-6
Installation: FXCWC.....7-7

7.4 ELECTRONIC CONTROL MODULE (ECM)

General.....7-9
Removal: All But FXCWC.....7-9
Installation: All But FXCWC.....7-9
Removal: FXCWC.....7-10
Installation: FXCWC.....7-10

7.5 BODY CONTROL MODULE (BCM)

General.....7-11
BCM Configuration.....7-11
Removal.....7-11
Installation.....7-11

7.6 H-DSSS ACTUATION

Sidecar Configuration.....7-12
Actuation.....7-12
Fob Assignment.....7-12

7.7 PERSONAL IDENTIFICATION NUMBER (PIN)

General.....7-13
Changing the Pin.....7-13
 Modifying an Existing Pin.....7-13

7.8 HD-SSS MAINTENANCE

Fob Battery.....7-15
 Battery Replacement Schedule.....7-15
 Battery Replacement.....7-15
Smart Siren (If Installed).....7-15
 Battery Replacement Schedule.....7-15
 Battery Replacement.....7-15

7.9 SECURITY SIREN

Removal.....7-16
Installation.....7-16

7.10 VOLTAGE REGULATOR

General.....7-17

7.11 FRONT ELECTRICAL CADDY

General.....7-18
Disassembly.....7-18
Assembly.....7-18

7.12 FUSES

Removal.....7-19
Installation.....7-19

7.13 IGNITION AND LIGHT SWITCH

General.....7-20
Removal and Installation: All But FXCWC.....7-20
Removal and Installation: FXCWC.....7-21

7.14 BATTERY CABLES

Routing Procedure.....7-22

7.15 STARTER

General.....7-24
Removal.....7-24
Drive Assembly.....7-24
 Disassembly.....7-24
 Inspection.....7-25
 Assembly.....7-25
Solenoid.....7-26
 Cover and Plunger Removal.....7-26
 Short Post Contact: Starter.....7-26
 Long Post Contact: Battery Positive.....7-26
 Plunger and Cover Installation.....7-27
Installation.....7-27

7.16 HEADLAMP

General.....7-28
Removal and Installation.....7-28
 FXCWC Models.....7-28
 FXST and FLSTSB Models.....7-28
 FLSTC, FLSTF/B, and FLSTN Models.....7-28

7.17 TAIL LAMP: ALL BUT FLSTN

General.....7-31
Bulb Replacement.....7-31
Base Replacement.....7-31

7.18 TAIL LAMP: FLSTN

Bulb Replacement.....7-33
Tail Lamp Replacement.....7-33

7.19 AUXILIARY LAMPS: FLSTC, FLSTN

Auxiliary Lamp Bulb.....7-35
 Removal.....7-35
 Installation.....7-35
FLSTC Models.....7-35
 Auxiliary Lamp Bracket Removal.....7-35
 Auxiliary Lamp Bracket Installation.....7-36
 Auxiliary Lamp Housing Removal.....7-36
 Auxiliary Lamp Housing Installation.....7-36
FLSTN Models.....7-38
 Auxiliary Lamp Bracket Removal.....7-38
 Auxiliary Lamp Bracket Installation.....7-38
 Auxiliary Lamp Housing Removal.....7-39
 Auxiliary Lamp Housing Installation.....7-39
Adjustment: FLSTC/FLSTN Models.....7-40

7.20 TURN SIGNALS AND RUNNING LIGHTS

Bulb Replacement: Bullet Style.....7-42

TABLE OF CONTENTS

Bulb Replacement: Flat Lens Style.....	7-42
Lamp Replacement.....	7-42
All Models.....	7-42
Front Turn Signals: All But FLSTC, FLSTN.....	7-43
Front Turn Signals: FLSTC, FLSTN.....	7-43
Rear Turn Signals: All But FXCWC, FLSTN.....	7-43
Rear Turn Signals: FXCWC.....	7-44
Rear Turn Signals: FLSTN.....	7-45
7.21 CRANK POSITION SENSOR (CKP)	
General.....	7-47
Removal.....	7-47
Installation.....	7-47
7.22 IGNITION COIL	
Removal.....	7-48
All Except FXCWC.....	7-48
FXCWC Only.....	7-48
Installation.....	7-48
All Except FXCWC.....	7-48
FXCWC Only.....	7-48
7.23 SPARK PLUG CABLES	
General.....	7-50
Removal.....	7-50
Installation.....	7-50
7.24 ALTERNATOR	
Removal.....	7-51
Cleaning and Inspection.....	7-51
Installation.....	7-51
7.25 FUEL GAUGE	
General.....	7-53
Removal.....	7-53
Installation.....	7-53
7.26 INSTRUMENT CONSOLE: FXCWC	
Removal.....	7-55
Installation.....	7-55
7.27 SPEEDOMETER: ALL BUT FXCWC	
Removal.....	7-56
Installation.....	7-56
7.28 SPEEDOMETER: FXCWC	
Removal.....	7-57
Installation.....	7-57
7.29 VEHICLE SPEED SENSOR (VSS)	
General.....	7-58
Removal.....	7-58
Installation.....	7-58
7.30 INDICATOR LAMPS: ALL BUT FXCWC	
General.....	7-59
Removal.....	7-59
Installation.....	7-59
7.31 INDICATOR LAMPS: FXCWC	
Removal.....	7-61
Installation.....	7-61
7.32 NEUTRAL SWITCH	
General.....	7-62
Removal.....	7-62
Installation.....	7-62
7.33 OIL PRESSURE SWITCH	
General.....	7-63
Removal.....	7-63
Installation.....	7-63
7.34 REAR STOPLIGHT SWITCH	
General.....	7-64
Removal.....	7-64
Installation.....	7-64
7.35 HORN	
Inspection.....	7-65
Removal and Installation: All But FXCWC.....	7-65
Removal and Installation: FXCWC.....	7-66
7.36 ACTIVE EXHAUST	
General.....	7-67
Removal.....	7-67
Repair.....	7-67
Installation.....	7-67
7.37 MAIN WIRING HARNESS	
Removal.....	7-68
Installation.....	7-69
7.38 HANDLEBAR SWITCH ASSEMBLIES	
General.....	7-72
Repair Procedures.....	7-72
7.39 RIGHT HANDLEBAR SWITCH ASSEMBLY	
Removal.....	7-73
Installation.....	7-74
Front Brake Switch Replacement.....	7-75
7.40 LEFT HANDLEBAR SWITCH ASSEMBLY	
Removal.....	7-76
Installation.....	7-76
Clutch Switch Replacement.....	7-77
APPENDIX A CONNECTOR REPAIR	
A.1 AUTOFUSE UNSEALED ELECTRICAL CONNECTORS	
Autofuse Unsealed Connector Repair.....	A-1
General.....	A-1
Disassembly.....	A-1
Assembly.....	A-1

TABLE OF CONTENTS

A.2 DELPHI 100W MICRO-PACK SEALED CONNECTOR

Delphi 100W Micro-Pack Sealed Connector Repair.....	A-2
General.....	A-2
Separating Socket Housing From ECM.....	A-2
Mating Socket Housing To ECM.....	A-2
Removing Socket Terminal.....	A-2
Installing Socket Terminal.....	A-2
Crimping Terminals.....	A-2

A.3 DELPHI 150 METRI-PACK SEALED CONNECTORS

Delphi 150 Metri-Pack Sealed Connector Repair.....	A-4
General.....	A-4
Separating Pin and Socket Housings.....	A-4
Mating Pin and Socket Housings.....	A-4
Removing Socket Terminal.....	A-4
Inserting Socket Terminal.....	A-4

A.4 DELPHI 280 METRI-PACK UNSEALED CONNECTORS

Fuse Block Repair.....	A-6
Removing Socket Terminals.....	A-6
Installing Socket Terminals.....	A-6
Crimping Terminals.....	A-6

A.5 DELPHI 480 METRI-PACK UNSEALED CONNECTORS

Delphi 480 Metri-Pack Unsealed Connector Repair.....	A-7
General.....	A-7
Separating Pin and Socket Housings.....	A-7
Mating Pin and Socket Housings.....	A-7
Removing Socket Terminals.....	A-7
Installing Socket Terminals.....	A-7

A.6 DELPHI 630 METRI-PACK UNSEALED CONNECTORS

Delphi 630 Metri-Pack Unsealed Connector Repair.....	A-8
Separating Pin and Socket Housings.....	A-8
Mating Pin and Socket Housings.....	A-8
Removing Socket Terminal.....	A-8
Installing Socket Terminal.....	A-8

A.7 DELPHI 800 METRI-PACK SEALED MAIN FUSE HOUSING

Delphi 800 Metri-Pack Sealed Main Fuse Housing Repair.....	A-9
Removing Socket Terminals.....	A-9
Installing Socket Terminals.....	A-9

A.8 DELPHI METRI-PACK TERMINAL REPAIR

Metri-Pack Terminal Crimps.....	A-10
Matching Terminal To Crimper.....	A-10
Preparing Wire Lead.....	A-10
Crimping Wire Core.....	A-10
Crimping Insulation/Seal.....	A-10
Inspecting Crimps.....	A-11

A.9 DELPHI MICRO 64 SEALED CONNECTORS

Delphi Micro 64 Sealed Connector Repair.....	A-12
General.....	A-12
Separating Pin and Socket Housings.....	A-12
Mating Pin and Socket Housings.....	A-12
Removing Terminal.....	A-12
Installing Terminal.....	A-13
Preparing Wire Leads for Crimping.....	A-13
Crimping Terminals.....	A-13
Inspecting Crimps.....	A-13

A.10 DELPHI GT 150 SEALED CONNECTORS

Delphi GT 150 Sealed Connector Repair.....	A-15
General.....	A-15
Separating Pin and Socket Housings.....	A-15
Mating Pin and Socket Housings.....	A-15
Removing Socket Terminals.....	A-15
Installing Socket Terminals.....	A-15

A.11 DELPHI GT 280 SEALED 73-TERMINAL ECM CONNECTOR

Delphi GT 280 Sealed 73-Terminal ECM Connector.....	A-17
Separating Socket Housing From ECM.....	A-17
Mating Socket Housing To ECM.....	A-17
Socket Terminal.....	A-17
ECM Ground Terminal.....	A-17

A.12 DEUTSCH DT SEALED CONNECTORS

Deutsch DT Sealed Connector Repair.....	A-19
General.....	A-19
Separating Pin and Socket Housings.....	A-19
Mating Pin and Socket Housings.....	A-19
Removing Socket Terminals.....	A-19
Installing Socket Terminals.....	A-19
Removing Pin Terminals.....	A-21
Installing Pin Terminals.....	A-21
Crimping Terminals.....	A-22

A.13 DEUTSCH DT SEALED TERMINAL REPAIR

Deutsch DT Sealed Terminal Crimps.....	A-23
Preparing Wire Leads for Crimping.....	A-23
Crimping Terminal to Lead.....	A-23
Inspecting Crimps.....	A-23

A.14 DEUTSCH DTM SEALED MINI TERMINAL REPAIR

Deutsch DTM Sealed Mini Terminal Crimps.....	A-24
Preparing Wire Leads for Crimping.....	A-24
Crimping a Mini Terminal to Wire Lead.....	A-24
Inspecting Crimps.....	A-24

A.15 DEUTSCH DTM SEALED SOLID BARREL MINI TERMINAL REPAIR

Deutsch DTM Sealed Solid Barrel Terminal Crimps.....	A-25
Preparing Wire Leads For Crimping.....	A-25
Adjusting Crimper Tool.....	A-25

TABLE OF CONTENTS

Crimping a Barrel Contact To Wire Lead.....	A-25	Wire Color Codes.....	B-4
Inspecting Crimps.....	A-25	Wiring Diagram Symbols.....	B-4
A.16 JAE MX19 SEALED CONNECTORS			
JAE MX19 Sealed Connectors.....	A-27	2011 Softail Wiring Diagrams.....	B-6
Connector Housings.....	A-27		
Removing Terminals.....	A-27		
Installing Terminals.....	A-27		
A.17 MOLEX CMC SEALED CONNECTORS			
Molex CMC Sealed Connectors.....	A-28		
Separating the Connector.....	A-28		
Removing Terminals.....	A-28		
Installing Terminals.....	A-28		
A.18 MOLEX MX 150 SEALED CONNECTORS			
Molex MX 150 Sealed Connector Repair.....	A-30		
Separating Pin and Socket Housings.....	A-30		
Mating Pin and Socket Housings.....	A-30		
Removing Terminals.....	A-30		
Installing Terminals.....	A-30		
Crimp Terminal to Lead.....	A-31		
Prepare Lead.....	A-31		
Prepare Tool.....	A-31		
Position Terminal in the Punch/Die.....	A-32		
Insert Stripped Lead.....	A-32		
Crimp Terminal to Lead.....	A-32		
Inspect Crimp.....	A-33		
A.19 TYCO 070 MULTILOCK UNSEALED CONNECTOR			
Tyco 070 Multilock Unsealed Connector Repair.....	A-34		
General.....	A-34		
Separating Pin and Socket Housings.....	A-34		
Mating Pin and Socket Housings.....	A-34		
Removing Terminals from Housing.....	A-34		
Inserting Terminals into Housing.....	A-35		
Preparing Wire Leads for Crimping.....	A-35		
Crimping Terminals to Leads.....	A-36		
Inspecting Crimped Terminals.....	A-37		
A.20 SEALED SPLICE CONNECTORS			
Sealed Splice Connector Repair.....	A-38		
General.....	A-38		
Preparing Wire Leads.....	A-38		
Splicing Wire Leads.....	A-38		
Inspecting Seals.....	A-38		
APPENDIX B WIRING			
B.1 CONNECTORS			
Connector Locations.....	B-1		
Function/Location.....	B-1		
Place and Color.....	B-1		
Connector Number.....	B-1		
Repair Instructions.....	B-1		
B.2 WIRING DIAGRAMS			
Wiring Diagram Information.....	B-4		
Wire Color Codes.....	B-4		
Wiring Diagram Symbols.....	B-4		
2011 Softail Wiring Diagrams.....	B-6		
APPENDIX C ABS			
C.1 FASTENER TORQUE VALUES			
Fastener Torque Values in this Chapter.....	C-1		
C.2 ELECTRONIC CONTROL UNIT (ECU)			
Removal.....	C-2		
Installation.....	C-2		
C.3 HYDRAULIC CONTROL UNIT (HCU)			
Front Hydraulic Control Unit (HCU).....	C-4		
Removal.....	C-4		
Installation.....	C-4		
Rear Hydraulic Control Unit (HCU).....	C-5		
Removal.....	C-5		
Installation.....	C-5		
C.4 WHEEL SPEED SENSORS			
Front Wheel Speed Sensor.....	C-7		
Removal.....	C-7		
Installation.....	C-7		
Rear Wheel Speed Sensor.....	C-8		
Removal.....	C-8		
Installation.....	C-8		
C.5 ABS BRAKE LINES			
Front Master Cylinder to Front HCU.....	C-10		
Removal.....	C-10		
Installation.....	C-10		
HCU to Front Brake Caliper.....	C-11		
Removal.....	C-11		
Installation.....	C-11		
Rear Master Cylinder to Rear HCU.....	C-12		
Removal.....	C-12		
Installation.....	C-13		
Rear HCU to Rear Brake Caliper.....	C-13		
Removal.....	C-13		
Installation.....	C-14		
APPENDIX D CONVERSIONS			
D.1 METRIC CONVERSION			
Conversion Table.....	D-1		
D.2 FLUID CONVERSIONS			
United States System.....	D-2		
Metric System.....	D-2		
British Imperial System.....	D-2		
D.3 TORQUE CONVERSIONS			
United States System.....	D-3		
Metric System.....	D-3		

TABLE OF CONTENTS

APPENDIX E GLOSSARY

E.1 GLOSSARY

Acronyms and Abbreviations.....E-1

REFERENCE MATERIAL

TOOLS.....I

TORQUE VALUES.....VII

INDEX.....XXI

TABLE OF CONTENTS XV

Thank you so much for reading.

**Please click the “Buy Now!”
button below to download the
complete manual.**

Buy Now



After you pay.

**You can download the most
perfect and complete manual in
the world immediately.**

Our support email:

ebooklibonline@outlook.com