

Workshop Service Manual

7400 series tractors



7400 series tractors

- 1 Introduction
 - 1A10 7400 series tractors - General
 - 1A11 7400 series tractors - Error codes
 - 1A12 7400 series tractors - Electrical and hydraulics diagrams
 - 1A16 7400 series tractors - Adjustments, bleeding and calibrations
- 2 Separation of assemblies

See existing chapter in manual 3378553M4
- 3 Engine
 - 3A10 Sisu Tier 3 engine - General
 - 3A11 Sisu Tier 3 engine - Error codes
 - 3A12 Sisu Tier 3 engine - Electrical and hydraulics diagrams
 - 3A13 Sisu Tier 3 engine - Layout of components
 - 3A14 Sisu Tier 3 engine - Tests and diagnostics
 - 3A15 Sisu Tier 3 engine - Programming and setting parameters
 - 3A16 Sisu Tier 3 engine - Adjustments, bleeding and calibrations
 - 3A17 Sisu Tier 3 engine - Disassembly and reassembly
 - 3A18 Sisu Tier 3 engine - Service tools
- 4 Clutch

Chapter intentionally left blank
- 5 Gearbox
 - 5A10 ML130/ML160 - General
 - 5A11 ML130/ML160 - Error codes
 - 5A12 ML130/ML160 - Electrical and hydraulics diagrams
 - 5A14 ML130/ML160 - Tests and diagnostics
 - 5A15 ML130/ML160 - Programming and setting parameters
 - 5A16 ML130/ML160 - Adjustments, bleeding and calibrations
 - 5A17 ML130/ML160 - Disassembly and reassembly
 - 5A18 ML130/ML160 - Service tools
- 6 Rear axle
 - 6A11 HA130/160 - Error codes
 - 6A15 HA130/160 - Programming and setting parameters
 - 6A16 HA130/160 - Adjustments, bleeding and calibrations
 - 6A23 HA130/160/Final drives - Layout of components
 - 6A25 HA130/160/Final drives - Programming and setting parameters
 - 6A27 HA130/160/Final drives - Disassembly and reassembly
 - 6A31 HA130/160/Differential - Error codes
 - 6A32 HA130/160/Differential - Electrical and hydraulics diagrams
 - 6A33 HA130/160/Differential - Layout of components
 - 6A34 HA130/160/Differential - Tests and diagnostics
 - 6A35 HA130/160/Differential - Programming and setting parameters
 - 6A36 HA130/160/Differential - Adjustments, bleeding and calibrations
 - 6A37 HA130/160/Differential - Disassembly and reassembly

6A41	HA130/160/Tractor braking - Error codes
6A42	HA130/160/Tractor braking - Electrical and hydraulics diagrams
6A43	HA130/160/Tractor braking - Layout of components
6A47	HA130/160/Tractor braking - Disassembly and reassembly
6A50	HA130/160/ParkLock - General
6A51	HA130/160/ParkLock - Error codes
6A52	HA130/160/ParkLock - Electrical and hydraulics diagrams
6A53	HA130/160/ParkLock - Layout of components
6A54	HA130/160/ParkLock - Tests and diagnostics
6A55	HA130/160/ParkLock - Programming and setting parameters
6A56	HA130/160/ParkLock - Adjustments, bleeding and calibrations
6A61	HA130/160/Hydraulic trailer braking - Error codes
6A62	HA130/160/Hydraulic trailer braking - Electrical and hydraulics diagrams
6A64	HA130/160/Hydraulic trailer braking - Tests and diagnostics
6A65	HA130/160/Hydraulic trailer braking - Programming and setting parameters
6A70	HA130/160/Pneumatic trailer braking - General
6A72	HA130/160/Pneumatic trailer braking - Electrical and hydraulics diagrams
6A73	HA130/160/Pneumatic trailer braking - Layout of components
6A74	HA130/160/Pneumatic trailer braking - Tests and diagnostics
6A76	HA130/160/Pneumatic trailer braking - Adjustments, bleeding and calibrations
6A82	HA130/160/Auto-hitch - Electrical and hydraulics diagrams
7	Power take-off
7A11	HA130/160/Power take-off - Error codes
7A12	HA130/160/Power take-off - Electrical and hydraulics diagrams
7A13	HA130/160/Power take-off - Layout of components
7A14	HA130/160/Power take-off - Tests and diagnostics
7A15	HA130/160/Power take-off - Programming and setting parameters
7A16	HA130/160/Power take-off - Adjustments, bleeding and calibrations
7A17	HA130/160/Power take-off - Disassembly and reassembly
7B10	Zuidberg front power take-off - General
7B12	Zuidberg front power take-off - Electrical and hydraulics diagrams
7B13	Zuidberg front power take-off - Layout of components
7B14	Zuidberg front power take-off - Tests and diagnostics
7B16	Zuidberg front power take-off - Adjustments, bleeding and calibrations
8	Front axle
8A11	DANA 735 - Error codes
8A12	DANA 735 - Electrical and hydraulics diagrams
8A14	DANA 735 - Tests and diagnostics
8A15	DANA 735 - Programming and setting parameters
8A16	DANA 735 - Adjustments, bleeding and calibrations
8A17	DANA 735 - Disassembly and reassembly
8B11	DANA 740 - Error codes
8B12	DANA 740 - Electrical and hydraulics diagrams
8B14	DANA 740 - Tests and diagnostics
8B15	DANA 740 - Programming and setting parameters
8B16	DANA 740 - Adjustments, bleeding and calibrations

8B17	DANA 740 - Disassembly and reassembly
8C11	DANA 745 - Error codes
8C12	DANA 745 - Electrical and hydraulics diagrams
8C14	DANA 745 - Tests and diagnostics
8C15	DANA 745 - Programming and setting parameters
8C16	DANA 745 - Adjustments, bleeding and calibrations
8C17	DANA 745 - Disassembly and reassembly
8D11	DANA 750 - Error codes
8D12	DANA 750 - Electrical and hydraulics diagrams
8D14	DANA 750 - Tests and diagnostics
8D15	DANA 750 - Programming and setting parameters
8D16	DANA 750 - Adjustments, bleeding and calibrations
8D17	DANA 750 - Disassembly and reassembly
8E11	DANA 755 - Error codes
8E12	DANA 755 - Electrical and hydraulics diagrams
8E14	DANA 755 - Tests and diagnostics
8E15	DANA 755 - Programming and setting parameters
8E16	DANA 755 - Adjustments, bleeding and calibrations
8E17	DANA 755 - Disassembly and reassembly
8G11	4WD clutch - Error codes
8G12	4WD clutch - Electrical and hydraulics diagrams
8G14	4WD clutch - Tests and diagnostics
8G15	4WD clutch - Programming and setting parameters
8G16	4WD clutch - Adjustments, bleeding and calibrations
9	Hydraulics
	See existing chapter in manual 3378553M4
10	Electricity
10A12	Lighting and equipment - Electrical and hydraulics diagrams
10A13	Lighting and equipment - Layout of components
10B10	Fuse box - General
10B12	Fuse box - Electrical and hydraulics diagrams
10B13	Fuse box - Layout of components
10B17	Fuse box - Disassembly and reassembly
10C14	Alternator - Tests and diagnostics
10C17	Alternator - Disassembly and reassembly
10C18	Alternator - Service tools
10E10	Starter - General
10E14	Starter - Tests and diagnostics
10E17	Starter - Disassembly and reassembly
11	Electronics
11A10	DCC2 - General
11A11	DCC2 - Error codes
11A12	DCC2 - Electrical and hydraulics diagrams
11A15	DCC2 - Programming and setting parameters
11B10	Datatronic 3 - General
11B12	Datatronic 3 - Electrical and hydraulics diagrams
11B15	Datatronic 3 - Programming and setting parameters Datatronic 3 - Adjustments, bleeding and calibrations
11C12	Isobus - Electrical and hydraulics diagrams
11D12	Auto-Guide - Electrical and hydraulics diagrams
11D14	Auto-Guide - Tests and diagnostics

- 11D15 Auto-Guide - Programming and setting parameters
- 11D16 Auto-Guide - Adjustments, bleeding and calibrations
- 11D17 Auto-Guide - Disassembly and reassembly
- 11D18 Auto-Guide - Service tools

- 12 Cab
 - 12A10 Standard air conditioning - General
 - 12A12 Standard air conditioning - Electrical and hydraulics diagrams
 - 12A14 Standard air conditioning - Tests and diagnostics
 - 12A16 Standard air conditioning - Adjustments, bleeding and calibrations
 - 12B10 Self-regulating air conditioning - General
 - 12B11 Self-regulating air conditioning - Error codes
 - 12B12 Self-regulating air conditioning - Electrical and hydraulics diagrams
 - 12B14 Self-regulating air conditioning - Tests and diagnostics
 - 12B16 Self-regulating air conditioning - Adjustments, bleeding and calibrations

- 13 Accessories
 - See existing chapter in manual 3378553M4

- 14 Service tools
 - 14A01 General
 - 14A03 Engine
 - 14A05 Gearbox
 - 14A06 Rear axle
 - 14A11 Electronics

1 Disassembling the Dyna-VT unit

Removing the cab

1. Disconnect all electrical harnesses from the cab front panel and the earth cable.



Fig. 1.

I016165

2. Disconnect the fuel gauge.



Fig. 2.

I016166

3. Remove the step. The nut is difficult to reach because it is located at the back of the step.



Fig. 3.

I016167

4. Remove the front cab supports.




Fig. 4.


I016168

5. Remove the 3 nuts from the rear cab supports on the transmission trumpet housings. The pneumatic springs and suspension system remain attached to the cab.



Fig. 5.

I016169

6.  **DANGER:**
Before disconnecting the pipes, it is necessary to release the pressure in the brake accumulator by pumping on the pedals.

Disconnect the hydraulic pipes from the steering system and braking system.




Fig. 6.

I016170

7. Remove the unions after emptying, taking all necessary precautions to prevent any dirty particles from entering the air conditioning system
NOTE: It is recommended to raise the cab slightly before splitting it.



Fig. 7.

I016172

8. Pinch the heating pipes closed to avoid draining the system.



Fig. 8.

I016165


9.  **CAUTION:**
Take care not to damage the roof cap.

Attach the cab to a suitable lifting system and raise it.



Fig. 9.

I016173

10.  **CAUTION:**
Take care not to lose the small fasten-
ing clips.

Disconnect the following cables:


- hand brake cable
- mechanical spool valves control cable



Fig. 10.

I016174

11. Disconnect the following pipes:
- cab heating pipes
 - brake and clutch pipes

12.  **CAUTION:**
Do not remove the hoses from the bar, as the assembly must be handled complete.

Remove the hose attachment bar from the housing, leaving one nut in place to keep the bar secured to the hoses.



Fig. 11.

I016175

13. Raise and move the cab.



Fig. 12.

I016176

14. Remove the hydraulic hoses from the lift rams.



Fig. 13.

I016177

15. Remove the trailer brake valve union.




Fig. 14.


I016178

16. Remove the spool valve block bleed system.



Fig. 15.

I016179

17.  **CAUTION:**
One of the screws is difficult to reach.
It cannot be completely removed.

Remove the screws from the spool valve support.





Fig. 16.

I016180

18.  **CAUTION:**
Take care not to move the hydraulic hoses inside the bar.

Use a suitable lift system to lift the spool valve block (approximate weight = 150 kg (331 lb)).



Fig. 17.

I016181

19. Fit the spool valve block onto the hydraulic tank.
NOTE: *This method of removal avoids disconnecting the hoses, thus limiting the risk of leaks.*



Fig. 18.

I016182

20. The top of the cover plate must be cleaned before it is removed.
NOTE: *To simplify removal and reduce the weight to be lifted, the rams can be removed.*




Fig. 19.

I016184

21. Remove the cover plate.



Fig. 20.

I016190

Removing the hydraulic unit



CAUTION:

Take care to precisely mark the different hydraulic hoses and electrical connectors before removing the hydraulic unit.

1. Measure the distance between the housing and the unit before starting removal. It should be $45 \text{ mm} \pm 0.1 \text{ mm}$.




Fig. 21.

I016192

2. Remove the retaining ring on the input shaft of the hydraulic unit and push the drive shaft inwards.




Fig. 22.

I016193

3. Disconnect the electrical connectors and mechanical link, and remove the control unit.



Fig. 23.

I016195

4. Remove the control spool valve block.




Fig. 24.

I016197

5. Remove the retaining rings and push the hydraulic pipes back inwards.



Fig. 25.

I016199

6. Disconnect the connector and remove the sensor.




Fig. 26.

I016202

7. Remove the hydraulic unions from the valve block housing, disconnect the electrical connectors, remove the pressure filter and then remove the valve block housing.




Fig. 27.

I016204

8. Remove the 2 retaining rings.




Fig. 28.

I016207

9. Remove the interior hose and then remove the plate.




Fig. 29.

I016212

10. Undo the screw holding the cam channel shaft.



Fig. 30.

I016214

11. Remove the cam channel control shaft.




Fig. 31.

I016216

12. Remove the 3 screws attaching the epicyclic gear train and push the shaft backwards.




Fig. 32.

I016218

13. Slide and stretch the retaining ring of the pinion and lock it on the shoulder located at the back (see arrows), then drive the coupling sleeve out towards the rear.




Fig. 33.

I016220

14. Use a lever to push the hydrostatic motor inwards.




Fig. 34.

I016222

15. Use a lever to push the hydrostatic pump inwards.




Fig. 35.

I016224

16. Unscrew the tank supports and offset the tank to provide access to the unit support lower shaft nut.



Fig. 36.

I016226

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com