

# Massey Ferguson®

## 2625 Tractor

### WORKSHOP SERVICE MANUAL 4283083M1

#### CONTENTS

INTRODUCTION AND SAFETY .....	01
MISCELLANEOUS DATA.....	02
TRACTOR IDENTIFICATION AND SPECIFICATIONS.....	03
SPLITTING THE TRACTOR.....	04
SHEET METAL.....	05
ENGINE .....	06
FRONT AXLE .....	07
CLUTCH .....	08
TRANSMISSION .....	09
REAR AXLE ANDS AND BRAKES .....	10
HYDRAULICS.....	11
PTO.....	12
STEERING .....	13
ELECTRICAL EQUIPMENT .....	14
WHEELS AND TIRES.....	15
DRAW BAR AND LINKAGES.....	16
STORAGE CARE.....	17

---

## REAR AXLE AND BRAKES

Operation no	Description	Page No
-----	Specification	
10 .1	General description	10A - 4
10 .2	Rear wheel stud	10A - 6
10 .3	Epicyclic unit outer housing and ring gear	10A - 6
10 .4	Epicyclic planet and sun gear	10A - 7
10 .5	Epicyclic unit	10A - 8
10 .6	Epicyclic preload	10A - 12
10 .7	Axle housing left-hand side	10A - 14
10 .8	Axle housing right-hand side	10A - 16
10 .9	Axle shaft - Direct drive wet brakes	10A - 17
10 .10	Left-hand carrier plate	10A - 18
10 .11	Right-hand carrier plate	10A - 18
10 .12	Left-hand brake actuator housing	10A - 19
10 .13	Right-hand brake actuator housing	10A - 20
10 .14	Brake adjusting and balancing	10A - 21
10 .15	Left-hand brakes servicing	10A - 22
10 .16	Right-hand brake servicing	10A - 24
10 .17	Differential lock actuator mechanism	10A - 25
10 .18	Differential lock coupler cap	10A - 26
10 .19	Differential lock preload checking and adjustment	10A - 27
10 .20	Right-hand differential bearing	10A - 29
10 .21	Differential unit	10A - 29
10 .22	Differential bearing left-hand	10A - 30
10 .23	Differential unit	10A - 31
10 .24	Crown wheel	10A - 32
10 .25	Pinion assembly	10A - 33
10 .26	Rear drive shaft	10A - 35
10 .27	Parking brake servicing	10A - 36

---

## SPECIFICATION:

Crown wheel pinion ratio	...	3.4545:1
Type	...	Direct drive with 11 X 38 crown wheel pinion
Pinion preload	...	18 - 22 lbs.inch
Brake operation	...	Rods and levers.
Parking brake	...	Cable operated on both brakes independent of foot brake.

## Special Tools:

SER / 054	...	Tractor splitting stand.
SER / 164	...	Drift
SER / 029	...	Adaptor.
SER / 028	...	Universal puller.
SER / 163	...	Bearing drive.
SER / 023	...	Differential bearing preload gauge.
SER / 024	...	Straight edge in conjunction with SER / 023.
SER / 162	...	Bearing driver.
SER / 017	...	Holder.
SER / 018	...	Bench Adaptor.
SER / 038	...	Hand press.
SER / 059	...	Adaptor.
SER / 056	...	Adaptor.
SER / 061	...	Pre - Load gauge.
SER / 022	...	Needle roller bearing puller.
SER / 063	...	Needle roller bearing driver.
SER / 058	...	Universal Handle.
SER / 060	...	Pinion lock nut 'C' Spanner.
SER / 064	...	Preload checking gauge aid.
SER / 117	...	Extractor.
SER / 030	...	Bearing remover main tool.
SER / 225	...	Axle housing cup remover.
SER / 118	...	Preload checking tool.
SER / G / 204	...	To press cup on differential carrier left - hand.
SER / G / 207	...	To press cone on differential lock.
SER / G / 228	...	Plate differential carrier cone removal.
SER / G / 227	...	Differential case left - hand cup removal.
SER / G / 223	...	To press bush into the carrier

---

SER / G / 224	...	Carrier bush pusher
SER / G / 194	...	Adaptor.
SER / G / 195	...	Adaptor
SER / G / 196	...	Bearing cup and seal remover.
SER / G / 198	...	Bearing cup assembler.
SER / G / 197	...	Seal replacer.
SER / G / 199	...	Bearing cone remover.
SER / G / 200	...	Bearing cone remover.
SER / G / 201	...	Bearing replacer.

### **Bolt torques:**

Rear Wheels nuts	...	200 lbf.ft (270 Nm)
Epicyclic unit housing bolts	...	55 lbf.ft (75 Nm)
Stabiliser mounting bolts	...	170 lbf.ft (230 Nm).
Differential case mounting bolts	...	80 lbf.ft ( 108 Nm)
Centre mounting bolts	...	18 lbf.ft (25 Nm)
Sleeve mounting bolts	...	118 lbf.ft (160 Nm)

## **10.1 GENERAL**

The drive from the Transmission mainshaft is transmitted through the rear drive shaft and shear tube to a spiral bevel driving pinion and crown wheel, then through the axle shafts to the rear wheel axles.

The driving pinion is supported in the centre housing by a straight roller pilot bearing and a pre-loaded housing assembly carrying two taper roller bearings.

The Crownwheel is attached to the split differential case, which is supported on each side by a taper roller bearing. The differential pinions run on a cross joint and thrust is taken by thrust washers behind the pinions.

The axle shaft inner ends are splined into differential gears, and the outer ends are mounted in rear wheel disc.

This tractor is fitted with multi-disc oil cooled brakes between the axle housings and the differential carrier plates adjacent to the centre housing.


The brakes are operated by two independently operated pedals located on the right of the transmission housing.

The right pedal operates the right hand brake and the left pedal operates the left hand brake, to assist turning.

For off-field use, the brakes are used together by operating an interlocking latch which joins the two brake pedals.

When only single brakes are applied on the tractor the parking brake also actuates these disc brakes.

Pressure on the brake pedal brings an actuating assembly in contact with two rotating middle (friction) discs splined to each axle shaft, these in turn contact fixed friction faces provided in the axle housing and in the differential carrier plate fitted between the centre and axle housings. The mechanism of each brake consists of two cast iron actuating disc, held together by tension springs and separated by steel balls located in inclined seats. Pressure on the brake pedal, pulling on the operating rod, rotates one actuating disc relative to the other, and the steel balls ride up their inclined seats and so spread the actuating disc apart. These come into contact with the rotating (friction disc), which are splined to the shaft being braked. The actuating assembly will move slightly in the direction of rotation until the torque ear of the one actuating disc comes into contact with a shaft in the housing. The other actuating disc tends to rotate further, increasing the angular displacement between the discs, and assisting the braking action. When the operating pull is released, the tension springs cause the discs to return to their normal position.



**Key to Figure – 1**

- |                                      |                                  |                                |
|--------------------------------------|----------------------------------|--------------------------------|
| 1 Axle Housing- Left-hand            | 18 Axle Housing – Right-hand     | 34 Gasket                      |
| 2 Carrier Plate - Left-hand          | 19 Epicyclic Hub-Inner bearing   | 35 Planet Gear                 |
| 3 Differential lock Coupler cap      | 20 Epicyclic hub – bush          | 36 Inner Oil seal              |
| 4 Differential lock Coupler          | 21 Thrust Washer                 | 37 Axle shaft                  |
| 5 RH Differential bearing            | 22 Roll pin                      | 38 Brake friction plate        |
| 6 Pinion Assembly                    | 23 Needle rollers                | 39 Brake stop rod              |
| 7 Roll pin                           | 24 Epicyclic unit securing bolts | 40 Actuator unit               |
| 8 Ground Speed gear                  | 25 Planet gear-shaft             | 41 Carrier plate-Right-hand    |
| 9 Differential lock coupler fork     | 26 Half ring                     | 42 'O' ring- Outer             |
| 10 Brake interplate                  | 27 Outer oil seal                | 43 'O' ring- Inner             |
| 11 Differential lock return spring   | 28 Stub axle                     | 44 Differential gear-RH        |
| 12 Washer                            | 29 Wheel stud                    | 45 Crown wheel                 |
| 13 Circlip                           | 30 Outer Bearing                 | 46 Cross shaft                 |
| 14 Differential lock actuating shaft | 31 Cover Rear Drive              | 47 Thrust washer               |
| 15 Differential lock adjusting nut   | 32 Sun gear                      | 48 Differential Bearing        |
| 16 Dust cover                        | 33 Ring Gear                     | 49 Differential Gear-Left-hand |

---

## 10. 2 REAR WHEEL STUD

### Removal and Replacement

#### Removal

1. Jack up the tractor.
2. Remove the rear wheel
3. Drive out the damaged stud.

**Examine the stud hole, the other studs and the wheel disc for signs of fretting or damage.**

#### Refitment:

4. Locate a new stud in the wheel axle.
5. Tap the stud gently to locate the splines.
6. Fit a new wheel nut, with the flat side against the axle to the stud and pull the stud through the axle to its correct position.
7. Remove the nut.
8. Refit the rear wheel and nuts and tighten the nuts progressively and evenly to a torque of 200 lbf.ft (270 Nm).




Fig 2

## 10. 3 EPICYCLIC UNIT OUTER HOUSING AND RING GEAR

### Removal and Refitment

#### Removal

1. Apply the parking brake.
2. Jack up the tractor.
3. Remove the rear wheel.
4. Scribe a mark across the outer housing, ring gear, and axle housing to facilitate refitment. Also scribe a mark across the outer housing and ring gear only, this will ensure that the ring gear is replaced with the teeth in full engagement.
5. Remove the nuts and bolts.
6. Remove the outer housing and ring gear assembly.
7. Remove the ring gear.




Fig 3

**Note:** Do not withdraw the axle shaft.

8. Remove and discard the two cork gaskets. Clean the recesses in which the ring gear spigots are located and check that there is no burr or deformity which could cause leakage.

#### Refitment

10. Reverse procedure 1 to 8 except:
  - a. Fit new cork gaskets.
  - b. Ensure that the scribe marks are correctly aligned ensuring that the teeth of the ring gear are in full engagement, otherwise severe damage can occur.
  - c. Tighten the nuts and bolts to a torque of 55 lbf ft (75 Nm).
  - d. Refill to the correct level with an approved oil.

## 10 .4 EPICYCLIC PLANET AND SUN GEAR

### Servicing

**Special Tools :** 3/8 inch UNF bolt

#### Disassembly

1. Remove the outer housing assembly. (See operation 10 .3) To service the sun gear it is only necessary to remove one planet gear.

**Note :** The sun gear will come out through only one of the planet gear operation. It is wider than the other two.

2. Drive out and discard the roll pin.
3. Fit the 3/8 inch bolt to the planet gear shaft.
4. Withdraw the shaft trying not to dislodge the needle rollers.
5. Remove the 3/8 inch bolt.
6. Remove the thrust washers and the planet gear. Repeat operations 2 to 6 only if the epicyclic hub is to be completely overhauled.
7. Withdraw the sun gear. Inspect all parts and replace any which show signs of undue wear or damage.




Fig 4

#### Reassembly

8. Reverse procedure 1 to 7 except:
  - a) If the needle rollers are dislodged, refit them using petroleum jelly, not grease. There are 58 needle rollers per planetary gear (two rows of 29, plus a spacer washer).
  - b) Ensure that the holes in the casting and shaft are aligned.
  - c) Fit a new roll pin.
  - d) The wider opening for the removal of the sun gear has special wide thrust washer. Ensure that they are fitted to the correct planetary gear.

**Note :** Planetary gears must be fitted with the larger shoulder facing the centre at the axle.

## 10 .5 EPICYCLIC UNIT

### Servicing

#### Special tools :

- a. SER/028 - Differential bearing remover.
- b. SER/029 - Base
- c. SER/038 - Hand press
- d. SER/G/223 - To press bush into carrier
- e. SER/G/224 - Carrier bush pusher
- f. SER/G/194 - Adaptor
- g. SER/G/195 - Adaptor
- h. SER/G/196 - Bearing cup and seal remover.
- i. SER/117 - Extractor
- j. SER/G/198 - Bearing cup assembler
- k. SER/030 - Bearing remover (Main tool)
- l. SER/225 - Axle Housing cup remover.
- m. SER/058 - Drive Handle
- n. SER/G/197 - Seal replacer
- o. SER/G/199 - Bearing cone replacer
- p. SER/G/200 - Bearing cone replacer
- q. SER/G/201 - Bearing replacer

#### Disassembly

1. Remove the planetary gear and sun gear.  
(See operation 10 .4)
2. Remove the bearing cone using SER/029 and SER/G/194.
3. Normal Duty Axles: Tap the bearing bush into the hub using SER/G/223
4. Normal Duty Axles: Remove the bush and SER/G/224 from the hub.
5. Place the dismantled wheel on the workshop floor.
6. Fit the outer housing and hub assembly and secure with two wheel nuts.
7. Fit SER/117 and remove the hub from the housing.
8. Remove the two half rings.
9. Using SER/038 and SER/G/195 press out the wheel axle.
10. Lift out the bearing cone.




Fig 5



- 
11. Tap out the outer seal. Using special tool SER/G/196.



Fig 6

12. Tap out the bearing cup. Using special tool SER/G/196.

13. Fully apply the parking brake and check that the transmission oil is no higher than the FULL mark on the dipstick. Remove the axle shaft.

14. Using SER/G/225, remove the inner bearing cup and shims.

15. Inspect all parts and replace any which show signs of undue wear or damage. Replace all seals and gaskets.



Fig 7

### Reassembly

16. Using SER/G/198 Refit the bearing cup, making sure it is fully seated.




Fig 8

17. Smear a new outer seal lightly with recommended "Loctite 243", then drive it into the housing using SER/G/197 metal face outwards, and 0.080 inch (2 mm) above the housing (dimension A). Smear the lip, and fill the seal cavity with petroleum jelly.

**Note :**

Allow the Cone assembly undisturbed for 72 hours for the seal to get firmly located in its position.

18. Carefully, insert the wheel axle through the outer seal.
19. Using SER/G/199 drive the bearing cone fully onto the wheel axle, seating the rollers in the cup.



Fig 9



Fig 10




Fig 11

## NORMAL AXLES

Using the number 0 half ring and feeler gauges measure the gap between the bearing cone and the half ring. If there is no clearance, the No. 0 half ring can be used. If the clearance is measurable, select a pair of half rings to give a clearance of 0.00 to 0.001 inch (0.00 to 0.025 mm) by using the following procedure and the table below.

Half ring		Feeler gap		Half ring thickness		Part No.	Identification No.
mm	inch	mm	inch	mm	inch		
5.92	0.233	5.84	0.230	882601M1	0		
5.94	0.234	5.89	0.232				
5.95	0.2341	5.90	0.2321	882602M1	1		
5.99	0.236	5.94	0.234				
6.00	0.2361	5.95	0.2341	882603M1	2		
6.04	0.238	5.99	0.236				
6.05	0.2381	6.00	0.2361	882604M1	3		
6.09	0.240	6.04	0.238				

- a. Using a micrometer, measure the thickness of the No. 0 half ring.
- b. Add the No. 0 half ring thickness to the feeler gauge measurement to give the thickness of the half rings required.

21. Fit the two half rings, ensuring that they seat fully in the groove.

22. Using the SER/058 Drive handle, SER/G/200, drive the bearing cone onto the spigot on the epicyclic hub.

23. Reassemble the planetary gears and the sun gear in the epicyclic hub.

24. Using the handle, SER/G/200 and a hydraulic press, drive the epicyclic hub onto the wheel axle.

25. Check the epicyclic preload.

26. Refit the inner bearing cup and shim in the axle housing, using special tool SER/G/201.

28. Refit the ring gear and outer housing assembly. (operation 10.3)



Fig 12



Fig 13

---

## 10 .6 EPICYCLIC PRE-LOAD

### Special Tools :

- SER/118 – Preload Checking tool
- SER/028 – Puller
- SER/029 – Base
- SER/G/194 – Adapter

### Procedure

1. Remove the outer housing and ring gear.
2. Remove the two cork gaskets and thoroughly clean the mating faces of the ring gear and outer housing.
3. Bolt the ring gear to the outer housing using four bolts from the epicyclic unit with four wheel nuts as spacers. These bolts should be equally spaced around the ring gear.

***Note:** Ensure that the ring gear is correctly fitted i.e., with the teeth in full engagement.*

4. Ensure that the oil level is not higher than the FULL mark on the dipstick, fully apply the handbrake and remove the half-shaft.
5. **Normal / Axle**  
Using SER/028, SER/029 & SER/G/194 remove the inner bearing cup from the trumpet housing.
6. Remove the old shims.
7. Place the bearing cup on the spigot in the centre of SER/118. Do not fit the shims.
8. Place the epicyclic unit on SER/118 and measure the gap at points 'A' using two feeler gauges.
9. Note the clearance, which must be equal at both sides, then select shim or shims as per sizes from the table provided.

### 11.7 REAR AXLE EPICYCLIC PRE-LOAD TABLE

Gap Measured by Feeler Gauges (Both Sides)				Shim thickness required	
mm		inches		mm	inches
0.02	0.11	0.001	0.004	1.14	0.045
0.12	0.24	0.005	0.009	1.02	0.040
0.25	0.36	0.010	0.014	0.89	0.035
0.37	0.49	0.015	0.019	0.76	0.030
0.50	0.62	0.020	0.024	0.64	0.025
0.63	0.74	0.025	0.029	0.51	0.020
0.75	0.87	0.030	0.034	0.38	0.015
0.88	1.00	0.035	0.039	0.25	0.010
1.01	1.13	0.040	0.044	0.13	0.005
1.14	1.25	0.045	0.049	0.000	0.000

The shims are available as follows :

Shim Thickness		Part No.
mm	inches	
0.13	0.005	894757M1
0.25	0.010	894758M1
0.38	0.015	894759M1

10. Fit the shims to the axle housing.
11. Refit the inner bearing cup, ensuring that it is fully seated.
12. Refit the axle shaft.
13. Remove the four bolts and spacers securing the ring gear to the outer housing.
14. Using new cork gasket, refit the ring gear and outer housing. (operation 10 .3)




Fig 14

---

## 10.7 AXLE HOUSING LEFT HAND

### Removal and Refitment

**Special tools :** SER / 054 Tractor splitting stand.

#### Removal

1. Drain the transmission oil.
2. Release the lift rod at the knuckle.
3. Release the check chain at the check chain anchor bracket.
4. Release the stabilizer bracket underneath the axle housing.
5. Release the forward end of the lower link from the axle housing bracket.
6. Remove the lift arm and lower link assembly complete.
7. Release the brake pull rods and the return spring.
8. Jack up the tractor under the axle housing being serviced.

9. Remove the left hand rear wheel.
10. Place the SER / 054 tractor splitting stand under the centre housing and lower the tractor until the jack is just taking the axle housing weight.
11. Remove all the nuts and bolts securing the axle housing to the centre housing.
12. Lower the axle housing slightly and withdraw it far enough to clear the half shaft from the differential splines.
13. Withdraw the axle housing completely.
14. Remove the 'O' ring from the flange on the carrier plate.

#### Refitment

15. Reverse procedures 1 to 14 except:
  - a. Fit a new 'O' ring, using petroleum jelly.
  - b. When manoeuvring the axle housing assembly back into position, take care to align the axle shaft splines in the differential unit and the studs through their holes in the centre housing.




Fig 15

- 
- c. Apply a few drops of stud lock, then fit and tighten the stabilizer mounting bolts to a torque of 170 lbf ft (230 Nm).
  - d. Brush the wheel stud threads clean.
  - e. Refit the rear wheel and lightly oil the stud threads before fitting the wheel nuts.

Tractors fitted with 11/16 inch (17.5 mm) diameter studs.

Tighten the nuts progressively and evenly to a torque of 240 lbf ft (325 Nm).

***Note :** The full quantity of oil, as stated in the specification will not be required as approximately 0.66 gal (2.5 liter) will be trapped by the carrier plates in the axle housing.*

16. Adjust and balance the brakes.

---

## 10.8 AXLE HOUSING RIGHT HAND

### Removal and Refitment

#### Special tools : SER / 054 Tractor splitting stand

1. Drain the transmission oil.
2. Release the leveling box at the knuckle.
3. Release the check chain at the check chain anchor bracket.
4. Release the stabilizer bracket underneath the axle housing.
5. Release the forward end of the lower link from the axle housing bracket.
6. Remove the lift arm and lower link assembly complete.
7. Release the brake pull rods and the return spring.
8. Jack up the tractor under the axle housing being serviced.
9. Remove the right hand rear wheel.
10. Place the SER / 054 Tractor splitting stand kit under the centre housing and lower the tractor until the jack is just taking the axle housing weight.
11. Remove all the nuts and bolts securing the axle housing to the centre housing.

12. Lower the trumpet housing slightly and withdraw it far enough to clear the half shaft from the differential splines.
13. Withdraw the axle housing completely.
14. Remove the 'O' ring from the flange on the carrier plate.

#### Refitment

15. Reverse procedures 1 to 14 except:
  - a. Fit a new 'O' ring using petroleum jelly.
  - b. Carefully manoeuvre the axle housing into position, taking care to align the axle shaft splines in the differential unit and the studs through their holes in the centre housing.
  - c. Apply a few drops of Loctite stud lock, then fit and tighten the cab stabilizer mounting bolts to a torque of 170 lbf ft (230 Nm).
  - d. Brush the wheel stud threads clean.
  - e. Refit the rear wheel and lightly oil the stud threads before fitting the wheel nuts.
16. Adjust and balance the brakes.

Tractors fitted with 11/16 inches (17.5 mm) diameter studs. Tighten the nuts progressively and evenly to a torque of 325 Nm (240 lbf ft).

**Note:** The full quantity of oil, as stated in the specification will not be required as approximately 0.66 gal (2.5 liter) will be trapped by carrier plate in the axle housing.




Fig 16






Fig 17

## 10 . 9 AXLE SHAFT – DIRECT DRIVE - WET BRAKES

### Removal and refitment

**Note:** This Axle shaft which has a taper roller bearing retained by a shrink fit collar. It can be identified by the large ball bearing retained by a spacer and circlips.

### Removal:

1. Jack up the tractor under the axle housing to be serviced.
2. Drain the oil from the transmission.
3. Remove the rear wheel.
4. Ensure that the parking brake is hard on.
5. Remove the 12 nuts, bolts and spring washer.
6. Pry apart the axle housing between the end cover and axle housing.
7. Remove the axle and end cover assembly.
8. Remove the 'O' ring and discard.
9. Remove the external circlip and spacer.
10. Drive the axle shaft out of the bearing and cover assembly.
11. Remove the internal circlip and ball bearing if necessary.

12. Remove and discard the oil seal.

### Refitment:

13. Coat the oil seal with MF lock and seal (Loctite 542) and press into the cover up to the shoulder.
14. Replace the ball bearing if necessary.
15. Refit the axle shaft, spacer and circlip.
16. Replace the 'O' ring.
17. Place the axle shaft into the axle housing. Carefully passing the shaft through the brake plates.
18. Refit the nuts and bolts tightening to a torque of 54 lbf.ft (74 Nm).
19. Refit the rear wheel and nuts, and then tighten the nuts progressively and evenly to a torque of 199 lbf.ft (270 Nm).
20. Refill the transmission with approved oil to the correct level.
21. Adjust the brakes.

## 10 .10 LEFT HAND. CARRIER PLATE

### Removal and Refitment

**Special tools :** SER / 054 Tractor splitting stand.

#### Removal

1. Remove the axle housing(see operation 10 .7)
2. Manoeuvre the axle housing, off the jack and stand it on end.
3. Remove the two countersunk screws.
4. Withdraw the carrier plate from the axle housing.
5. Remove and discard the inner 'O' ring.

#### Refitment

6. Reverse procedures 1 to 5 except:
  - a. Place a new 'O' ring in the recess in the axle housing using a smear of petroleum jelly for location. Do not attempt to fit the 'O' ring to the carrier plate.
  - b. Secure each countersunk screw with a centre punch mark.




Fig 18

## 10 .11 RIGHT HAND CARRIER PLATE

### Removal and Refitment

**Special Tools:** SER / 054 Tractor splitting stand.

#### Removal

1. Remove the axle housing(see operation 10 .8)
2. Manoeuvre the axle housing, off the jack and stand it on end.
3. Remove, and discard the roll pin.
4. Remove the two countersunk screws.
5. Remove the carrier plate complete with the differential lock coupler fork and coupler.
6. Remove and discard the inner 'O' ring.
7. Remove the differential lock coupler fork and coupler.

#### Refitment

8. Reverse procedures 1 to 7 except:




Fig 19

- a. Fit a new 'O' ring to the recess in the axle housing using petroleum jelly. Do not attempt of fit the 'O' ring to the carrier plate.
- b. Assemble the differential lock coupler fork and coupler to the carrier plate, then refit the assembly, aligning the coupler splines on the axle shaft and the coupler fork on its shaft. (if fitted)
- c. Secure each countersunk screw with a centre punch mark.
- d. Fit a new roll pin.

## 10 .12 LEFTHAND. BRAKE ACTUATOR HOUSING (MECHANICAL BRAKES)

**Servicing Tools :** SER/164 - Drift

### Disassembly

1. Drain the transmission oil to the MIN mark on the dipstick.
2. Disconnect the brake pull rods.
3. Remove the brake return spring.
4. Remove the locknut, nut and spacer.
5. Remove the three bolts and spring washers.
6. Remove the housing.
7. Remove and discard the gasket.
8. Tap out and, if damaged, discard the rubber boot.
9. If necessary, remove the brake pull lever by removing the split pin(9) and pushing out the pivot shaft (10).

### Examination

**Examine the mating faces of the actuator housing and the axle housing for damage.  
Clean both surfaces before reassembly.**

### Reassembly

10. Reverse procedures 1 to 8 except:
  - a. If necessary fit a new rubber boot, preferable using a SER/164.
  - b. Fit a new gasket.
  - c. Before refitting the housing, smear the brake actuator rod with petroleum jelly. When refitting the housing take care to seat the lips of the rubber boot in the step on the actuator rod, without disturbing the garter spring.




Fig 20

- d. The three bolts are of varying lengths according to their position in the actuator housing.

11. Adjust and balance the brakes.

## 10.13 RIGHTHAND. BRAKE ACTUATOR HOUSING AND DIFFERENTIAL LOCK MECHANISM

### (MECHANICAL BRAKES)

**Servicing Tools :** SER/164 - Drift

#### Disassembly

1. Drain the transmission oil to the MIN mark on the dipstick.
2. Disconnect the brake pull rods.
3. Remove the brake return spring.
4. Remove the locknut, nut and spacer.
5. Remove the three bolts and spring washers.
6. Remove the actuator housing complete.
7. Remove and discard the gasket.
8. Tap out and , if damaged , discard the rubber boot.

**Note:** Do not remove the differential lock lever mechanism or the brake pull lever unless they are to be serviced. (if fitted)

Only If necessary continue as follows:

9. Tap out and discard the groove pin.
10. Remove the pivot pin.
11. Remove the lever assembly.
12. Remove and discard the split pin.
13. Push out the pivot shaft.
14. Remove the brake pull lever.
15. Examine the joint faces of the actuator housing and the trumpet housing for damage, clean both surfaces thoroughly before reassembly.

#### Reassembly

16. Reverse procedures 1 to 8 or 1 to 15 depending on the extent of disassembly except:
  - a. If necessary, fit a new rubber boot, preferably using a SER/164.
  - b. Fit a new gasket.




Fig 21

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)