



MASSEY FERGUSON

MF 4600M

Series Tractors


Models: 4607M / 4609M / 4610M / 4610M HC



OPERATOR'S MANUAL

FROM MASSEY FERGUSON

Operator's Manual



MASSEY FERGUSON

4600M Utility Tractor

4607M

4609M

4610M

4610M HC

**North America
4205 River Green Parkway, Duluth GA 30096 USA
© AGCO 2017
Original Operator's Manual**

**April 2017
4283579M3
NA
English**

4600M Utility Tractor

1 Safety	9
1.1 Introduction	11
1.1.1 Safety alert symbol	11
1.1.2 Safety messages	11
1.1.3 Informational messages	11
1.1.4 Safety signs	11
1.1.5 A word to the operator	12
1.1.6 This manual	13
1.2 Operation	14
1.2.1 Prepare for operation	14
1.2.2 Roll over protective structure	14
1.2.3 General information	14
1.2.4 Personal protective equipment	18
1.2.5 Seat instruction	18
1.2.6 Shield and guards	18
1.2.7 Power take-off safety	19
1.2.8 Exhaust warning	20
1.2.9 Flying debris	20
1.2.10 Agricultural chemicals	20
1.3 Travel on public roads	21
1.4 Maintenance	23
1.4.1 General maintenance information	23
1.4.2 Fire prevention and first aid	24
1.4.3 High pressure leaks	25
1.4.4 Engine safety	26
1.4.5 Fuel safety	27
1.4.6 Battery safety	28
1.4.7 Tire safety	28
1.4.8 Replacement parts	29
1.5 Safety and informational signs - 4600M	30
1.5.1 Warning - state of California	32
1.5.2 Warning - electrical shock hazard	32
1.5.3 Warning - explosion and/or fire hazard	32
1.5.4 Warning - high pressure steam and hot water hazard	32
1.5.5 Warning - entanglement hazard in belt drive	33
1.5.6 Warning - shearing hazard - engine fan	33
1.5.7 Warning - hot surfaces - burn hazard	33
1.5.8 Danger - run-away machine and run over hazard	33
1.5.9 Warning - general safety alert	34
1.5.10 Danger - entanglement hazard in PTO drive line	34
1.5.11 Sign - ultra low sulfur diesel	34
1.5.12 Warning - fall off or run over hazard	34
1.5.13 Warning - rollover hazard risk of crushing	35
1.5.14 Warning - roll over hazard	35
1.5.15 Warning - run-away machine	35
1.5.16 Danger - rear rollover hazard risk of being crushed	35
1.5.17 Warning - component separation flying object	36
1.5.18 Sign - Not a step	36
1.5.19 Sign - DEF only	36
2 Introduction	37

2.1 Introduction	39
2.1.1 Intended use	39
2.1.2 Proper disposal of waste	39
2.2 Machine identification	40
2.2.1 Serial number plate	40
2.2.2 Engine identification	41
2.2.3 Chassis number	42
2.3 Major components	43
2.3.1 Cab tractor major components	43
2.3.2 Platform tractor major components	44
2.4 California emission control warranty statement	45
2.5 United States and Canada emission control warranty statement	49
3 Operation	53
3.1 Location of instruments and controls	55
3.2 Instrument panel components	56
3.2.1 Main switch	56
3.2.2 Lamp switches	57
3.2.3 Tachometer	58
3.2.4 Indicators and gauges	58
3.2.5 Display select switch	64
3.3 Clutch pedal	65
3.4 Brake pedals and parking brake	66
3.4.1 Brake pedals	66
3.4.2 Applying the park brake	66
3.4.3 Releasing the park brake	66
3.5 Breaking in the tractor	68
3.6 Starting the tractor	69
3.6.1 Inspecting before operation	69
3.6.2 Starting the tractor - normal conditions	69
3.6.3 Cold weather starting	70
3.6.4 Warm engine starting	71
3.6.5 Warm up period	71
3.6.6 Operator check items	71
3.7 Engine speed controls	73
3.7.1 Using the stored engine speed switch	73
3.7.2 Using the stored engine speed switch with the power take-off	74
3.7.3 Adjusting the stored engine speeds	74
3.8 Ground speed controls	76
3.8.1 Forward/reverse lever	76
3.8.2 Range shift lever and gear shift lever	77
3.8.2.1 Shifting the main gears	77
3.8.2.2 Changing range speed	77
3.8.2.3 Engage creeper speed	77
3.8.2.4 Disengage creeper speed	77
3.8.3 Ground speed charts	78
3.8.4 Four-wheel drive	84
3.8.5 Engaging the differential lock	85
3.8.6 Stopping the machine	85
3.8.7 Remove a stuck machine from mud	86
3.9 Joystick, if equipped	88
3.9.1 Joystick control lever	88
3.9.2 Joystick operation	88
3.9.3 Joystick lockout	89
3.9.4 Hydraulic ports	89

3.10 Rear auxiliary hydraulics	91
3.11 Cab components	92
3.11.1 Doors	92
3.11.2 Rear windscreen	94
3.11.3 Corner windows	95
3.11.4 Cab lamp	95
3.11.5 Work lamps	96
3.11.6 Air vents	97
3.11.7 Air conditioning operation	98
3.11.7.1 Air conditioning controls	98
3.11.7.2 Operating the cooling system	100
3.11.7.3 Operating the heating system	100
3.11.7.4 Operating the defrosting system	101
3.11.8 Windscreen wiper and washer	101
3.11.8.1 Front windscreen wiper and washer	101
3.11.8.2 Rear windscreen wiper and washer, if equipped	102
3.11.8.3 Washer reservoir	102
3.11.9 Rear windscreen defroster	103
3.11.9.1 Rear windscreen defroster switch	103
3.11.10 Antenna	103
3.11.11 Additional storage	104
3.11.12 Sun visor	104
3.12 Seat and steering column	105
3.12.1 Platform tractor seat adjustments	105
3.12.2 Cab tractor seat adjustments	105
3.12.3 Seat switch	105
3.12.4 Steering column tilt	106
3.12.5 Manual holder	106
3.13 Roll over protective structure	107
3.13.1 Folding down the ROPS	107
3.13.2 Putting the ROPS in the upright position	108
3.14 Tool box	109
3.15 Power take-off	110
3.15.1 Rear power take-off	110
3.15.2 Engaging the power take-off	111
3.15.3 Disengaging the power take-off	112
3.15.4 Power take-off speed	112
3.15.5 Changing the power take-off shaft	113
3.16 3-point linkage	115
3.16.1 Lift control	115
3.16.2 Lift control stops	116
3.16.3 Lift control buttons	116
3.16.4 Draft control, if equipped	116
3.16.5 Lowering rate control	117
3.16.6 3-point linkage	118
3.16.7 3-Point linkage dimensions	118
3.16.8 3-point linkage adjustments	118
3.16.8.1 Lift rod length	119
3.16.8.2 Lift rod mounting	119
3.16.8.3 Top link connection position	119
3.16.8.4 Top link length	120
3.16.8.5 Stabilizer	120
3.16.9 Connecting implements - ball type hitch	120
3.16.10 Disconnecting implements	122
3.17 Drawbar	123
3.18 Auxiliary electrical connectors	124

4 Maintenance	125
4.1 Lubrication and maintenance chart	127
4.1.1 Initial lubrication and maintenance chart	128
4.2 Lubrication fill and drain locations	130
4.3 Engine cover	131
4.3.1 Opening the engine cover	131
4.3.2 Closing the engine cover	131
4.4 Lubrication details	132
4.4.1 Lubrication fittings	132
4.4.2 Engine oil and filter	132
4.4.2.1 Checking the engine oil level	132
4.4.2.2 Changing the engine oil	132
4.4.2.3 Replacing the engine oil filter	133
4.4.3 Transmission oil	133
4.4.3.1 Checking the transmission oil level	133
4.4.3.2 Changing the transmission oil and filter	134
4.4.4 Front axle oil	134
4.4.4.1 Checking the front axle oil level	135
4.4.4.2 Changing the front axle oil	135
4.5 Coolant	136
4.5.1 Coolant level	136
4.5.2 Replacing coolant	136
4.5.3 Antifreeze	137
4.5.4 Cleaning the radiator	137
4.6 Belts	139
4.6.1 Engine belt	139
4.6.2 Adjusting the engine belt	139
4.6.3 Adjusting the air conditioner compressor belt	140
4.7 Engine air filter	141
4.7.1 Replacing the engine air filter	141
4.7.2 Clean the engine air filter	142
4.8 Cab air filters	144
4.8.1 Changing the air conditioner filter	144
4.8.2 Servicing the recirculation air filter	146
4.9 Fuel system	147
4.9.1 Fuel filter	147
4.9.2 Removing the water from the fuel system	147
4.9.3 Replacing the fuel filter	148
4.9.4 Bleeding the fuel system	149
4.9.5 Fuel tank filler cap	149
4.9.6 DEF tank	149
4.9.6.1 DEF additive	150
4.9.6.2 Replacing the DEF filter	150
4.10 Electrical system	153
4.10.1 Battery	153
4.10.2 Replacing the battery	153
4.10.3 Fuses	154
4.10.3.1 Main fuse box - platform tractor	154
4.10.3.2 Main fuse box - cab tractor	155
4.10.3.3 Cab fuses	156
4.10.3.4 Time delay fuses	157
4.10.4 Connectors	157
4.10.4.1 Connectors - platform tractor	157
4.10.4.2 Connectors - cab tractor	158
4.10.5 Checking the neutral start system	159

4.11 Brakes	161
4.11.1 Examine the brake adjustment	161
4.11.2 Adjusting the brakes	161
4.12 Wheels and tires	163
4.12.1 Tire inflation pressures	163
4.12.2 Wheel bolt torque	164
4.12.2.1 Wheel bolt torque chart	164
4.12.3 Adjusting the front wheel alignment	165
4.12.4 Tie rod end	165
4.12.5 Front axle stop bolts	166
4.12.6 Front wheel spacing	166
4.12.7 Rear wheel spacing	168
4.12.7.1 Changing the rim offset	170
4.12.7.2 Moving the rear wheels from side to side	171
4.12.8 Steering free play	171
4.12.9 Front axle fore and aft	172
4.13 Clutch housing plug	173
4.14 Preparing for storage	174
4.15 Power washing	175
5 Troubleshooting	177
5.1 Engine troubleshooting	179
5.2 Clutch troubleshooting	183
5.3 Brakes troubleshooting	184
5.4 Electrical system troubleshooting	185
5.5 Hydraulic system troubleshooting	186
5.6 Steering system troubleshooting	187
5.7 Fault code display	188
5.7.1 Fault code list for the vehicle electronic control unit (ECU)	190
5.7.2 Fault code list for the engine ECU	191
6 Specifications	197
6.1 Specifications	199
6.1.1 Engine specifications	199
6.1.2 Electrical specifications	199
6.1.3 Transmission specifications	200
6.1.4 Power take-off specifications	200
6.1.5 Front axle specifications	200
6.1.6 Rear axle specifications	200
6.1.7 Brake specifications	201
6.1.8 Hydraulic specifications	201
6.1.9 Fuel specifications	202
6.1.10 Slope angle for stationary operation	202
6.1.11 Capacities	202
6.1.12 Lubrication specifications	202
6.1.13 Wheel bolt torque chart	203
6.1.14 Tire inflation pressures	203
6.1.15 Maximum load capacity	204
6.2 Dimensions	207
6.2.1 Platform tractor dimensions	207
6.2.2 Cab tractor dimensions	208
7 Accessories	211
7.1 Accessories	213
7.1.1 Engine block heater	213

7.1.2	Rear weight frame	213
7.1.3	Hang-on weights	213
7.1.4	Wheel weights	213
7.1.5	Auxiliary hydraulic valves	213
7.1.5.1	Free flow valve and kickout valve	213
7.1.6	Three-point assist cylinder	213
7.1.7	Drawbar (clevis)	213
7.1.8	Lockable fuel cap and DEF cap	213
7.1.9	Implements and attachments	213
7.1.10	Canopy	213
7.1.11	Work lamp	214
7.1.12	Joystick	214
7.1.13	Rear windscreen wiper	214
7.1.14	Speaker and antenna	214
7.1.15	Creep set	214
8	Assembly	215
8.1	Checklists	217
8.1.1	Pre-delivery checklist	217
8.1.2	Delivery checklist	217
9	Index	219

1. Safety

1.1 Introduction	11
1.1.1 Safety alert symbol	11
1.1.2 Safety messages	11
1.1.3 Informational messages	11
1.1.4 Safety signs	11
1.1.5 A word to the operator	12
1.1.6 This manual	13
1.2 Operation	14
1.2.1 Prepare for operation	14
1.2.2 Roll over protective structure	14
1.2.3 General information	14
1.2.4 Personal protective equipment	18
1.2.5 Seat instruction	18
1.2.6 Shield and guards	18
1.2.7 Power take-off safety	19
1.2.8 Exhaust warning	20
1.2.9 Flying debris	20
1.2.10 Agricultural chemicals	20
1.3 Travel on public roads	21
1.4 Maintenance	23
1.4.1 General maintenance information	23
1.4.2 Fire prevention and first aid	24
1.4.3 High pressure leaks	25
1.4.4 Engine safety	26
1.4.5 Fuel safety	27
1.4.6 Battery safety	28
1.4.7 Tire safety	28
1.4.8 Replacement parts	29
1.5 Safety and informational signs - 4600M	30
1.5.1 Warning - state of California	32
1.5.2 Warning - electrical shock hazard	32
1.5.3 Warning - explosion and/or fire hazard	32
1.5.4 Warning - high pressure steam and hot water hazard	32
1.5.5 Warning - entanglement hazard in belt drive	33
1.5.6 Warning - shearing hazard - engine fan	33
1.5.7 Warning - hot surfaces - burn hazard	33
1.5.8 Danger - run-away machine and run over hazard	33
1.5.9 Warning - general safety alert	34
1.5.10 Danger - entanglement hazard in PTO drive line	34
1.5.11 Sign - ultra low sulfur diesel	34
1.5.12 Warning - fall off or run over hazard	34
1.5.13 Warning - rollover hazard risk of crushing	35
1.5.14 Warning - roll over hazard	35
1.5.15 Warning - run-away machine	35
1.5.16 Danger - rear rollover hazard risk of being crushed	35
1.5.17 Warning - component separation flying object	36
1.5.18 Sign - Not a step	36
1.5.19 Sign - DEF only	36

1.1 Introduction

1.1.1 Safety alert symbol

The safety alert symbol means Attention! Become Alert! Your Safety Is Involved!

Look for the safety alert symbol both in this manual and on safety signs on this machine. The safety alert symbol will direct your attention to information that involves your safety and the safety of others.



Fig. 1

1.1.2 Safety messages

The words DANGER, WARNING or CAUTION are used with the safety alert symbol. Learn to recognize these safety alerts and follow the recommended precautions and safety practices.



DANGER:
Indicates an imminently hazardous situation that, if not avoided, will result in DEATH OR VERY SERIOUS INJURY.



WARNING:
Indicates a potentially hazardous situation that, if not avoided, could result in DEATH OR SERIOUS INJURY.



CAUTION:
Indicates a potentially hazardous situation that, if not avoided, may result in MINOR INJURY.



Fig. 2

1.1.3 Informational messages

The words important and note are not related to personal safety, but are used to give additional information and tips for operating or servicing this equipment.

IMPORTANT: *Identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of the machine, process, or its surroundings*

NOTE: *Identifies points of particular interest for more efficient and convenient repair or operation.*

1.1.4 Safety signs



WARNING:
Do not remove or obscure safety signs. Replace any safety signs that are not readable or are missing. Replacement signs are available from your dealer in the event of loss or damage. The actual location of the safety signs is illustrated at the end of this section.

Keep signs clean by wiping off regularly. Use a mild soap and water solution if necessary.

If parts have been replaced or a used machine has been purchased, make sure all safety signs are present and in the correct location and can be read. Illustrations of safety sign locations are located at the rear of this section.

Replace any safety signs that can not be read, are damaged, or are missing. Clean the machine surface thoroughly with a mild soap and water solution before replacing signs. Replacement safety signs are available from your dealer.

1.1.5 A word to the operator

It is your responsibility to read and understand the safety section in this manual and the manual for all attachments before operating this machine. Remember you are the key to safety. Good safety practices not only protect you, but also the people around you.

Study the content in this manual and make the content a working part of your safety program. Keep in mind that this safety section is written only for this type of machine. Practice all other usual and customary safe working precautions, and above all remember - safety is your responsibility. You can prevent serious injury or death.

This safety section is intended to point out some of the basic safety situations that may be encountered during the normal operation and maintenance of your machine. This section also suggests possible ways of dealing with these situations. This section is not a replacement for other safety practices featured in other sections of this manual.

Personal injury or death may result if these precautions are not followed.

Learn how to operate the machine and how to use the controls properly.

Do not let anyone operate the machine without instruction and training.

For your personal safety and the personal safety of others, follow all safety precautions and instructions found in the manuals and on safety signs affixed to the machine and all attachments.

Use only approved attachments and equipment.

Make sure your machine has the correct equipment needed by the local regulations.



Fig. 3



WARNING:

An operator should not use alcohol or drugs which can affect their alertness or coordination. An operator on prescription or 'over the counter' drugs needs medical advice on whether or not they can properly operate machines.



CAUTION:
If any attachments used on this equipment have a separate Operator Manual, see that manual for other important safety information.

1.1.6 This manual

This manual covers general safety practices for this machine. The operator manual must always be kept with the machine.

Right-hand and left-hand, as used in this manual, are determined by facing the direction the machine will travel when in use.

The photos, illustrations, and data used in this manual were current at the time of printing, but due to possible in-line production changes, your machine can vary slightly in detail. The manufacturer reserves the right to redesign and change the machine as necessary without notification.



WARNING:
In some of the illustrations and photos used in this manual, shields or guards may have been removed for clarity. Never operate the machine with any shields or guards removed. If the removal of shields or guards is necessary to make a repair, they must be replaced before operation.

The Operator Manual is stored in the holder on the machine. After using the Operator Manual, return the manual to the storage location.

1.2 Operation

1.2.1 Prepare for operation

Read and understand all operating instructions and precautions in this manual before operating or servicing the machine.

Make sure you know and understand the positions and operations of all controls. Make certain all controls are in neutral and the park brake is applied before starting the machine.

Make certain all people are well away from your area of work before starting and operating the machine. Check and learn all controls in an area clear of people and obstacles before starting your work. Be aware of the machine size and have enough space available to allow for operation. Never operate the machine at high speeds in crowded places.

Emphasize the importance of using correct procedures when working around and operating the machine. Do not let children or unqualified persons operate the machine. Keep others, especially children, away from your area of work. Do not permit others to ride on the machine.

Make sure the machine is in the proper operating condition as stated in the Operator Manual. Make sure the machine has the correct equipment required by local regulations.

1.2.2 Roll over protective structure

The roll over protective structure (ROPS) is effective in reducing injuries during overturns. Overturning a tractor without ROPS or with the ROPS folded down can result in serious injury or death. Operate with ROPS folded down only when conditions make this necessary. Return ROPS to upright, locked position as soon as conditions permit.

Do not weld, drill, or alter the ROPS.

If the tractor has been rolled over or the ROPS frame has been damaged in any manner, the ROPS must be replaced. Do not attempt to repair a damaged ROPS. If damage does occur, consult your dealer and replace all damaged parts.

Before using the tractor make sure the ROPS frame is not damaged and it is securely fastened to the tractor.

Do not attach chains, ropes, or cables to the ROPS for pulling purposes - damage to the ROPS and/or overturn of the tractor may result. Always pull from the tractor drawbar.

Observe all recommendations and instructions regarding the installation of covers or roofs which are used as sunshields only, and do not afford the operator protection from falling objects.

1.2.3 General information

When parking, park the machine on a solid level surface and lower any implements to the ground. Put all controls in neutral and apply the park brake. Stop the engine and take the key with you.



WARNING:
Do not leave the machine unattended with any implement or attachment in the raised position. Lower the implement or attachment fully before leaving the machine. A sudden loss of hydraulic pressure can cause the implement or attachment to drop without warning.




Fig. 4

Make sure the machine is in the proper operating condition according to the Operator Manual.

Do not dismount from moving machinery.

Stay off slopes too steep for operation.

Be aware of the size of the machine and have enough space available to allow for operation.

Do not operate near the edge of banks. Setback distance from the bank must equal or exceed, the overall height of the bank.

Whenever possible, travel directly up or down slopes, keeping the heavy end of the tractor on the uphill side. If necessary to cross a steep slope, avoid turning uphill. Slow down and make a wide turn.

Do not operate on steep slopes as overturn may result.




Fig. 5

On models with independent brake pedals, keep the brake pedals latched together at all times unless independent braking is required. Never use independent braking during transport.

Always drive at a proper speed relative to local conditions and ensure your speed is low enough for an emergency stop.

Reduce speed prior to turns to avoid the risk of overturning.

Keep speed to a minimum.




Fig. 6

Always keep the tractor in gear to provide engine braking when going downhill. Do not coast.

Avoid sudden or heavy brake applications when operating in wet, muddy, or icy ground conditions, or on loose surfaces, such as sand or gravel.

Sudden or heavy braking during turns increases the tendency to over steer. This effect is more pronounced with trailed equipment.

Keep a firm grip on the steering wheel at all times, with the thumbs clear of the spokes when driving the tractor.

Remain seated in operator's seat.



Fig. 7

1. Safety

In the event of an overturn, hold the steering wheel firmly and keep your seat belt fastened. Do not attempt to leave the seat until the tractor has come to rest.

Watch for holes, rocks, or other hidden hazards. Always inspect area prior to operation.

Be observant of the operating area and terrain.




Fig. 8

Avoid contact with electrical power lines. Contact with electrical power lines can cause electrical shock, resulting in very serious injury or death.




Fig. 9

Never allow anyone on any part of the tractor or attachments except in the operator's seat when the engine is running.

Do not get on or off the tractor or attachments while the tractor is moving.

Do not carry passengers.



Fig. 10

Always shut off the engine, shift the transmission to neutral, set park brake and remove the start key before leaving the operator's seat or before permitting anyone to inspect, clean, lubricate, adjust or repair any part of the tractor or attachments. Never leave the tractor unattended while the engine is operating.




Fig. 11

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com