

# SERVICE MANUAL

**VM Motori**  
**R 753 IE4**  
**Tier 4B (final) and Stage IV**  
Engine



## **SERVICE MANUAL**

**R 753 IE4**

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.101] Cylinder heads .....	10.2
[10.102] Pan and covers .....	10.3
[10.103] Crankshaft and flywheel.....	10.4
[10.105] Connecting rods and pistons.....	10.5
[10.106] Valve drive and gears .....	10.6
[10.206] Fuel filters .....	10.7
[10.218] Fuel injection system.....	10.8
[10.250] Turbocharger and lines.....	10.9
[10.254] Intake and exhaust manifolds and muffler .....	10.10
[10.304] Engine lubrication system.....	10.11
[10.400] Engine cooling system .....	10.12
[10.408] Oil cooler and lines.....	10.13
[10.414] Fan and drive .....	10.14
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.15
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.16
Electrical systems.....	55
[55.010] Fuel injection system.....	55.1
[55.012] Engine cooling system .....	55.2
[55.014] Engine intake and exhaust system.....	55.3
[55.015] Engine control system.....	55.4
[55.202] Cold start aid .....	55.5
[55.989] Exhaust Gas Recirculation (EGR) electrical system .....	55.6



## INTRODUCTION

# Contents

---

## INTRODUCTION

Foreword - Important notice regarding equipment servicing .....	3
Safety rules .....	4
Safety rules - Ecology and the environment .....	5
Torque – Minimum tightening torques for normal assembly .....	6
Torque – Standard torque data for hydraulics .....	11
Basic instructions - Shop and assembly .....	13
Consumables .....	15
General specification .....	16
Product identification .....	17
Product overview – Orientation .....	18

---

## **Foreword - Important notice regarding equipment servicing**

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CNH Sales and Service Networks.

## Safety rules


### Personal safety





This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.**

### Machine safety

**NOTICE:** Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

### Information

**NOTE:** Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

---

## Safety rules - Ecology and the environment

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

### Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

### Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. CNH strongly recommends that you return all used batteries to a CNH dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



### Mandatory battery recycling

**NOTE:** The following requirements are mandatory in Brazil.

Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling



## Torque – Minimum tightening torques for normal assembly

**NOTE:** In the metric tables, nominal sizes M4 through M8 hardware torque specifications are shown as a Newton meters (pound-inches) numerical value.

Nominal sizes M10 through M24 hardware torque specifications are shown as a Newton meters (pound-feet) numerical value.

### Metric non-flanged hardware

Plain (PLN) an unplated hardware finish with residual manufacturing oils

Zinc-dichromate (ZND) – a yellow colored chemical plating formula yellow applied to the hardware

Nominal size	Class (CL) 8.8 bolt and Class (CL) 8 nut	Class (CL) 10.9 bolt and Class (CL) 10 nut	Locknut CL 8 w/CL 8.8 bolt	Locknut CL 10 w/CL 10.9 bolt
	PLN and ZND	PLN and ZND	ZND	ZND
	N·m (lb in)	N·m (lb in)	N·m (lb in)	N·m (lb in)
M4	2.9 (26)	4.2 (37)	2 (18)	2.9 (26)
M5	5.9 (52)	8.5 (75)	4 (36)	5.8 (51)
M6	10.1 (89)	14.5 (128)	6.8 (60)	10 (89)
M8	24.5 (217)	35.1 (311)	17 (151)	24 (212)
	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)
M10	48.7 (36)	69.5 (90)	33 (25)	48 (35)
M12	85 (63)	121 (67)	58 (43)	83 (61)
M14	135 (100)	193 (142)	92 (68)	132 (97)
M16	210 (155)	301 (222)	143 (106)	205 (151)
M18	299 (221)	414 (305)	203 (150)	281 (207)
M20	425 (313)	587 (433)	290 (214)	400 (295)
M24	735 (542)	1016 (749)	501 (370)	693 (510)

### Metric flanged hardware


Plain (PLN) – an unplated hardware finish with residual manufacturing oils

Zinc-dichromate (ZND) – a yellow colored chemical plating formula yellow applied to the hardware

Nominal size	Class (CL) 8.8 bolt and Class (CL) 8 nut	Class (CL) 10.9 bolt and Class (CL) 10 nut	Locknut CL 8 w/CL 8.8 bolt	Locknut CL 10 w/CL 10.9 bolt
	PLN and ZND	PLN and ZND	ZND	ZND
	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)
M4	3.2 (28)	4.6 (41)	2.2 (19)	3.1 (27)
M5	6.5 (58)	9.4 (83)	4.4 (39)	6.4 (57)
M6	11.1 (98)	15.9 (141)	7.5 (66)	11 (96)
M8	27 (239)	39 (345)	18 (163)	27 (240)
	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)
M10	53.6 (40)	76.5 (56)	37 (27)	53 (39)
M12	93 (69)	134 (98)	63 (47)	91 (67)
M14	148 (109)	213 (157)	101 (75)	145 (107)
M16	231 (171)	331 (244)	158 (116)	226 (167)
M18	329 (243)	455 (336)	223 (165)	309 (228)
M20	467 (345)	645 (476)	318 (235)	440 (325)
M24	809 (597)	1118 (824)	552 (407)	

## Identification markings

### Metric hex head, flange hex head and carriage bolts, Classes (CL) 5.6 and upward




NHIL14RB00662AA 1

**Metric bolt identification markings**

1. Manufacturer's identification
2. Property class

### Metric hex nuts and locknuts, Classes (CL) 05 and upward



NHIL14RB00663AA 2

**Metric hex nut identification markings**

- (1) – Manufacturer's identification
- (3) – Property class
- (2) – Clockwise type markings indicate property class and may include manufacturer identification (if applied), Example: property marks **240** ° apart (shown) at the eight o'clock position indicate a Class 8 property, and marks **300** ° apart at the ten o'clock position indicate a Class 10 property.

INTRODUCTION

**NOTE:** In the Imperial units tables, the nominal sizes, **1/4 (0.25) in (inch)** and **5/16 (0.3125) in (inch)** hardware torque specifications are shown as a Newton meters (pound-inches) numerical value.  
Nominal sizes **3/8 (0.375) in (inch)** through **1 (1.0) in (inch)** hardware torque specifications are shown as a Newton meters (pound-feet) numerical value.

**Inch non-flanged hardware**

Plain (PLN) – an unplated hardware finish with residual manufacturing oils

Zinc-dichromate (ZND) – a yellow colored chemical plating formula yellow applied to the hardware

Nominal size	SAE Grade (GR) 5 bolt and nut	SAE Grade (GR) 8 bolt and nut	Flange locknut GR F w/ GR 5 bolt	Flange locknut GR G w/ GR 8 bolt
	PLN and ZND	PLN and ZND	ZND	ZND
	N·m (lb in)	N·m (lb in)	N·m (lb in)	N·m (lb in)
<b>1/4 (0.25) in</b>	11 (97)	16 (142)	8.5 (75)	12.2 (109)
<b>5/16 (0.3125) in</b>	23 (204)	32 (283)	17.5 (155)	25 (220)
	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)
<b>3/8 (0.375) in</b>	40 (30)	57 (42)	31 (23)	44 (33)
<b>7/16 (0.4375) in</b>	65 (48)	91 (67)	50 (37)	71 (53)
<b>1/2 (0.50) in</b>	98 (73)	139 (103)	76 (56)	108 (80)
<b>9/16 (0.5625) in</b>	142 (105)	201 (148)	111 (82)	156 (115)
<b>5/8 (0.625) in</b>	196 (145)	277 (204)	153 (113)	215 (159)
<b>3/4 (0.75) in</b>	348 (257)	491 (362)	271 (200)	383 (282)
<b>7/8 (0.875) in</b>	561 (413)	791 (584)	437 (323)	617 (455)
<b>1 (1.0) in</b>	841 (620)	1187 (875)	654 (483)	924 (681)

**Inch flanged hardware**

Plain (PLN) – an unplated hardware finish with residual manufacturing oils










Zinc-dichromate (ZND) – a yellow colored chemical plating formula yellow applied to the hardware

Nominal size	SAE Grade (GR) 5 bolt and nut	SAE Grade (GR) 8 bolt and nut	Flange locknut GR F w/ GR 5 bolt	Flange locknut GR G w/ GR 8 bolt
	PLN and ZND	PLN and ZND	ZND	ZND
	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)
<b>1/4 (0.25) in</b>	12 (106)	17 (150)	8 (71)	12 (106)
<b>5/16 (0.3125) in</b>	25 (221)	35 (310)	17 (150)	24 (212)
	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)	N·m (lb ft)
<b>3/8 (0.375) in</b>	44 (33)	63 (46)	30 (22)	43 (32)
<b>7/16 (0.4375) in</b>	71 (52)	100 (74)	48 (35)	68 (50)
<b>1/2 (0.50) in</b>	108 (90)	153 (113)	74 (55)	104 (77)
<b>9/16 (0.5625) in</b>	156 (115)	221 (163)	106 (78)	157 (116)
<b>5/8 (0.625) in</b>	216 (159)	304 (225)	147 (108)	207 (153)
<b>3/4 (0.75) in</b>	383 (282)	541 (399)	261 (193)	369 (272)
<b>7/8 (0.875) in</b>	617 (455)	871 (642)	421 (311)	594 (438)
<b>1 (1.0) in</b>	925 (682)	1305 (963)	631 (465)	890 (656)

**Identification marking**

**Grades of inch bolts and free-spinning nuts**










**SAE (J995) bolt head and nut grade identification**

Grade identification marking	Grade Marking description
	<p><b>Grade 2</b> No line marks</p>
	<p><b>Grade 5</b> Three line marks</p>
	<p><b>Grade 8</b> Six line marks</p>
	<p><b>Grade 2</b> No circumferential line marks</p>
	<p><b>Grade 5</b> Two circumferential line marks located 120° apart</p>
	<p><b>Grade 2</b> Two circumferential line marks located 60° apart</p>
	<p><b>Grade 2</b> No circumferential line marks</p>
	<p><b>Grade 5</b> Two circumferential line marks located 120° apart</p>
	<p><b>Grade 8</b> Two circumferential line marks located 60° apart</p>

**Grades of inch prevailing torque locknuts, all metal (three common marking methods)**

On prevailing torque locknuts, the grade of nut is identified by one of three different sets of markings that denote the strength level and manufacturer.

**Common prevailing torque locknut grade identification markings**

Grade identification marking	Grade Marking description
	<p><b>Grade A</b> No marks</p>
	<p><b>Grade B (hex nut) and Grade F (flange nut)</b> Three raised or indented dot marks (Marks do not have to be in corners.)</p>
	<p><b>Grade C (hex nut) and Grade F (flange nut)</b> Six raised or indented dot marks (Marks do not have to be in corners.)</p>
	<p><b>Grade A</b> No letter mark on side flat</p>
	<p><b>Grade B</b> Letter B on side flat</p>
	<p><b>Grade C</b> Letter C on side flat</p>
	<p><b>Grade A</b> No notches</p>
	<p><b>Grade B</b> One circumferential notch on all six corners</p>
	<p><b>Grade C</b> Two circumferential notches on all six corners</p>

## Torque – Standard torque data for hydraulics

### Installation of adjustable fittings in straight thread O-ring bosses

**NOTICE:** O-ring boss fittings can be used multiple times. Always inspect the O-ring for damage and lubricate the O-ring with clean hydraulic oil or petroleum jelly at installation. Damaged O-rings will cause leakage and affect performance.

#### Nonadjustable O-ring boss fittings


1. Inspect the components and make sure the port, O-ring, sealing surfaces, and threads are clean, and free of damage.
2. Install the O-ring if needed. Take special care not to cut the O-ring on the threads.

**NOTE:** Apply electrical tape over the threads to prevent O-ring damage if installing the O-ring, and then remove the tape.

3. Lubricate the threads and O-ring with clean hydraulic oil or petroleum jelly.
4. Install the O-ring (2) in the groove (4) adjacent to the metal backup washer (1) which is assembled at the extreme end of the groove.
5. Install the fitting into the **SAE** straight thread boss and hand tighten until the metal backup washer (1) contacts the face of the boss (3).

**NOTICE:** Do not over tighten and distort the metal backup washer.

6. Using the proper size wrenches, holding the head end of the fitting with a wrench, and then torque the locknut (5) and washer (1) against the face of the boss (3) to the proper specified torque value.



NHIL14RB00661AA 1

#### Adjustable (swivel) O-ring boss fittings

1. Inspect the components and make sure the port, O-ring, sealing surfaces, and threads are clean, and free of damage.
2. Install the O-ring if needed. Take special care not to cut the O-ring on the threads.

**NOTE:** Apply electrical tape over the threads to prevent O-ring damage if installing the O-ring, and then remove the tape.

3. Lubricate the threads and O-ring with clean hydraulic oil or petroleum jelly.
4. Install the O-ring (2) in the groove (4) adjacent to the metal backup washer which is assembled at the extreme end of the groove.
5. Completely back-off the locknut (5) and washer (1) .
6. Install the fitting into the **SAE** straight thread boss and hand tighten until the metal backup washer (1) contacts the face of the boss (3).

**NOTICE:** Do not over tighten and distort the metal backup washer.

7. Position the fitting as needed by turning the head of the fitting counterclockwise up to a maximum of one turn.
8. Using the proper size wrenches, hold the head end of the fitting with a wrench, and then torque the locknut (5) and washer (1) against the face of the boss (3) to the proper specified torque value.

## Standard torque data for hydraulic tubes and fittings

**NOTICE:** These torques are not recommended for tubes of **12.7 mm (1/2 in)** Outer Diameter (OD) and larger with wall thickness of **0.889 mm (0.035 in)** or less. The torque is specified for **0.889 mm (0.035 in)** wall tubes on each application individually.

**NOTE:** Acronyms in the following table, Joint Industry Council (JIC), Outer Diameter (OD).

Tube nuts for 37 ° flared fittings				O-ring boss plugs, adjustable fitting locknuts, swivel JIC – 37 ° seats
Size	Tubing OD mm (in)	Thread size	Torque N·m (lb ft)	Torque N·m (lb ft)
4	6.4 (1/4)	7/16–20	12 – 16 (9 – 12)	8 – 14 (6 – 10)
5	7.9 (5/16)	1/2–20	16 – 20 (12 – 15)	14 – 20 (10 – 15)
6	9.5 (3/8)	9/16–18	29 – 33 (21 – 24)	20 – 27 (15 – 20)
8	12.7 (1/2)	3/4–16	47 – 54 (35 – 40)	34 – 41 (25 – 30)
10	15.9 (5/8)	7/8–14	72 – 79 (53 – 58)	47 – 54 (35 – 40)
12	19.1 (3/4)	1-1/16–12	104 – 111 (77 – 82)	81 – 95 (60 – 70)
14	22.2 (7/8)	1-3/16–12	122 – 136 (90 – 100)	95 – 109 (70 – 80)
16	25.4 (1)	1-5/16–12	149 – 163 (110 – 120)	108 – 122 (80 – 90)
20	31.8 (1-1/4)	1-5/8–12	190 – 204 (140 – 150)	129 – 158 (95 – 115)
24	38.1 (1-1/2)	1-7/8–12	217 – 237 (160 – 175)	163 – 190 (120 – 140)
32	50.8 (2)	2-1/2–12	305 – 325 (225 – 240)	339 – 407 (250 – 300)

Installing and torquing 37 ° flared fittings;

1. Clean the face of the flare and threads with **LOCTITE® ODC-FREE CLEANER AND DEGREASER** cleaning solvent or equivalent cleaning solvent.
2. Allow the cleaning the cleaning solvent to completely dry before application sealant.
3. Apply **LOCTITE® 569™** hydraulic sealant to the 37 ° flare and the threads.
4. Install the fitting, and then torque to the specified torque.
5. Loosen the fitting, and then torque once more to the specified torque.

## Pipe thread fitting torque

Thread Size (inch)	Torque (Maximum) N·m (lb ft)
1/8–27	13 (10)
1/4–18	16 (12)
3/8–18	22 (16)
1/2–14	41 (30)
3/4–14	54 (40)

Before installing and torquing pipe fittings;

1. Clean the threads with **LOCTITE® ODC-FREE CLEANER AND DEGREASER** cleaning solvent or an equivalent cleaning solvent.
2. Allow the cleaning the cleaning solvent to completely dry before application sealant.
3. Apply **LOCTITE® 567™ PST PIPE SEALANT** for all fittings, including stainless steel or **LOCTITE® 565™ PST** sealant for most other metal fittings.

**NOTICE:** For high filtration/zero contamination systems use **LOCTITE® 545™** sealant.

---

## Basic instructions - Shop and assembly

### Shimming

For each adjustment operation, select adjusting shims and measure the adjusting shims individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value shown on each shim.

### Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

1. Before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes.
2. Thoroughly clean the shaft and check that the working surface on the shaft is not damaged.
3. Position the sealing lip facing the fluid.

**NOTE:** *With hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will move the fluid towards the inner side of the seal.*

4. Coat the sealing lip with a thin layer of lubricant (use oil rather than grease). Fill the gap between the sealing lip and the dust lip on double lip seals with grease.
5. Insert the seal in its seat and press down using a flat punch or seal installation tool. Do not tap the seal with a hammer or mallet.
6. While you insert the seal, check that the seal is perpendicular to the seat. When the seal settles, make sure that the seal makes contact with the thrust element, if required.
7. To prevent damage to the seal lip on the shaft, position a protective guard during installation operations.

### O-ring seals

Lubricate the O-ring seals before you insert them in the seats. This will prevent the O-ring seals from overturning and twisting, which would jeopardize sealing efficiency.

### Sealing compounds

Apply a sealing compound on the mating surfaces when specified by the procedure. Before you apply the sealing compound, prepare the surfaces as directed by the product container.

### Spare parts

Only use CNH Original Parts or CNH Original Parts.

Only genuine spare parts guarantee the same quality, duration, and safety as original parts, as they are the same parts that are assembled during standard production. Only CNH Original Parts or CNH Original Parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and Product Identification Number (PIN)
- Part number of the ordered part, which can be found in the parts catalog



---

## Protecting the electronic and/or electrical systems during charging and welding

To avoid damage to the electronic and/or electrical systems, always observe the following practices:

1. Never make or break any of the charging circuit connections when the engine is running, including the battery connections.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any machine attachment.
  - Position the welder ground clamp as close to the welding area as possible.
  - If you weld in close proximity to a computer module, then you should remove the module from the machine.
  - Never allow welding cables to lie on, near, or across any electrical wiring or electronic component while you weld.
4. Always disconnect the negative cable from the battery when charging the battery in the machine with a battery charger.

**NOTICE:** *If you must weld on the unit, you must disconnect the battery ground cable from the machine battery. The electronic monitoring system and charging system will be damaged if this is not done.*

5. Remove the battery ground cable. Reconnect the cable when you complete welding.

### **⚠ WARNING**

**Battery acid causes burns. Batteries contain sulfuric acid.**

**Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately. Failure to comply could result in death or serious injury.**

W0111A

## Special tools

The special tools that CNH suggests and illustrate in this manual have been specifically researched and designed for use with CNH machines. The special tools are essential for reliable repair operations. The special tools are accurately built and rigorously tested to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:

- Operating in optimal technical conditions
- Obtaining the best results
- Saving time and effort
- Working in safe conditions


## General specification

Engine specifications	
Cycle	Four stroke diesel
Total displacement	<b>2.228 L (2.354 US qt)</b>
Number of cylinders	3
Bore and stroke	94 x 107
Compression ratio	17.5 : 1
Intake	Turbocharged and inter-cooled circuit
Cooling	Liquid cooled
Water pump control	Belt driven
Cooler	Water / Oil
Crankshaft rotation	Counter-clockwise
Firing order	1 - 3 - 2
Timing	Pushrods and rocker arms
	With hydraulic tappets and camshaft
	Gear cascade control and camshaft fitted on the crankcase
Minimum idling speed (RPM)	<b>800 - 1000 RPM</b>
Maximum operating speed (RPM)	<b>3000 RPM</b>
Rated operating speed	<b>2600 RPM</b>
Rated power	<b>48.5 kW (65 Hp) @ 2600 RPM</b>
Maximum torque	<b>220 N·m (162 lb ft) @ 1800 RPM</b>
Injection	Common rail direct injection
Fuel supply	Gear pump
Injector supply	High pressure injection pump
Circuit fuel supply	Rotor pump
Type of lubrication	Forced lubrication
Oil change including filter	<b>6.3 L (6.7 US qt)</b>
Oil pressure at minimum speed	<b>2.5 bar (36.2 psi)</b>
Total capacity of cooling circuit (excluding radiator and relevant pipes)	<b>3.6 L (3.8 US qt)</b>
Expansion tank cap pressure setting	<b>1.1 bar (16.0 psi)</b>
Coolant	50/50 mix
Coolant maximum temperature alarm	<b>105 °C (221 °F)</b>
Nominal voltage	<b>12 V</b>
Alternating current generator (nominal voltage)	<b>14 V</b>
Alternating current generator (nominal current)	<b>75 A</b>
Starter motor output	<b>2 kW (3 Hp)</b>

---


## Product identification

The engine Product Identification Number (PIN) plate **(1)** is located on the right-hand side of the engine flywheel housing.




NHIL14ENG1111FA 1

## Product overview – Orientation



NHIL14ENG1111FA 1


**Right-hand view**



NHIL14ENG1092FA 2


**Front view**

INTRODUCTION



NHIL14ENG1091FA 3

**Left-hand view**



NHIL14ENG1093FA 4

**Rear view**





## **SERVICE MANUAL**

**Engine**

**R 753 IE4**

# Contents

---

## Engine - 10

[10.001] Engine and crankcase .....	10.1
[10.101] Cylinder heads .....	10.2
[10.102] Pan and covers .....	10.3
[10.103] Crankshaft and flywheel.....	10.4
[10.105] Connecting rods and pistons .....	10.5
[10.106] Valve drive and gears .....	10.6
[10.206] Fuel filters .....	10.7
[10.218] Fuel injection system.....	10.8
[10.250] Turbocharger and lines.....	10.9
[10.254] Intake and exhaust manifolds and muffler .....	10.10
[10.304] Engine lubrication system.....	10.11
[10.400] Engine cooling system .....	10.12
[10.408] Oil cooler and lines.....	10.13
[10.414] Fan and drive .....	10.14
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.15
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.16





## **Engine - 10**

**Engine and crankcase - 001**

**R 753 IE4**

# Contents

---

## Engine - 10

### Engine and crankcase - 001

#### TECHNICAL DATA

Engine	
Technical Data .....	3

#### FUNCTIONAL DATA

Engine	
Overview – Orientation .....	4

#### SERVICE

Engine	
Timing adjust .....	6
Crankcase	
Liner - Remove .....	8
Liner - Measure – Protrusion .....	10
Liner - Install .....	11
Engine support and mounts	
Remove .....	12
Install .....	13


#### DIAGNOSTIC

Engine	
Troubleshooting .....	14

## Engine - Technical Data


Engine specifications	
Cycle	Four stroke diesel
Total displacement	<b>2.228 L (2.354 US qt)</b>
Number of cylinders	3
Bore and stroke	94 x 107
Compression ratio	17.5 : 1
Intake	Turbocharged and inter-cooled circuit
Cooling	Liquid cooled
Water pump control	Belt driven
Cooler	Water / Oil
Crankshaft rotation	Counter-clockwise
Firing order	1 - 3 - 2
Timing	Pushrods and rocker arms
	With hydraulic tappets and camshaft
	Gear cascade control and camshaft fitted on the crankcase
Minimum idling speed (RPM)	<b>800 - 1000 RPM</b>
Maximum operating speed (RPM)	<b>3000 RPM</b>
Rated operating speed	<b>2600 RPM</b>
Rated power	<b>48.5 kW (65 Hp) @ 2600 RPM</b>
Maximum torque	<b>220 N·m (162 lb ft) @ 1800 RPM</b>
Injection	Common rail direct injection
Fuel supply	Gear pump
Injector supply	High pressure injection pump
Circuit fuel supply	Rotor pump
Type of lubrication	Forced lubrication
Oil change including filter	<b>6.3 L (6.7 US qt)</b>
Oil pressure at minimum speed	<b>2.5 bar (36.2 psi)</b>
Total capacity of cooling circuit (excluding radiator and relevant pipes)	<b>3.6 L (3.8 US qt)</b>
Expansion tank cap pressure setting	<b>1.1 bar (16.0 psi)</b>
Coolant	50/50 mix
Coolant maximum temperature alarm	<b>105 °C (221 °F)</b>
Nominal voltage	<b>12 V</b>
Alternating current generator (nominal voltage)	<b>14 V</b>
Alternating current generator (nominal current)	<b>75 A</b>
Starter motor output	<b>2 kW (3 Hp)</b>

## Engine - Overview – Orientation




NHIL14ENG1111FA 1

**Right-hand view**




NHIL14ENG1092FA 2

**Front view**



NHIL14ENG1091FA 3

**Left-hand view**




NHIL14ENG1093FA 4

**Rear view**

## Engine - Timing adjust

Prior operation:


Timing gear housing - Remove (10.102)



NHIL14ENG1257FA 1


(1) Idler gear	(4) Idler gear
(2) Camshaft gear	(5) Oil pump gear
(3) High pressure injection pump gear	(6) Crankshaft gear

1. Remove the cylinder one fuel injector. See **Fuel injectors - Remove (10.218)**.
2. Install the Top Dead Center (TDC) tool **380003392 (1)** into the cylinder one fuel injector hole.



NHIL14ENG1286AA 2


3. Rotate the crankshaft and monitor the TDC tool gauge (1) to determine when cylinder one is at TDC.



NHIL14ENG1285AA 3

4. Install the idler gear (1) while you align the reference marks for proper crankshaft (3) to camshaft (2) timing.

**NOTE:** When the engine is set to cylinder one TDC of the compression stroke, the reference marks will be aligned as shown.




NHIL14ENG1253AA 4

## Crankcase Liner - Remove

### Prior operation:


### Connecting rod and piston - Remove (10.105)

1. Install the piston liner tool **380003381 (1)** as shown.



NHIL14ENG1275AA 1


2. Check to make sure the plate (1) rests on the bottom of the cylinder liner (2) correctly.




NHIL14ENG1277AA 2

3. Tighten the bolt (1) to extract the cylinder liner from the crankcase.

**NOTE:** Label the cylinder liners to ensure the correct placement on the installation.



NHIL14ENG1278AA 3



NHIL14ENG1112AA 4



Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)