


**Forage Harvester  
CHX320, CHX420, CHX520  
and CHX620**

**Repair Manual**

6-71020EN

**CASE *III***



# CHX320-CHX420-CHX520-CHX620 FORAGE HARVESTERS REPAIR MANUAL

## SECTIONS

### CONTENT

GENERAL INFORMATION .....	00
ENGINE .....	10
LIVE P.T.O. ....	14
TRANSMISSION .....	21
4WD LINES .....	23
FRONT MECHANICAL DRIVE .....	25
HYDROSTATIC TRANSMISSION .....	29
BRAKES AND CONTROL .....	33
HYDRAULIC SYSTEM .....	35
STEERING .....	41
CAB CLIMATE CONTROL .....	50
ELECTRICAL SYSTEM .....	55
ATTACHMENTS/HEADERS .....	58
PRODUCT FEEDING .....	60
CHOPPING .....	64
EJECTION .....	70
ACCESSORIES .....	88

S E R V I C E

## GENERAL INFORMATION

Section	Description	Page
	Introduction .....	2
	Important information .....	2
	General instructions .....	3
	Shimming .....	3
	Rotating shaft seals .....	3
	O-ring seals .....	3
	Sealing compounds .....	3
	Bearings .....	3
	Cotter pins .....	3
	Protecting the electronic / electrical systems during charging or welding .....	4
	Spare parts .....	5
	Tools .....	5
	Abbreviations .....	5
	Safety regulations .....	6
	Accident prevention .....	6
	Safety rules .....	6
	General guidelines .....	6
	Start-up .....	8
	Engine .....	8
	Electrical system .....	8
	Hydraulic systems .....	8
	Wheels and Tyres .....	9
	Removal and Re-fitting .....	9
	Explanation of machine serial number .....	10
	Conversion chart .....	11
	Hardware tightening torques .....	12
	Drive line and components .....	14
	Lubricants to be used .....	16

## SECTION 10 - ENGINE

### Chapter 1 - IVECO Engine F3A - General

	Walk around the engine .....	2
	The Iveco engine .....	7
	Engine block and cylinder liners .....	9
	Crankshaft .....	9
	Crankshaft sealing rings .....	10
	Connecting rods .....	10
	Pistons .....	10
	Camshaft .....	11
	Timing system .....	11

Flywheel .....	12
Auxiliary drivebelt .....	13
Lubrication .....	14
Oil filter .....	15
Oil sump .....	16
Cooling .....	16
Electronically controlled injection system .....	17
Pump injector .....	18

## SECTION 10 - ENGINE

### Chapter 2 - IVECO Engine - F3A

General specifications .....	3
Fuel system data .....	7
Main data .....	8
Torque settings .....	17
Plan of tightening sequence .....	22
Tools .....	25
Mechanical troubleshooting .....	29
Preliminary conditions .....	29
Engine - Disassembly - Assembly .....	33
General notes .....	43
Crankshaft .....	44
Pistons, Pistons rings and Connecting rods .....	48
Cylinder head .....	50
Oil pump and , timing system intermediate gears .....	51
Engine flywheel .....	53
Camshaft .....	54
Injectors pump .....	55
Rocker arm shaft .....	55
Completing the engine .....	59
Assembly diagram for Fan drive belt - Water pump - Alternator .....	63
Crankcase, Cylinder liners .....	64
Crankshaft, Bearings .....	67
Selecting main and big end bearing shells .....	70
Preliminary appraisal of data to make the selection .....	72
Pistons .....	86
Connecting rods .....	89
Piston and Connecting rod - Assembly .....	92
Cylinder head .....	96
Tappets and Camshaft .....	99
Valve springs, Rocker arm shaft and Rocker arms .....	104
Checks, Measurements and Repairs .....	104
Fitting valves and oil seal .....	105

---

Rocker arm shaft .....	106
Main data of the rocker arm shaft (Dimensions in mm) .....	106
Rocker arms .....	107
Lubrication system .....	107
Cooling circuit .....	112
Fuel supply .....	113
Replacing the valve guides .....	116
Injector case - Replacement .....	117
Crankshaft front cover seal - Replacement .....	120
Adjusting clearance of rocker arms to valves and pre-load of pump injector rocker arms	121
Pump injector - Removal - Refitting .....	123
Bleeding the fuel supply system .....	126
Water pump - Removal-Refitting .....	127
Thermostat - Removal - Refitting .....	128

**SECTION 10 - ENGINE**

**Chapter 3 - IVECO Engine F3B - General**

Engine description .....	3
Engine main components .....	3
Crankshaft .....	4
Crankcase gas ring .....	4
Connecting rods .....	5
Pistons .....	5
Cylinder head .....	6
Camshaft .....	6
Intake valve control .....	6
Exhaust valve control .....	6
Injector-pump control .....	6
Camshaft drive .....	7
Camshaft driving .....	7
Engine flywheel .....	8
Auxiliary component control .....	9
Oil sump .....	9
Oil filter .....	10
Fuel supply .....	11
Main components of the ms6.2 edc system .....	11
MS6.2 electronic control unit .....	13
Control unit operation .....	14
Engine coolant temperature sensor .....	16
Fuel temperature sensor .....	16
Supercharging air temperature sensor .....	17
Supercharging pressure sensor .....	17

Flywheel sensor .....	17
Distribution sensor .....	18
Pre - After heating resistance .....	18

## SECTION 10 - ENGINE

### Chapter 4 - IVECO Engine F3B

General specification .....	3
Fuel system data .....	7
Main data .....	8
Torque settings .....	13
Plan of tightening sequence .....	16
Tools .....	19
Mechanical troubleshooting .....	22
Engine - Disassembly - Assembly .....	30
General notes .....	39
Crankshaft .....	41
Pistons and connecting rods .....	45
Cylinder head .....	47
Oil pump and intermediate timing gears .....	48
Engine flywheel .....	49
Camshaft .....	50
Injectors pump .....	52
Rocker arm shaft .....	52
Completing the engine .....	56
Crankcase and cylinder liners .....	61
Crankshaft and Bearings .....	63
Selecting main and big end bearing shells .....	66
Preliminary appraisal of data to make the selection .....	67
Pistons .....	78
Connecting rods .....	81
Piston - Connecting rod assembly .....	84
Cylinder head .....	86
Valves .....	87
Tappets and Camshaft .....	90
Valve springs, Rocker arm shaft and rocker arms .....	94
Main data for checking the valve springs .....	95
Fitting valves and oil seal .....	95
Rocker arm shaft .....	96
Rocker arms .....	97
Lubrication system .....	98
Cooling system .....	102
Fuel supply .....	103
Valve guides - Replacement .....	106
Injector case - Replacement .....	107

Crankshaft front cover seal – Replacement .....	110
Clearance of valves to rocker arms and pre-load of pump injector rocker arms .....	111
Pump injector – Removal, Refitting .....	113
Bleeding the fuel supply system .....	117
Water pump – Removal, Refitting .....	118
Thermostat – Removal, Refitting .....	118

**SECTION 10 - ENGINE**

**Chapter 5 - CATERPILLAR Engine**

General .....	2
Case IH - Caterpillar .....	2
Caterpillar engine .....	2
Service / Parts .....	3

**SECTION 21 - TRANSMISSION**

Specifications .....	2
Tightening torques and Adjustments .....	2
Special tools .....	3
Gearbox shafts .....	4
Shifting diagram .....	4
Disassembly of traction gearbox .....	5
General .....	5
Removal of selector forks and shifter shafts .....	5
Removal of drive shaft .....	5
Removal of the countershaft .....	6
Removal of transmission main shaft .....	7
Removal of the half-shaft from the differential .....	8
Removal of the differential .....	9
Assembly of traction gearbox .....	10
Assembly of the differential .....	10
Assembly of the half-shafts of the differential .....	10
Assembly of transmission main shaft .....	11
Assembly of the countershaft .....	12
Assembly of the drive shaft .....	12
Assembly of selector shafts and forks .....	13
Calculation of shims to be installed on the shafts .....	13
Assembly of the cover .....	14

---

**SECTION 23 - 4WD LINES**

Specifications .....	2
Tightening torques .....	2
Special tools .....	3
Self-made tools .....	3
Gearbox shafts .....	5
4WD gearbox - Removal .....	6
4WD gearbox - Components .....	7
4WD gearbox - Disassembly .....	9
Intermediate shaft .....	10
Input shaft .....	11
Output shaft and clutch .....	12
Clutch cylinder .....	13
4WD gearbox - Assembly .....	14
Clutch cylinder .....	14
Output shaft and clutch - pre assembly .....	15
Input shaft - pre assembly .....	19
Intermediate shaft - installation .....	21
Input shaft - installation .....	22
Cover - installation .....	25
Clutch pre-assembly - installation .....	25
4WD gearbox - Installation .....	26

**SECTION 25 - FRONT MECHANICAL DRIVE**
**Chapter 1 - Final drives CHX320**

Final drives - Disassembly .....	2
Output shaft .....	2
Input shaft .....	2
Final drives - Assembly .....	4
Input shaft .....	4
End play adjustment .....	4
Output shaft .....	4
Preload adjustment .....	4



---

**SECTION 25 - FRONT MECHANICAL DRIVE**
**Chapter 2 - Final drives CHX420-520-620**

Specifications .....	2
Tightening Torques .....	2
Gearbox shafts .....	3
Wheel bolt - Replacement .....	4
Final drive - R./ I. ....	5
Final drive D./A. ....	7
Disassembly .....	7
Assembly .....	10

**SECTION 29 - HYDROSTATIC SYSTEM**

Hydrostatic circuit and components .....	2
Circuit .....	2
Hydrostatic Pump and motor Identification plate .....	4
Hydrostatic Pump .....	5
Pump operation .....	5
Circuit .....	6
Pump characteristics .....	9
Multifunction valve .....	10
Servo Valve .....	14
System in Neutral .....	14
Servo Solenoid Valve Energized .....	14
Hydrostatic Motor .....	16
Fixed Displacement Motors .....	16
Drive Motor Characteristics .....	17
Oil Cooler bypass Valve .....	18
Filling and bleeding the hydrostatic system .....	19
Starting the hydrostatic system .....	21

**SECTION 33 - BRAKES AND CONTROL**

Brake system .....	2
General .....	2
Road Mode .....	3
Parking brake adjustment .....	4
Replacement of the brake linings .....	5
Removal .....	5
Installation .....	5
Bleeding the brakes .....	6
Bleeding the left-hand side circuit .....	6
Bleeding the connection pipe between the two main cylinders .....	6

Bleeding the right-hand side circuit .....	7
Disassembly and assembly of brake shoes and discs .....	8
Disassembly of brake shoes .....	8
Disassembly of brake discs .....	8
Assembly of brake discs .....	8
Assembly of brake shoes .....	9

## SECTION 35 - HYDRAULIC SYSTEM

### Chapter 1 - General

Torque tables for hydraulic components .....	2
Union nuts .....	2
Ferrules .....	2
Metric fittings .....	2
Unions .....	2
Connections .....	3
Swivel nut with ball-type nipple .....	3
Pump group - Disassembly and Assembly .....	4
Disassembly of the pump group .....	5
Removal of the triple pump from the hydrostatic pump .....	6
Splitting of the triple pump .....	7
Assembly of the pump group .....	10
Installation of the pump group to the hydrostatic pump .....	10

## SECTION 35 - HYDRAULIC SYSTEM

### Chapter 2 - Work hydraulics - Attachment height control

Circuit diagrams .....	2
Work Hydraulics - Attachment height control .....	2
Hydraulic oil reservoir .....	4
Low pressure filter .....	5
Breather .....	5
High pressure filter .....	5
Non-return valve .....	5
Function .....	5
Work hydraulics pump .....	6
Specifications .....	6
High pressure relief valve .....	7
Attachment height control valve (EMR) .....	8
Neutral position .....	10
Attachment lifting position .....	10
Attachment lowering position .....	11
Pressure relief valve h .....	11

---

Emergency hand buttons .....	11
Specifications .....	11
Attachment compensation valve .....	12
Specifications .....	12
Transport mode .....	14
Compensation mode .....	14
Stubble height mode .....	14
Pressure sensor .....	15
Specifications .....	15
Hydropneumatic accumulators .....	16
Filling .....	17
Attachment lift cylinders .....	18

## **SECTION 35 - HYDRAULIC SYSTEM**

### **Chapter 3 - Work hydraulics - Base unit**

Circuit diagrams - Base unit .....	2
Stack valve .....	7
Repair of control valves .....	8
Load sensing valve .....	9
System in neutral .....	9
Cutterhead reverse drive motor .....	10
Specifications .....	10
Spout rotation pressure relief valve .....	12
Spout rotation motor .....	12
Specifications .....	12
Quick-release couplings .....	13
Specifications .....	13
Spout lift cylinder .....	14
Cylinder disassembly and assembly .....	14
Reinstallation of spout lift cylinder .....	15

## **SECTION 35 - HYDRAULIC SYSTEM**

### **Chapter 4 - Steering hydraulics**

Circuit diagrams - Steering hydraulics .....	2
Steering hydraulics pump .....	7
Specifications .....	7
Steering valve .....	8
Special tools .....	9
Steering valve - D./A. ....	10
Steering cylinders .....	18
Disassembly and assembly .....	18
Toe-in adjustment, steering ball joints, steering wheel stops .....	19

## SECTION 35 - HYDRAULIC SYSTEM

### Chapter 5 - Low pressure hydraulics

Circuit diagrams - Low pressure hydraulics .....	2
Low pressure hydraulic reservoir .....	4
Oil and Filter change procedure .....	4
Oil pressure check procedure .....	5
Filling the system when (re)installing the low pressure pump .....	5
Filling the system after (re)installing the main drive transfer gearbox .....	5
Low pressure pump .....	6
Specifications .....	6
Low pressure valve .....	7
Main drive belt tensioning cylinder .....	10
Spout deflector cylinder .....	11

## SECTION 35 - HYDRAULIC SYSTEM

### Chapter 6 - High-flow hydraulics

Circuit diagrams - High-Flow hydraulics .....	2
---	---

## SECTION 50 - CAB CLIMATE CONTROL

Correct use of the airconditioning system .....	2
Storage maintenance .....	2
Air conditioning circuit .....	3
Components .....	3
Specifications .....	4
Refrigerant .....	4
Compressor .....	4
Compressor clutch .....	4
Circuit parameters .....	4
Low pressure switch .....	4
High pressure switch .....	4
Filter-drier .....	5
Compressor clutch replacement .....	6
Clutch removal .....	6
Clutch installation .....	8
Ventilation unit .....	10

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 1 - General

General information .....	2
Wires .....	2
Color code .....	2
Wire identification .....	3
Fuses .....	4
Symbols .....	4
Relays .....	10
Connectors .....	11

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 2 - Wiring Diagrams CHX Europe

Wiring diagrams CHX Europe .....	2
----------------------------------	---

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 3 - Wiring Diagrams CHX NA

Wiring diagrams CHX NA .....	Not used
------------------------------	----------

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 4 - Can network basics

Can network basics .....	2
General layout electronic system .....	2
Electronic components .....	2
Conclusion .....	2
Electronic system layout .....	4
Input .....	4
Output .....	4
Analog signals (from input or to output) .....	4
Digital Information .....	4
Interfaces .....	4
Software .....	5
Calibrations .....	5
Additional info: .....	5
Can spy .....	6
Decimal and hexadecimal counting .....	6
Decimal .....	6

Hexadecimal .....	6
How to use the CAN Identifiers .....	8
How to Enter CAN-SPY .....	9
CAN-SPY in practice .....	9
Error codes messages .....	15
Wiring checking procedure .....	16
Fault finding routine .....	17

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 5 - Calibration

General .....	2
Special tools .....	2
Machine calibration with EST tool .....	3
Configuration Item Selection screen .....	6
Maximum Handle position calibration .....	7
Minimum forward pump current calibration .....	9
Minimum reverse pump current calibration .....	11
Vehicle Configuration .....	13

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 6 - Software update

Software Revision .....	2
Software update with EST tool .....	3

## SECTION 55 - ELECTRICAL SYSTEM

### Chapter 7 - Troubleshooting

Machine error messages .....	2
Attachment height control error messages .....	51
Error reports .....	52
Caterpillar error messages .....	57
List of CAN identifiers .....	59
Detailed analysis per function .....	89
1. Electric conditions, engine running or not running .....	91
2. Engine protection .....	93
3. Harvest mode .....	96
5. Cutterhead engagement .....	102
6. Feed rolls forward engagement .....	105
7. Feed rolls reverse engagement .....	107
8. Power reverse .....	109
9. Four-wheel drive .....	111

10. Spout rotation .....	113
11. Raise / lower spout .....	116
12. Spout deflector .....	118
13. Reverse cutterhead .....	120
14. Auxiliary front hydraulics .....	123
15. Auxiliary rear hydraulics .....	125
16. Air conditioning .....	127
17. Silage additives application .....	129
18. Knife sharpening .....	131
19. Adjust-O-Matic routine .....	135
20. Crop processor .....	141
21. Metal detector operation and troubleshooting .....	143
22. Attachment height control .....	155
23. Ground speed .....	164
24. High flow hydraulics .....	169
25. Rotary screens .....	171
26. Rotary screen brushes .....	172
27. Caterpillar engine .....	173
28. CAN network .....	177

## **SECTION 60 - PRODUCT FEEDING**

### **Chapter 1 - Feed rolls**

Metal detector roll .....	2
Removal .....	2
Disassembly .....	4
Metal detector components - D./A. ....	5
Disassembly .....	5
Assembly .....	5
Assembly .....	6
Installation .....	7
Smooth roll .....	9
Removal .....	9
Installation .....	10
Upper feed rolls - R./l. ....	11
Before removal .....	11
Removal of the upper feed rolls as a complete assembly. ....	12
Removal of the upper feed rolls as separate components. ....	12
Replacing wear plates on the upper feed rolls frame .....	15
Installation .....	15

## SECTION 60 - PRODUCT FEEDING

### Chapter 2 - Length of Control gearbox

Length of Control gearbox - R./I. ....	2
Removal .....	2
Installation .....	3
Gearbox shafts .....	5
Specifications .....	7
Length of Control gearbox - D./A. ....	8
1. Alternative drive shaft. ....	12
2. Transfer shaft .....	15
3. Upper feed rolls drive shaft .....	16
4. Selector shaft .....	17
5. Smooth roll drive shaft .....	19
6. Metal detector roll drive shaft .....	20
7. Reinstall the alternative drive shaft .....	22
8. Install seals and covers. ....	24

## SECTION 60 - PRODUCT FEEDING

### Chapter 3 - Attachments drive gearbox

Attachments drive gearbox - R./I. ....	2
Removal .....	2
Installation .....	3
Gearbox shafts .....	4
Specifications .....	5
Attachments drive gearbox - D./A. ....	6
Assembly .....	10
Idler shaft .....	10
Input shaft .....	11
Transfer shaft .....	12
Attachment drive shaft .....	13
Idler shaft - Re-installation .....	14



## SECTION 60 - PRODUCT FEEDING

### Chapter 4 - Upper feed rolls drive gearbox

Special tools .....	2
Upper feed rolls drive gearbox - R./l. ....	2
Removal .....	2
Installation .....	4
Gearbox shafts .....	5
Specifications .....	5
Upper feed rolls drive gearbox - D./A. ....	6
Assembly .....	10
Upper feed rolls drive shaft .....	10
Front upper feed roll drive shaft .....	11
Rear upper feed roll drive shaft .....	14
Re-install the upper feed rolls drive shaft .....	16
Seals and cover .....	17

## SECTION 64 - CHOPPING

### Chapter 1 - Cutterhead

Splitting of components .....	2
Rotor and bearings - R./l. ....	2
Removal .....	2
Assembly .....	4
Shearbar - R./l. ....	8
Shearbar support - R./l. ....	8
Removal .....	8
Installation .....	9

## SECTION 64 - CHOPPING

### Chapter 2 - Cutterhead gearbox

Cutterhead gearbox - R./l. ....	2
Removal .....	2
Installation .....	3
Cutterhead gearbox - D./A. ....	4
Oil cooler - D./A. ....	7
Gearbox - Disassembly .....	8
Input shaft .....	8
Output shaft .....	8
Gearbox - Assembly .....	10
Input shaft .....	10
Output shaft .....	10
Backlash .....	10

## SECTION 70 - EJECTION

### Chapter 1 - Blower gearbox

Inspection between cutterhead and blower .....	2
Blower - R./l. ....	2
Blower gearbox - R./l. ....	2
Blower gearbox - D./A. ....	3
Disassembly .....	3
Assembly .....	4
Input shaft .....	4
Output shaft .....	4
Adjusting the shimming .....	5

# GENERAL INFORMATION

## CONTENT

Section	Description	Page
	Introduction .....	2
	Important information .....	2
	General instructions .....	3
	Shimming .....	3
	Rotating shaft seals .....	3
	O-ring seals .....	3
	Sealing compounds .....	3
	Bearings .....	3
	Cotter pins .....	3
	Protecting the electronic / electrical systems during charging or welding .....	4
	Spare parts .....	5
	Tools .....	5
	Abbreviations .....	5
	Safety regulations .....	6
	Accident prevention .....	6
	Safety rules .....	6
	General guidelines .....	6
	Start-up .....	8
	Engine .....	8
	Electrical system .....	8
	Hydraulic systems .....	8
	Wheels and Tyres .....	9
	Removal and Re-fitting .....	9
	Explanation of machine serial number .....	10
	Conversion chart .....	11
	Hardware tightening torques .....	12
	Drive line and components .....	14
	Lubricants to be used .....	16

## INTRODUCTION

This manual is subdivided in sections marked by two-digit numbers, with independent page numbering within each section. For a quick reference, these sections have the same identification number and the same description of the relevant Flat Time Rate Manual.

The dealt matters and the information can be easily detected by index on the previous pages.

At the bottom of each page there is the manual print number and the relevant publication/up-dating date.

The information of this manual are up-dated at the date of the publication. As Case IH continuously improves its product range, some information could be not up-dated due to modifications of technical or commercial type, as well as for suiting the law regulations of the different countries.

In case of disagreement, refer to Case IH Sales and Service networks.

## IMPORTANT INFORMATION

All repair and maintenance works listed in this manual must be carried out only by staff belonging to the Case IH Service network, strictly complying with the instructions given and using, whenever required, the special tools.

Anyone who carries out the above operations without complying with the prescriptions shall be responsible for the subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional or local dealers, reject any responsibility for damages due to the anomalous behaviour of parts and/or components not approved by the manufacturer himself, including those used for the servicing or repair of the product manufactured or marketed by the Manufacturer.

In any case, no warranty is given or attributed on the product manufactured or marketed by the Manufacturer in case of damages due to an anomalous behaviour of parts and/or components not approved by the Manufacturer.

No reproduction, though partial of text and illustrations allowed

## GENERAL INSTRUCTIONS

### Shimming

For each adjustment operation, select adjusting shims and measure individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated on each shim.

### Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

- before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes
- thoroughly clean the shaft and check that the working surface on the shaft is not damaged
- position the sealing lip facing the fluid; with hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will deviate the fluid towards the inner side of the seal
- coat the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease
- insert the seal in its seat and press down using a flat punch, do not tap the seal with a hammer or mallet
- whilst inserting the seal, check that it is perpendicular to the seat; once settled, make sure that it makes contact with the thrust element, if required
- to prevent damaging the seal lip on the shaft, position a protective guard during installation operations

### O-ring seals

Lubricate the O-RING seals before inserting them in the seats, this will prevent them from overturning and twisting, which would jeopardise sealing efficiency.

### Sealing compounds

Apply one of the following sealing compounds on the mating surfaces marked with an X: RTV SILMATE, RHODORSIL CAF 1 or LOCTITE PLASTIC GASKET.

Before applying the sealing compound, prepare the surfaces as follows:

- remove any incrustations using a metal brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

### Bearings

When installing bearings it is advised to:

- heat the bearings to 80 to 90 °C before fitting on the shafts;
- allow the bearings to cool before installing them from the outside.

### Cotter pins

When fitting split cotter pins, ensure that the pin notch is positioned in the direction of the force required to stress the pin.

Spiral cotter pins do not require special positioning.

**Protecting the electronic / electrical systems during charging or welding**

To avoid damage to the electronic/electrical systems, always observe the following:

1. Never make or break any of the charging circuit connections, including the battery connections, when the engine is running.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any attachment attached to the machine.
  - Position the welder ground clamp as close to the welding area as possible.
  - If welding in close proximity to a computer module, then the module should be removed.
  - Never allow welding cables to lay on, near or across any electrical wiring or electronic component while welding is in progress.

***IMPORTANT:*** *If welding must be performed on the unit or the attachment (if it is attached), the battery ground cable must be disconnected from the battery. The electronic monitoring system and charging system will be damaged if this is not done.*

Remove the battery ground cable.  
Reconnect the cable when welding is completed.

4. Always disconnect the negative cable from the battery when charging the battery with a battery charger.

**WARNING**

**Batteries contain sulfuric acid. In case of contact with skin, flush the affected area with water for five minutes. Seek medical attention immediately. Avoid contact with the skin, eyes or clothing. Wear eye protection when working near batteries.**

---

## SPARE PARTS

Only genuine spare parts guarantee the same quality, duration and safety as original parts, as they are the same parts that are assembled during standard production.

Only Case IH genuine spare parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and serial number
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing

## TOOLS

The tools that CASE IH suggests and illustrate in this manual have been:

- specifically researched and designed for use with Case IH machines
- essential for reliable repair operations
- accurately built and rigorously tested so as to offer efficient and long-lasting operation

By using these tools, Repair Personnel will benefit from:

- operating in optimal technical conditions
- obtaining the best results
- saving time and effort
- working in safe conditions

### **NOTE:**

Wear limit values indicated for certain parts should be considered to be recommended, but not binding. The terms "front", "rear", "right-hand" and "left-hand" (when referred to different parts) are determined from the rear, facing in the direction of travel of the machine during operation.

## ABBREVIATIONS

Below some often used abbreviations used in this manual:

AKS: Automatic Knife Sharpening

ASBA: Automatic Shear Bar Adjustment

CP: Crop Processor

CPU: Central Processing Unit

EST: Electronic Service Tool

LCD: Liquid Crystal Display

MD: Metal Detector

## SAFETY REGULATIONS

### WARNING AND DANGER SYMBOL



*This warning symbol points out important personal safety messages. Carefully read the following safety regulations and observe advised precautions in order to avoid potential hazards and safeguard your health and safety. In this manual the symbol is accompanied by the following key-words:*



**WARNING** - Warnings concerning unsuitable repair operations that may jeopardise the safety of Repair personnel.

**DANGER** - Specific warnings concerning potential hazards for operator safety or for other persons directly or indirectly involved.



### ACCIDENT PREVENTION

Most accidents or injuries that occur in workshops are the result of non-observance of simple and fundamental safety regulations. For this reason, **IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED** by foreseeing possible causes and consequently acting with the necessary caution and care.

Accidents may occur with all types of machine, regardless of how well the machine in question was designed and built.

A careful and judicious service technician is the best guarantee against accidents.

Precise observance of the most basic safety rule is normally sufficient to avoid many serious accident


**DANGER**


*Never carry out any cleaning, lubrication or maintenance operations when the engine is running.*

### SAFETY RULES

#### General guidelines

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts. It is advised to wear approved safety clothing, e.g.: non-slip footwear, gloves, safety goggles, helmets, etc.
- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Do not operate the machine or use any of the implements from different positions, other than the driver's seat.
- Do not carry out operations on the machine with the engine running, unless specifically indicated.
- Stop the engine and check that the hydraulic circuits are pressure-free before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in the workshop or elsewhere should be built according to standard accident prevention regulations.
- Disconnect the batteries and label all controls to indicate that the machine is being serviced. Any parts that are to be raised must be locked in position.
- Do not check or fill fuel tanks, accumulator batteries, nor use starting liquid when smoking or near naked flames, as these fluids are inflammable.
- Brakes are inoperative when manually released for repair or maintenance purposes. Use blocks or similar devices to control the machine in these conditions.



- The fuel nozzle should always be in contact with the filling aperture. Maintain this position until filling operations are completed in order to avoid possible sparks caused by the accumulation of static electricity.
- Only use specified towing points for towing the machine. Connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- Transport machines that cannot be driven using a trailer or a low-loading platform trolley, if available.
- When loading or unloading the machine from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the machine to the truck or trailer and lock the wheels in the position used by the carrier.
- Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Take extra care if bystanders are present.
- Never pour gasoline or diesel oil into open, wide or low containers.
- Never use gasoline, diesel oil or other inflammable liquids as cleaning agents. Use non-inflammable, non toxic commercially available solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Reduce the air pressure according to the local regulations in force..
- Do not run the engine in confined spaces without suitable ventilation.
- Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- Never use naked flames for lighting when working on the machine or checking for leaks.
- All movements must be carried out carefully when working under, on or near the machine. Wear protective equipment: helmets, goggles and special footwear.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the machine on a flat surface and lock in position. If working on a slope, lock the machine in position. Move to a flat area as soon as is safely possible.
- Damaged or bent chains or cables are unreliable. Do not use them for lifting or towing. Always use suitable protective gloves when handling chains or cables.
- Chains should always be safely secured. Make sure that the hitch-up point is capable of sustaining the load in question. Keep the area near the hitch-up point, chains or cables free of all bystanders.
- Maintenance and repair operations must be carried out in a CLEAN and DRY area. Eliminate any water or oil spillage immediately.
- Do not create piles of oil or grease-soaked rags as they represent a serious fire hazard. Always store rags in a closed metal container. Before engaging the machine, make sure that there are no persons within the machine or implement range of action.
- Empty your pockets of all objects that may fall accidentally unobserved into the machine inner compartments.
- In the presence of protruding metal parts, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.

- Metal cables tend to fray with repeated use. Always use suitable protective devices (gloves, goggles, etc.) when handling cables.
- Handle all parts carefully. Do not put your hands or fingers between moving parts. Wear suitable safety clothing – safety goggles, gloves and shoes.

### Start-up

- Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- Never place the head, body, limbs, feet, hands or fingers near rotating and moving parts.

### Engine

- Always loosen the radiator cap slowly before removing it to allow any remaining pressure in the system to be discharged. Filling up with coolant should only be carried out with the engine stopped or idling (if hot)..
- Never fill up with fuel when the engine is running, especially if hot, in order to prevent the outbreak of fire as a result of fuel spillage.
- Never check or adjust fan belt tension when the engine is running. Never adjust the fuel injection pump when the Forage Harvester is moving.
- Never lubricate the Forage Harvester when the engine is running.

### Electrical system

- If it is necessary to use auxiliary batteries, remember that both ends of the cables must be connected as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY INFLAMMABLE. During charging, leave the battery compartment uncovered to improve ventilation. Never check the battery charge using "jumpers" (metal objects placed on the terminals). Avoid sparks or flames near the battery zone. Do not smoke to prevent explosion hazards.
- Before servicing operations, check for fuel or current leaks. Eliminate any eventual leaks before proceeding with work.
- Never charge batteries in confined spaces. Make sure that there is adequate ventilation in order to prevent accidental explosion hazards as a result of the accumulation of gases released during charging operations.
- Always disconnect the batteries before performing any kind of servicing on the electrical system.

### Hydraulic systems

- A liquid leaking from a tiny hole may be almost invisible but, at the same time, be powerful enough to penetrate the skin. Therefore, NEVER USE HANDS TO CHECK FOR LEAKS but use a piece of cardboard or wood for this purpose. If any liquid penetrates skin tissue, call for medical aid immediately. Failure to treat this condition with correct medical procedure may result in serious infection or dermatosis.
- In order to check the pressure in the system use suitable instruments.

**Wheels and Tyres**

- Make sure that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check the rims and tyres for damage.
- Stand away from (at the side of) the tyre when checking inflation pressure.
- Do not use parts of recovered wheels as incorrect welding brazing or heating may weaken and eventually cause damage to the wheel.
- Never cut or weld a rim mounted with an inflated tyre.
- To remove the wheels, lock all wheels. After having raised the machine, position supports underneath, according to regulations in force.
- Deflate the tyre before removing any objects that may be jammed in the tyre tread.
- Never inflate tyres using inflammable gases, as this may result in explosions and injury to bystanders.

**Removal and Re-fitting**

- Lift and handle all heavy parts using suitable hoisting equipment. Make sure that parts are sustained by appropriate hooks and slings. Use the hoisting eyebolts for lifting operations. Extra care should be taken if persons are present near the load to be lifted.
- Handle all parts carefully. Do not put your hands or fingers between parts. Wear suitable safety clothing – safety goggles, gloves and shoes.
- Avoid twisting chains or metal cables. Always wear safety gloves when handling cables or chains.

## EXPLANATION OF MACHINE SERIAL NUMBER

Example : n° 285266001

**28**5266001: The first two digits identify the model within a product line:

CHX320 = 19

CHX420 = 20

CHX520 = 28

CHX620 = 17

**285**266001 : The third digit indicates the product line. The code for the forage harvester product line is (5).

285**266**001 : These 3 digits indicate the batch in which the machine was made.

285**266**001 : Product line number (5) and batch (266) together form the series number (5266).

285266**001** : The last 3 digits are a sequential number for each model within a batch.

Summarizing we can say that this machine is the first CHX520 of serie 5266.

**CONVERSION CHART**

## Linear

1 mm	=	0.03937 in	1 in	=	25.4 mm
1 Km	=	0.6214 miles	1 mile	=	1.6093 km
1 m	=	3.281 ft	1 ft	=	0.3048 m

## Area

1 ha	=	2.471 acre	1 acre	=	0.4047 ha
------	---	------------	--------	---	-----------

## Volume

1 litre	=	0.0063 barrel	1 barrel	=	158.987 litre
1 litre	=	0.028 US bushel	1 US bushel	=	35.2391 litre
1 litre	=	0.2642 US gal	1 US gal	=	3.7853 litre
1 litre	=	1.057 US quart	1 US quart	=	0.9464 litre
1 mm <sup>3</sup>	=	0.061 in <sup>3</sup>	1 in <sup>3</sup>	=	16387 mm <sup>3</sup>

## Weight

1 kg	=	2.204 pound	1 pound	=	0.4536 kg
------	---	-------------	---------	---	-----------

## Torque

1 Nm	=	0.7376 lbf.ft	1 lbf ft	=	1.3558 Nm
------	---	---------------	----------	---	-----------

## Power

1 kW	=	1.358 hp	1 hp	=	0.746 kW
------	---	----------	------	---	----------

## Pressure

1 bar	=	14.505 lbf/in <sup>2</sup> (psi)	1 lbf/in <sup>2</sup> (psi)	=	0.06894 bar
1 kPa	=	0.145 lbf/in <sup>2</sup> (psi)	1 lbf/in <sup>2</sup> (psi)	=	6.894 kPa
1 pa	=	10 <sup>-5</sup> bar	1 bar	=	100 kPa

## Temperature

1 °C	=	((1.8 x ° C) + 32) ° F	1 °F	=	(0.56 x (° F - 32))°C
------	---	------------------------	------	---	-----------------------

## HARDWARE TIGHTENING TORQUES

## MINIMUM HARDWARE TIGHTENING TORQUES

IN NEWTON-METRES - Nm (FOOT POUNDS - LBF. FT)  
FOR NORMAL ASSEMBLY APPLICATIONS


## METRIC HARDWARE AND LOCKNUTS

NOMINAL SIZE	CLASS 5.8		CLASS 8.8		CLASS 10.9		LOCKNUT CL.8 W/CL.8 BOLT
	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr	UNPLATED	PLATED W/ZnCr	
M4	1.7 (15*)	2.2 (19*)	2.6 (23*)	3.4 (30*)	3.7 (33*)	4.8 (42*)	1.8 (16*)
M6	5.8 (51*)	7.6 (67*)	8.9 (79*)	12 (102*)	13 (115*)	17 (150*)	6.3 (56*)
M8	14 (124*)	18 (159*)	22 (195*)	28 (248*)	31 (274*)	40 (354*)	15 (133*)
M10	28 (21)	36 (27)	43 (32)	56 (41)	61 (45)	79 (58)	30 (22)
M12	49 (36)	63 (46)	75 (55)	97 (72)	107 (79)	138 (102)	53 (39)
M16	121 (89)	158 (117)	186 (137)	240 (177)	266 (196)	344 (254)	131 (97)
M20	237 (175)	307 (226)	375 (277)	485 (358)	519 (383)	671 (495)	265 (195)
M24	411 (303)	531 (392)	648 (478)	839 (619)	897 (662)	1160 (855)	458 (338)

NOTE: Torque values shown with \* are inch pounds.

IDENTIFICATION  
HEX CAP SCREW AND CARRIAGE BOLTS  
CLASSES 5.6 AND UP


## MANUFACTURER'S IDENTIFICATION



## PROPERTY CLASS

HEX NUTS AND LOCKNUTS  
CLASSES 05 AND UP

## MANUFACTURER'S IDENTIFICATION



## PROPERTY CLASS

## CLOCK MARKING

# MINIMUM HARDWARE TIGHTENING TORQUES

IN NEWTON-METRES - Nm (FOOT POUNDS - LBF. FT)  
FOR NORMAL ASSEMBLY APPLICATIONS

## INCH HARDWARE AND LOCKNUTS


NOMINAL SIZE	SAE GRADE 2		SAE GRADE 5		SAE GRADE 8		LOCKNUTS		NOMINAL SIZE
	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	UNPLATED or PLATED SILVER	PLATED W/ZnCr GOLD	GR.B w/GR5 BOLT	GR.C w/GR8 BOLT	
1/4	6.2 (55*)	8.1 (72*)	9.7 (86*)	13 (112*)	14 (121*)	18 (157*)	6.9 (61*)	9.8 (86*)	1/4
5/16	13 (115*)	17 (149*)	20 (178*)	26 (229*)	28 (250*)	37 (324*)	14 (125*)	20 (176*)	5/16
3/8	23 (17)	30 ( 22)	35 (26)	46 (34)	50 (37)	65 (48)	26 (19)	35 (26)	3/8
7/16	37( 27)	47 (35)	57 (42)	73 (54)	80 (59)	104 (77)	41 (30)	57 (42)	7/16
1/2	57 (42)	73 (54)	87 (64)	113 (83)	123 (91)	159 (117)	61 (45)	88 (64)	1/2
9/16	81 (60)	104 (77)	125 (92)	163 (120)	176 (130)	229 (169)	88 (65)	125 (92)	9/16
5/8	112 (83)	145 (107)	174 (128)	224 (165)	244 (180 )	316 (233)	122 (90)	172 (127)	5/8
3/4	198 (146)	256 (189)	306 (226)	397 (293)	432 (319)	560 (413)	217 (160)	306 (226)	3/4
7/8	193 (142)	248 (183)	495 (365)	641 (473)	698 (515)	904 (667)	350 (258)	494 (364)	7/8
1	289 ((213)	373 (275)	742 (547)	960 ( 708)	1048 (773)	1356 (1000)	523 (386)	739 (545)	1

NOTE: Torque values shown with \* are inch pounds.

### IDENTIFICATION CAP SCREWS AND CARRIAGE BOLTS



### LOCKNUTS



Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)