

Workshop Service Manual



Large Square Baler

1290 UD



TABLE OF CONTENT

- General 1
- Main frame 2
- Drive system 3
- Hydraulic system 4
- Electrical system 5
- Bale feed system 6
- Bale forming system 7
- Roller bale chute system 8
- Diagrams 9
- Index 10

1 General

1.1	Safety	1-5
1.1.1	Safety symbol	1-5
1.1.2	Safety messages	1-5
1.1.3	Information messages	1-5
1.1.4	Safety signs	1-5
1.1.5	Safety warnings	1-6
1.1.6	A word to the technician	1-6
1.1.7	The service manual	1-7
1.1.8	The operator manual	1-7
1.1.9	Tool box	1-8
1.1.10	Operation	1-8
1.1.10.1	General information	1-8
1.1.10.2	Prepare for operation	1-9
1.1.10.3	Personal protective equipment	1-10
1.1.10.4	Seat instructions	1-10
1.1.10.5	Shield and guards	1-10
1.1.10.6	Exhaust warning	1-11
1.1.10.7	Flying debris	1-11
1.1.10.8	Handrails	1-12
1.1.10.9	Agricultural chemicals	1-12
1.1.11	Travel on public roads	1-12
1.1.12	Maintenance	1-14
1.1.12.1	General maintenance information	1-14
1.1.12.2	Fire prevention and first aid	1-16
1.1.12.3	High pressure leaks	1-17
1.1.12.4	Tire safety	1-17
1.2	General information	1-19
1.2.1	Introduction to this service manual	1-19
1.2.2	Units of measurement	1-19
1.2.3	Table of contents	1-19
1.2.4	Page numbers	1-19
1.2.5	Remove a gib key	1-19
1.2.6	Install a gib key	1-20
1.2.7	Remove a lock collar	1-21
1.2.8	Install a lock collar	1-21
1.3	Specifications	1-22
1.3.1	Specifications	1-22
1.3.1.1	Dimensions and weights	1-22
1.3.1.2	Drive system specifications	1-22
1.3.1.3	Shearbolt specifications	1-23
1.3.1.4	Hydraulic specifications	1-23
1.3.1.5	Pickup specifications	1-23
1.3.1.6	ProCut™ cutter specifications	1-24
1.3.1.7	Packer specifications	1-25
1.3.1.8	Stuffer specifications	1-25
1.3.1.9	Plunger specifications	1-25
1.3.1.10	Twine specifications	1-25
1.3.1.11	Knotter and needle specifications	1-26
1.3.1.12	Bale chamber tension specifications	1-26
1.3.1.13	Ejector specifications	1-26
1.3.1.14	Roller bale chute specifications	1-26

1.3.1.15	Lamp specifications	1-26
1.3.1.16	Knotter lubrication pump specifications	1-27
1.3.1.17	Chain lubrication pump specifications	1-27
1.3.1.18	Lubricants and capacities	1-27
1.3.1.19	Tire specifications	1-28
1.3.1.20	Brake specifications	1-28
1.3.1.21	Maximum speed	1-28
1.3.1.22	Tractor requirements	1-29
1.3.1.23	Noise level	1-29
1.3.2	Bolt torque values	1-29
1.4	Machine identification	1-32
1.4.1	Location of the serial number plates and the type certification plate - if equipped	1-32
1.4.2	Serial number description	1-32
1.5	Machine component views	1-34
1.5.1	Outside view - left side	1-34
1.5.2	Outside view - right side	1-35
1.5.3	Inner view - left side	1-36
1.5.4	Inner view - right side	1-37
1.5.5	Outside view - top	1-38
1.5.6	Outside view - bottom	1-39
1.6	Service and lubrication schedule	1-40
1.6.1	Service schedule	1-40
1.6.2	Lubrication procedures and general information	1-43
1.6.2.1	Drive chains	1-43
1.6.2.2	Driveline lubrication and maintenance	1-44
1.6.2.3	Lubricate the hitch ball, if equipped	1-46
1.6.2.4	Do not lubricate the overrunning clutch	1-47
1.6.2.5	Do not lubricate the slip clutch for the main drive	1-47
1.6.2.6	Lubricate the connecting rods	1-47
1.6.2.7	Examine the packer crank bearings	1-48
1.6.2.8	Lubricate the bearing for the main drive sprocket	1-48
1.6.2.9	Lubricate the stuffer drive	1-48
1.6.2.10	Lubricate the knotter/needle clutch arm and the clutch arm roller	1-49
1.6.2.11	Lubricate the brake linkages	1-49
1.6.2.12	Lubricate the steering axle pivots and the steering axle tie-rods	1-50
1.6.2.13	Lubricate the pivot bushings for the tandem axle springs	1-50
1.6.2.14	Lubricate the center fitting for the six twine knotter	1-51
1.6.2.15	Lubricate the linkages for the bale density cylinders	1-51
1.6.2.16	Lubricate the packer clutch bushing and the splines	1-51
1.7	Connect to the tractor - CE	1-53
1.7.1	Hitch component identification	1-53
1.7.2	Set the tongue height	1-53
1.7.3	Tractor setup dimensions with an 80 mm (3.15 in) ball hitch, a CE spherical ball hitch, or a 50 mm (2 in) ring hitch	1-54
1.7.4	Connect a 50 mm (2 in) ring hitch to the tractor	1-54
1.7.5	Connect an 80 mm (3.15 in) ball hitch to the tractor	1-55
1.7.6	Operate a manual jack installed on the tongue	1-55
1.7.7	Operate a hydraulic jack installed on the tongue	1-56
1.7.8	Install the safety transport chain	1-57
1.7.9	Constant velocity implement driveline, if equipped	1-57
1.7.9.1	Check the constant velocity implement driveline for correct length	1-57
1.7.9.2	Connect a constant velocity implement driveline to a power take-off (PTO)	1-59
1.7.9.3	Adjust the pedestal gearbox	1-60
1.8	Checklists	1-61
1.8.1	Daily checklist	1-61
1.8.2	Examine after the first hour of operation	1-61

1.9	Lamps and Reflectors	1-63
1.9.1	Lamps and reflectors	1-63
1.9.2	Lamps and reflectors	1-65
1.10	Baler operation	1-69
1.10.1	Description of operation	1-69
1.10.2	General terminal information	1-69
1.10.3	Prepare to bale	1-69
1.10.4	Plunger position indication	1-70
1.10.5	Start the machine	1-70
1.10.5.1	Start the machine: determine the direction of plunger travel	1-70
1.10.5.2	Start the machine: plunger on the retraction (green) stroke	1-72
1.10.5.3	Start the machine: plunger on the compression (red) stroke	1-73
1.10.5.4	Start the machine: machine does not start after four attempts	1-73
1.10.6	Make the first bale	1-74
1.10.7	Make bales	1-75
1.10.8	Stop the machine	1-75
1.10.9	Stuffer cycle	1-76
1.11	Prepare to road the machine or move the machine on a trailer	1-77
1.12	Tie down points, jack points, and lift points	1-79
1.12.1	Tie down points	1-79
1.12.2	Jack points	1-80
1.12.3	Lift points	1-80
1.12.4	Lift and move a machine correctly	1-80
1.13	Disconnect the tractor	1-82

1.1 Safety

1.1.1 Safety symbol

The safety symbol tells you about a potentially hazardous area!

Look for the safety symbol in this manual and on the machine. The safety symbols tell you that there is important safety instructions in the manual.



Fig. 1

1.1.2 Safety messages

The words DANGER, WARNING or CAUTION are used with the safety symbol. Learn these safety messages and obey the recommended precautions and safety instructions.



DANGER:
If you do not obey the recommended precautions and safety instructions, **DEATH OR INJURY will occur.**



WARNING:
If you do not obey the recommended precautions and safety instructions, **DEATH OR INJURY can occur.**



CAUTION:
If you do not obey the recommended precautions and safety instructions, **INJURY can possibly occur.**



Fig. 2

1.1.3 Information messages

The words important and note are not related to personal safety, and are used to give information about the operation and servicing of the machine.

IMPORTANT: Identifies special instructions or procedures which, if not followed, can cause damage to the machine, the process, or the area around the machine.

NOTE: Information to make procedures easier.

1.1.4 Safety signs



WARNING:
Do not remove the safety signs. Replace safety signs that you cannot read, are damaged, or are missing.

Clean the machine surface with a weak soap and water solution before you replace the safety signs. Replacement safety signs are available from your dealer.

1. General

Always make sure that safety signs are in the correct locations and that you can read the safety signs. Illustrations of safety sign locations are in this section.

Keep the safety signs clean. If necessary, use a weak soap and water solution.

1.1.5 Safety warnings

Before doing any unplugging, lubricating, servicing, cleaning, or adjusting:

- Park the machine on a solid level surface.
- Disengage the tractor power take-off (PTO).
- Put the tractor transmission in PARK and apply the tractor park brake.
- Turn off the terminal.
- Stop the tractor engine and take the key with you.
- Apply the baler flywheel brake.
- Apply the baler park brake, if equipped.
- Look and listen! Make sure all moving parts have stopped.
- Put blocks in front of and behind the wheels of the machine and the tractor before working on or under the machine.



WARNING:

After lubrication, servicing, or adjusting the machine, make sure all tools and equipment have been removed.



WARNING:

All shields and guards must be in position before operating the machine.

1.1.6 A word to the technician

Read and understand the safety section in this service manual before operating or servicing the machine. Read and understand the safety sections in the manuals for all attachments before operating or servicing attachments. The technician has the key to safety. Good safety practices protect everyone.

Study the safety information in this service manual. Make the safety information a working part of the safety program. The safety information in this service manual applies specifically to this type of machine. Always do all other usual and customary safe working precautions. Remember - The technician has the responsibility for safety. Good safety practices can prevent serious injury or death.

The safety section points out some basic safety situations that can occur during the operation and maintenance of the machine. The safety section also suggests possible ways to deal with these situations. The safety section does not replace safety practices in other parts of this service manual.

Practice good safety to help prevent injury or death.

Learn how to operate the machine and how to use the controls correctly.




Fig. 3

Do not let other persons operate the machine without instruction and training.

Follow all safety precautions and instructions in the manuals and on safety signs affixed to the machine and all attachments.

Use only approved attachments and equipment.

Make sure the machine has the correct equipment needed by the local regulations.



WARNING:

An operator should not use alcohol or drugs which can affect their alertness or coordination. An operator on prescription or 'over the counter' drugs needs medical advice on whether or not they can properly operate machines. If any attachments used on this equipment have a separate Operator Manual, see that manual for other important safety information.

1.1.7 The service manual

Read the table of contents and basic layout. Become familiar with all parts of this service manual. This service manual gives the technician very important information.

Machine movement when in normal use determines right-hand and left-hand.

This manual covers general safety practices for this machine.

The photos, illustrations, and data used in this manual were current at the time of printing. Inline production changes can make machines vary from the information in the service manual. The manufacturer reserves the right to redesign and change the machine as necessary without notification.



WARNING:

In some of the illustrations and photos used in this manual, shields or guards may have been removed for clarity. Never operate the machine with any shields or guards removed. If the removal of shields or guards is necessary to make a repair, they must be replaced before operation.

1.1.8 The operator manual

Always keep the operator manual with the machine.

Store the operator manual in the container (1) located on the left-hand side of the machine.




Fig. 4

1.1.9 Tool box

The machine has a toolbox (1) on the top of the machine on the right side. Keep service parts and the shear bolts in the tool box.




Fig. 5

1.1.10 Operation

1.1.10.1 General information

When parking, park the machine and the tractor on a solid level surface. put all controls in neutral and apply the tractor park brake. Stop the tractor engine and take the key with you.

Make sure the tractor and implement are in the proper operating condition according to the operator manuals. Make sure the tractor brakes and the machine brakes are adjusted correctly.

The tractor must have enough weight and braking capacity, especially when operating on roads and terrain that is not even. Use a tractor of recommended size and weight to tow the machine.

Tractor must be equipped with rollover protective structure (ROPS) and a seat belt. Use seat belt during operation.

Do not dismount from moving machinery.

Always operate the machine with the terminal turned on.

Never start the tractor with the PTO engaged or terminal turned on.

Stay off slopes too steep for operation.

Where possible avoid operating the machine near ditches, embankments, and holes. Reduce ground speed when operating on rough, slippery, or muddy surfaces and when turning or crossing slopes.

Be aware of the size of the machine and have enough space available to allow for operation.




Fig. 6

Make sure all persons are clear of the rear of the bale chute when raising and lowering the chute, ejecting or dumping a bale.

Do not stand between the tractor and the implement to install the hitch pin when the tractor engine is running.

Avoid contact with electrical power lines. Contact with electrical power lines can cause electrical shock, resulting in very serious injury or death.




Fig. 7

Related Links

[Tractor requirements](#) page 1-29

1.1.10.2 Prepare for operation

Read and understand all operation instructions and precautions in this manual before you operate the machine or do the servicing.

Make sure that you know and understand the positions and operations of all controls. Make sure that all controls are in neutral and that the parking brake is applied before you start the machine.

Make sure that all persons are away from your area of work before you start and operate the machine. Examine and learn the controls in an area that is clear of persons and obstacles before you start work. Know the machine dimensions and make sure that you have sufficient space available to operate the machine. Do not operate the machine at high speeds in crowded areas.

It is important to know and use the correct procedures when you do work around and operate the machine. Do not let children or unqualified persons operate the machine. Keep others, especially children, away from your area of work. Do not let others ride on the machine.

Make sure that the machine is in good condition for operation. Refer to the operator manual. Make sure that the machine has the correct equipment required by local regulations.

All equipment has a limit. Make sure you understand the speed, brakes, steering, stability and load characteristics of this machine and the tractor before you start.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com