

BOOK 1 - 87681734

STANDARD TORQUE SPECIFICATIONS.....	SECTION 1001
TORQUE SPECIFICATIONS - DECIMAL HARDWARE	1001-3
TORQUE SPECIFICATIONS - METRIC HARDWARE	1001-4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS	1001-5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC O-RING FITTINGS	1001-6
FLUIDS AND LUBRICANTS	SECTION 1010
ENGINE	1010-3
COOLING SYSTEM	1010-3
FUEL SYSTEM	1010-3
TRANSMISSION	1010-3
FINAL DRIVE	1010-3
HYDRAULIC SYSTEM	1010-3
CHASSIS GEAR BOX - RIGHT AND LEFT	1010-3
DRUM TOP GEAR BOX	1010-4
AIR CONDITIONING REFRIGERANT CAPACITY	1010-4
PICKER BAR AUTOMATIC LUBRICATION SYSTEM	1010-4
MODULE CHAMBER UNLOADER CONVEYOR CHAIN	1010-4
UNLOADER CONVEYOR DRIVE CHAIN	1010-4
GREASE FITTINGS	1010-4
WATER TANK	1010-4
CHASSIS AUTOMATIC LUBRICATION	1010-4
ENGINE REMOVAL AND INSTALLATION.....	SECTION 2015
GENERAL INFORMATION.....	2015-3
RECOMMENDED TOOLS.....	2015-3
ENGINE REMOVAL.....	2015-5
Raising the Module with a Non-Operating Engine	2015-5
Raising the Module with an Operating Engine	2015-6
REFERENCE ILLUSTRATIONS.....	2015-22
ENGINE INSTALLATION.....	2015-25
ELECTRICAL SYSTEM - HOW IT WORKS - Prior to P.I.N. Y7T012801	SECTION 4010
SPECIAL TOOLS	4010-3
FUSE/RELAY IDENTIFICATION AND LOCATIONS	4010-4
WIRE SIZE CONVERSION	4010-7
WIRE COLOR ABBREVIATIONS	4010-7
MAIN VALVE ASSEMBLY, DRUM CONTROL VALVE AND TILT VALVE	4010-8
MODULE BUILDER VALVE ASSEMBLY	4010-10
XCM CONTROLLER CONNECTORS	4010-12
WIRING HARNESS CONNECTORS	4010-15
POWER DISTRIBUTION SYSTEM CIRCUIT	4010-54
CRANKING MOTOR (STARTER) CIRCUIT	4010-55
CHARGING CIRCUIT	4010-56
INSTRUMENTATION / DIGITAL TACHOMETER	4010-57
COTTON MONITOR FEEDS	4010-58
COTTON MONITOR BAR LUBE	4010-58
INSTRUMENT PANEL AND WARNING LIGHTS	4010-59
PARK BRAKE CIRCUIT	4010-63
WINDSHIELD WIPER CIRCUIT	4010-64
MODULE CHAMBER CONTROL CIRCUIT	4010-65
DRUM CONTROLS	4010-66
COMPACTOR/AUGER CONTROLS	4010-69
POWER GUIDE AXLE	4010-71

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

OPERATOR PRESENCE SYSTEM (OPS)	4010-72
ENGINE OIL PRESSURE/HYDRAULIC LOCK OUT SYSTEM	4010-73
LIGHTING SYSTEM	4010-74
SERVICE LIGHTS AND RADIO	4010-77
CIGAR LIGHTER / DOME LIGHTS / AIR SEAT AND AUXILIARY POWER CIRCUITS	4010-78
MOISTENER CONTROL	4010-79
FAN CONTROL	4010-80
DRUM SPREAD CIRCUIT	4010-81
COTTON MONITOR SYSTEM	4010-82
ELECTRICAL SYSTEM - HOW IT WORKS - P.I.N. Y7T012801 and After	SECTION 4011
SPECIAL TOOLS	4011-3
FUSE/RELAY IDENTIFICATION AND LOCATIONS	4011-4
WIRE SIZE CONVERSION	4011-7
WIRE COLOR ABBREVIATIONS	4011-7
MAIN VALVE ASSEMBLY, DRUM CONTROL VALVE AND TILT VALVE	4011-8
MODULE EXPRESS VALVE ASSEMBLY	4011-10
XCM CONTROLLER CONNECTORS	4011-12
WIRING HARNESS CONNECTORS	4011-15
POWER DISTRIBUTION SYSTEM CIRCUIT	4011-53
CRANKING MOTOR (STARTER) CIRCUIT	4011-54
CHARGING CIRCUIT	4011-55
INSTRUMENTATION / DIGITAL TACHOMETER	4011-56
COTTON MONITOR FEEDS	4011-57
COTTON MONITOR BAR LUBE	4011-57
INSTRUMENT PANEL AND WARNING LIGHTS	4011-58
PARK BRAKE CIRCUIT	4011-62
WINDSHIELD WIPER CIRCUIT	4011-63
MODULE CHAMBER CONTROL CIRCUIT	4011-64
DRUM CONTROLS	4011-65
COMPACTOR/AUGER CONTROLS	4011-68
DOOR OPEN/CLOSE AND CHAMBER TILT UP/DOWN SYSTEM.....	4011-70
POWER GUIDE AXLE	4011-71
OPERATOR PRESENCE SYSTEM (OPS)	4011-72
ENGINE OIL PRESSURE/HYDRAULIC LOCK OUT SYSTEM	4011-73
LIGHTING SYSTEM	4011-74
SERVICE LIGHTS AND RADIO	4011-77
CIGAR LIGHTER / DOME LIGHTS / AIR SEAT AND AUXILIARY POWER CIRCUITS	4011-78
MOISTENER CONTROL	4011-79
FAN CONTROL	4011-80
DRUM SPREAD CIRCUIT	4011-81
COTTON MONITOR SYSTEM	4011-82
ELECTRICAL TROUBLESHOOTING - Prior to P.I.N. Y7T012801.....	SECTION 4020
GENERAL	4020-3
CRANKING MOTOR (STARTER) AND POWER DISTRIBUTION	4020-4
DRUM SERVICE CONTROLS OPERATION AND TROUBLESHOOTING	4020-7
Troubleshooting Drum Tilt Does Not Lower	4020-7
Troubleshooting Drums Do Not Lower	4020-8
Troubleshooting Drum (s) Do Not Raise	4020-10
Troubleshooting Drum Tilt Will Not Raise (Tilt Back)	4020-11
COMPACTOR/AUGER OPERATION AND TROUBLESHOOTING	4020-12

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

ELECTRICAL TROUBLESHOOTING - P.I.N. Y7T012801 and After.....SECTION 4021
GENERAL 4021-3
CRANKING MOTOR (STARTER) AND POWER DISTRIBUTION 4021-3
DRUM SERVICE CONTROLS OPERATION AND TROUBLESHOOTING 4021-6
 Troubleshooting Drum Tilt Does Not Lower 4021-6
 Troubleshooting Drums Do Not Lower 4021-7
 Troubleshooting Drum (s) Do Not Raise 4021-9
 Troubleshooting Drum Tilt Will Not Raise (Tilt Back) 4021-10
COMPACTOR/AUGER OPERATION AND TROUBLESHOOTING 4021-11

AUTOMATIC STEERING GUIDANCE SYSTEM.....SECTION 4030
SAFETY INFORMATION 4030-3
GUIDANCE SYSTEM MAIN COMPONENTS 4030-4
HOW IT WORKS 4030-5
TROUBLESHOOTING 4030-6
 Guidance System Evaluation 4030-6
ENTERING DIAGNOSTIC MODES 4030-8
DIAGNOSTIC MODE CHART 4030-9
GUIDANCE SYSTEM AUTOMATIC VALVE SETUP 4030-11
GUIDANCE SYSTEM LEARN PROCEDURE 4030-12
PENDULUM YOKE ASSEMBLY 4030-13
DRUM INPUT SENSOR 4030-14
 Adjustment 4030-14
 Installation 4030-15
STEERING AXLE FEEDBACK SENSOR 4030-16
 Installation 4030-16
 Adjustment 4030-17
STEERING CONTROL VALVE 4030-18

STEERING AXLE.....SECTION 5010
GENERAL INFORMATION.....5010-3
 Symbols5010-3
TECHNICAL INFORMATION5010-4
 Main Dimensions.....5010-4
MAIN COMPONENT GROUPS.....5010-5
GENERAL SAFETY INFORMATION.....5010-7
SPECIAL TOOLS.....5010-7
AXLE MAINTENANCE.....5010-10
 Fill and Drain Plugs.....5010-10
 Service Schedule5010-11
 Oil Change5010-11
ADHESIVE AND SEALANT.....5010-13
TORQUE CHART5010-15
DISASSEMBLY AND ASSEMBLY PROCEDURE.....5010-18
 Steering Cylinder.....5010-18
 Cylinder Disassembly.....5010-20
 Cylinder Assembly.....5010-23
 Epicyclic Reduction Gear5010-22
 Reduction Gear Disassembly.....5010-22
 Reduction Gear Assembly.....5010-24
 Wheel Hub5010-26
 Wheel Hub Disassembly5010-27
 Wheel Hub Assembly5010-31
 Potentiometer Assembly5010-35
 Trunnions and Flange5010-37
 Trunnions and Flange Disassembly.....5010-37
 Trunnions and Flange Assembly.....5010-39

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

Axle Beam.....5010-41
Axle Beam Disassembly.....5010-44
Axle Beam Assembly5010-43
Differential Support5010-46
Differential Support Disassembly5010-46
Differential Support Assembly5010-49
Bevel Gear Marking Test5010-55
Differential5010-57
Differential Disassembly.....5010-57
Differential Assembly.....5010-59
Pinion5010-60
Pinion Disassembly5010-60
Pinion Assembly.....5010-63
TOE-IN AND STEERING ANGLE.....5010-69
Toe-In Adjustment.....5010-69
Steering Angle Adjustment.....5010-72
TESTING AFTER ASSEMBLY5010-74
Testing Procedure.....5010-74
TROUBLESHOOTING.....5010-75

BOOK 2 - 87399158

TRANSMISSION SERVICE SECTION 6010
SPECIFICATIONS 6010-3
SPECIAL TORQUES 6010-3
SPECIAL TOOLS 6010-3
GENERAL INFORMATION 6010-4
BRAKE ASSEMBLY AND TRANSMISSION COVER REMOVAL 6010-5
SHIFTER RAIL AND SHIFT FORK REMOVAL 6010-7
CHANGE GEAR SHAFT REMOVAL AND DISASSEMBLY 6010-10
DIFFERENTIAL REMOVAL AND DISASSEMBLY 6010-13
DIFFERENTIAL PINION SHAFT REMOVAL AND DISASSEMBLY 6010-17
DIFFERENTIAL PINION SHAFT ASSEMBLY AND INSTALLATION 6010-23
Checking the Differential Pinion Shaft End Play 6010-29
DIFFERENTIAL ASSEMBLY AND INSTALLATION 6010-31
Measuring the Shim Thickness for Differential Bearing Cap 6010-34
CHANGE GEAR SHAFT ASSEMBLY 6010-36
CHANGE GEAR SHAFT AND INPUT HOUSING INSTALLATION 6010-38
Drum Drive to Transmission Installation 6010-40
Measuring the Change Gear Shaft End Play 6010-41
Measuring the Internal Spline Shaft Wear 6010-42
SHIFTER RAILS AND SHIFT FORK ASSEMBLY 6010-46
TRANSMISSION COVER AND BRAKE INSTALLATION 6010-50
CROSS-SECTIONAL DRAWING OF TRANSMISSION 6010-52

DRUM DRIVE..... SECTION 6020
DISASSEMBLY OF THE DRUM DRIVE 6020-3
INSPECTION 6020-10
EXPLODED VIEW DRAWING 6020-11
ASSEMBLY OF THE DRUM DRIVE 6020-12
IDLER GEAR (ROLLER BEARING) SHIM PROCEDURE 6020-20
CROSS-SECTIONAL DRAWING 6020-22

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

FINAL DRIVE	SECTION 6030
SPECIFICATIONS	6030-2
SPECIAL TOOLS	6030-2
SERVICING THE FINAL DRIVE	6030-3
Removal	6030-3
Disassembly	6030-5
Cleaning and Inspection	6030-10
Assembly	6030-11
Setting the Pinion Shaft Rolling Torque	6030-12
Setting the Output Shaft Rolling Torque	6030-18
Installation	6030-19
CROSS-SECTIONAL DRAWING OF FINAL DRIVE	6030-21
CABLE ADJUSTMENT	SECTION 6040
PROPULSION CONTROL CABLE ADJUSTMENT	6040-3
GEAR SHIFT CABLE ADJUSTMENT	6040-8
BRAKE ASSEMBLIES	SECTION 7010
SPECIFICATIONS	7010-2
SERVICING THE BRAKE ASSEMBLIES	7010-3
Disassembly	7010-3
Inspection	7010-10
Assembly	7010-12
CROSS-SECTIONAL DRAWING OF BRAKE ASSEMBLY	7010-21
MASTER BRAKE VALVE	SECTION 7020
SPECIAL TORQUES	7020-2
SPECIFICATIONS	7020-2
BRAKE VALVE REMOVAL	7020-3
BRAKE VALVE DISASSEMBLY	7020-5
BRAKE VALVE ASSEMBLY	7020-9
CROSS-SECTIONAL DRAWING OF BRAKE VALVE	7020-13
BRAKE VALVE INSTALLATION	7020-14
Brake Pedal Adjustment	7020-14

BOOK 3 - 87399159

HYDRAULIC SYSTEM - HOW IT WORKS	SECTION 8010
GENERAL INTRODUCTION	8010-3
BASIC PRINCIPLES OF THE HYDRAULIC SYSTEM	8010-3
HOW IT WORKS	8010-3
HYDRAULIC OIL RESERVOIR, FILTRATION AND COOLING	8010-4
PISTON PUMP AND COMPENSATOR VALVE	8010-6
MAIN VALVE ASSEMBLY, DRUM CONTROL VALVE AND TILT VALVE	8010-12
MODULE BUILDER VALVE ASSEMBLY	8010-14
STEERING SYSTEM	8010-16
BRAKE SYSTEM	8010-21
DRUM CIRCUIT SPECIAL COMPONENT DESCRIPTIONS	8010-27

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

HYDRAULIC SYSTEM TESTSSECTION 8020
PACKAGER PFC PISTON PUMP FLOW AND PRESSURE TEST 8020-3
PACKAGER PFC PISTON PUMP DIFFERENTIAL PRESSURE TEST 8020-5
AUXILIARY PFC PISTON PUMP FLOW AND PRESSURE TEST 8020-6
AUXILIARY PFC PISTON PUMP CUT OFF PRESSURE TEST 8020-8
AUXILIARY PFC PISTON PUMP DIFFERENTIAL PRESSURE TEST 8020-9
BRAKE LEAKAGE CHECK 8020-10

HYDRAULIC SYSTEM TROUBLESHOOTINGSECTION 8030
GENERAL INTRODUCTION 8030-3
HYDRAULIC SYSTEM TROUBLESHOOTING 8030-3
MAIN VALVE ASSEMBLY AND MODULE BUILDER VALVE DIAGNOSTIC PORTS 8030-4
1 - No Hydraulics - Packager PFC Piston Pump Circuits 8030-5
1A - No Hydraulics - Auxiliary PFC Piston Pump Circuits 8030-5
2 - Steering Works But No Electro-hydraulic Functions 8030-5
3 - Electro-hydraulic Functions Operate Only When Steering Is Held Against Stop 8030-6
4 - Excessive Steering Effort - Auxiliary PFC Pump Circuit 8030-6
6 - Steering Slips (Too Many Turns Stop To Stop) 8030-7
7 - Steering Auto Rotates / High Initial Effort 8030-7
8 - Module Will Not Tilt to Unload Position - Raise 8030-8
8 - Module Will Not Tilt to Unload Position - Raise (Continued) 8030-9
9 - Module Will Not Lower or Lowers Slowly 8030-10
12 - Module Primary and Secondary Doors Will Not Open 8030-12
13 - Module Primary and Secondary Doors Will Not Close 8030-13
14 - Module Primary and Secondary Door Unloader Conveyors Do Not Move or Move Slowly 8030-14
16 - Fan Will Not Engage 8030-17
17 - Fan Will Not Disengage 8030-18
18 - Rockshaft Will Not Lower 8030-19
19 - Rockshaft Tilted Down, Drum(s) Will Not Lower (Main Valve Assembly) 8030-20
20 - Rockshaft Will Not Raise (Tilt Raise) 8030-21
21 - Rockshaft or Drum Cylinder Is Leaking Down 8030-22
22 - Drum(s) Will Not Raise 8030-23
23 - Drum Automatic Height Control Does Not Function 8030-25
24 - Compactor Will Not Begin Cycle (Cylinders Will Not Extend) 8030-26
25 - Compactor Will Not Raise After Compacting (Cylinders Will Not Retract) 8030-27
26 - Compactor Will Not Raise or Lower Evenly 8030-28
27 - Auger Motors Will Not Turn (Module Chamber Is Not Full) 8030-29
28 - Drum Service Cylinders Will Not Spread 8030-31
29 - Drum Service Cylinders Will Not Return to Harvest Position (Close) 8030-33
30 - Drum Lube Pump Will Not Operate 8030-35
31 - Brake Pedals are Soft or Travel to Floor 8030-36
32 - Brake Light ON 8030-36

ROTARY AIR SCREENSECTION 8040
ROTARY AIR SCREEN HYDRAULIC MOTOR 8040-3
Removal 8040-3
Disassembly 8040-5
Assembly 8040-10
Inspection 8040-10
Shaft End Assembly 8040-11
Motor Stator End Assembly 8040-16
Timing Procedure 8040-17
Installation 8040-20

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

ROTARY AIR SCREEN HYDRAULIC PUMP	8040-22
Installation	8040-23
ROTARY AIR SCREEN HYDRAULIC VALVE	8040-24
Valve Service	8040-26
Installation	8040-27
ROTARY AIR SCREEN REPAIR	8040-28
CYLINDERS.....	SECTION 8050
SPECIAL TORQUES	8050-3
SPECIAL TOOLS	8050-4
CYLINDER SERVICE PROCEDURE	8050-5
CYLINDER SERVICE	8050-6
Fan Engage Cylinder	8050-6
Disassembly	8050-6
Assembly	8050-7
Drum Tilt and Lift Cylinders	8050-8
Disassembly	8050-8
Assembly	8050-10
Drum Spread Cylinder	8050-11
Disassembly	8050-11
Assembly	8050-12
Module Chamber Primary Door Cylinder	8050-13
Disassembly	8050-13
Assembly	8050-14
Module Chamber Secondary Door Cylinder	8050-15
Disassembly	8050-15
Assembly	8050-16
Compactor Cylinder	8050-17
Disassembly	8050-17
Assembly	8050-18
Module Chamber Tilt Cylinder	8050-19
Disassembly	8050-19
Assembly	8050-21
HYDRAULIC OIL FILTERS	SECTION 8060
HYDRAULIC OIL FILTERS	8060-3
Manifold Valve Inline Filter	8060-4
HYDRAULIC SYSTEM AIR REMOVAL	8060-4
 BOOK 4 - 87681735 	
AIR-CONDITIONING TROUBLESHOOTING	SECTION 9010
SAFETY PROCEDURES	9010-3
SPECIAL TOOLS	9010-4
ACCESSING THE EVAPORATOR/HEATER ASSEMBLY	9010-5
THEORY OF OPERATION	9010-6
ATC System	9010-8
Temperature Range	9010-8
Smart Pressure Switch Cycling System	9010-9
A/C OPERATION	9010-9
ATC TROUBLESHOOTING	9010-11
ATC Electrical Troubleshooting	9010-11
ATC Fault Codes	9010-15
1 - High Pressure Switch and Circuit Test	9010-18
2 - Low Pressure Switch and Circuit Test	9010-18

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

3 - Blower Potentiometer and Circuit Test	9010-20
4 - Temperature Potentiometer and Circuit Test	9010-21
5 - Cab Temperature Sensor and Circuit Test	9010-22
6 - Evaporator Temperature Sensor and Circuit Test	9010-22
7 - ATC Controller Power Supply and Ground Test	9010-23
8 - Blower Motor Power Supply and Ground Test	9010-24
9 - Clutch Relay Power Supply and Ground Test	9010-25
10 - Heater Control Valve Power Supply and Ground Test	9010-25
11 - ATC Switch and Circuit Test	9010-26
12 - PWM Module Power Supply and Circuit Test	9010-26
13 - LCD Display and Circuit Test	9010-27
14 - Cab Pressurizer Blower Motor and Circuit Test	9010-27
EXTERNAL COMPRESSOR CHECK	9010-28
OPERATIONAL MODES	9010-30
BLOWER AND TEMPERATURE CONTROL	9010-32
ATC CONTROLLER	9010-35
CAB TEMPERATURE CHECK	9010-38
EVAPORATOR AND PLENUM CHECK	9010-42
CAB AND EVAPORATOR TEMPERATURE SENSORS	9010-43
CAB PRESSURIZER BLOWER	9010-44
ATC COMPONENT LOCATIONS	9010-45
AIR-CONDITIONING SYSTEM SERVICE FOR SYSTEMS WITH R-134a REFRIGERANTSECTION 9020	
SPECIFICATIONS	9020-3
SPECIAL TORQUES	9020-3
SPECIAL TOOLS	9020-3
SAFETY PROCEDURES	9020-4
AIR CONDITIONER SYSTEM REFRIGERANT RECOVERY	9020-5
A/C COMPRESSOR	9020-9
Oil Level Check or Adjustment	9020-9
Injection Method	9020-9
Dipstick Method	9020-10
Compressor Installation	9020-14
Compressor Belt Removal, Installation and Adjustment	9020-16
AIR CONDITIONER SYSTEM EVACUATION AND RECHARGING	9020-19
A/C COMPRESSOR CLUTCH	9020-25
Clutch Removal	9020-25
Exploded View Illustration of Clutch	9020-30
Compressor Clutch Replacement	9020-31
THERMAL EXPANSION VALVE TESTING	9020-37
THERMAL EXPANSION VALVE REPLACEMENT	9020-39
ILLUSTRATION OF ATC COMPONENTS	9020-42
CONDENSER, RECEIVER-DRIER AND TUBES	9020-46
INSTALLATION OF EVAPORATOR TEMPERATURE SENSOR	9020-47
ILLUSTRATION OF BLOWER AND EVAPORATOR	9020-48
HEATER AND EVAPORATOR CORE	9020-49
Accessing the A/C Unit	9020-49
Heater and Evaporator Core Removal	9020-50
Heater and Evaporator Core Installation	9020-54
ATC CONTROLLER AND PWM MODULE REPLACEMENT	9020-59
CAB RECIRCULATION AIR FILTER SERVICE	9020-60
CAB INTAKE AIR FILTER SERVICE	9020-60
CAB PRESSURIZATION TEST	9020-61

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

LINCOLN® LUBRICATION SYSTEM.....SECTION 9030
SPECIFICATIONS 9030-3
LINCOLN LUBRICATION SYSTEM OPERATION 9030-4
 How The LINCOLN Lubrication System Works 9030-4
MANUAL START SWITCH AND SYSTEM INDICATOR LAMPS 9030-6
MAINTENANCE 9030-7
 Daily 9030-7
 Reservoir Manual Fill (If Equipped) 9030-7
 50 Hours 9030-8
 Splicing Broken Lubricating Lines 9030-8
CHASSIS LUBRICATION 9030-9
DRUM LUBRICATION 9030-10
LINCOLN LUBRICATION PUMP 9030-11
LINCOLN LUBRICATION PUMP DISASSEMBLY AND ASSEMBLY 9030-12
SYSTEM CHECKOUT 9030-14
TROUBLESHOOTING 9030-15
 Service 9030-15
 Field Operation 9030-17

AIR SUSPENSION SEATSECTION 9040
Seat Cushion and Backrest 9040-3
 Disassembly 9040-4
 Assembly 9040-4
Slide Rail 9040-5
 Removal 9040-6
 Installation 9040-6
Suspension 9040-7
 Disassembly 9040-8
 Assembly 9040-8

FAN ASSEMBLYSECTION 9050
FAN DRIVE BELT REPLACEMENT 9050-3
 Rear Fan Belt 9050-3
 Rear Fan Drive Belt Adjustment 9050-10
 Front Fan Belt 9050-11
 Replacement 9050-11
 Adjustment 9050-12
FAN ASSEMBLY SERVICE 9050-13
 Rear Fan Removal 9050-13
 Disassembly 9050-16
 Assembly 9050-19
 Installation 9050-24
 Front Fan Removal 9050-27
 Disassembly 9050-29
 Assembly 9050-32
 Installation 9050-36

PRESSURE MOISTENER SYSTEM.....SECTION 9060
PRESSURE MOISTENER PUMP 9060-3
WATER FILTER 9060-5
 Removal 9060-5
 Installation 9060-6
IN-LINE FILTER 9060-7
SPRAY NOZZLES 9060-8
WATER TANK SUPPORTS 9060-9
WATER TANK 9060-10
PRESSURE MOISTENER SYSTEM LAYOUT 9060-11

MODULE EXPRESS 625 COTTON PICKER MASTER TABLE OF CONTENTS

PICKER DRUM REMOVAL AND INSTALLATIONSECTION 9070
DRUM REMOVAL 9070-3
DRUM INSTALLATION 9070-8


PICKER DRUM SERVICESECTION 9080
SPECIAL TOOLS 9080-3
COMPONENT WEAR SPECIFICATIONS 9080-7
SPECIAL TORQUES 9080-7
PICKER BAR AND SPINDLE SERVICE 9080-8
MOISTURE ASSEMBLY SERVICE 9080-26
DOFFER ASSEMBLY SERVICE 9080-32
DOFFER DRIVE ASSEMBLY SERVICE 9080-39
GEAR DRIVE SERVICE 9080-45
RATCHET CLUTCH 9080-51
DRUM TO DRUM DRIVE SHAFT 9080-53
DRUM INPUT DRIVE SHAFT 9080-58

PICKER BAR AND SPINDLE LUBRICATION SYSTEMSECTION 9090
MOTOR/PUMP REPLACEMENT 9090-3
BLEEDING LUBRICATION SYSTEM OF AIR 9090-5
Filling Picker Bar Lube Reservoir 9090-6
PICKING UNIT LUBRICATION LINE ROUTING 9090-8
LUBRICATION VALVE 9090-9

DRUM DRIVE GEARBOX.....SECTION 9095
SPECIAL TOOLS 9095-3
LUBRICANT CAPACITY 9095-3
CHASSIS MOUNTED, DRUM DRIVE GEARBOXES 9095-4
DRUM MOUNTED GEARBOXES WITHOUT SNOOTS 9095-26
DRUM MOUNTED GEARBOXES WITH SNOOTS 9095-54

SCHEMATICS

ELECTRICAL SCHEMATIC - Prior to P.I.N. Y7T01280187516879
ELECTRICAL SCHEMATIC - P.I.N. Y7T012801 and After.....87676928
HYDRAULIC SCHEMATIC.....87516880



Module Express™ 625 Cotton Picker

Repair Manual

Book 1
General
Engine
Electrical
Steering

87681734
Issued June, 2007
(Replaces 87399157)

CASE IH

Repair Manual Number 87642590

Book 1 - Publication 87681734

**General
Engine
Electrical
Steering**

Book 2 - Publication 87399158

Power Train

Book 3 - Publication 87399159

Hydraulics

Book 4 - Publication 87681735

Chassis

Electrical Schematic, Prior to P.I.N. Y7P01801 - 87516879
Electrical Schematic, P.I.N. Y7P01801 and After - 87676928

Hydraulic Schematic - 87516880

You can order Repair Manual Books separately
(see publication numbers above)
or you can order a complete Repair Manual 87642590.

BOOK 1 - TABLE OF CONTENTS

BOOK 1 - 87681734

STANDARD TORQUE SPECIFICATIONS SECTION 1001
TORQUE SPECIFICATIONS - DECIMAL HARDWARE 1001-3
TORQUE SPECIFICATIONS - METRIC HARDWARE 1001-4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 1001-5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC O-RING FITTINGS 1001-6

FLUIDS AND LUBRICANTS SECTION 1010
ENGINE 1010-3
COOLING SYSTEM 1010-3
FUEL SYSTEM 1010-3
TRANSMISSION 1010-3
FINAL DRIVE 1010-3
HYDRAULIC SYSTEM 1010-3
CHASSIS GEAR BOX - RIGHT AND LEFT 1010-3
DRUM TOP GEAR BOX 1010-4
AIR CONDITIONING REFRIGERANT CAPACITY 1010-4
PICKER BAR AUTOMATIC LUBRICATION SYSTEM 1010-4
MODULE CHAMBER UNLOADER CONVEYOR CHAIN 1010-4
UNLOADER CONVEYOR DRIVE CHAIN 1010-4
GREASE FITTINGS 1010-4
WATER TANK 1010-4
CHASSIS AUTOMATIC LUBRICATION 1010-4

ENGINE REMOVAL AND INSTALLATION SECTION 2015
GENERAL INFORMATION 2015-3
RECOMMENDED TOOLS 2015-3
ENGINE REMOVAL 2015-4
 Raising the Module with a Non-Operating Engine 2015-4
 Raising the Module with an Operating Engine 2015-5
REFERENCE ILLUSTRATIONS 2015-21
ENGINE INSTALLATION 2015-24
 Alternate Method 2015-26

ELECTRICAL SYSTEM - HOW IT WORKS SECTION 4010
SPECIAL TOOLS 4010-3
FUSE/RELAY IDENTIFICATION AND LOCATIONS 4010-4
WIRE SIZE CONVERSION 4010-7
WIRE COLOR ABBREVIATIONS 4010-7
MAIN VALVE ASSEMBLY, DRUM CONTROL VALVE AND TILT VALVE 4010-8
MODULE BUILDER VALVE ASSEMBLY 4010-10
XCM CONTROLLER CONNECTORS 4010-12
WIRING HARNESS CONNECTORS 4010-15
POWER DISTRIBUTION SYSTEM CIRCUIT 4010-54
CRANKING MOTOR (STARTER) CIRCUIT 4010-55
CHARGING CIRCUIT 4010-56
INSTRUMENTATION / DIGITAL TACHOMETER 4010-57
COTTON MONITOR FEEDS 4010-58
COTTON MONITOR BAR LUBE 4010-58
INSTRUMENT PANEL AND WARNING LIGHTS 4010-59
PARK BRAKE CIRCUIT 4010-63
WINDSHIELD WIPER CIRCUIT 4010-64
MODULE CHAMBER CONTROL CIRCUIT 4010-65
DRUM CONTROLS 4010-66
COMPACTOR/AUGER CONTROLS 4010-69
POWER GUIDE AXLE 4010-71

BOOK 1 - TABLE OF CONTENTS

OPERATOR PRESENCE SYSTEM (OPS)	4010-72
ENGINE OIL PRESSURE/HYDRAULIC LOCK OUT SYSTEM	4010-73
LIGHTING SYSTEM	4010-74
SERVICE LIGHTS AND RADIO	4010-77
CIGAR LIGHTER / DOME LIGHTS / AIR SEAT AND AUXILIARY POWER CIRCUITS	4010-78
MOISTENER CONTROL	4010-79
FAN CONTROL	4010-80
DRUM SPREAD CIRCUIT	4010-81
COTTON MONITOR SYSTEM	4010-82
ELECTRICAL SYSTEM - HOW IT WORKS - P.I.N. T7T012801 AND AFTER	SECTION 4011
SPECIAL TOOLS	4011-3
FUSE/RELAY IDENTIFICATION AND LOCATIONS	4011-4
WIRE SIZE CONVERSION	4011-7
WIRE COLOR ABBREVIATIONS	4011-7
MAIN VALVE ASSEMBLY, DRUM CONTROL VALVE AND TILT VALVE	4011-8
MODULE EXPRESS VALVE ASSEMBLY	4011-10
XCM CONTROLLER CONNECTORS	4011-12
WIRING HARNESS CONNECTORS	4011-15
POWER DISTRIBUTION SYSTEM CIRCUIT	4011-53
CRANKING MOTOR (STARTER) CIRCUIT	4011-54
CHARGING CIRCUIT	4011-55
INSTRUMENTATION / DIGITAL TACHOMETER	4011-56
COTTON MONITOR FEEDS	4011-57
COTTON MONITOR BAR LUBE	4011-57
INSTRUMENT PANEL AND WARNING LIGHTS	4011-58
PARK BRAKE CIRCUIT	4011-62
WINDSHIELD WIPER CIRCUIT	4011-63
MODULE CHAMBER CONTROL CIRCUIT	4011-64
DRUM CONTROLS	4011-65
COMPACTOR AND AUGER SYSTEM	4011-68
DOOR OPEN/CLOSE AND CHAMBER TILT UP/DOWN SYSTEM	4011-70
POWER GUIDE AXLE	4011-71
OPERATOR PRESENCE SYSTEM (OPS)	4011-72
ENGINE OIL PRESSURE/HYDRAULIC LOCK OUT SYSTEM	4011-73
LIGHTING SYSTEM	4011-74
SERVICE LIGHTS AND RADIO	4011-77
CIGAR LIGHTER / DOME LIGHTS / AIR SEAT AND AUXILIARY POWER CIRCUITS	4011-78
MOISTENER CONTROL	4011-79
FAN CONTROL	4011-80
DRUM SPREAD CIRCUIT	4011-81
COTTON MONITOR SYSTEM	4011-82
ELECTRICAL TROUBLESHOOTING, PRIOR TO P.I.N. Y7T012801	SECTION 4020
GENERAL	4020-3
CRANKING MOTOR (STARTER) AND POWER DISTRIBUTION	4020-4
DRUM SERVICE CONTROLS OPERATION AND TROUBLESHOOTING	4020-7
Troubleshooting Drum Tilt Does Not Lower	4020-7
Troubleshooting Drums Do Not Lower	4020-8
Troubleshooting Drum (s) Do Not Raise	4020-10
Troubleshooting Drum Tilt Will Not Raise (Tilt Back)	4020-11
COMPACTOR/AUGER OPERATION AND TROUBLESHOOTING	4020-12

BOOK 1 - TABLE OF CONTENTS

ELECTRICAL TROUBLESHOOTING, P.I.N. Y7T012801 AND AFTER	SECTION 4021
GENERAL	4021-3
CRANKING MOTOR (STARTER) AND POWER DISTRIBUTION	4021-3
DRUM SERVICE CONTROLS OPERATION AND TROUBLESHOOTING	4021-6
Troubleshooting Drum Tilt Does Not Lower	4021-6
Troubleshooting Drums Do Not Lower	4021-7
Troubleshooting Drum (s) Do Not Raise	4021-9
Troubleshooting Drum Tilt Will Not Raise (Tilt Back)	4021-10
COMPACTOR/AUGER OPERATION AND TROUBLESHOOTING	4021-11
AUTOMATIC STEERING GUIDANCE SYSTEM	SECTION 4030
SAFETY INFORMATION	4030-3
GUIDANCE SYSTEM MAIN COMPONENTS	4030-4
HOW IT WORKS	4030-5
TROUBLESHOOTING	4030-6
Guidance System Evaluation	4030-6
ENTERING DIAGNOSTIC MODES	4030-8
DIAGNOSTIC MODE CHART	4030-9
GUIDANCE SYSTEM AUTOMATIC VALVE SETUP	4030-11
GUIDANCE SYSTEM LEARN PROCEDURE	4030-12
PENDULUM YOKE ASSEMBLY	4030-13
DRUM INPUT SENSOR	4030-14
Adjustment	4030-14
Installation	4030-15
STEERING AXLE FEEDBACK SENSOR	4030-16
Installation	4030-16
Adjustment	4030-17
STEERING CONTROL VALVE	4030-18
STEERING AXLE	SECTION 5010
GENERAL INFORMATION	5010-3
TECHNICAL INFORMATION	5010-4
MAIN COMPONENT GROUPS	5010-5
GENERAL SAFETY INFORMATION	5010-6
SPECIAL TOOLS	5010-7
AXLE MAINTENANCE	5010-10
ADHESIVE AND SEALANT	5010-13
TORQUE CHART	5010-15
DISASSEMBLY AND ASSEMBLY PROCEDURE	5010-18
Steering Cylinder	5010-18
Epicyclic Reduction Gear	5010-22
Wheel Hub	5010-26
Potentiometer Assembly	5010-35
Trunnions and Flange	5010-37
Axle Beam	5010-41
Differential Support	5010-46
Bevel Gear Marking Test	5010-55
Differential	5010-57
Pinion	5010-60
TOE-IN AND STEERING ANGLE	5010-69
Toe-In Adjustment	5010-69
Steering Angle Adjustment	5010-72
TESTING AFTER ASSEMBLY	5010-74
Testing Procedure	5010-74
TROUBLESHOOTING	5010-75

Section 1001


STANDARD TORQUE SPECIFICATIONS


TABLE OF CONTENTS

TORQUE SPECIFICATIONS - DECIMAL HARDWARE	1001-3
TORQUE SPECIFICATIONS - METRIC HARDWARE	1001-4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS	1001-5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC O-RING FITTINGS	1001-6

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphities, Molydisulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
1/4 inch	108 to 132	12 to 15
5/16 inch	204 to 252	23 to 28
3/8 inch	420 to 504	48 to 57
Size	Pound-Feet	Newton metres
7/16 inch	54 to 64	73 to 87
1/2 inch	80 to 96	109 to 130
9/16 inch	110 to 132	149 to 179
5/8 inch	150 to 180	203 to 244
3/4 inch	270 to 324	366 to 439
7/8 inch	400 to 480	542 to 651
1.0 inch	580 to 696	787 to 944
1-1/8 inch	800 to 880	1085 to 1193
1-1/4 inch	1120 to 1240	1519 to 1681
1-3/8 inch	1460 to 1680	1980 to 2278
1-1/2 inch	1940 to 2200	2631 to 2983


Grade 8 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
1/4 inch	144 to 180	16 to 20
5/16 inch	288 to 348	33 to 39
3/8 inch	540 to 648	61 to 73
Size	Pound-Feet	Newton metres
7/16 inch	70 to 84	95 to 114
1/2 inch	110 to 132	149 to 179
9/16 inch	160 to 192	217 to 260
5/8 inch	220 to 264	298 to 358
3/4 inch	380 to 456	515 to 618
7/8 inch	600 to 720	814 to 976
1.0 inch	900 to 1080	1220 to 1465
1-1/8 inch	1280 to 1440	1736 to 1953
1-1/4 inch	1820 to 2000	2468 to 2712
1-3/8 inch	2380 to 2720	3227 to 3688
1-1/2 inch	3160 to 3560	4285 to 4827


NOTE: Use thick nuts with Grade 8 bolts.

TORQUE SPECIFICATIONS - METRIC HARDWARE

Use the following torques when specifications are not given.

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or Molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
M4	24 to 36	3 to 4
M5	60 to 72	7 to 8
M6	96 to 108	11 to 12
M8	228 to 276	26 to 31
M10	456 to 540	52 to 61
Size	Pound-Feet	Newton metres
M12	66 to 79	90 to 107
M14	106 to 127	144 to 172
M16	160 to 200	217 to 271
M20	320 to 380	434 to 515
M24	500 to 600	675 to 815
M30	920 to 1100	1250 to 1500
M36	1600 to 1950	2175 to 2600

Grade 10.9 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
M4	36 to 48	4 to 5
M5	84 to 96	9 to 11
M6	132 to 156	15 to 18
M8	324 to 384	37 to 43
Size	Pound-Feet	Newton metres
M10	54 to 64	73 to 87
M12	93 to 112	125 to 150
M14	149 to 179	200 to 245
M16	230 to 280	310 to 380
M20	450 to 540	610 to 730
M24	780 to 940	1050 to 1275
M30	1470 to 1770	2000 to 2400
M36	2580 to 3090	3500 to 4200

Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
37 Degree Flare Fitting			
1/4 inch 6.4 mm	7/16-20	72 to 144	8 to 16
5/16 inch 7.9 mm	1/2-20	96 to 192	11 to 22
3/8 inch 9.5 mm	9/16-18	120 to 300	14 to 34
1/2 inch 12.7 mm	3/4-16	180 to 504	20 to 57
5/8 inch 15.9 mm	7/8-14	300 to 696	34 to 79
Tube OD Hose ID	Thread Size	Pound- Foot	Newton metres
3/4 inch 19.0 mm	1-1/16-12	77 to 82	104 to 111
7/8 inch 22.2 mm	1-3/16-12	90 to 100	122 to 136
1.0 inch 25.4 mm	1-5/16-12	110 to 120	149 to 163
1-1/4 inch 31.8 mm	1-5/8-12	140 to 150	190 to 204
1-1/2 inch 38.1 mm	1-7/8-12	225 to 240	305 to 325

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
Straight Threads with O-ring			
1/4 inch 6.4 mm	7/16-20	144 to 228	16 to 26
5/16 inch 7.9 mm	1/2-20	192 to 300	22 to 34
3/8 inch 9.5 mm	9/16-18	300 to 480	34 to 54
1/2 inch 12.7 mm	3/4-16	540 to 804	57 to 91
Tube OD Hose ID	Thread Size	Pound- Foot	Newton metres
5/8 inch 15.9 mm	7/8-14	58 to 92	79 to 124
3/4 inch 19.0 mm	1-1/16-12	80 to 128	108 to 174
7/8 inch 22.2 mm	1-3/16-12	100 to 160	136 to 216
1.0 inch 25.4 mm	1-5/16-12	117 to 187	159 to 253
1-1/4 inch 31.8 mm	1-5/8-12	165 to 264	224 to 357
1-1/2 inch 38.1 mm	1-7/8-12	250 to 400	339 to 542

Split Flange Mounting Bolts		
Size	Pound- Inches	Newton metres
5/16-18	180 to 240	20 to 27
3/8-16	240 to 300	27 to 34
7/16-14	420 to 540	47 to 61
Size	Pound- Feet	Newton metres
1/2-13	55 to 65	74 to 88
5/8-11	140 to 150	190 to 203

TORQUE SPECIFICATIONS - STEEL HYDRAULIC O-RING FITTINGS

Nom. SAE Dash Size	Tube OD	Thread Size	Pound-Inches	Newton metres	Thread Size	Pound-Inches	Newton metres
O-ring Face Seal End					O-ring Boss End Fitting or Lock Nut		
-4	1/4 inch 6.4 mm	9/16-18	120 to 144	14 to 16	7/16-20	204 to 240	23 to 27
-6	3/8 inch 9.5 mm	11/16-16	216 to 240	24 to 27	9/16-18	300 to 360	34 to 41
-8	1/2 inch 12.7 mm	13/16-16	384 to 480	43 to 54	3/4-16	540 to 600	61 to 68
					Thread Size	Pound-Foot	Newton metres
-10	5/8 inch 15.9 mm	1-14	552 to 672	62 to 76	7/8-14	35 to 40	47 to 54
Nom. SAE Dash Size	Tube OD	Thread Size	Pound-Foot	Newton metres	1-1/16-12	60 to 70	81 to 95
					1-3/16-12	70 to 80	95 to 109
-12	3/4 inch 19.0 mm	1-3/16-12	65 to 70	90 to 95	1-5/16-12	80 to 90	108 to 122
-14	7/8 inch 22.2 mm	1-3/16-12	65 to 70	90 to 95	1-5/8-12	95 to 115	129 to 156
-16	1.0 inch 25.4 mm	1-7/16-12	92 to 100	125 to 135	1-7/8-12	120 to 140	163 to 190
-20	1-1/4 inch 31.8 mm	1-11/16-12	125 to 140	170 to 190			
-24	1-1/2 inch 38.1 mm	2-12	150 to 165	200 to 225			

Section 1010

FLUIDS AND LUBRICANTS

TABLE OF CONTENTS

ENGINE	1010-3
COOLING SYSTEM	1010-3
FUEL SYSTEM	1010-3
TRANSMISSION	1010-3
FINAL DRIVE	1010-3
HYDRAULIC SYSTEM	1010-3
CHASSIS GEAR BOX - RIGHT AND LEFT	1010-3
DRUM TOP GEAR BOX	1010-4
AIR CONDITIONING REFRIGERANT CAPACITY	1010-4
PICKER BAR AUTOMATIC LUBRICATION SYSTEM	1010-4
MODULE CHAMBER UNLOADER CONVEYOR CHAIN	1010-4
UNLOADER CONVEYOR DRIVE CHAIN	1010-4
GREASE FITTINGS	1010-4
WATER TANK	1010-4
CHASSIS AUTOMATIC LUBRICATION	1010-4

ENGINE

Oil Type..... CASE No. 1 Engine Oil
 Oil Capacity - Without Filter Change 20 U.S. Quarts (19 Litres)
 Oil Capacity - With Filter Change 22 U.S. Quarts (21 Litres)

NOTE: *DO NOT put Performance Additives or other oil additive products in the engine crankcase.*

COOLING SYSTEM

Coolant Type 50 Percent Mixture of Water and Ethylene Glycol Solution
 Coolant Capacity 68.2 U.S. Quarts (65 Litres)

IMPORTANT: *Use only heavy duty low silicate coolant. Automotive antifreeze purchased at local supply store outlets most likely is not low silicate and must not be used in Case engines.*

FUEL SYSTEM

Fuel Type ASTM D975 Grade 2-D Number 2 Diesel Fuel
 Fuel Capacity 200 U.S. Gallons (756 Litres)

TRANSMISSION

Oil Type..... CASE HY-TRAN® ULTRA
 Oil Capacity 15 U.S. Quarts (14 Litres)

NOTE: *If brakes are removed from the transmission for service, an additional 1 U.S. Quart (0.95 Liter) per brake assembly must be added to the transmission.*

FINAL DRIVE

Oil Type..... CASE HY-TRAN® ULTRA
 Oil Capacity 13 U.S. Quarts (12.3 Litres)

HYDRAULIC SYSTEM

Oil Type..... CASE HY-TRAN® ULTRA
 Reservoir Capacity 20 U.S. Gallons (76 Litres)
 System Capacity 32 U.S. Gallons (121 Litres)

CHASSIS GEAR BOX - RIGHT AND LEFT

Oil Type..... CASE 135H EP 85W 140 Gear Lubricant
 Oil Capacity (Each Gear Box) 1 1/2 U.S. Quarts (1.4 Litres)

DRUM TOP GEAR BOX

No Snout

Oil Type..... CASE 135H EP 85W 140 Gear Lubricant
Oil Capacity (Each Gear Box)..... 1.06 U.S. Quart (1.0 Litres)

Short Snout

Oil Type..... CASE 135H EP 85W 140 Gear Lubricant
Oil Capacity (Each Gear Box)..... 1.25 U.S. Quart (1.2 Litres)

Long Snout

Oil Type..... CASE 135H EP 85W 140 Gear Lubricant
Oil Capacity (Each Gear Box)..... 1.5 U.S. Quart (1.4 Litres)

AIR CONDITIONING REFRIGERANT CAPACITY

Air Conditioning System Refrigerant Capacity4.87 lbs (2.21 kg)
Refrigerant Type..... HFC-134A

PICKER BAR AUTOMATIC LUBRICATION SYSTEM

Oil Type..... Picker Bar and Spindle Lubricant - PN 407515R1
Reservoir Capacity80 U.S. Gallons (303 Litres)

IMPORTANT: *DO NOT substitute any other lubricant for this application. Improper lubrication will cause damage to the parts.*

MODULE CHAMBER UNLOADER CONVEYOR CHAIN

Oil Type..... CASE No. 1 Engine Oil

UNLOADER CONVEYOR DRIVE CHAIN

Oil Type..... CASE No. 1 Engine Oil

GREASE FITTINGS

Lubricant Type..... CASE Lithium Grease HEP251 or equivalent

WATER TANK

Reservoir Capacity 365 U.S. Gallons (1380 litres)
Clean water with Spindle Cleaner additives or wetting agent

CHASSIS AUTOMATIC LUBRICATION

Reservoir Capacity2.1 U.S. Gallons (8 litres)
Lubricant Type..... CASE Lithium Grease HEP251 or equivalent

Section 2015

ENGINE REMOVAL AND INSTALLATION

TABLE OF CONTENTS

GENERAL INFORMATION	2015-3
RECOMMENDED TOOLS	2015-3
ENGINE REMOVAL	2015-4
Raising the Module with a Non-Operating Engine	2015-4
Raising the Module with an Operating Engine	2015-5
REFERENCE ILLUSTRATIONS	2015-21
ENGINE INSTALLATION	2015-24
Alternate Method	2015-26

GENERAL INFORMATION

The machine should be on a firm, level surface while doing these procedures. The Left and Right side are the same as your Left and Right hand while sitting in the operator's seat facing the normal field operation direction of travel. All service or repairs should be performed by a qualified technician. Repair procedure instructions should be read and understood before starting the procedure.

All damaged or worn parts should be replaced. Make sure all parts are clean and free of debris before assembly.

Proper tools should be used when during disassemble and assemble procedures.


RECOMMENDED TOOLS

IMPORTANT: *Lift equipment, boom, equalizer, chains and slings used to remove and install the engine must be rated to handle the engine weight - 770 kg (1700 pounds), or personal injury or equipment damage may occur.*

An equalizer with an adjustable tilt feature can speed engine removal and installation on the machine.


A boom arm mounted to a lift truck or a mobile lifting crane is recommended for engine removal and installation.

Engine Barring Tool - CAS1690




OEM-4130 OR EQUIVALENT

RD01E144



LIFT TRUCK BOOM

RD01E137R




CAS1690

RH01F038

ENGINE REMOVAL

ATTENTION: ALWAYS place the hydraulic lockout switch in the LOCK position and block the tilted module chamber before working under the tilted module. NEVER work under a tilted module without placing the lockout switch in the LOCK position and blocking the module chamber. Failure to comply will result in death or serious injury.




RH99D028 / RD01F167

Raising the Module with a Non-Operating Engine

1. If the module can be raised with the engine, go to Step 3.

If the module cannot be raised with the engine, do the following:

- A. Locate the hydraulic lockout valve (1) on the tilt cylinder and plumb an alternate hydraulic source into the existing fitting (2).
- B. Plug the hose that was connected at the fitting (2) to prevent hydraulic fluid loss and to prevent contamination of the hydraulic system.



RR07D001

1. LOCKOUT VALVE
2. VALVE FITTING


2. Use a Tractor remote valve or other source to raise the module chamber. Engage the hydraulic lockout switch and block module chamber.

NOTE: Leave the hose used to raise the module chamber connected to the valve by disconnecting it from the hydraulic power source. After reinstalling the engine, use the auxiliary hydraulic power source to recapture the excess oil that was introduced into the Cotton Picker's tilt cylinder.

NOTE: If hydraulic fluids with different performance characteristics were mixed to raise the module, both reservoirs - Cotton Picker and hydraulic source - may have to be drained and refilled with new hydraulic fluid.


Raising the Module with an Operating Engine

3. Disconnect the batteries by rotating the lever to the VERTICAL position.




RD01C019

4. Remove the side panels (1) on both sides of the machine.




RD01E182

5. Turn off the fuel at the shutoff valve.



RD01C037


6. Drain engine coolant into an appropriate container.



RD01C032

NOTE: Refer to Reference Illustrations in this section for component locations.


7. Open the engine compartment door. Remove the four nuts at the hinges (1) from the underside of the door, and remove the door.
8. Open the fan compartment door. Remove the four nuts from the underside of the door at the hinges, and remove the door.



RD01E186

1. HINGE


9. Remove the door support channel (1) by removing the two nuts and bolts on both ends of the channel. Remove the channel brace(s) at the same time.
10. Remove the engine door support (2) by removing the nut and bolt at both ends.
11. Retain all hardware removed during this procedure for reinstallation.



RD01E073

1. DOOR CHANNEL
2. ENGINE DOOR SUPPORT


12. Remove the Right mounting bolt and nut for the muffler.



RD01E074

13. Loosen the clamp and remove the aspirator hose from the muffler. Cut any tie straps securing the hose in the engine compartment, and move the hose out of the way.


14. Loosen the turbocharger clamp and remove the muffler from the compartment.



RD01E076

1. ASPIRATOR HOSE
2. TURBOCHARGER CLAMP


15. Remove the charge air line to the manifold by removing the four bolts and nuts and the gasket.



RD01E078


2015-8

16. Seal the manifold and charge air line with duct tape.




RD01E079

17. Loosen the clamp and remove the turbo air line to the turbocharger. Retain the O-ring.




RD01E080

18. Seal with duct tape.




RD01E081

19. At the opposite end of the charge air and turbocharger air tubes, loosen the clamps and remove the tubes from the Left engine sheet. Use a clean shop cloth or tape to seal the tubes and openings.




RD01F161

20. Loosen the clamp and remove the air cleaner line to the turbocharger. Loosen the clamp on the other end beyond the Left engine sheet, and remove line from the compartment.



RD01E082

21. Use a clean shop cloth and clamp to seal off the cleaner line. Seal the turbocharger inlet with tape.




RD01E083

22. Loosen the clamp and remove the upper radiator tube.

NOTE: *Be prepared to collect some coolant when the tube is removed.*


23. Loosen the clamp and remove the engine head vent line.



RD01E085

- 1. UPPER RADIATOR TUBE
- 2. ENGINE HEAD VENT LINE

24. At the air conditioning compressor, disconnect the harness to the compressor clutch and the high pressure switch.




RD01E086

- 1. CLUTCH HARNESS
- 2. HIGH PRESSURE SWITCH HARNESS

25. Remove the two mounting bolts and nuts for the compressor and the bolt from the adjusting strap, and remove the compressor with hoses.

NOTE: Hang the compressor clutch belt from the drive pulley for now.


26. Move the compressor with hoses outside the engine compartment and support the assembly.



RD01E087

- 1. ADJUSTING STRAP BOLT

27. Remove the two bolts and gasket to remove the auxiliary pump with hoses from the engine.



RR07D002

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com