


Workshop Service Manual



MASSEY FERGUSON

MF 6700 S series tractors



**Beauvais
AGCO S.A.S. - 41 avenue Blaise Pascal - 60000
Beauvais - France - RC B562 104 539
© AGCO 2016**

**May 2016
ACT0025630
English**

MF 6700 S series tractors

1 Introduction	1-1
1.1 General	1-3
1.1.1 Using the manual	1-3
1.1.2 General specifications	1-3
1.1.2.1 MF 6700 S Dyna-4 tractors	1-3
1.1.2.2 MF 6700 S Dyna-6 tractors	1-12
1.1.2.3 MF 6700 S Dyna-VT tractors	1-21
1.1.3 Forward speeds	1-30
1.1.3.1 Forward speed with Dyna-4 40 kph transmission and 18.4R38 tires	1-30
1.1.3.2 Forward speed with Dyna-4 40 kph transmission and 20.8R38 tires	1-31
1.1.3.3 Forward speed with Dyna-6 40 kph ECO transmission and 20.8R38 tires	1-32
1.1.3.4 Forward speed with Dyna-6 50 kph transmission and 20.8R38 tires	1-34
1.1.3.5 Forward speed for all models with transmission in Dyna-VT mode	1-36
1.1.4 Dimensions and weights	1-37
1.1.5 Attachment points	1-41
1.1.5.1 Attachment points: MF 6712 S / MF 6713 S / MF 6714 S Dyna-4/Dyna-6 models without front linkage	1-41
1.1.5.2 Attachment points: MF 6712 S / MF 6713 S / MF 6714 S Dyna-4/Dyna-6 models with front linkage	1-43
1.1.5.3 Attachment points: MF 6715 S / MF 6716 S / MF 6718 S Dyna-4/Dyna-6 models without front linkage	1-45
1.1.5.4 Attachment points: MF 6715 S / MF 6716 S / MF 6718 S Dyna-4/Dyna-6 models with front linkage	1-47
1.1.5.5 Attachment points: MF 6713 S / MF 6714 S / MF 6715 S / MF 6716 S / MF 6718 S Dyna-VT models without front linkage:	1-49
1.1.5.6 Attachment points: MF 6713 S / MF 6714 S / MF 6715 S / MF 6716 S / MF 6718 S Dyna-VT models with front linkage	1-51
1.1.6 Capacities	1-52
1.1.7 Conversion table	1-54
1.1.8 Retaining compounds and sealing products	1-55
1.1.9 Tightening torques	1-57
1.1.9.1 Tightening torques for screws and nuts	1-57
1.1.9.2 Tightening torques for hydraulic unions	1-61
1.2 Adjustments, bleeding and calibrations	1-65
1.2.1 Bleed operations: Dyna-VT - Assisted brake master cylinders	1-65
1.2.1.1 Charge connector	1-65
1.2.1.2 Pressure connector	1-65
1.2.1.3 Bleed screw locations	1-65
1.2.1.4 Procedure for bleeding the assisted braking system	1-66
1.2.2 Bleed operations: Dyna-4/Dyna-6 - Assisted brake master cylinders	1-68
1.2.2.1 Charge connector	1-68
1.2.2.2 Pressure connector - Load Sensing system	1-68
1.2.2.3 Pressure connector - Open Center system	1-68
1.2.2.4 Bleed screw locations	1-69
1.2.2.5 Procedure for bleeding the assisted braking system	1-70
1.2.3 Bleed operations: Dyna-4/Dyna-6 - High-pressure braking	1-72
1.2.3.1 Bleed screw locations	1-72
1.2.3.2 Procedure for bleeding the high-pressure braking system	1-73
1.2.4 Calibrations	1-74
1.2.4.1 Calibrating the automatic disengagement of the differential and 4-wheel drive	1-74
1.2.4.2 Calibration of the forward-travel lever	1-76

1.2.4.3	Forward speed calibration	1-79
1.2.4.4	Calibration of the Dyna-4 and Dyna-6 PowerShuttle transmission	1-79
1.2.4.5	Calibrating the power sensor on the Dyna-6 transmission	1-82
1.2.4.6	Dyna-VT transmission calibrations: Introduction and access to calibration using the instrument panel	1-83
1.2.4.7	Calibration of the high/low speed ranges (Hare/Tortoise) for Dyna-VT	1-84
1.2.4.8	Dyna-VT transmission calibration	1-85
1.2.4.9	Calibration of the Dyna-VT coupler function	1-86
1.2.4.10	Rear power take-off calibration for Dyna-VT	1-87
1.2.4.11	Front power take-off calibration for Dyna-VT	1-88
1.2.4.12	Dyna-VT transmission calibration error code	1-89
1.2.4.13	Calibration of the clutch pedal sensor	1-92
1.2.4.14	Calibration of the throttle pedal sensor	1-93
1.2.4.15	Calibrating the rear linkage	1-93
1.2.4.16	Calibration of the front linkage position sensor	1-95
1.2.4.17	Calibrate the suspended front axle.	1-96
1.2.4.18	Calibrations to be carried out using the diagnostic tool	1-98
2	Separation of assemblies	2-1
2.1	Front linkage	2-3
2.1.1	Removal/refitting	2-3
2.2	Front axle	2-6
2.2.1	Removal/refitting	2-6
2.3	Cooling unit	2-8
2.3.1	Removal/refitting	2-8
2.4	Front frame	2-10
2.4.1	Removal/refitting	2-10
2.5	Engine cover	2-14
2.5.1	Removal/refitting	2-14
2.6	Engine	2-16
2.6.1	Removing and refitting the engine	2-16
2.6.2	Reassembling the engine flywheel	2-20
2.7	Operator environment	2-22
2.7.1	Removal/refitting	2-22
3	Engine	3-1
3.1	Tier 4F/Stage IV SCR Technology engine 4 cylinders	3-3
3.1.1	General	3-3
3.1.1.1	Notice to the technician	3-3
3.1.1.2	Safety instructions	3-3
3.1.1.3	Description of engine types	3-4
3.1.1.4	Location of the engine serial number	3-4
3.1.1.5	Lifting the engine	3-5
3.1.2	Principles of operation	3-6
3.1.2.1	General operating diagram	3-6
3.1.2.2	Mechanical part	3-7
3.1.2.3	Exhaust and intake system	3-9
3.1.2.4	Cooling system	3-11
3.1.2.5	Lubrication system	3-12
3.1.2.6	Fuel system	3-13
3.1.2.7	Electric control circuit	3-14
3.1.2.8	CCV system	3-15
3.1.3	Layout of components	3-16
3.1.3.1	Layout of components in the VRT engine compartment	3-16
3.1.4	Tests and diagnostics	3-17
3.1.4.1	Measuring the engine oil pressure	3-17

3.1.5	Adjustments, bleeding and calibrations	3-18
3.1.5.1	Adjustments	3-18
3.1.5.2	Bleeding	3-19
3.1.6	Disassembly/reassembly	3-20
3.1.6.1	AGCO Power Workshop Service Manual	3-20
3.1.7	Service tools	3-20
3.1.7.1	General	3-20
3.1.7.2	Cylinder block tools	3-20
3.1.7.3	Timing gear and flywheel housing tools	3-21
3.1.7.4	Cylinder head and valve mechanism tools	3-22
3.1.7.5	Crank mechanism tools	3-23
3.1.7.6	Coolant pump tools	3-24
3.1.7.7	Engine control system tools	3-25
3.1.7.8	Maintenance and troubleshooting tools	3-25
3.2	SCR Technology	3-27
3.2.1	General	3-27
3.2.1.1	Notice to the technician	3-27
3.2.1.2	Safety instructions for DEF or AdBlue™ . Identification of hazards	3-28
3.2.1.3	Abbreviations or terms used	3-31
3.2.2	Principles of operation	3-31
3.2.2.1	Principles of operation	3-31
3.2.2.2	Architecture of the VRT 4-cylinder SCR Technology system	3-35
3.2.3	Schematic diagrams	3-36
3.2.3.1	VRT 4-cylinder SCR Technology system schematic diagram	3-36
3.2.4	Layout of components	3-38
3.2.4.1	SCR Technology components for VRT engine	3-38
3.2.5	Disassembly/reassembly	3-40
3.2.5.1	Removing the metering module	3-40
3.2.5.2	Injector	3-42
3.2.5.3	Coolant solenoid valve	3-44
3.2.5.4	DEF or AdBlue™ tank	3-45
3.2.5.5	Removing the DEF or AdBlue™ gage	3-47
3.2.5.6	Catalytic converter or DOC (catalyseur d'oxydation diesel)	3-48
3.2.6	Service tools	3-49
3.2.6.1	General	3-49
3.2.6.2	3rd generation SCR engine - Service tools	3-49
4	Clutch	4-1
4.1	Chapter not used for this model	4-3
5	Gearbox	5-1
5.1	ML140	5-5
5.1.1	General	5-5
5.1.1.1	General	5-5
5.1.1.2	Transmission operating principle	5-5
5.1.1.3	Transmission operating principle diagram	5-9
5.1.1.4	Forward/reverse high-pressure relief valves	5-15
5.1.1.5	Control spool valve	5-17
5.1.1.6	Flushing valve	5-20
5.1.2	Layout of components	5-23
5.1.2.1	Gearbox main components - parts list	5-23
5.1.2.2	Gearbox main components - diagram	5-24
5.1.3	Tests and diagnostics	5-25
5.1.3.1	Hydraulic tests	5-25
5.1.4	Disassembly/reassembly	5-35
5.1.4.1	Disassembling the Dyna-VT module	5-35
5.1.4.2	Reassembling the Dyna-VT unit	5-43

5.1.4.3	Filling the gearbox	5-54
5.1.4.4	Removing/refitting forward (2V3)/reverse (2V4) high-pressure relief valves	5-55
5.1.4.5	Removing/refitting the flushing valve	5-56
5.1.5	Service tools	5-56
5.1.5.1	General	5-56
5.1.5.2	ML130/ML140/ML160/ML180 - Service tools	5-57
5.2	GBA25/General	5-67
5.2.1	General	5-67
5.2.2	Principles of operation	5-70
5.2.2.1	Construction and description	5-70
5.2.2.2	Kinematics of the Dyna-4 GBA25 gearbox	5-75
5.2.2.3	Kinematics of the Dyna-6 GBA25 gearbox	5-78
5.2.2.4	Synchronisers	5-81
5.2.2.5	Main gearbox robotic control	5-83
5.2.3	Layout of components	5-85
5.2.3.1	View of Dyna-4 GBA25 gearbox assembly	5-85
5.2.3.2	View of Dyna-4 GBA25 gearbox assembly	5-87
5.2.3.3	View of Dyna-6 GBA25 gearbox assembly	5-89
5.2.3.4	View of Dyna-6 GBA25 gearbox assembly	5-91
5.2.3.5	Dyna-4 GBA25 gearbox specifications	5-93
5.2.3.6	Dyna-6 GBA25 gearbox specifications	5-94
5.2.3.7	GBA25 gearbox specifications	5-95
5.2.4	Disassembly/reassembly	5-97
5.2.4.1	Dyna-4 GBA25 gearbox disassembly	5-97
5.2.4.2	Dyna-6 GBA25 gearbox disassembly	5-102
5.2.4.3	Synchronizers	5-106
5.3	GBA25/PowerShuttle	5-109
5.3.1	General	5-109
5.3.2	Principles of operation	5-109
5.3.3	Layout of components	5-113
5.3.3.1	View of the GBA25 PowerShuttle assembly	5-113
5.3.3.2	Blown-up view of the GBA25 PowerShuttle	5-115
5.3.4	Disassembly/reassembly	5-117
5.3.4.1	Dyna-4 transmission	5-117
5.3.4.2	Dyna-6 transmission	5-122
5.3.4.3	Disassembling the PowerShuttle	5-127
5.3.4.4	Reassembling the PowerShuttle	5-129
5.3.4.5	Final steps	5-131
5.3.5	Service tools	5-131
5.3.5.1	General	5-131
5.3.5.2	PowerShuttle - Service tools	5-131
5.4	GBA25/Dyna-4 PowerShift module	5-132
5.4.1	Dyna-4 General information	5-132
5.4.2	Dyna-4 Operating principle	5-132
5.4.2.1	Kinematics	5-134
5.4.3	Layout of components	5-141
5.4.3.1	View of Dyna-4 assembly	5-141
5.4.3.2	Dyna-4 blown-up view	5-143
5.4.4	Removing/refitting Dyna-4	5-145
5.4.4.1	Preliminary steps	5-145
5.4.4.2	Removing the Dynashift module	5-145
5.4.4.3	Refitting the Dynashift module	5-147
5.4.4.4	Disassembling the Dynashift module	5-148
5.4.4.5	Reassembling the Dynashift module	5-153
5.4.4.6	Disassembling the planet gears	5-157
5.4.4.7	Reassembling the planet gears	5-158

5.4.4.8	Final steps	5-159
5.4.5	Service tools	5-160
5.4.5.1	General	5-160
5.4.5.2	Powershift module - Service tools	5-160
5.5	GBA25/Dyna-6 PowerShift module	5-161
5.5.1	Dyna-6 - General information	5-161
5.5.2	Dyna-6 Operating principle	5-161
5.5.2.1	Kinematics	5-163
5.5.3	Layout of components	5-171
5.5.3.1	View of Dyna-6 assembly	5-171
5.5.3.2	Dyna-6 blown-up view	5-173
5.5.4	Removing/refitting Dyna-6	5-175
5.5.4.1	Preliminary steps	5-175
5.5.4.2	Removing the Powershift module	5-175
5.5.4.3	Refitting the Powershift module	5-177
5.5.4.4	Disassembling the Dynashift module	5-178
5.5.4.5	Reassembling the Dynashift module	5-182
5.5.4.6	Disassembling the multiplier module	5-185
5.5.4.7	Reassembling the multiplier module	5-186
5.5.4.8	Disassembling the planet gears	5-189
5.5.4.9	Reassembling the planet gears	5-189
5.5.4.10	Final steps	5-190
5.5.5	Service tools	5-191
5.5.5.1	General	5-191
5.5.5.2	Powershift module - Service tools	5-191
5.6	GBA25/Robotic mechanical gearbox	5-193
5.6.1	General	5-193
5.6.2	Principles of operation	5-193
5.6.2.1	Description and kinematics of ratios	5-195
5.6.3	Layout of components	5-199
5.6.3.1	View of the primary and secondary shaft assembly	5-199
5.6.3.2	View of the reverse layshaft and synchroniser control assembly	5-202
5.6.3.3	Blown-up view of the robotic mechanical gearbox	5-204
5.6.4	Disassembly/reassembly	5-207
5.6.4.1	Preliminary steps	5-207
5.6.4.2	Removing the primary and secondary shafts	5-207
5.6.4.3	Refitting the primary and secondary shafts	5-210
5.6.4.4	Disassembling the primary and secondary shafts	5-212
5.6.4.5	Reassembling the primary and secondary shafts	5-215
5.6.4.6	Shimming the primary and secondary shafts in the housing	5-219
5.6.4.7	Adjusting the selector rails and forks	5-221
5.6.4.8	Adjusting the interlock mechanism	5-225
5.6.4.9	Final steps	5-226
5.6.5	Service tools	5-227
5.6.5.1	General	5-227
5.6.5.2	Robotic mechanical gearbox - Service tools	5-227
5.7	GBA25/Super creeper gears	5-228
5.7.1	General	5-228
5.7.2	Principles of operation	5-229
5.7.3	Layout of components	5-232
5.7.3.1	View of the assembly	5-232
5.7.3.2	Blown-up view	5-233
5.7.4	Disassembly/reassembly	5-234
5.7.4.1	Removing/refitting and disassembling/reassembling the epicyclic gear trains	5-234
5.7.4.2	Disassembling the input planet carrier	5-235
5.7.4.3	Reassembling the input planet carrier	5-236

5.7.4.4	Disassembling the output planet carrier	5-237
5.7.4.5	Reassembling the output planet carrier	5-238
5.7.4.6	Final steps	5-240
5.7.4.7	Adjusting the control	5-240
6	Rear Axle	6-1
6.1	HA140	6-7
6.1.1	General	6-7
6.1.1.1	General	6-7
6.1.1.2	Principles of operation	6-7
6.1.1.3	Schematic diagram	6-8
6.1.2	Layout of components	6-9
6.1.2.1	Rear axle main components	6-9
6.1.3	Disassembly/reassembly	6-10
6.1.3.1	Cross section view of the rear axle	6-10
6.2	HA140/Final drives	6-11
6.2.1	General	6-11
6.2.2	Layout of components	6-13
6.2.2.1	Cross-section view of a final drive unit	6-13
6.2.3	Disassembly/reassembly	6-15
6.2.3.1	Removing a final drive unit	6-15
6.2.3.2	Refitting a final drive unit	6-15
6.2.4	Service tools	6-15
6.2.4.1	General	6-15
6.2.4.2	Final drives - Service tools	6-16
6.3	HA140/Differential	6-18
6.3.1	General	6-18
6.3.1.1	General	6-18
6.3.1.2	Principles of operation	6-18
6.3.1.3	Schematic diagram	6-20
6.3.2	Layout of components	6-21
6.3.2.1	Cross section view of the differential.	6-21
6.3.2.2	Blown-up view of the pinion	6-22
6.3.2.3	Blown-up view of the differential	6-23
6.3.3	Disassembly/reassembly	6-24
6.3.3.1	Removing the differential	6-24
6.3.3.2	Refitting the differential	6-27
6.3.3.3	Disassembling the pinion	6-35
6.3.3.4	Reassembling the pinion	6-41
6.3.3.5	Disassembling the differential	6-49
6.3.3.6	Reassembling the differential	6-55
6.3.4	Service tools	6-62
6.3.4.1	General	6-62
6.3.4.2	Differential - Service tools	6-63
6.4	HA140/Tractor braking	6-66
6.4.1	General	6-66
6.4.1.1	General	6-66
6.4.1.2	Principles of operation	6-67
6.4.1.3	Hydraulic assistance	6-69
6.4.2	Layout of components	6-70
6.4.2.1	Blown-up view of the rear axle brake system	6-70
6.4.2.2	Layout of components	6-71
6.4.3	Adjustments, bleeding and calibrations	6-73
6.4.3.1	Adjustments	6-73
6.4.3.2	Bleeding	6-75
6.4.4	Disassembly/reassembly	6-79
6.4.4.1	Removing the rear axle brakes	6-79

6.4.4.2	Assembling the rear axle brakes	6-83
6.4.4.3	Removing/refitting the assisted-brake master cylinders	6-88
6.4.5	Service tools	6-91
6.4.5.1	General	6-91
6.4.5.2	Tractor braking - Service tools	6-91
6.5	HA140/Hydraulic trailer braking	6-93
6.5.1	General	6-93
6.5.1.1	Trailer brake unit	6-93
6.5.2	Hydraulic test	6-94
6.6	GPA20 - General	6-96
6.6.1	General	6-96
6.6.2	Principles of operation	6-96
6.6.3	Layout of components	6-97
6.6.3.1	Center housing assembly (longitudinal cross-section)	6-97
6.6.3.2	Center housing assembly (transverse cross-section)	6-98
6.7	GPA20/Heavy Duty and Heavy Duty + final drives	6-99
6.7.1	General	6-99
6.7.1.1	General	6-99
6.7.1.2	Principles of operation	6-99
6.7.2	Layout of components	6-101
6.7.2.1	View of the assembly	6-101
6.7.2.2	Blown-up view	6-103
6.7.3	Disassembly/reassembly	6-105
6.7.3.1	Removing/refitting a final drive	6-105
6.7.3.2	Removing/refitting and disassembling/reassembling a planet carrier	6-106
6.7.3.3	Replacing tapered roller bearings and seals	6-109
6.7.3.4	Shimming the tapered roller bearings of the axle shaft	6-112
6.7.3.5	Replacing a wheel stud	6-116
6.7.4	Service tools	6-116
6.7.4.1	General	6-116
6.7.4.2	GPA20/Final drives - Service tools	6-117
6.8	GPA20/Super Heavy Duty final drives	6-118
6.8.1	General	6-118
6.8.1.1	General	6-118
6.8.1.2	Principles of operation	6-118
6.8.2	Layout of components	6-119
6.8.2.1	View of the assembly	6-119
6.8.2.2	Blown-up view	6-121
6.8.3	Disassembly/reassembly	6-123
6.8.3.1	Removing/refitting a final drive	6-123
6.8.3.2	Disassembling/reassembling the planet carrier	6-124
6.8.3.3	Fitting and shimming the tapered roller bearings of the axle shaft	6-126
6.8.3.4	Replacing a wheel stud	6-128
6.8.4	Service tools	6-129
6.8.4.1	General	6-129
6.8.4.2	GPA20/Final drives - Service tools	6-129
6.9	GPA20/Differential	6-130
6.9.1	General	6-130
6.9.2	Layout of components	6-131
6.9.2.1	View of the assembly	6-131
6.9.2.2	Blown-up view	6-133
6.9.3	Disassembly/reassembly	6-135
6.9.3.1	Removing the left-hand flange and differential lock assembly	6-135
6.9.3.2	Disassembling and reassembling the differential lock assembly	6-136
6.9.3.3	Refitting the left-hand flange and the differential lock assembly	6-137
6.9.3.4	Removing the differential assembly	6-138
6.9.3.5	Disassembling the differential assembly and the crown wheel	6-139

6.9.3.6	Removing and disassembling the gear	6-140
6.9.3.7	Reassembling the crown wheel and the differential assembly	6-142
6.9.3.8	Adjusting the taper distance, refitting and shimming the gear	6-143
6.9.3.9	Refitting and shimming the differential assembly	6-147
6.9.3.10	Adjusting and checking the backlash	6-152
6.9.3.11	Final reassembly	6-156
6.9.4	Service tools	6-157
6.9.4.1	General	6-157
6.9.4.2	GPA20/Differential - Service tools	6-157
6.10	GPA20/Brake pistons	6-158
6.10.1	General	6-158
6.10.2	Principles of operation	6-158
6.10.3	Layout of components	6-159
6.10.3.1	View of the assembly	6-159
6.10.3.2	Blown-up view	6-160
6.10.4	Disassembly/reassembly	6-160
6.10.4.1	Disassembly	6-160
6.10.4.2	Reassembly	6-162
6.11	GPA20/Hand brake unit and control	6-165
6.11.1	General	6-165
6.11.2	Principles of operation	6-165
6.11.3	Layout of components	6-167
6.11.3.1	View of the assembly	6-167
6.11.3.2	Blown-up view - Three disks	6-169
6.11.4	Disassembly/reassembly	6-171
6.11.4.1	Disassembly	6-171
6.11.4.2	Reassembly	6-173
6.11.4.3	Fitting the control	6-178
6.11.4.4	Adjusting the control	6-178
6.12	GPA20/Tractor braking	6-180
6.12.1	Assisted brake master cylinders:	6-180
6.12.1.1	General	6-180
6.12.1.2	Principles of operation	6-181
6.12.1.3	Layout of components	6-182
6.12.1.4	Removing/refitting the assisted-brake master cylinders	6-183
6.12.2	High-pressure braking	6-186
6.12.2.1	General	6-186
6.12.2.2	Principles of operation	6-187
6.12.2.3	Layout of components and designation of hydraulic ports in the high-pressure braking unit	6-189
6.12.2.4	Decompressing the high-pressure braking system	6-190
6.12.2.5	Removing and refitting the high-pressure braking unit	6-190
6.12.3	Load Sensing trailer braking	6-192
6.12.3.1	General	6-192
6.12.3.2	Principles of operation	6-193
6.12.3.3	Schematic diagram	6-195
6.12.3.4	Identification of 110 l/min Load Sensing ports	6-197
6.12.3.5	Removing and refitting the trailer braking unit	6-200
6.12.3.6	Plug tightening torques in the event of maintenance on the spools (2) (6)	6-203
6.12.4	Open Center trailer braking	6-203
6.12.4.1	General	6-203
6.12.4.2	Principles of operation	6-204
6.12.4.3	Identification of pipes, hoses and ports	6-207
6.12.4.4	Identification of channels	6-208
6.12.4.5	Removing and refitting the brake spool valve	6-209
6.12.5	Adjustments, bleeding and calibrations	6-210

6.12.5.1	Assisted brake master cylinders:	6-210
6.12.5.2	High-pressure braking	6-214
6.12.5.3	Pedals	6-216
6.12.6	Service tools	6-217
6.12.6.1	General	6-217
6.12.6.2	Tractor braking - Service tools	6-217
6.13	GPA20/Hitch/Linkage	6-218
6.13.1	Linkage - General	6-218
6.13.2	Hitch - General	6-218
6.13.3	Layout of components	6-219
6.13.3.1	View of the assembly	6-219
6.13.3.2	Blown-up view	6-221
6.13.4	Adjustments, bleeding and calibrations	6-223
6.13.4.1	Adjusting the angular position sensor	6-223
6.13.5	Disassembly/reassembly	6-224
6.13.5.1	Removing the linkage cover plate	6-224
6.13.5.2	Disassembling the linkage cover plate	6-227
6.13.5.3	Reassembling the linkage cover plate	6-228
6.13.5.4	Shimming the linkage shaft	6-230
6.13.5.5	Refitting the linkage cover plate	6-230
6.13.5.6	Disassembling and reassembling a lift ram	6-231
6.14	GPA20+/Hitch/Increased capacity linkage - General	6-233
6.14.1	Linkage - General	6-233
6.14.2	Hitch - General	6-234
6.14.3	Layout of components	6-235
6.14.3.1	View of the assembly	6-235
6.14.3.2	Blown-up view	6-237
6.14.4	Adjustments, bleeding and calibrations	6-239
6.14.4.1	Adjusting the angular position sensor	6-239
6.14.4.2	Adjusting the forward speed sensor	6-243
6.14.5	Disassembly/reassembly	6-244
6.14.5.1	Removing and refitting the increased capacity linkage cover plate	6-244
6.14.5.2	Removing and refitting the increased capacity linkage cover plate	6-248
6.14.5.3	Shimming the linkage shaft	6-256
6.14.5.4	Disassembling and reassembling a lift ram	6-258
6.14.6	Service tools	6-260
6.14.6.1	General	6-260
6.14.6.2	GPA20 +/Hitch/Increased capacity linkage - Service tools	6-260
6.15	Pneumatic trailer braking	6-261
6.15.1	General	6-261
6.15.1.1	GPA20/20+	6-261
6.15.1.2	GPA40 and HA140/180	6-265
6.15.2	Layout of components	6-271
6.15.3	Test and diagnostics	6-272
6.15.3.1	Pneumatic system test	6-272
6.15.3.2	Sealing test on the pneumatic system.	6-274
6.15.4	Adjustments, bleeding and calibrations	6-274
6.15.4.1	Adjusting the pressure relief valve	6-274
6.15.4.2	Adjusting the hand brake rod	6-276
6.15.5	Disassembly/reassembly	6-277
6.15.5.1	General	6-277
6.15.5.2	Compressor	6-277
6.15.6	Service tools	6-279
6.15.6.1	General	6-279
6.15.6.2	Pneumatic trailer brake — Service tools	6-279
6.16	Auto-hitch	6-282
6.16.1	General	6-282

6.16.2	Principles of operation	6-282
6.16.3	Layout of components	6-283
6.16.3.1	Blown-up view	6-283
6.16.4	Adjustments, bleeding and calibrations	6-284
6.16.4.1	Adjusting the tie rods and the control	6-284
6.16.5	Disassembly/reassembly	6-286
6.16.5.1	Refitting the frame	6-286
6.17	Rear wheels/hubs	6-288
6.17.1	General	6-288
6.17.2	Disassembly/reassembly	6-291
6.17.2.1	Flanged axle shaft	6-291
6.17.2.2	Straight axle shaft	6-294
6.17.2.3	Adjusting the rear wheel track width	6-296
6.17.2.4	Fitting the rear wheel weights	6-300
7	Power take-off	7-1
7.1	HA140	7-3
7.1.1	General	7-3
7.1.2	Principles of operation	7-4
7.1.3	Layout of components	7-7
7.1.3.1	Cross-section view	7-7
7.1.4	Disassembly/reassembly	7-9
7.1.4.1	Disassembling/reassembling the PTO clutch	7-9
7.1.4.2	Disassembling the PTO shafts	7-13
7.1.4.3	Reassembling the PTO shafts	7-17
7.2	GPA20	7-22
7.2.1	General	7-22
7.2.2	Principles of operation	7-23
7.3	GPA20/Clutch	7-30
7.3.1	General	7-30
7.3.2	Principles of operation	7-30
7.3.3	Layout of components	7-32
7.3.3.1	Parts list	7-32
7.3.3.2	Blown-up view	7-34
7.3.4	Layout of components	7-35
7.3.4.1	View of the assembly	7-35
7.3.5	Disassembly/reassembly	7-37
7.3.5.1	Removing and refitting the PTO clutch	7-37
7.3.5.2	Disassembling/reassembling the clutch	7-38
7.3.6	Service tools	7-40
7.3.6.1	General	7-40
7.3.6.2	GPA20/Clutch - Service tools	7-41
7.4	GPA20/Intermediate shaft/Drive gear/PTO brake	7-42
7.4.1	General	7-42
7.4.2	Principles of operation	7-42
7.4.3	Layout of components	7-44
7.4.3.1	Power take-off (PTO) parts list	7-44
7.4.3.2	Exploded view (2-speed version)	7-45
7.4.3.3	Overview (2-speed version)	7-45
7.4.3.4	Exploded view (4-speed version)	7-46
7.4.3.5	Assembly view (4-speed version)	7-47
7.4.4	Disassembly/reassembly	7-47
7.4.4.1	Removing and refitting the upper shaftline (2-speed version)	7-47
7.4.4.2	Removing/refitting the driving gears (4-speed version)	7-49
7.4.4.3	Shimming the driving gear	7-52
7.4.4.4	Adjustment of the control (4-speed version)	7-53
7.5	GPA20/Output shaft without speed selection	7-55

7.5.1	General	7-55
7.5.2	Layout of components	7-55
7.5.2.1	View of the assembly	7-55
7.5.2.2	Blown-up view	7-56
7.5.3	Disassembly/reassembly	7-57
7.5.3.1	Removing/refitting the rear bearing	7-57
7.5.3.2	Disassembling and reassembling the gears	7-58
7.6	GPA20/Output shaft with speed selection	7-60
7.6.1	General	7-60
7.6.2	Layout of components	7-60
7.6.2.1	Power take-off (PTO) parts list	7-60
7.6.2.2	View of the assembly	7-62
7.6.2.3	Blown-up view	7-65
7.6.3	Disassembly/reassembly	7-66
7.6.3.1	Removing/refitting the rear bearing	7-66
7.6.3.2	Disassembling and reassembling the gears	7-67
7.6.3.3	Shimming the shaft with reinforced sealing	7-70
7.6.3.4	Adjusting the control	7-70
7.7	GPA20/PTO electrohydraulic controls	7-72
7.7.1	General	7-72
7.7.2	Principles of operation	7-72
7.7.3	Layout of components	7-74
7.7.3.1	View of the assembly	7-74
7.7.3.2	Blown-up view	7-75
7.7.4	Disassembly/reassembly	7-75
7.7.4.1	Removing/refitting the 540/1000 control	7-75
7.7.4.2	Removing/refitting the Standard/Economy control	7-77
7.8	GPA20/GSPTO	7-79
7.8.1	General	7-79
7.8.2	Principles of operation	7-79
7.8.3	Layout of components	7-80
7.8.3.1	View of the assembly	7-80
7.8.3.2	Blown-up view	7-81
7.8.4	Disassembly/reassembly	7-81
7.8.4.1	Disassembling and reassembling the PTO	7-81
7.8.4.2	Assembling and adjusting the control	7-84
7.9	Zuidberg front power take-off	7-87
7.9.1	General	7-87
7.9.1.1	General	7-87
7.9.1.2	Principles of operation	7-87
7.9.1.3	Schematic diagrams	7-90
7.9.2	Layout of components	7-91
7.9.2.1	Blown-up view of the PTO unit	7-91
7.9.2.2	Blown-up view of the hydraulic pump and the PTO clutch	7-92
7.9.2.3	Blown-up view of the drive shaft and the oil cooler	7-93
7.9.3	Tests and diagnostics	7-94
7.9.3.1	Hydraulic tests	7-94
7.9.3.2	Electrical tests	7-95
7.9.4	Adjustments, bleeding and calibrations	7-95
7.9.4.1	Draining and changing the filter	7-95
7.9.5	Disassembly/reassembly	7-96
7.9.5.1	Removing and refitting the front power take-off unit	7-96
7.9.5.2	Disassembling and reassembling the front power take-off unit	7-97
8	Front axle	8-1
8.1	DANA 735 front axle	8-3
8.1.1	General	8-3

8.1.1.1	DANA General	8-3
8.1.1.2	Principles of operation	8-3
8.1.1.3	DANA front axle 740/528-529-530-613-614-615 Dimensions - Specifications - Identification	8-4
8.1.1.4	Topping up and checking levels	8-7
8.1.2	Layout of components	8-8
8.1.2.1	Layout of front axle components	8-8
8.1.2.2	View of front axle assembly	8-10
8.1.3	Tests and diagnostics	8-12
8.1.3.1	Troubleshooting	8-12
8.1.4	Disassembly/reassembly	8-14
8.1.4.1	DANA 735 tightening torques	8-14
8.1.4.2	DANA Workshop Service Manuals	8-16
8.2	DANA 740 front axle	8-17
8.2.1	General	8-17
8.2.1.1	DANA General	8-17
8.2.1.2	Principles of operation	8-17
8.2.1.3	DANA front axle 740/553-554-614-615- Dimensions - Specifications - Identification	8-18
8.2.1.4	Topping up and checking levels	8-21
8.2.2	Layout of components	8-22
8.2.2.1	Layout of front axle components	8-22
8.2.2.2	View of front axle assembly	8-24
8.2.3	Tests and diagnostics	8-26
8.2.3.1	Troubleshooting	8-26
8.2.4	Disassembly/reassembly	8-28
8.2.4.1	DANA 740 tightening torques	8-28
8.2.4.2	DANA Workshop Service Manuals	8-30
8.3	HA140/4-wheel drive clutch	8-31
8.3.1	General	8-31
8.3.1.1	General - 4-wheel drive clutch	8-31
8.3.1.2	Four-wheel drive function operating principles	8-31
8.3.2	Layout of components	8-33
8.3.2.1	Cross-section view of the 4-wheel drive clutch	8-33
8.3.2.2	Blown-up view of the 4-wheel drive clutch	8-34
8.3.3	Disassembly/reassembly	8-35
8.3.3.1	Disassembling the 4WD clutch	8-35
8.3.3.2	Reassembling the 4WD clutch	8-39
8.4	HA140/Universal joint shaft brake	8-46
8.4.1	Layout of components	8-46
8.4.1.1	Cross-section view of the universal joint shaft brake	8-46
8.4.1.2	Exploded view of the universal joint shaft brake	8-47
8.4.2	Disassembly/reassembly	8-47
8.4.2.1	Disassembling the universal joint shaft brake	8-47
8.4.2.2	Reassembling the universal joint shaft brake	8-52
8.5	GPA20/4-wheel drive clutch	8-59
8.5.1	General	8-59
8.5.2	Principles of operation	8-59
8.5.3	Layout of components	8-60
8.5.3.1	View of the assembly	8-60
8.5.3.2	Blown-up view	8-62
8.5.4	Disassembly/reassembly	8-63
8.5.4.1	Removing the clutch assembly	8-63
8.5.4.2	Disassembling the clutch	8-65
8.5.4.3	Reassembling the clutch	8-66
8.5.4.4	Refitting the clutch assembly	8-67
8.5.5	Service tools	8-69

8.5.5.1	General	8-69
8.5.5.2	4-wheel drive clutch - Service tools	8-69
8.6	Steering unit/Closed Center	8-71
8.6.1	General	8-71
8.6.2	Hydraulic operating principle	8-72
8.6.2.1	Reaction/non-reaction steering unit	8-73
8.6.3	Electrohydraulic operating principle	8-75
8.6.4	Layout of steering unit components	8-77
8.6.5	Removing and refitting the steering unit	8-77
8.6.5.1	Refitting	8-78
8.7	Steering unit/Open Center	8-79
8.7.1	General	8-79
8.7.2	Principles of operation	8-80
8.7.2.1	Reaction/non-reaction steering unit	8-82
8.7.3	Schematic diagram	8-84
8.7.4	Layout of steering unit components	8-85
8.7.5	Removing and refitting the steering unit	8-85
8.7.5.1	Refitting	8-86
9	Hydraulics	9-1
9.1	HA140/Load Sensing	9-5
9.1.1	General	9-5
9.1.2	Principles of operation	9-5
9.1.3	Trailer brake unit	9-7
9.1.4	Layout of components	9-9
9.1.4.1	Steering and cooling system	9-9
9.1.4.2	High-pressure system	9-11
9.1.4.3	Distribution unit — Power Beyond	9-12
9.1.5	Hydraulic tests	9-14
9.1.5.1	General	9-14
9.1.5.2	Auxiliary hydraulic system	9-14
9.1.5.3	Steering system	9-19
9.1.6	Disassembly/reassembly	9-19
9.1.6.1	Variable displacement pump	9-19
9.1.6.2	Fixed displacement pumps	9-21
9.1.7	Service tools	9-23
9.1.7.1	General	9-23
9.1.7.2	Hydraulic test – Service tools	9-24
9.2	GPA20/Load Sensing	9-30
9.2.1	General	9-30
9.2.2	Principles of operation	9-30
9.2.3	Layout of components	9-32
9.2.3.1	Filtration and cooling	9-32
9.2.3.2	Transmission lubrication system	9-34
9.2.3.3	High-pressure system	9-36
9.2.3.4	Low pressure system	9-37
9.2.3.5	Distribution unit — Power Beyond	9-40
9.2.4	Hydraulic tests	9-40
9.2.4.1	General	9-40
9.2.4.2	High pressure system	9-41
9.2.4.3	Low pressure system (20 bar)	9-47
9.2.4.4	Cooling and lubrication system	9-52
9.2.5	Service tools	9-54
9.2.5.1	General	9-54
9.2.5.2	Hydraulic test – Service tools	9-54
9.3	GPA20/Load Sensing/Right-hand cover plate	9-61
9.3.1	General	9-61

9.3.2	Principles of operation	9-61
9.3.3	Description and operation of the variable displacement pump	9-63
9.3.4	Priority block	9-66
9.3.5	Layout of components	9-71
9.3.5.1	View of the assembly	9-71
9.3.5.2	Blown-up view	9-73
9.3.6	Identification of channels and ports	9-75
9.3.7	Disassembly/reassembly	9-77
9.3.7.1	Removing and refitting the hydraulic cover plate	9-77
9.3.7.2	Removing and refitting the variable displacement pump	9-80
9.3.8	Service tools	9-82
9.3.8.1	General	9-82
9.3.8.2	Load Sensing/Right-hand cover plate - Service tools	9-83
9.4	GPA20/Load Sensing/Left-hand cover plate	9-84
9.4.1	General	9-84
9.4.2	Principles of operation	9-84
9.4.3	Layout of components	9-86
9.4.3.1	View of the assembly	9-86
9.4.3.2	GPA20 exploded view	9-87
9.4.3.3	Identification of ports and channels on the cover plate	9-88
9.4.4	Disassembly/reassembly	9-88
9.4.4.1	Removing/refitting the LS cover plate	9-88
9.4.4.2	Removing and refitting the charge pump	9-88
9.4.4.3	Replacing the charge pump seals	9-91
9.5	Load Sensing/Linkage spool valve	9-94
9.5.1	General	9-94
9.5.2	Principles of operation	9-95
9.5.3	Schematic diagram	9-97
9.5.4	Removing/refitting the linkage spool valve	9-98
9.5.4.1	Removal	9-98
9.5.4.2	Refitting	9-99
9.5.4.3	Disassembly	9-99
9.5.4.4	Reassembly	9-99
9.5.4.5	Final steps	9-99
9.6	Load Sensing/Rear auxiliary spool valves	9-101
9.6.1	General	9-101
9.6.2	Mechanical auxiliary spool valves	9-104
9.6.2.1	Principles of operation	9-104
9.6.2.2	Control cables	9-105
9.6.3	Electrohydraulic auxiliary spool valves	9-105
9.6.3.1	Principles of operation	9-105
9.6.3.2	Working pressure block	9-108
9.6.4	Adjustments and bleeding	9-109
9.6.4.1	Spool valve cables	9-109
9.6.5	Disassembly/reassembly	9-111
9.6.5.1	Removing/refitting the rear spool valves	9-111
9.6.5.2	Spool valve lever	9-113
9.7	Load Sensing/Front auxiliary spool valves	9-115
9.7.1	General	9-115
9.7.2	Principles of operation	9-117
9.7.3	Working pressure block	9-121
9.7.4	Removing/refitting the front spool valves	9-121
9.7.4.1	Removing the front spool valves — Dyna-4 and Dyna-6	9-122
9.7.4.2	Removing the front spool valves — Dyna-VT	9-123
9.7.4.3	Refitting the front spool valves	9-124
9.7.4.4	Disassembling/reassembling the spool valve assembly	9-125
9.8	GPA20/Open Center	9-127

9.8.1	General	9-127
9.8.2	Low-pressure system, low flow rate	9-127
9.8.3	High-pressure system, high flow rate	9-130
9.8.4	Hydraulic tests	9-130
9.8.4.1	General	9-130
9.8.4.2	High flow rate system	9-131
9.8.4.3	Low flow rate system	9-134
9.9	GPA20/Open Center/Right-hand cover plate	9-141
9.9.1	General	9-141
9.9.2	Layout of components	9-142
9.9.2.1	View of external assembly	9-142
9.9.2.2	View of internal assembly	9-144
9.9.3	Blown-up view	9-147
9.9.4	Disassembly/reassembly	9-149
9.9.4.1	Removing/refitting the cover plate	9-149
9.9.4.2	Disassembling/reassembling the high pressure valve	9-152
9.9.4.3	Removing/refitting the pump	9-153
9.10	GPA20/Open Center/Left-hand cover plate	9-154
9.10.1	General	9-154
9.10.2	Layout of components	9-155
9.10.3	Removal/refitting	9-156
9.10.3.1	Removal	9-156
9.10.3.2	Preparing for refitting	9-158
9.10.3.3	Refitting	9-159
9.10.3.4	Final steps	9-159
9.11	GPA20/100 I/min Open Center	9-160
9.11.1	General	9-160
9.11.2	Low-pressure system, low flow rate	9-160
9.11.3	High-pressure system, high flow rate	9-163
9.11.4	Hydraulic tests	9-163
9.11.4.1	General	9-163
9.11.4.2	High flow rate system	9-164
9.11.4.3	Low flow rate system	9-168
9.12	GPA20/100 I/min Open Center/Right-hand cover plate	9-174
9.12.1	General	9-174
9.12.2	Layout of components	9-175
9.12.2.1	View of external assembly	9-175
9.12.2.2	View of internal assembly	9-177
9.12.3	Blown-up view	9-179
9.12.4	Disassembly/reassembly	9-181
9.12.4.1	Removing/refitting the cover plate	9-181
9.12.4.2	Disassembling/reassembling the high pressure valve	9-184
9.12.4.3	Removing/refitting the pump	9-185
9.13	GPA20/100 I/min Open Center/Left-hand cover plate	9-186
9.13.1	General	9-186
9.13.2	Layout of components	9-187
9.13.3	Disassembly/reassembly	9-188
9.13.3.1	Removal/refitting	9-188
9.14	GPA20/Open Center/Linkage spool valve	9-192
9.14.1	General	9-192
9.14.2	Principles of operation	9-192
9.14.3	Layout of components and identification of ports	9-201
9.14.4	Removing/refitting the spool valve	9-202
9.14.4.1	Removal	9-202
9.14.4.2	Preparing for refitting	9-203
9.14.4.3	Refitting	9-203
9.14.4.4	Final steps	9-203

9.15 GPA20/Open Center/Auxiliary spool valves	9-205
9.15.1 General	9-205
9.15.2 Principles of operation	9-207
9.15.2.1 Operation of the flow divider	9-207
9.15.2.2 3-position spool valve, SE/DE with return to neutral by spring	9-208
9.15.2.3 3-position spool valve, SE/DE with automatic return to neutral	9-211
9.15.2.4 3-position SE/DE spool valve with non-return valve and automatic return	9-212
9.15.2.5 Four-position DE spool valve, with automatic return to neutral and floating position	9-214
9.15.3 Schematic diagram	9-216
9.15.4 Layout of components	9-219
9.15.4.1 Blown-up view	9-219
9.15.5 Layout of ports and channels	9-221
9.15.6 Adjustments and bleeding	9-223
9.15.6.1 Adjusting the flow divider	9-223
9.15.7 Disassembly/reassembly	9-223
9.15.7.1 Removing/refitting the spool valves	9-223
9.15.7.2 Fitting and adjusting the control cables	9-225
9.16 GPA20/Open Center/Valve	9-230
9.16.1 General	9-230
9.16.2 Description of the 21-bar low pressure valve	9-230
9.16.3 Layout of components	9-232
9.16.3.1 Identification of ports	9-233
9.16.4 Adjusting the 21 bar valve	9-233
9.16.5 Disassembly/reassembly	9-233
9.16.5.1 Removing/refitting and disassembling/reassembling the 21-bar valve ..	9-233
9.16.5.2 Assembling the 5 bar valve	9-234
10 Electricity	10-1
10.1 Diagnostic procedure	10-3
10.1.1 List of generic procedures	10-3
10.1.2 Checking the insulation of a harness	10-3
10.1.3 Checking the continuity of a harness	10-3
10.1.4 Checking the CAN network	10-5
10.1.5 Checking a harness	10-7
10.1.6 Measuring a voltage	10-7
10.1.7 Measuring the resistance of a component	10-8
10.1.8 Measuring current	10-8
10.1.9 Hook-on ammeter procedure	10-8
10.1.10 Ammeter procedure	10-9
10.2 Electrical circuit	10-10
10.2.1 General	10-10
10.2.1.1 General	10-10
10.2.1.2 Principles of operation	10-11
10.2.1.3 Electricity - color code	10-11
10.2.1.4 Schematic diagram of the electrical circuit	10-12
10.2.2 Layout of components	10-13
10.3 Fuse box	10-15
10.3.1 General	10-15
10.3.1.1 General	10-15
10.3.1.2 Principles of operation	10-15
10.3.2 Layout of components	10-16
10.3.2.1 Fuse box - Connectors	10-16
10.3.3 Disassembly/reassembly	10-17
10.3.3.1 Tightening torques	10-17
10.3.3.2 Removing and refitting the fuse box	10-17

10.4 Alternator	10-19
10.4.1 Layout of components	10-19
10.4.2 Tests and diagnostics	10-20
10.4.2.1 Alternator - test procedure	10-20
10.4.3 Disassembly/reassembly	10-22
10.4.3.1 Removing and refitting the drive belts	10-22
10.4.3.2 Removing and refitting the alternators	10-23
10.4.4 Service tools	10-24
10.4.4.1 General	10-24
10.4.4.2 Belt - Service tools	10-24
10.5 Starter - General	10-25
10.5.1 General	10-25
10.5.1.1 General	10-25
10.5.1.2 Principles of operation	10-25
10.5.1.3 Schematic diagram	10-26
10.5.2 Layout of components	10-27
10.5.3 Tests and diagnostics	10-28
10.5.3.1 Starter diagnostics	10-28
10.5.4 Disassembly/reassembly	10-28
10.5.4.1 Removing/refitting the starter	10-28
10.6 Battery isolator	10-30
10.6.1 General	10-30
10.6.1.1 Battery isolator	10-30
10.6.1.2 Principles of operation	10-31
10.6.2 Layout of components	10-33
10.7 Triflash triangle - Disassembly/reassembly	10-34
10.7.1 Triflash on standard roof	10-34
10.7.2 Triflash on high-visibility roof	10-37
11 Electronics	11-1
11.1 Diagnostic tool	11-3
11.1.1 Diagnostic tool	11-3
11.2 Telemetry	11-4
11.2.1 General	11-4
11.2.1.1 General	11-4
11.2.1.2 Principles of operation	11-4
11.2.1.3 Schematic diagram	11-6
11.2.2 Telemetry error codes	11-6
11.2.3 Layout of components	11-8
11.2.4 Programming and setting parameters	11-8
11.2.5 Disassembly/reassembly	11-9
11.2.5.1 Access to the AGCOMMAND aerial	11-9
11.2.5.2 Disassembling the AM50 AGCOMMAND unit	11-10
12 Operator environment	12-1
12.1 Standard air conditioning	12-3
12.1.1 General	12-3
12.1.1.1 General	12-3
12.1.1.2 Principles of operation	12-3
12.1.1.3 Technical specifications	12-4
12.1.1.4 Schematic diagram of the air conditioning	12-7
12.1.1.5 Air conditioning hydraulics diagram	12-10
12.1.2 Layout of components	12-11
12.1.2.1 Diagram of the air conditioning compressor	12-11
12.1.2.2 Layout of components	12-12
12.1.3 Tests and diagnostics	12-13
12.1.3.1 Air conditioning tests - General	12-13

12.1.3.2	Air conditioning tests - Air conditioning unit breakdown	12-14
12.1.3.3	Air conditioning tests - Cleaning the system	12-15
12.1.4	Adjustments, bleeding and calibrations	12-16
12.1.4.1	Safety instructions	12-16
12.1.4.2	General maintenance	12-17
12.1.4.3	Adjusting the clutch air gap	12-17
12.1.4.4	Draining the system and checking for leaks	12-18
12.1.4.5	Filling the unit (engine stopped)	12-19
12.1.4.6	Checking pressures	12-21
12.1.5	Disassembly/reassembly	12-22
12.1.5.1	Removing and refitting the roof trim	12-22
12.1.5.2	Removing and refitting the drive belts	12-25
12.1.5.3	Air conditioning - Replacing the dryer	12-26
12.1.6	Service tools	12-28
12.1.6.1	General	12-28
12.1.6.2	Belt - Service tools	12-29
12.2	Self-regulating air conditioning	12-30
12.2.1	General	12-30
12.2.1.1	General	12-30
12.2.1.2	Using the air conditioning system	12-30
12.2.1.3	Fan control	12-30
12.2.1.4	Activating the compressor	12-31
12.2.1.5	Defrosting	12-31
12.2.1.6	Recirculation	12-31
12.2.1.7	Special conditions	12-32
12.2.2	Layout of components	12-32
12.2.2.1	Diagram of the air conditioning compressor	12-32
12.2.2.2	Layout of components	12-33
12.2.2.3	Self-regulating air conditioning - Layout of components	12-34
12.2.3	Tests and diagnostics	12-35
12.2.3.1	Air conditioning tests - General	12-35
12.2.3.2	Air conditioning tests - Air conditioning unit breakdown	12-35
12.2.3.3	Air conditioning tests - Cleaning the system	12-37
12.2.4	Adjustments, bleeding and calibrations	12-37
12.2.4.1	Safety instructions	12-37
12.2.4.2	General maintenance	12-38
12.2.4.3	Adjusting the clutch air gap	12-39
12.2.4.4	Draining the system and checking for leaks	12-40
12.2.4.5	Filling the unit (engine stopped)	12-41
12.2.4.6	Checking pressures	12-42
12.2.5	Disassembly/reassembly	12-44
12.2.5.1	Removing and refitting the roof trim	12-44
12.2.5.2	Removing and refitting the drive belts	12-47
12.2.5.3	Air conditioning - Replacing the dryer	12-48
12.2.6	Service tools	12-50
12.2.6.1	General	12-50
12.2.6.2	Belt - Service tools	12-51
12.3	Mechanical suspension	12-52
12.3.1	General	12-52
12.3.2	Layout of components	12-55
12.3.2.1	View of the assembly	12-55
12.3.3	Disassembly/reassembly	12-56
12.3.3.1	Tightening torques	12-56
12.4	Active mechanical suspension	12-57
12.4.1	General	12-57
12.4.2	Principles of operation	12-61
12.4.3	Schematic diagram	12-63

12.4.4	View of the assembly	12-67
12.4.5	Disassembly/reassembly	12-68
12.4.5.1	Tightening torques	12-68
13	Accessories	13-1
13.1	accessories kits	13-3
13.1.1	Accessories kits - Engine	13-3
13.1.2	Accessories kits - Gearbox	13-3
13.1.3	Accessories kits - Rear axle	13-3
13.1.4	Accessories kits - Power take-off	13-4
13.1.5	Accessories kits - Hydraulics	13-4
13.1.6	Accessories kits - Electronics	13-5
13.1.7	Accessories kits - Cab	13-5
14	Service tools	14-1
14.1	General	14-3
14.1.1	General	14-3
14.2	Separation of assemblies	14-4
14.2.1	Separation of assemblies - Service tools	14-4
14.3	Engine	14-5
14.3.1	AGCO Power engine - Service tools	14-5
14.3.1.1	Cylinder block tools	14-5
14.3.1.2	Timing gear and flywheel housing tools	14-6
14.3.1.3	Cylinder head and valve mechanism tools	14-7
14.3.1.4	Crank mechanism tools	14-8
14.3.1.5	Coolant pump tools	14-9
14.3.1.6	Engine control system tools	14-10
14.3.1.7	Maintenance and troubleshooting tools	14-10
14.3.2	3rd generation SCR engine - Service tools	14-11
14.4	Gearbox	14-12
14.4.1	GBA25	14-12
14.4.1.1	Powershift module - Service tools	14-12
14.4.1.2	PowerShuttle - Service tools	14-13
14.4.1.3	Robotic mechanical gearbox - Service tools	14-13
14.4.2	ML140	14-14
14.4.2.1	ML130/ML140/ML160/ML180 - Service tools	14-14
14.5	Rear Axle	14-24
14.5.1	GPA20	14-24
14.5.1.1	GPA20/Final drives - Service tools	14-24
14.5.1.2	GPA20/Differential - Service tools	14-24
14.5.1.3	GPA20 +/-Hitch/Increased capacity linkage - Service tools	14-25
14.5.1.4	Tractor braking - Service tools	14-26
14.5.2	HA140	14-26
14.5.2.1	Final drives - Service tools	14-26
14.5.2.2	Differential - Service tools	14-28
14.5.2.3	Tractor braking - Service tools	14-30
14.6	Power take-off	14-33
14.6.1	GPA20	14-33
14.6.1.1	GPA20/Clutch - Service tools	14-33
14.7	Front axle	14-34
14.7.1	Front axle - Service tools	14-34
14.7.2	4-wheel drive clutch - Service tools	14-35
14.8	Hydraulics	14-38
14.8.1	Hydraulic test – Service tools	14-38
14.8.2	GPA20/Hydraulic Load Sensing system	14-44
14.8.2.1	Load Sensing/Right-hand cover plate - Service tools	14-44

14.9 Electricity	14-45
14.9.1 Belt - Service tools	14-45
14.10 Electronics	14-46
14.10.1 Harness - Service tools	14-46
14.11 Operator environment	14-56
14.11.1 Belt - Service tools	14-56

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com