

# ***Workshop Manual for 7280 CENTORA Combine Series***

*MF7280 - MF7282 CENTORA + Auto Level*



# Workshop Manual for 7280 CENTORA Combine Series

<b>1</b>	<b>Introduction - Specifications</b>	13
1.1	<b>Using the manual</b>	15
1.1.1	Using the manual	15
1.2	<b>General specifications</b>	16
1.2.1	General specifications	16
1.2.2	Tyre pressure	19
1.3	<b>Dimensions and weight</b>	21
1.3.1	Dimensions and weight	21
1.4	<b>Safety precautions</b>	23
1.4.1	Safety precautions	23
1.4.2	Safety in the workshop	23
1.4.3	Safety - a word to the mechanic	23
1.4.4	Safety - danger, warning and caution	23
1.4.5	Safety decals	24
1.4.6	General	24
1.4.7	Personal safety	24
1.4.8	Considerations with regard to equipment	25
1.4.9	General considerations	26
1.4.10	Operational considerations	26
1.4.11	Maintenance techniques	27
1.5	<b>Practical advice</b>	29
1.5.1	Practical advice	29
1.6	<b>Start-up instructions</b>	33
1.6.1	General	33
1.6.2	Pre-delivery checks	33
1.6.3	Instruction of combine operator	35
1.7	<b>Conversion tables</b>	38
1.7.1	Conventional units of measurement	38
1.8	<b>Locking and sealing agents</b>	39
1.8.1	Locking and sealing agents	39
1.9	<b>Wheel nut torques</b>	40
1.9.1	Wheels	40
1.9.2	Bolts with metric threads	40
1.9.3	Nuts with metric threads	41
<b>2</b>	<b>Cutting table</b>	43
2.1	<b>General</b>	45
2.1.1	Cutting table, general	45
2.2	<b>Knife drive - wobble box</b>	46
2.2.1	Removal	46
2.2.2	Assembly	46
2.2.3	Reconditioning the wobble box	47
2.2.4	Positioning the double fingers, knife and crop lifters	53
2.3	<b>Table auger</b>	54
2.3.1	Removal	54
2.3.2	Assembly	55
2.3.3	Replacing the shaft on the right-hand side	55
2.3.4	Replacing the shaft on the left-hand side	56
2.3.5	Replacing the crankshaft	57
2.3.6	Replacing the feathering fingers, bearings and bushes	58
2.3.7	Adjusting the table auger and feathering fingers	59

<b>2.4</b>	<b>Table body</b>	60
2.4.1	Adjusting the cut-off strips	60
2.4.2	Adjusting and positioning the ground sensor - PowerFlow	61
<b>2.5</b>	<b>Slip clutch and chain drive</b>	63
2.5.1	Removal	63
2.5.2	Assembly	63
2.5.3	Replacing the bearings and sprockets	64
<b>2.6</b>	<b>Countershaft</b>	65
2.6.1	Removal	65
2.6.2	Assembly	66
<b>2.7</b>	<b>PowerFlow table</b>	67
2.7.1	PowerFlow Table	67
2.7.2	Removal, belts	67
2.7.3	Assembly, belts	70
2.7.4	Replacing the front rollers and bearings, scraper adjustment	71
2.7.5	Replacing the rear rollers and bearings, scraper adjustment	73
2.7.6	Replacing and aligning the bearing housing, rear rollers	74
2.7.7	Belt tensioning and running-in	75
<b>3</b>	<b>Reel</b>	79
<b>3.1</b>	<b>Reel</b>	81
3.1.1	Removal	81
3.1.2	Assembly	82
3.1.3	Replacing the reel tine bar and plastic bearings	83
3.1.4	Replacing the guide rollers, eccentric, guide ring and bearings	84
3.1.5	Replacing the reel plates	85
3.1.6	Replacing the reel tube, bearings	85
<b>3.2</b>	<b>Oil motor and chain drive</b>	86
3.2.1	Replacing the oil motor	86
3.2.2	Replacing the flow divider	86
<b>3.3</b>	<b>Hydraulic cylinders</b>	90
3.3.1	Replacing the cylinder – reel up/down	90
3.3.2	Replacement of cylinder – reel forward/back	91
3.3.3	Reconditioning of hydraulic cylinders	91
<b>4</b>	<b>Main crop elevator</b>	95
<b>4.1</b>	<b>General</b>	97
4.1.1	Main crop elevator, general	97
<b>4.2</b>	<b>Main crop elevator</b>	98
4.2.1	Removal	98
4.2.2	Assembly	99
4.2.3	Bearing block on machine frame	100
4.2.4	Replacement of lifting ram	100
4.2.5	Reconditioning of hydraulic cylinder	100
4.2.6	Replacing the cutting height preset sensor	101
<b>4.3</b>	<b>Crop elevator chain</b>	103
4.3.1	Crop elevator chain, general	103
4.3.2	Removal	103
4.3.3	Assembly	103
4.3.4	Replacement of slats	105
4.3.5	Replacing the slide rails in the crop elevator	105
4.3.6	Replacing the intermediate plate	106
<b>4.4</b>	<b>Elevator chain top shaft</b>	107
4.4.1	Removal	107
4.4.2	Assembly	108
4.4.3	Replacing the bearings	108
4.4.4	Replacing the sprockets	108
4.4.5	Replacing the shaft protection tube	110
<b>4.5</b>	<b>Elevator chain front shaft</b>	111
4.5.1	Removal	111
4.5.2	Assembly	111
4.5.3	Replacing the shaft, bearings and plate wheels	112



<b>4.6</b>	<b>Elevator countershaft</b> .....	113
4.6.1	Removal .....	113
4.6.2	Assembly .....	114
4.6.3	Replacing the bearings, belt pulley .....	114
<b>4.7</b>	<b>Table clutch and chain drive</b> .....	115
4.7.1	Removal .....	115
4.7.2	Assembly .....	115
4.7.3	Reconditioning the clutch .....	116
<b>4.8</b>	<b>Adapter</b> .....	117
4.8.1	Removal .....	117
4.8.2	Assembly .....	118
4.8.3	Replacing the cylinder/connecting rod .....	118
4.8.4	Reconditioning of hydraulic cylinder .....	118
4.8.5	Replacing the angle sensor .....	119
<b>4.9</b>	<b>Hydraulic reversing</b> .....	120
4.9.1	Removal .....	120
4.9.2	Assembly .....	120
<b>5</b>	<b>Threshing unit</b> .....	121
<b>5.1</b>	<b>General</b> .....	123
5.1.1	Threshing unit, general .....	123
<b>5.2</b>	<b>Stone trap</b> .....	124
5.2.1	Removal .....	124
5.2.2	Assembly .....	125
<b>5.3</b>	<b>Concave</b> .....	126
5.3.1	Removal .....	126
5.3.2	Assembly .....	127
5.3.3	Adjusting the concave laterally .....	127
5.3.4	Concave setting - initial setting .....	128
5.3.5	Replacing the actuator .....	128
5.3.6	Replacing the lead-in plate .....	129
5.3.7	Replacing the shaft for concave setting .....	130
<b>5.4</b>	<b>Threshing cylinder</b> .....	131
5.4.1	Removal .....	131
5.4.2	Assembly .....	132
5.4.3	Replacing the bearings .....	133
5.4.4	Replacing the rasp bars and backing bars .....	134
5.4.5	Replacing the shaft and cylinder spiders .....	134
<b>5.5</b>	<b>Cylinder variator - table clutch</b> .....	136
5.5.1	Removal, hydraulic variator .....	136
5.5.2	Assembly, hydraulic variator .....	137
5.5.3	Reconditioning the hydraulic variator pulley .....	137
5.5.4	Removal, mechanical variator .....	139
5.5.5	Assembly, mechanical variator .....	139
5.5.6	Reconditioning the mechanical variator pulley .....	140
5.5.7	Removal, magnetic clutch .....	141
5.5.8	Assembly, magnetic clutch .....	142
5.5.9	Reconditioning the magnetic clutch .....	143
<b>5.6</b>	<b>Bracket for counter drive</b> .....	146
5.6.1	Removal .....	146
5.6.2	Assembly and alignment .....	146
<b>5.7</b>	<b>Rear beater</b> .....	148
5.7.1	Removal .....	148
5.7.2	Assembly .....	149
5.7.3	Replacing the bearings .....	150
<b>5.8</b>	<b>Rear beater concave</b> .....	151
5.8.1	Removal .....	151
5.8.2	Assembly .....	151
<b>5.9</b>	<b>Rotary separator cylinder</b> .....	152
5.9.1	Removal .....	152
5.9.2	Assembly .....	153
5.9.3	Replacing the bearings .....	154

5.9.4	Replacing the rasp bars	155
<b>5.10</b>	<b>Rotary separator concave</b>	156
5.10.1	Removal	156
5.10.2	Assembly	157
5.10.3	Concave setting - initial setting	158
5.10.4	Replacing the shaft for concave setting	159
<b>6</b>	<b>Straw walkers</b>	161
<b>6.1</b>	<b>General</b>	163
6.1.1	Straw walkers, general	163
<b>6.2</b>	<b>Straw walkers</b>	164
6.2.1	Removal	164
6.2.2	Assembly	164
<b>6.3</b>	<b>Crank - front</b>	166
6.3.1	Removal	166
6.3.2	Fitting	167
6.3.3	Replacing the bearings	167
<b>6.4</b>	<b>Crank - rear</b>	169
6.4.1	Removal	169
6.4.2	Fitting	169
6.4.3	Replacing the bearings	169
<b>7</b>	<b>Shaker shoe - Fanning mill</b>	171
<b>7.1</b>	<b>General</b>	173
7.1.1	Shaker shoe - fanning mill, general	173
<b>7.2</b>	<b>Fanning mill</b>	174
7.2.1	Removal	174
7.2.2	Assembly	175
7.2.3	Replacing the fan blades	175
7.2.4	Replacing the fanning mill deflectors	176
7.2.5	Replacement of seals	177
<b>7.3</b>	<b>Main grain pan frame</b>	178
7.3.1	General	178
7.3.2	Removal	178
7.3.3	Assembly	179
7.3.4	Replacing the swivel arm and bearings	180
7.3.5	Replacing the seals	181
<b>7.4</b>	<b>Second grain pan</b>	182
7.4.1	Removal	182
7.4.2	Assembly	182
7.4.3	Replacing the swivel arm and bearings	183
7.4.4	Adjusting second grain pan	184
<b>7.5</b>	<b>Top shaker shoe</b>	186
7.5.1	Removal	186
7.5.2	Assembly	187
7.5.3	Replacing the swivel arm and bearings	188
7.5.4	Replacement of seals	189
7.5.5	Replacing and calibrating the actuator - sieves	189
<b>7.6</b>	<b>Bottom shaker shoe</b>	191
7.6.1	Removal	191
7.6.2	Assembly	192
7.6.3	Replacing the swivel arm and bearings	193
7.6.4	Replacing the seals	193
7.6.5	Electric sieve setting – initial setting	193
<b>7.7</b>	<b>Bottom augers</b>	194
7.7.1	Bottom augers	194
7.7.2	Removal	194
7.7.3	Assembly	195
<b>7.8</b>	<b>Eccentric drive</b>	196
7.8.1	Removal	196
7.8.2	Assembly	197
7.8.3	Adjusting the connecting rod / aligning the shaker shoes	198



7.8.4	Replacing the connecting rod bearing	199
7.8.5	Replacing the bearings and eccentric shaft	200
<b>7.9</b>	<b>Transmissions</b>	201
7.9.1	Replacing and reconditioning the fanning mill variator	201
7.9.2	Adjusting the fanning mill variator	202
7.9.3	Replacing and reconditioning the counter drive	203
<b>8</b>	<b>Elevators</b>	205
<b>8.1</b>	<b>Tank filling elevator</b>	207
8.1.1	Removal	207
8.1.2	Assembly	208
8.1.3	Replacing the top shaft, bearings and sprockets	209
8.1.4	Replacement of bottom sprocket	210
8.1.5	Replacing the elevator chain	210
8.1.6	Moisture sensor	211
8.1.7	Yieldmeter sensor	211
<b>8.2</b>	<b>Returns elevator</b>	212
8.2.1	Removal	212
8.2.2	Assembly	213
8.2.3	Replacing the top shaft, bearings and sprockets	213
8.2.4	Replacing the bottom sprocket	214
8.2.5	Replacing the elevator chain	214
8.2.6	Returns volume sensor	214
<b>8.3</b>	<b>Returns thresher</b>	215
8.3.1	Removal	215
8.3.2	Fitting	215
8.3.3	Replacing the sprockets	215
8.3.4	Replacement of threshing cylinder	216
8.3.5	Reconditioning the right-angle gear	216
<b>8.4</b>	<b>Tank filling auger</b>	219
8.4.1	Removal	219
8.4.2	Fitting	219
8.4.3	Replacing the top bearing	219
8.4.4	Reconditioning the right-angle gear	220
<b>8.5</b>	<b>Transmission</b>	221
8.5.1	Replacing the shaft, bearings and sprockets	221
<b>9</b>	<b>Engine</b>	223
<b>9.1</b>	<b>General</b>	225
9.1.1	Engine, general	225
<b>9.2</b>	<b>Replacing the engine</b>	226
9.2.1	Removing the engine assembly	226
9.2.2	Fitting the engine assembly	228
<b>10</b>	<b>Unloading auger - Grain tank</b>	231
<b>10.1</b>	<b>Unloading auger - horizontal</b>	233
10.1.1	Removal	233
10.1.2	Assembly	233
<b>10.2</b>	<b>Unloading auger - vertical</b>	235
10.2.1	Removal	235
10.2.2	Assembly	235
10.2.3	Reconditioning the right-angle gear	236
<b>10.3</b>	<b>Unloading tube - horizontal</b>	237
10.3.1	Removal	237
10.3.2	Assembly	237
<b>10.4</b>	<b>Unloading tube - vertical</b>	238
10.4.1	Removal	238
10.4.2	Assembly	238
10.4.3	Replacing the swivel bearing	239
10.4.4	Replacing the hydraulic cylinder	240
10.4.5	Reconditioning of hydraulic cylinder	240

<b>10.5 Unloading tube elbow</b> .....	241
10.5.1 Removal .....	241
10.5.2 Assembly .....	241
10.5.3 Reconditioning the right-angle gear .....	242
<b>10.6 Bottom auger and cover plate</b> .....	244
10.6.1 Removal .....	244
10.6.2 Fitting .....	245
10.6.3 Replacing the bearings, safety clutch .....	245
<b>10.7 Transmission</b> .....	247
10.7.1 Replacing the unloading auger shaft, bearings .....	247
10.7.2 Replacing and reconditioning the magnetic clutch .....	248
<b>10.8 Grain tank covers</b> .....	250
10.8.1 Removal .....	250
10.8.2 Assembly .....	251
<b>11 Drive unit</b> .....	253
<b>11.1 Radiator – intercooler</b> .....	255
11.1.1 Removal .....	255
11.1.2 Fitting .....	256
<b>11.2 Oil cooler</b> .....	257
11.2.1 Removal .....	257
11.2.2 Assembly .....	257
<b>11.3 Fuel cooler</b> .....	258
11.3.1 Removal .....	258
11.3.2 Assembly .....	258
<b>11.4 Condenser – air conditioning</b> .....	259
11.4.1 Removal .....	259
11.4.2 Assembly .....	259
<b>11.5 Rotary screen</b> .....	260
11.5.1 Removal .....	260
11.5.2 Assembly .....	261
11.5.3 Adjusting the rotary screen and cleaning blade .....	262
11.5.4 Replacing the drive shaft and clutch .....	263
<b>11.6 Dust aspirator</b> .....	266
11.6.1 Removal .....	266
11.6.2 Assembly .....	267
<b>11.7 Hydrostatic pump</b> .....	268
11.7.1 Removal .....	268
11.7.2 Assembly .....	270
11.7.3 Tensioning device .....	271
<b>11.8 Auxiliary hydraulic pump</b> .....	272
11.8.1 Removal .....	272
11.8.2 Fitting .....	272
<b>11.9 Hydraulic pump - Maxi Spreader</b> .....	273
11.9.1 Removal .....	273
11.9.2 Assembly .....	273
<b>11.10 Hydraulic oil tank</b> .....	274
11.10.1 Removal .....	274
11.10.2 Fitting .....	274
<b>11.11 Fuel tank</b> .....	275
11.11.1 Removal .....	275
11.11.2 Fitting .....	275
11.11.3 Tank gauge .....	275
<b>11.12 Diesel additive and dosing equipment</b> .....	276
11.12.1 Removal .....	276
11.12.2 Assembly .....	276
11.12.3 Supply module .....	276
11.12.4 Dosing module .....	277
11.12.5 Tank sensor .....	277
<b>11.13 Compressor – air conditioning</b> .....	278
11.13.1 Removal .....	278
11.13.2 Assembly .....	278

<b>11.14 Power take-off</b>	279
11.14.1 Removal	279
11.14.2 Assembly	279
11.14.3 Replacing the clutch disc	280
11.14.4 Replacing the output shaft, bearing and hub	281
<b>12 Transmissions</b>	283
<b>12.1 General</b>	285
12.1.1 Transmissions, General	285
<b>12.2 Countershaft</b>	286
12.2.1 Removal	286
12.2.2 Assembly	288
12.2.3 Replacing the bearings	288
12.2.4 Reconditioning the safety clutch	289
<b>12.3 Replacing the belts, right-hand side</b>	290
12.3.1 Rear beater - counter drive, cylinder variator	290
12.3.2 Counter drive, variator - threshing cylinder	291
12.3.3 Rear beater - rotary separator	292
12.3.4 Fanning mill - fanning mill variator	292
12.3.5 Rear beater - fanning mill variator	293
12.3.6 Unloading auger shaft - unloading auger	293
12.3.7 Unloading auger shaft - rotary screen clutch	294
12.3.8 Unloading auger shaft - dust aspirator	295
12.3.9 Countershaft – counter drive, elevators	296
<b>12.4 Replacing the chains, right-hand side</b>	297
12.4.1 Counter drive, elevators - returns elevator	297
12.4.2 Counter drive, elevators - tank filling elevator	297
12.4.3 Counter drive, elevators - tank filling auger	298
12.4.4 Returns elevator - returns thresher	298
12.4.5 Reel drive	299
<b>12.5 Replacing the belts, left-hand side</b>	300
12.5.1 Countershaft - rear beater	300
12.5.2 Countershaft - counter drive, straw chopper	300
12.5.3 Counter drive - straw chopper	301
12.5.4 Engine - countershaft	301
12.5.5 Rear beater - countershaft, shaker shoe drive	303
12.5.6 Countershaft, shaker shoe drive - eccentric shaft	304
12.5.7 Countershaft, shaker shoe drive - straw walker crank	304
12.5.8 Rear beater - elevator chain top shaft / front shaft	305
12.5.9 Engine - unloading auger shaft	307
12.5.10 Engine - hydrostatic pump	307
12.5.11 PTO shaft – table countershaft	308
12.5.12 Table countershaft - knife drive	309
12.5.13 Countershaft - hydraulic pump, chaff spreader	309
<b>12.6 Replacing the chains, left-hand side</b>	310
12.6.1 Table countershaft - table auger	310
12.6.2 Table auger - belt rollers (PowerFlow)	310
12.6.3 Hydraulic motor, reversing - elevator countershaft	311
12.6.4 Bottom auger – unloading auger	312
<b>13 Undercarriage</b>	313
<b>13.1 Auto Level final drive bracket</b>	315
13.1.1 Removal	315
13.1.2 Assembly	316
13.1.3 Replacing the bushing	318
13.1.4 Replacing the hydraulic cylinder	319
13.1.5 Reconditioning of hydraulic cylinder	319
13.1.6 Adjusting the Auto Level potentiometer	320
<b>13.2 Final drives</b>	321
13.2.1 Removal	321
13.2.2 Assembly	322
13.2.3 Reconditioning the final drives	323



<b>13.3</b>	<b>Gearbox</b> .....	327
13.3.1	Removal .....	327
13.3.2	Assembly .....	328
13.3.3	Replacing the shifter cylinders and sensor .....	329
13.3.4	Adjusting the shifter cylinders and sensor .....	330
13.3.5	Replacing the lubrication pump .....	333
13.3.6	Replacing the shifter forks .....	334
13.3.7	Reconditioning the differential .....	335
13.3.8	Reconditioning the gearbox .....	338
<b>13.4</b>	<b>Hydrostatic motor</b> .....	342
13.4.1	Removal .....	342
13.4.2	Assembly .....	342
<b>13.5</b>	<b>Brakes</b> .....	343
13.5.1	Replacing the brake blocks .....	343
13.5.2	Replacement of brake discs .....	344
13.5.3	Bleeding the brakes .....	346
13.5.4	Brake pedals and main cylinder .....	346
13.5.5	Replacing the handbrake shoes .....	349
13.5.6	Adjustment of hydraulic hand brake .....	350
<b>13.6</b>	<b>Rear axle</b> .....	351
13.6.1	General .....	351
13.6.2	Removal .....	351
13.6.3	Assembly .....	352
13.6.4	Replacing the king pins and bushings .....	353
13.6.5	Replacing the steering cylinder .....	354
13.6.6	Reconditioning the hydraulic cylinder, rear axle .....	354
13.6.7	Adjusting the toe-in and steering deflection .....	355
<b>14</b>	<b>Cab</b> .....	359
<b>14.1</b>	<b>Multi-function lever and control panel</b> .....	361
14.1.1	Control panel .....	361
14.1.2	Armrest .....	362
14.1.3	Multi-function lever .....	363
<b>14.2</b>	<b>Replacing the windscreen</b> .....	365
14.2.1	Replacing the windscreen .....	365
<b>14.3</b>	<b>Control panel in roof</b> .....	366
14.3.1	Control panel in roof .....	366
<b>14.4</b>	<b>Roof</b> .....	367
14.4.1	Outer roof .....	367
14.4.2	Inspection doors .....	368
14.4.3	Replacing the windscreen wiper .....	368
14.4.4	Replacing the blower .....	369
14.4.5	Replacing the heating element/tap .....	370
14.4.6	Replacing evaporator .....	370
<b>14.5</b>	<b>Troubleshooting – Climate control</b> .....	371
14.5.1	Climate control faults in general .....	371
14.5.2	ECS – Electronic control unit .....	371
14.5.3	Troubleshooting table .....	371
<b>15</b>	<b>Hydraulics</b> .....	375
<b>15.1</b>	<b>General</b> .....	377
15.1.1	Hydraulics, general .....	377
15.1.2	Emptying and filling the hydrostatic system .....	379
15.1.3	Running in and bleeding the hydrostatic system .....	380
15.1.4	Running in and bleeding the auxiliary hydraulics .....	381
<b>15.2</b>	<b>Hydraulic diagrams</b> .....	382
15.2.1	Hydraulic diagrams .....	382
<b>15.3</b>	<b>Hydrostatic system</b> .....	385
15.3.1	Hydrostatic system .....	385
<b>15.4</b>	<b>Gearshift</b> .....	387
15.4.1	Gearshift .....	387

<b>15.5 Handbrake</b> .....	388
15.5.1 Hand brake .....	388
<b>15.6 Auxiliary hydraulics</b> .....	389
15.6.1 Auxiliary hydraulics .....	389
<b>15.7 Cutting table</b> .....	391
15.7.1 Cutting table .....	391
<b>15.8 Auto Level</b> .....	394
15.8.1 Auto Level - hydraulic cylinders .....	394
<b>15.9 Reel</b> .....	395
15.9.1 Reel .....	395
<b>15.10 Steering</b> .....	398
15.10.1 Steering - hydraulics .....	398
<b>15.11 Cylinder variator</b> .....	399
15.11.1 Cylinder variator - hydraulics .....	399
<b>15.12 Unloading auger</b> .....	400
15.12.1 Unloading auger - hydraulics .....	400
<b>15.13 Reversing</b> .....	401
15.13.1 Reversing - hydraulics .....	401
<b>15.14 Chaff spreader</b> .....	402
15.14.1 Chaff spreader - hydraulics .....	402
<b>15.15 Maxi Spreader</b> .....	403
15.15.1 Maxi Spreader - hydraulics .....	403
<b>15.16 Troubleshooting - hydrostatic transmission</b> .....	405
15.16.1 Hydrostatic transmission faults in general .....	405
15.16.2 Pump and motor specifications .....	405
15.16.3 Functional diagram, HPV pump - HMF motor .....	406
15.16.4 Connecting test equipment .....	408
15.16.5 Troubleshooting table .....	409
15.16.6 Checking the charge pump .....	410
15.16.7 Checking the high pressure valves .....	410
15.16.8 Checking the cold start valve .....	410
15.16.9 Checking the servo control .....	411
15.16.10 Checking the hydraulic pump .....	412
15.16.11 Checking the hydraulic motor .....	413
<b>16 Electrical system</b> .....	415
<b>16.1 General</b> .....	417
16.1.1 Electrical system, general .....	417
<b>16.2 Description of DATAVISION</b> .....	418
16.2.1 Description of DATAVISION .....	418
<b>16.3 Electric box</b> .....	419
16.3.1 Replacing the terminal .....	419
16.3.2 Replacing the job computers .....	419
<b>16.4 Calibrations</b> .....	422
16.4.1 Speed calibration .....	422
16.4.2 Calibrating the concave .....	422
16.4.3 Shaft alarm calibration .....	422
16.4.4 Calibrating the electrical sieves .....	423
16.4.5 Calibrating the electrical straw deflectors .....	423
16.4.6 Calibrating the Auto Level combine .....	423
16.4.7 Table calibration .....	424
<b>16.5 Diagrams overview</b> .....	426
16.5.1 Diagrams overview .....	426
<b>16.6 Wiring diagrams</b> .....	430
16.6.1 Wiring diagrams .....	430
<b>16.7 Diagrams - computer input/output</b> .....	444
16.7.1 Diagrams input/output .....	444
<b>16.8 Diagramme ECU sensor connections</b> .....	448
16.8.1 Diagramme ECU sensor connections, Stage 3B engine, 6 cylinders .....	448
<b>16.9 Connectors</b> .....	450
16.9.1 Connectors .....	450

<b>16.10 W-connecting points</b> .....	457
16.10.1 W-connecting points .....	457
<b>16.11 Components</b> .....	458
16.11.1 Components .....	458
<b>16.12 Key to symbols</b> .....	526
16.12.1 Key to symbols .....	526
<b>16.13 Wiring overview</b> .....	527
16.13.1 Wiring overview .....	527
<b>17 Straw chopper</b> .....	573
<b>17.1 General</b> .....	575
17.1.1 Replacing and calibrating the electric actuator – straw deflectors .....	575
<b>18 General assembly instructions</b> .....	577
<b>18.1 Fitting gib-head keys</b> .....	579
18.1.1 Fitting gib-head keys .....	579
<b>18.2 Fitting tightening pins</b> .....	580
18.2.1 Fitting tightening pins .....	580
<b>18.3 Fitting hydraulic pipes and screw connections</b> .....	581
18.3.1 Fitting hydraulic pipes and screw connections .....	581
<b>18.4 Fitting a flanged bearing with locking collar</b> .....	583
18.4.1 Fitting a flanged bearing with locking collar .....	583
<b>18.5 Fitting sliding bushings</b> .....	584
18.5.1 Fitting sliding bushings .....	584
<b>18.6 Removing the revolution sensor</b> .....	585
18.6.1 Removing the revolution sensor .....	585
<b>18.7 Fitting tightening rings</b> .....	586
18.7.1 Fitting tightening rings .....	586
<b>19 Miscellaneous data</b> .....	587
<b>19.1 General</b> .....	589
19.1.1 Miscellaneous data, general .....	589
<b>19.2 Speeds - adjustment values</b> .....	590
19.2.1 Speeds - adjustment values .....	590
<b>19.3 Maintenance</b> .....	591
19.3.1 Lubrication chart, intervals .....	591
19.3.2 Lubrication chart, right- and left-hand side .....	594
19.3.3 Lubrication chart, main crop elevator and front axle .....	596
19.3.4 Lubrication points, left-hand machine side .....	597
19.3.5 Lubrication points, right-hand machine side .....	611
19.3.6 Recommended lubricants .....	622
19.3.7 Gear .....	623
19.3.8 Air-conditioning .....	624

# 1. Introduction - Specifications

<b>1.1</b>	<b>Using the manual</b> . . . . .	15
1.1.1	Using the manual . . . . .	15
<b>1.2</b>	<b>General specifications</b> . . . . .	16
1.2.1	General specifications . . . . .	16
1.2.2	Tyre pressure . . . . .	19
<b>1.3</b>	<b>Dimensions and weight</b> . . . . .	21
1.3.1	Dimensions and weight . . . . .	21
<b>1.4</b>	<b>Safety precautions</b> . . . . .	23
1.4.1	Safety precautions . . . . .	23
1.4.2	Safety in the workshop . . . . .	23
1.4.3	Safety - a word to the mechanic . . . . .	23
1.4.4	Safety - danger, warning and caution . . . . .	23
1.4.5	Safety decals . . . . .	24
1.4.6	General . . . . .	24
1.4.7	Personal safety . . . . .	24
1.4.8	Considerations with regard to equipment . . . . .	25
1.4.9	General considerations . . . . .	26
1.4.10	Operational considerations . . . . .	26
1.4.11	Maintenance techniques . . . . .	27
<b>1.5</b>	<b>Practical advice</b> . . . . .	29
1.5.1	Practical advice . . . . .	29
<b>1.6</b>	<b>Start-up instructions</b> . . . . .	33
1.6.1	General . . . . .	33
1.6.2	Pre-delivery checks . . . . .	33
1.6.3	Instruction of combine operator . . . . .	35
<b>1.7</b>	<b>Conversion tables</b> . . . . .	38
1.7.1	Conventional units of measurement . . . . .	38
<b>1.8</b>	<b>Locking and sealing agents</b> . . . . .	39
1.8.1	Locking and sealing agents . . . . .	39
<b>1.9</b>	<b>Wheel nut torques</b> . . . . .	40
1.9.1	Wheels . . . . .	40
1.9.2	Bolts with metric threads . . . . .	40
1.9.3	Nuts with metric threads . . . . .	41



## 1.1 Using the manual

### 1.1.1 Using the manual

T008027

#### General

All operations described in this manual relating to repairs and maintenance must only be carried out by trained service personnel. The purpose of the manual is to help dealers and workshops start up, service and repair AGCO's equipment as efficiently and effectively as possible. If the specified procedures are followed and the recommended special tools used where necessary, jobs can be completed within the time indicated in the "Repair Time Schedule" manual.

#### Pagination

Example: [see §3.1.3, page 83](#)

This manual is divided into chapters and sections. In the example the figures show:

First figure = Chapter

Second figure = Section

Third figure = Consecutive number in the section in question

69 = Page number in manual

The publication number and version appear at the bottom of the page.

#### Use

To make it easier to look things up, there is a table of contents at the beginning of every chapter listing the various sections in the chapter.

#### Modifications

Modified pages have the same section numbering as their predecessors: Only the page number and version number change.

The old pages must be destroyed.

#### Service tools

In the case of jobs that require service tools, the number of the tool is specified at the point in the text where it is needed.

#### Repairs and replacing parts

When replacing parts, it is very important to only ever use genuine AGCO spares.

Please pay particular attention to the following points when it comes to repairs and fitting spare parts or other equipment.

Fitting non-genuine spare parts may impair the safety of the machine.

In some countries it is against the law to fit parts that do not conform to the manufacturer's specifications. Torque wrenches must always be adjusted in accordance with the instructions given in the workshop manual. Fit locking devices where specified. If the locking device breaks when removed, fit a new one.

If non-genuine AGCO parts are fitted, the machine will no longer be covered by the right to complain, as the manufacturer provides a warranty on all AGCO components. AGCO dealers are under the obligation to supply genuine parts only.

#### Repair Time Schedule

The "Repair Time Schedule" manual contains a table of standard time requirements for the commonest repairs on a combine. The manual's sections follow the layout of the spare parts catalogue.

## 1.2 General specifications

### 1.2.1 General specifications

T008028

Cutting table Quick-attach type, can be attached and removed directly on the ground. Power take-off with transmission shaft	Unit	7280 CENTORA	7282 CENTORA
Cutting height PowerFlow	cm	-40 to +148	-40 to +148
Knife speed	strokes/min.	1138	1138
Hydraulically balanced by pressure accumulators		yes	yes
Electrohydraulic cutting height presetting		yes	yes

Reel	Unit	7280 CENTORA	7282 CENTORA
Electrohydraulic reel drive	rpm	0-50	0-50
Peripheral speed	km/h	0-9.1	0-9.1
Electrohydraulic reel control up/down and fore/aft		yes	yes

Threshing cylinder	Unit	7280 CENTORA	7282 CENTORA
Speed, normal	rpm	400-1120	400-1120
Speed, reduced	rpm	307-945	307-945
Width	cm	168	168
Number of rasp bars	units	8	8
Diameter	cm	60	60
Weight	kg	318	318
Electrohydraulic speed adjustment		yes	yes
Peripheral speed	m/sec.	12.3-36.1	12.3-36.1
Peripheral speed, reduced	m/sec.	9.6-29.7	9.6-29.7

Concave	Unit	7280 CENTORA	7282 CENTORA
Concave area	cm <sup>2</sup>	10600	10600
Number of rub bars	units	13	13
Concave wires, self-cleaning, spring steel	mm	Ø 3.5	Ø 3.5
Concave wrap	degrees	117	117
Concave adjustable from operator seat		yes	yes

Rear beater	Unit	7280 CENTORA	7282 CENTORA
Diameter	cm	37.5	37.5

Rotary Separator	Unit	7280 CENTORA	7282 CENTORA
Speed, normal	rpm	950	950
Speed, reduced	rpm	475	475
Width	cm	168	168
Diameter	cm	50	50
Separation area	cm <sup>2</sup>	10400	10400

<b>Straw walkers</b>	<b>Unit</b>	<b>7280 CENTORA</b>	<b>7282 CENTORA</b>
Qty	units	8	8
Area	cm <sup>2</sup>	7400	7400
Area with rotary separator	cm <sup>2</sup>	6680	6680
Length	cm	400	400
Number of steps	units	5	5
Shutters in straw hood for cleaning straw walkers		yes	yes

<b>Main grain pan</b>	<b>7280 CENTORA</b>	<b>7282 CENTORA</b>
Two-sectioned lengthwise	yes	yes
Stepped sections removable for cleaning	yes	yes
Crop channelling	yes	yes

<b>Shaker shoe</b>	<b>Unit</b>	<b>7280 CENTORA</b>	<b>7282 CENTORA</b>
Two-sectioned lengthwise		yes	yes
Adjustable sieves		yes	yes
Sieve area	cm <sup>2</sup>	5300	5300
Opposite movement of sieves		yes	yes
Crop channelling		yes	yes
Work light		yes	yes

<b>Fanning mill</b>	<b>Unit</b>	<b>7280 CENTORA</b>	<b>7282 CENTORA</b>
Two-sectioned centrifugal blower		yes	yes
Electrical speed adjustment from operator seat or at shaker shoe (left-hand side)		yes	yes
Speed	rpm	460-1150	460-1150
Reduced speed	rpm	310-790	310-790

<b>Grain tank</b>	<b>Unit</b>	<b>7280 CENTORA</b>	<b>7282 CENTORA</b>
Capacity	litres	9500	10500 (AL 9500)
Inside light		yes	yes
Adjustable full warning		yes	yes
Outside steps and inside ladder for easy access		yes	yes
Sampling tray		yes	yes

<b>Unloading auger</b>	<b>Unit</b>	<b>7280 CENTORA</b>	<b>7282 CENTORA</b>
Enclosed system, electrohydraulically pivotable		yes	yes
Unloading also in partially turned-in position, and without threshing unit being engaged		yes	yes
Unloading (depending on conditions)	sec.	110	121
Unloading height <b>(G)</b>	cm	440	440
Unloading auger diameter	cm	33	33



1

Engine	Unit	7280 CENTORA	7282 CENTORA
Type, AGCO SISU POWER		84 AWI 748	84 AWI 680
Speed	rpm	2100	2100
Volume	litres	8.4	8.4
Number of cylinders	units	6	6
Gross power* (with Power Boost**)	HP	348 (375)	375
Gross power* (with Power Boost**)	kW	256 (276)	276
Maximum power***	HP	381	404
Maximum power***	kW	280	297
Engine oil, capacity	litres	27	27
Rotary screen	units	1	1
Self-cleaning main filter on air intake		yes	yes
Fuel tank, capacity	litres	750	750
AdBlue tank, capacity	litres	85	85
Coolant	litres	45	45

\* Gross power at 2100 rpm according to ECE R 120.

\*\* Power Boost ensures additional capacity during unloading. Through a signal from the unloading system the engine output is increased by 27 HP / 20 kW during unloading.

\*\*\* Maximum power at 1950 rpm according to ECE R 120.

Gear oil	Unit	7280 CENTORA	7282 CENTORA
Gearbox contains	litres	9.5	9.5
Coupler housing for oil motor	litres	1.5	1.5
Final drives contain	litres	6	6

Transmission				Unit	7280 CENTORA	7282 CENTORA
Hydrostatic transmission					yes	yes
4-speed, electric gearshift					yes	yes
Speed	1. gear	Forward	km/h	0-6	0-6	
		Reverse	km/h	0-3*	0-3*	
	2. gear	Forward	km/h	0-12	0-12	
		Reverse	km/h	0-6	0-6	
	3. gear	Forward	km/h	0-20	0-20	
		Reverse	km/h	0-10	0-10	
	4. gear	Forward	km/h	0-25**	0-25**	
		Reverse	km/h	0-12	0-12	

\*Reverse speed ranges up to 6 km/h when the threshing unit is engaged.

\*\* Applies to all countries except Germany where max. speed is 20 km/h.

Brakes	7280 CENTORA	7282 CENTORA
Hydraulically activated independent brakes	yes	yes
Electric/mechanical parking brake	yes	yes

Operator cab	7280 CENTORA	7282 CENTORA
Integrated operator environment with rubber suspension for platform and cab	yes	yes
Electrical control of all functions	yes	yes
DATAVISION	yes	yes
Fully automatic air conditioning	yes	yes
"Sealed Beams" light system with 10 fixed lamps for cutting table, area in front of and to the right of the machine plus unloading auger	yes	yes
Deluxe seat	yes	yes

Hydraulic system	Unit	7280 CENTORA	7282 CENTORA
Decentralised, electrically controlled valve functions		yes	yes
Pump	units	3	3
Hydraulic orbitrol steering		yes	yes
Hydraulic system contains	litres	90	90
Hydraulic tank contains	litres	34	34

## 1.2.2 Tyre pressure

T005755

**NOTE:** Use only the tyres listed in the chart below or in the technical specifications of the combine.

Model	Tyre size	Make	Rim	Pressure, bar
<b>Traction wheels</b>				
7280 CENTORA	650/75 R32	CONTINENTAL	DW21Ax32	4.1
	680/85 R32	CONTINENTAL	DW21Ax32	3.2
	800/65 R32	GOODYEAR	DW27Ax32	2.0
	900/55 R32	GOODYEAR	DW27Ax32	1.9
	900/60 R32	MICHELIN	DW27Ax32	2.0
	1050/50 R32	MICHELIN	DW36Ax32	1.9
7282 CENTORA	650/75 R32	CONTINENTAL	DW21Ax32	4.1
	680/85 R32	CONTINENTAL	DW21Ax32	3.2
	800/65 R32	GOODYEAR	DW27Ax32	2.0
	900/55 R32	GOODYEAR	DW27Ax32	1.9
	900/60 R32	MICHELIN	DW27Ax32	2.0
	1050/50 R32	MICHELIN	DW36Ax32	1.9
7280 AL CENTORA	620/75 R34	GOODYEAR	DW20Ax34	4.0
	800/65 R32	GOODYEAR	DW27Ax32	3.0
	900/55 R32	GOODYEAR	DW27Ax32	1.9
7282 AL CENTORA	620/75 R34	GOODYEAR	DW20Ax34	4.0
	800/65 R32	GOODYEAR	DW27Ax32	3.0
	900/55 R32	GOODYEAR	DW27Ax32	1.9
<b>Rear wheels</b>				
7280 CENTORA	600/55-26.5	TRELLEBORG	20.0x26.5	1.5
	500/60-26.5	TRELLEBORG	16.0x26.5	2.2
7282 CENTORA	600/55-26.5	TRELLEBORG	20.0x26.5	1.5
	500/60-26.5	TRELLEBORG	16.0x26.5	2.2

1

Model	Tyre size	Make	Rim	Pressure, bar
<b>Rear wheels, four-wheel drive</b>				
7280 CENTORA	600/55-26.5	TRELLEBORG	20.0x26.5	1.5
	500/60-26.5	TRELLEBORG	16.0x26.5	2.2
7282 CENTORA	600/55-26.5	TRELLEBORG	20.0x26.5	1.5
	500/60-26.5	TRELLEBORG	16.0x26.5	2.2
<b>Wheels, table trailer</b>				
Without brakes	185/60R12		6.00lx12H12	6.5
With brakes	195/50R13		5.5Jx13H2	6.5

**WARNING:**

*Twin wheels/dual wheels must not be fitted to the machine. AGCO disclaims all liability resulting from the use of equipment not approved by AGCO.*

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)