

# Operator's Manual

---

*Combine*

*FENDT 8300*

*FENDT 8350*

*+ Auto Level*

*+ Rotary Separator*



# Contents

<b>1</b>	<b>General Information</b>	<b>9</b>
1.1	Appropriate Use	11
1.2	Preface	12
1.3	Product Identification	13
1.4	Sectional Drawing and Parts Identification	14
<b>2</b>	<b>Safety</b>	<b>17</b>
2.1	General Safety Precautions	18
2.2	Attention - Warning Symbols	19
2.3	Safety Precautions	20
2.4	Road Transport	22
2.5	CE Marking and Type Plate on the Combine	23
2.6	Warning/Instruction decals	34
2.7	Position of CE Markings and Type Plate	39
<b>3</b>	<b>Operation, Controls and Cab</b>	<b>43</b>
3.1	Before Start	45
3.2	Operator Cab, Arrangement and Controls	48
	Optional Extra	50
3.3	Safety Precautions	51
3.4	Starting and Stopping the Engine	52
	Starting the engine	52
	Stopping the engine	53
3.5	Drive Controls	54
	Multi-Function Lever	54
	Adjustable Armrest	55
	Changing Gears	55
	Reduced Engine Revolutions in Road Transport (Speed Matching System)	56
	Steering column	57
	Brakes	57
	Adjustment of Operator Seat	58
	Adjustment of Air-Suspended Seat	58
	Ladder	59
	Removable Ladder	59
	Lights	60
	Main Light and Work Light	60
3.6	Operator Cab, Ventilation	61
	Air-Conditioning	61
	Using the Air-Conditioning	61
3.7	Printer	62
	Exchanging Paper and Ribbon in Printer	62
	Inserting the Paper Roll	62
	Fitting the Ribbon	62
3.8	Four-Wheel Drive	63
	Activating Four-Wheel Drive	63
	Forward Speed	63
	Operation of Four-Wheel Drive	64
	Service	64
3.9	Other Optional Extra	65
	Reversing Camera	65
	Electrically Adjustable Rearview Mirrors	65
<b>4</b>	<b>Operation, FIELDSTAR®</b>	<b>67</b>
4.1	Safety Precautions	69
4.2	FIELDSTAR®	71
	Menu Structure and Operation	71
	Operating FIELDSTAR® on Terminal	72

# Contents

---

	Operating the Terminal by Remote Control in the Multi-Function Lever .....	73
	Contrast and Brightness Control .....	74
	Cleaning the Terminal .....	74
	Data Cards .....	75
	FIELDSTAR® Menu Structure .....	75
<b>4.3</b>	<b>Harvest Menu .....</b>	<b>77</b>
<b>4.4</b>	<b>Main Menu .....</b>	<b>81</b>
<b>4.5</b>	<b>Monitoring .....</b>	<b>83</b>
	Shaft Speeds .....	83
	Engine Monitoring/Alarm .....	83
	Engine Safety Alarm .....	84
	Information .....	84
	Shaft Speeds .....	85
<b>4.6</b>	<b>Harvesting Data .....</b>	<b>87</b>
	Accumulated Machine Data .....	87
	Trip Data and Field Data .....	87
	4.6.1 Data Logging in General .....	88
	4.6.2 Using Data Logging .....	90
	Creating a New Field Job .....	90
	Starting a Job .....	92
	Field Map for a Job .....	94
	Data Logging Messages .....	96
	4.6.3 Data Logging Setup .....	98
	Marker Setup .....	99
	Selecting Position Data .....	100
	Setup of Logging Rate .....	100
	4.6.4 Using Markers .....	101
<b>4.7</b>	<b>Operator Manual .....</b>	<b>103</b>
	Harvest Settings .....	103
	Routine Servicing .....	103
	FIELDSTAR® .....	103
<b>4.8</b>	<b>Diagnostics .....</b>	<b>105</b>
	Electric Diagnostics .....	105
	Yield Meter .....	105
	System Information .....	105
	System Setup .....	105
	Programming Computer .....	105
	Control .....	105
	GPS Information .....	106
	DGPS Information .....	107
	Programming .....	109
	Diagnosis .....	109
	Screen Calibration (Touch Calibration) .....	109
<b>4.9</b>	<b>Coding .....</b>	<b>111</b>
	Clock Adjustment .....	111
	Language .....	111
	Area Measuring .....	112
	Table Calibration .....	113
	Returns Volume .....	113
	Grain loss monitor .....	113
	Concave Calibration .....	114
	Constant Flow .....	114
	Wheel Track and Auto Level Combine .....	114
	Coding of Electrical Straw Deflectors .....	115
	Straw chopper vibrations .....	115
	Lead Time and Lag Time .....	116
	Calibration of Actuator for Electrical Sieves .....	117
<b>4.10</b>	<b>Settings .....</b>	<b>119</b>
	Harvest Settings .....	119
	Table Settings .....	122

# Contents

Machine Settings, . . . . .	124
<b>4.11 Returns Volume Monitor. . . . .</b>	<b>126</b>
Coding, . . . . .	126
<b>4.12 Grain Loss Monitoring . . . . .</b>	<b>127</b>
Sensors . . . . .	127
Adjustment of Grain Loss Sensors, . . . . .	127
<b>4.13 Shaft Alarm Calibration. . . . .</b>	<b>128</b>
<b>4.14 Straw Chopper Vibrations. . . . .</b>	<b>129</b>
Coding . . . . .	129
<b>4.15 Yield Meter. . . . .</b>	<b>130</b>
4.15.1 Yield meter (Isotopic) . . . . .	130
Measuring Principle . . . . .	130
Mass Flow Measuring . . . . .	130
Yield Meter Status . . . . .	131
Using the Yield Meter. . . . .	131
Calibration of Yield Meter . . . . .	131
4.15.2 Micro-Trak Yield Meter . . . . .	132
Measuring Principle . . . . .	132
Zero Point for Micro-Trak Yield Meter . . . . .	132
Calibration of Micro-Trak Yield Meter . . . . .	133
Slope Compensation for Micro-Trak Yield Meter . . . . .	133
4.15.3 Yield Meter Calibration. . . . .	134
<b>4.16 Moisture Meter . . . . .</b>	<b>136</b>
Continuous Moisture Measuring . . . . .	136
Measuring Principle . . . . .	136
Using the Moisture Meter . . . . .	136
Cleaning the Moisture Meter . . . . .	137
Calibration of Moisture Meter. . . . .	138
<b>4.17 Cutting Height Control . . . . .</b>	<b>140</b>
Cutting Height Control Setting and Operation . . . . .	140
Coding of Table. . . . .	141
<b>4.18 Field Pressure Control. . . . .</b>	<b>142</b>
Field Pressure Control Setting and Operation . . . . .	142
<b>4.19 Auto Level Table . . . . .</b>	<b>144</b>
Bleeding . . . . .	144
Coding of Auto Level Table. . . . .	145
Calibration of Table Angle. . . . .	145
<b>4.20 Operation of Auto Level Table . . . . .</b>	<b>146</b>
Manual Control . . . . .	146
Levelling at Turns . . . . .	146
<b>4.21 Interaction Between Table Controls. . . . .</b>	<b>147</b>
<b>4.22 Checking and Adjusting the Ground Sensors. . . . .</b>	<b>148</b>
<b>4.23 Constant Flow . . . . .</b>	<b>149</b>
Start-up and Adjustment of Constant Flow . . . . .	149
Constant Flow Engagement. . . . .	151
<b>5 Operation, Auto Level Combine . . . . .</b>	<b>153</b>
<b>5.1 Safety Precautions. . . . .</b>	<b>155</b>
Safety System . . . . .	156
<b>5.2 Combinations. . . . .</b>	<b>157</b>
Selecting Combination . . . . .	157
<b>5.3 Auto Level Combine . . . . .</b>	<b>158</b>
Manual Control of Auto Level Combine . . . . .	158
<b>5.4 Auto Level Combine/Table . . . . .</b>	<b>159</b>
Combine . . . . .	159
Transport, . . . . .	159
Auto Level table . . . . .	160
<b>5.5 Calibration of Auto Level Combine . . . . .</b>	<b>161</b>

# Contents

---

	Errors during Calibration .....	162
<b>5.6</b>	<b>Coding of Auto Level Table .....</b>	<b>162</b>
	Zero Cutting Height .....	162
<b>5.7</b>	<b>Attachment/Removal of Table .....</b>	<b>163</b>
<b>5.8</b>	<b>Operation of Auto Level Combine/Auto Level Table .....</b>	<b>164</b>
	Combinations .....	164
	Priority of Hydraulic Functions .....	165
<b>5.9</b>	<b>Safety System, Auto Level .....</b>	<b>166</b>
	Automatic Control of the Tilt Sensor Function .....	166
	Safety System .....	166
	Hose Breach Protection for Auto Level Hydraulics .....	167
<b>5.10</b>	<b>Troubleshooting .....</b>	<b>168</b>
	Mechanical Connections .....	168
	Checking Sensor Adjustment and Inclinator .....	168
	Machine Not Levelling Correctly .....	169
<b>5.11</b>	<b>Servicing and User Tips .....</b>	<b>170</b>
	Retrofit of New FIELDSTAR® Auto Level Job Computer and Sensors .....	170
	Unintentional Use of Manual Keys in Automatic Mode .....	170
	Diagnostics - Auto Level Combine Functions and Sensors .....	170
<b>6</b>	<b>Engine .....</b>	<b>171</b>
<b>6.1</b>	<b>Safety Precautions .....</b>	<b>173</b>
<b>6.2</b>	<b>Engine Types .....</b>	<b>174</b>
<b>6.3</b>	<b>Air-Intake .....</b>	<b>174</b>
	Filter System .....	174
<b>6.4</b>	<b>Cooling System .....</b>	<b>175</b>
	Rotary Screen and Dust Aspirator .....	175
	Coolers .....	175
	Coolant .....	176
	Checking the Fan Belt Tension .....	176
<b>6.5</b>	<b>Fuel System .....</b>	<b>177</b>
	Filter change .....	178
<b>6.6</b>	<b>Engine Oil/Change .....</b>	<b>179</b>
	Oil and Filter Change .....	179
<b>6.7</b>	<b>Cleaning the Engine Compartment .....</b>	<b>179</b>
<b>6.8</b>	<b>Electronic Engine Management .....</b>	<b>180</b>
<b>6.9</b>	<b>Engine Trouble Shooting .....</b>	<b>180</b>
	EEM3 Electronic Engine Management - Failure Codes (Self-Diagnosis) .....	180
<b>7</b>	<b>Cutting Tables .....</b>	<b>183</b>
<b>7.1</b>	<b>Safety Precautions .....</b>	<b>185</b>
<b>7.2</b>	<b>Attachment of Table, Standard and Auto Level .....</b>	<b>186</b>
	Alignment of Table .....	187
<b>7.3</b>	<b>Removal of Table .....</b>	<b>188</b>
	Table Trailer .....	188
	Attachment of Combine and Trailer .....	189
	Supports .....	189
<b>7.4</b>	<b>Reel .....</b>	<b>190</b>
	Reel Adjustment Up/Down, Fore/Aft .....	190
	Bleeding .....	190
	Reel Rotation .....	191
	Reel Tine Bars .....	191
	Adjustment of Reel in the Table .....	191
<b>7.5</b>	<b>Knife .....</b>	<b>192</b>
	Knife and Knife Drive .....	192
	Knife Adjustment .....	192
<b>7.6</b>	<b>Feeding .....</b>	<b>193</b>

# Contents

Table Auger	193
Cut-Off Strip	193
Replacement of Feathering Fingers	193
Auger Flight Extensions, 20-22-25-30' Tables	193
Reversing	194
<b>7.7 Transmission</b>	<b>195</b>
PowerFlow Table, Knife Drive and Table Auger	195
Slip Clutch for Table Auger	195
<b>7.8 PowerFlow Table</b>	<b>196</b>
Inspection and Start-Up of PowerFlow Belts	196
Adjustment of Belts	196
Front Scrapers	197
Rear Scrapers and Adjustment of Bearing Housings	197
Table Bottom	197
Cleaning	198
<b>7.9 Crop Lifters</b>	<b>198</b>
Using Crop Lifters	198
<b>7.10 Vertical Knives, Rape Auger and Straw Dividers</b>	<b>199</b>
Vertical Knife	199
Mounting of Vertical Knife	199
Rape Auger	199
Torpedo Divider and Straw Divider Bow	200
Mounting of Straw Dividers	200
Adjustment of Torpedo Divider	200
<b>7.11 Fixed Table Auger Fingers</b>	<b>201</b>
Using Fixed Table Auger Fingers	201
High Table Sides	201
<b>7.12 Main crop elevator</b>	<b>202</b>
Crop Elevator Chain	202
Transmission for Table	202
Stone Trap	202
Initial Adjustment of Cutting Height Indication	203
<b>8 Operation of Machine and Cutting Table</b>	<b>205</b>
<b>8.1 Safety Precautions</b>	<b>207</b>
<b>8.2 Operation of Table</b>	<b>208</b>
Table Height and Table Automatic Control	208
Cutting Height Control	209
Field Pressure Control	209
Preset Cutting Height	210
Auto Level Table	210
Table Engagement - Emergency Stop	211
Slip Clutch	211
<b>8.3 Threshing Unit Transmission</b>	<b>212</b>
Threshing Unit Engagement	212
Cylinder Variator	212
Turning Tool for Cylinder	213
<b>8.4 Concave Setting, Electrically Adjustable</b>	<b>214</b>
Operation of Concave	214
Concave Setting	214
<b>8.5 Threshing</b>	<b>216</b>
Concave Filler Plates	216
Straw Walkers	216
Rear Beater Curtain	217
<b>8.6 Straw Chopper and Spreader Hood</b>	<b>218</b>
Straw chopper	218
Adjustment of Spreader Hood	219
Counter Knives and Cross Bar	220
Replacement of Knives	221

# Contents

---

<b>8.7</b>	<b>Fanning Mill and Sieves</b> .....	<b>222</b>
	Fanning Mill .....	222
	Shaker Shoe .....	222
	Shaker Shoe with Electrical Sieves .....	223
	Manual Adjustment of Sieves .....	223
	Cleaning of Sieves and Main Grain Pan .....	224
	Cleaning the Sieves .....	224
	Shaker Shoe Light .....	225
	Special Sieves .....	226
<b>8.8</b>	<b>Internal Grain Transport</b> .....	<b>227</b>
	Auger Housing/Elevators .....	227
	Returns Thresher .....	227
	Tank Filling Auger .....	228
	Grain Tank .....	229
	Unloading Auger .....	230
	Unloading Auger Clutch .....	230
	Unloading Tube .....	231
<b>8.9</b>	<b>Rotary Separator</b> .....	<b>232</b>
	Change of Rotor Revolutions .....	232
	Concave Setting .....	232
<b>8.10</b>	<b>Straw hood</b> .....	<b>233</b>
	Alarm switch for straw hood blocked .....	233
	Blockage in straw hood .....	233
<b>8.11</b>	<b>Chaff Spreader</b> .....	<b>234</b>
	Setting .....	234
<b>8.12</b>	<b>Maize Threshing</b> .....	<b>235</b>
	Attachment of Maize Header .....	235
	Area measuring .....	235
	Main crop elevator .....	236
	Concave/Cylinder/Stone Trap .....	236
	Concave/Initial Settings .....	236
	Threshing cylinder .....	236
	Rotary separator .....	237
	Shaker Shoe .....	237
	Machine with Electrical Sieves .....	237
	Straw walkers .....	237
	Bottom Auger Cover Plate .....	238
	Scrapers .....	238
	Rear Beater Curtain .....	238
	Straw chopper .....	238
<b>8.13</b>	<b>Suggested Harvest Settings</b> .....	<b>239</b>
<b>8.14</b>	<b>Threshing</b> .....	<b>240</b>
<b>9</b>	<b>Transmissions</b> .....	<b>241</b>
<b>9.1</b>	<b>Safety Precautions</b> .....	<b>243</b>
<b>9.2</b>	<b>Adjustment of Transmissions</b> .....	<b>244</b>
	General .....	244
	Threshing Unit Clutch .....	244
	Hydrostatic Transmission .....	244
<b>9.3</b>	<b>Transmissions</b> .....	<b>245</b>
	Rear Beater .....	245
	Main Crop Elevator and Table .....	245
	Straw chopper .....	245
	Threshing cylinder .....	246
	Unloading Auger .....	246
	Shaker Shoe and Chaff Spreader Counter Drive, and Straw Walker Drive .....	247
	Filling and Returns System Countershaft .....	248
	Returns Elevator and Returns Thresher .....	248
	Tank Filling Elevator and Tank Filling Auger .....	249

# Contents

Dust aspirator	249
Rotary screen	250
Fanning Mill	251
Rotary Separator	251
Alternator and Fan	251
Air-conditioning	252
<b>9.4 Transmission Diagram, Left-Hand Side</b>	<b>254</b>
<b>9.5 Transmission Diagram, Right-Hand Side</b>	<b>256</b>
<b>10 Hydraulics</b>	<b>259</b>
10.1 Safety Precautions	261
10.2 Hydraulic System, Standard Combine	262
Hydrostatic Transmission	262
10.3 Hydraulic System, Four-Wheel Drive	263
Hydrostatic Transmission	263
10.4 Oil Change	264
Draining Oil	264
Refilling Oil	264
10.5 Filter Change	265
Return Oil Filter	265
Storage of Hydraulic System	265
10.6 Auxiliary Hydraulics	266
Functions and Auxiliary Hydraulics	266
Reel Adjustment Fore/Aft - Up/down	266
10.7 Hydraulics Diagram, Standard Combine	268
10.8 Hydraulics Diagram, Auto Level Combine	270
10.9 Hydraulics Diagram for Chaff Spreader	272
<b>11 Maintenance</b>	<b>273</b>
11.1 Safety Precautions	275
11.2 Undercarriage	277
Wheel Nut Torques	277
11.3 Tyre Pressure	278
11.4 Lubrication Chart	280
Daily/10 Hours (Red)	280
50 hours (blue)	280
100 hours (yellow)	280
200 hours (white)	281
11.4.1 Lubrication Chart	282
11.4.2 Lubrication Points, Auto Level Combine	284
11.5 Lubricants and Operating Fluids	285
11.6 Maintenance Required	286
11.7 Gear Oil Change	288
Gearbox	288
Final Drives	288
11.8 Air-Conditioning	289
Diagram for air-conditioning	289
Maintenance	289
11.9 Cleaning and Off-Season Storage	290
Cleaning	290
Off-season storage	291
Storage of Engine, Fuel System and Hydraulic System	292
Periodical Start-Up	292
Removal of Main Crop Elevator	293
Removal of Elevator Chains	293
After Off-Season Storage	293
11.10 Adjustment of Brakes	294



# Contents

---

Adjustment of Foot Brakes, Disc Brakes . . . . .	294
Adjustment of Parking Brake, Drum Brake . . . . .	294
<b>11.11 Dealer Servicing Schedule for FENDT Combine Range. . . . .</b>	<b>295</b>
<b>12 Electrical System . . . . .</b>	<b>301</b>
12.1 Safety Precautions . . . . .	303
12.2 Electrical System . . . . .	304
Charging System . . . . .	304
Electric Boxes and Main Switch . . . . .	304
12.3 External 12V connectors . . . . .	305
12.4 Electro-Hydraulic System . . . . .	307
Hydraulic safety . . . . .	307
12.5 Key to Signatures for Wiring Harness . . . . .	308
Wire Codes . . . . .	308
Component Codes . . . . .	308
12.6 Position of Connectors in Electric Box . . . . .	309
12.7 Fuses and Relays, Electric Box and Cab . . . . .	310
12.8 Key to Symbols . . . . .	312
12.9 Fuses, Alphabetical . . . . .	313
12.10 Fuse Ratings . . . . .	314
12.11 W-Connecting Points . . . . .	315
12.12 Diagrams survey . . . . .	316
12.13 Diagrams . . . . .	319
<b>13 Specifications . . . . .</b>	<b>365</b>
13.1 Dimensions and Specifications . . . . .	365
<b>14 Index . . . . .</b>	<b>369</b>

# 1. General Information

---

## Contents

1.1	Appropriate Use.....	11
1.2	Preface .....	12
1.3	Product Identification .....	13
1.4	Sectional Drawing and Parts Identification .....	14

# 1. General Information

---

# 1. General Information

---

## 1.1 Appropriate Use



### **Appropriate use:**

This self-propelled combine harvester is manufactured exclusively for usual agricultural purposes (appropriate use).

Any other use is considered as being contrary to the appropriate use. AGCO declines all liability in cases of physical damage or injuries resulting from non-appropriate use. The risk lies exclusively with the user.

The conformity and strict adherence to the operating, maintenance and repair requirements specified by AGCO are also essential factors for appropriate use.

This self-propelled combine harvester may be used, serviced and repaired only by personnel having full knowledge of its specific features and who are aware of the danger involved and the applicable safety rules (prevention of accidents).

It is the responsibility of the owner/user to ensure that prescribed safety precautions and other general technical, health and safety and road-safety rules are observed.

AGCO disclaims all liability to any claim resulting from the fitting of non-approved parts or accessories or unauthorised modification or alteration.

Customers are strongly recommended to contact an AGCO dealer in the event of after-sale problems and for any adjustments that may be necessary.

*In accordance with the Company's policy of continuous improvements to its products, alterations in the specifications may be made at any time without notice.*

*The Company accepts no responsibility for any discrepancies which may occur between the specifications of its machines and the descriptions thereof contained in its publications.*

*This machine has been designed and produced in conformity with the machine directive 98/37/EF. An EU declaration of conformity is supplied with the machine.*

This machine has been tested according to the

**EEC directive 77/311/EEC and ISO 5131-1982**

Noise level: FENDT 8300 RS = 78 dB (A)

Noise level: FENDT 8350 RS = 78 dB (A)

# 1. General Information

---

## 1.2 Preface

### **This Manual**

The purpose of this manual is to enable the owner/operator to handle and maintain the combine efficiently. Time spent in becoming familiar with the Operator's Manual now will save time in the field.

Wide variations in operation conditions make it impossible for the Company to make comprehensive or definite statements in its publications concerning performance and the use of its machines, or to accept liability for any damage which may result from errors or omissions.

The specifications and illustrations contained in this manual pertain to combines manufactured for specific countries. Due to differing laws and requirements in various countries, some apparent discrepancies may result between any particular combine and those depicted in this manual. Some accessories and optional equipment appearing in this manual are not necessarily available in all territories.

### **AGCO service**

During the warranty period, all maintenance and repair work must be carried out by the AGCO dealer who will carefully carry out detailed checks of the progress and performance of the new combine.

To obtain best results from an AGCO combine, it is important to continue regular servicing and periodical inspection after the warranty has expired. All major overhaul work on the combine must be carried out by a local AGCO dealer; an experienced technician will detect any problems which may arise between two overhauls.

Mechanical staff regularly follow training courses to update their knowledge of the product, maintenance and repair techniques and the use of special modern tools and equipment for troubleshooting. They receive regular Service Bulletins and have access to all the workshop manuals and technical publications required to carry out repairs or maintenance meeting the quality standards required by AGCO.

### *Warning concerning spare parts*

Parts other than original AGCO parts are likely to be of lower quality. AGCO disclaims all liability in the event of loss or damage arising as a result of such parts being fitted. The manufacturer's warranty may also become void, if such parts are fitted during the normal warranty period.

### **Warranty, pre-delivery check and installation**

The Company, when selling new goods to its Distributors, gives a warranty which, subject to certain conditions, guarantees that the goods are free from defects in material and workmanship. The Company's Distributors and Dealers are required to give the benefit of a similar warranty to the first retail purchaser of all new goods supplied by the Company, and users should inquire of the Distributor or Dealer from whom they purchase as to the terms of the warranty made available to them.

Before delivering a new combine to the Customer's premises, it is the responsibility of the Distributor to conduct a pre-delivery check of the machine. This consists of a series of detailed inspections, adjustments and functional checks, which should ensure that when received by the Customer the combine is ready to start work immediately.

Upon delivery the Distributor is required to instruct the Customer in the basic principles and operating procedures of the combine. This is termed Combine Installation, which should include instruction on controls and instruments, field settings, maintenance requirements, safety precautions and winter storage, and should preferably be undertaken in the presence of all who will be concerned with the operation and maintenance of the machine.

This manual is published for World wide distribution, and the availability of equipment shown either as basic or accessory varies according to the territory in which the combine is to be used. Details of equipment available in your area can be obtained from your AGCO Distributor/Dealer.

# 1. General Information

## 1.3 Product Identification

Always quote combine model and serial number in any communication to your Distributor/Dealer.

Keep this manual safely for convenient reference.

Combine model: FENDT \_\_\_\_\_

Serial number: \_\_\_\_\_

Table serial number: \_\_\_\_\_

Engine type: \_\_\_\_\_

Serial number: \_\_\_\_\_

Owner's name: \_\_\_\_\_

Address: \_\_\_\_\_

Installation date: \_\_\_\_\_

Dealer's name: \_\_\_\_\_

Address: \_\_\_\_\_



Fig. 1



Fig. 2




Fig. 3

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)