
WORKSHOP SERVICE MANUAL

FENDT

FENDT 8370 P

FENDT 8370 P AL

FENDT 8400 P

FENDT 8400 P AL



Workshop Manual for Fendt 8370 P / 8400 P Combine Series

1	Introduction - Specifications	13
1.1	Using the manual	15
1.1.1	Using the manual	15
1.2	General specifications	16
1.2.1	General specifications	16
1.2.2	Tyre pressure	19
1.3	Dimensions and weight	21
1.3.1	Dimensions and weight	21
1.4	Safety precautions	23
1.4.1	Safety precautions	23
1.4.2	Safety in the workshop	23
1.4.3	Safety - a word to the mechanic	23
1.4.4	Safety - danger, warning and caution	23
1.4.5	Safety decals	24
1.4.6	General	24
1.4.7	Personal safety	24
1.4.8	Considerations with regard to equipment	25
1.4.9	General considerations	26
1.4.10	Operational considerations	26
1.4.11	Maintenance techniques	27
1.5	Practical advice	29
1.5.1	Practical advice	29
1.6	Start-up instructions	33
1.6.1	General	33
1.6.2	Pre-delivery checks	33
1.6.3	Instruction of combine operator	35
1.7	Conversion tables	38
1.7.1	Conventional units of measurement	38
1.8	Locking and sealing agents	39
1.8.1	Locking and sealing agents	39
1.9	Wheel nut torques	40
1.9.1	Wheels	40
1.9.2	Bolts with metric threads	40
1.9.3	Nuts with metric threads	41
2	Cutting table	43
2.1	General	45
2.1.1	Cutting table, general	45
2.2	Knife drive - wobble box	46
2.2.1	Removal	46
2.2.2	Assembly	46
2.2.3	Reconditioning the wobble box	47
2.2.4	Positioning the double fingers, knife and crop lifters	53
2.3	Table auger	54
2.3.1	Removal	54
2.3.2	Assembly	55
2.3.3	Replacing the shaft on the right-hand side	55
2.3.4	Replacing the shaft on the left-hand side	56
2.3.5	Replacing the crankshaft	57
2.3.6	Replacing the feathering fingers, bearings and bushes	58
2.3.7	Adjusting the table auger and feathering fingers	59

2.4	Table body	60
2.4.1	Adjusting the cut-off strips	60
2.4.2	Adjusting and positioning the ground sensor - PowerFlow	61
2.5	Slip clutch and chain drive	63
2.5.1	Removal	63
2.5.2	Assembly	63
2.5.3	Replacing the bearings and sprockets	64
2.6	Countershaft	65
2.6.1	Removal	65
2.6.2	Assembly	66
2.7	PowerFlow table	67
2.7.1	PowerFlow Table	67
2.7.2	Removal, belts	67
2.7.3	Assembly, belts	70
2.7.4	Replacing the front rollers and bearings, scraper adjustment	71
2.7.5	Replacing the rear rollers and bearings, scraper adjustment	73
2.7.6	Replacing and aligning the bearing housing, rear rollers	74
2.7.7	Belt tensioning and running-in	75
3	Reel	79
3.1	Reel	81
3.1.1	Removal	81
3.1.2	Assembly	82
3.1.3	Replacing the reel tine bar and plastic bearings	83
3.1.4	Replacing the guide rollers, eccentric, guide ring and bearings	84
3.1.5	Replacing the reel plates	85
3.1.6	Replacing the reel tube, bearings	85
3.2	Oil motor and chain drive	86
3.2.1	Replacing the oil motor	86
3.2.2	Replacing the flow divider	86
3.3	Hydraulic cylinders	90
3.3.1	Replacing the cylinder – reel up/down	90
3.3.2	Replacement of cylinder – reel forward/back	91
3.3.3	Reconditioning of hydraulic cylinders	91
4	Main crop elevator	95
4.1	General	97
4.1.1	Main crop elevator, general	97
4.2	Main crop elevator	98
4.2.1	Removal	98
4.2.2	Assembly	99
4.2.3	Bearing block on machine frame	100
4.2.4	Replacement of lifting ram	100
4.2.5	Reconditioning of hydraulic cylinder	100
4.2.6	Replacing the cutting height preset sensor	101
4.3	Crop elevator chain	103
4.3.1	Crop elevator chain, general	103
4.3.2	Removal	103
4.3.3	Assembly	103
4.3.4	Replacement of slats	105
4.3.5	Replacing the slide rails in the crop elevator	105
4.3.6	Replacing the intermediate plate	106
4.4	Elevator chain top shaft	107
4.4.1	Removal	107
4.4.2	Assembly	108
4.4.3	Replacing the bearings	108
4.4.4	Replacing the sprockets	108
4.4.5	Replacing the shaft protection tube	110
4.5	Elevator chain front shaft	111
4.5.1	Removal	111
4.5.2	Assembly	111
4.5.3	Replacing the shaft, bearings and plate wheels	112

4.6	Elevator countershaft	113
4.6.1	Removal	113
4.6.2	Assembly	114
4.6.3	Replacing the bearings, belt pulley	114
4.7	Table clutch and chain drive	115
4.7.1	Removal	115
4.7.2	Assembly	115
4.7.3	Reconditioning the clutch	116
4.8	Adapter	117
4.8.1	Removal	117
4.8.2	Assembly	118
4.8.3	Replacing the cylinder/connecting rod	118
4.8.4	Reconditioning of hydraulic cylinder	118
4.8.5	Replacing the angle sensor	119
4.9	Hydraulic reversing	120
4.9.1	Removal	120
4.9.2	Assembly	120
5	Threshing unit	121
5.1	General	123
5.1.1	Threshing unit, general	123
5.2	Stone trap	124
5.2.1	Removal	124
5.2.2	Assembly	125
5.3	Concave	126
5.3.1	Removal	126
5.3.2	Assembly	127
5.3.3	Adjusting the concave laterally	127
5.3.4	Concave setting - initial setting	128
5.3.5	Replacing the actuator	128
5.3.6	Replacing the lead-in plate	129
5.3.7	Replacing the shaft for concave setting	130
5.4	Threshing cylinder	131
5.4.1	Removal	131
5.4.2	Assembly	132
5.4.3	Replacing the bearings	133
5.4.4	Replacing the rasp bars and backing bars	134
5.4.5	Replacing the shaft and cylinder spiders	134
5.5	Cylinder variator - table clutch	136
5.5.1	Removal, hydraulic variator	136
5.5.2	Assembly, hydraulic variator	137
5.5.3	Reconditioning the hydraulic variator pulley	137
5.5.4	Removal, mechanical variator	139
5.5.5	Assembly, mechanical variator	139
5.5.6	Reconditioning the mechanical variator pulley	140
5.5.7	Removal, magnetic clutch	141
5.5.8	Assembly, magnetic clutch	142
5.5.9	Reconditioning the magnetic clutch	143
5.6	Bracket for counter drive	146
5.6.1	Removal	146
5.6.2	Assembly and alignment	146
5.7	Rear beater	148
5.7.1	Removal	148
5.7.2	Assembly	149
5.7.3	Replacing the bearings	150
5.8	Rear beater concave	151
5.8.1	Removal	151
5.8.2	Assembly	151
5.9	Rotary separator cylinder	152
5.9.1	Removal	152
5.9.2	Assembly	153
5.9.3	Replacing the bearings	154

5.9.4	Replacing the rasp bars	155
5.10	Rotary separator concave	156
5.10.1	Removal	156
5.10.2	Assembly	157
5.10.3	Concave setting - initial setting	158
5.10.4	Replacing the shaft for concave setting	159
6	Straw walkers	161
6.1	General	163
6.1.1	Straw walkers, general	163
6.2	Straw walkers	164
6.2.1	Removal	164
6.2.2	Assembly	164
6.3	Crank - front	166
6.3.1	Removal	166
6.3.2	Fitting	167
6.3.3	Replacing the bearings	167
6.4	Crank - rear	169
6.4.1	Removal	169
6.4.2	Fitting	169
6.4.3	Replacing the bearings	169
7	Shaker shoe - Fanning mill	171
7.1	General	173
7.1.1	Shaker shoe - fanning mill, general	173
7.2	Fanning mill	174
7.2.1	Removal	174
7.2.2	Assembly	175
7.2.3	Replacing the fan blades	175
7.2.4	Replacing the fanning mill deflectors	176
7.2.5	Replacement of seals	177
7.3	Main grain pan frame	178
7.3.1	General	178
7.3.2	Removal	178
7.3.3	Assembly	179
7.3.4	Replacing the swivel arm and bearings	180
7.3.5	Replacing the seals	181
7.4	Second grain pan	182
7.4.1	Removal	182
7.4.2	Assembly	182
7.4.3	Replacing the swivel arm and bearings	183
7.4.4	Adjusting second grain pan	184
7.5	Top shaker shoe	186
7.5.1	Removal	186
7.5.2	Assembly	187
7.5.3	Replacing the swivel arm and bearings	188
7.5.4	Replacement of seals	189
7.5.5	Replacing and calibrating the actuator - sieves	189
7.6	Bottom shaker shoe	191
7.6.1	Removal	191
7.6.2	Assembly	192
7.6.3	Replacing the swivel arm and bearings	193
7.6.4	Replacing the seals	193
7.6.5	Electric sieve setting – initial setting	193
7.7	Bottom augers	194
7.7.1	Bottom augers	194
7.7.2	Removal	194
7.7.3	Assembly	195
7.8	Eccentric drive	196
7.8.1	Removal	196
7.8.2	Assembly	197
7.8.3	Adjusting the connecting rod / aligning the shaker shoes	198

7.8.4	Replacing the connecting rod bearing	199
7.8.5	Replacing the bearings and eccentric shaft	200
7.9	Transmissions	201
7.9.1	Replacing and reconditioning the fanning mill variator	201
7.9.2	Adjusting the fanning mill variator	202
7.9.3	Replacing and reconditioning the counter drive	203
8	Elevators	205
8.1	Tank filling elevator	207
8.1.1	Removal	207
8.1.2	Assembly	208
8.1.3	Replacing the top shaft, bearings and sprockets	209
8.1.4	Replacement of bottom sprocket	210
8.1.5	Replacing the elevator chain	210
8.1.6	Moisture sensor	211
8.1.7	Yieldmeter sensor	211
8.2	Returns elevator	212
8.2.1	Removal	212
8.2.2	Assembly	213
8.2.3	Replacing the top shaft, bearings and sprockets	213
8.2.4	Replacing the bottom sprocket	214
8.2.5	Replacing the elevator chain	214
8.2.6	Returns volume sensor	214
8.3	Returns thresher	215
8.3.1	Removal	215
8.3.2	Fitting	215
8.3.3	Replacing the sprockets	215
8.3.4	Replacement of threshing cylinder	216
8.3.5	Reconditioning the right-angle gear	216
8.4	Tank filling auger	219
8.4.1	Removal	219
8.4.2	Fitting	219
8.4.3	Replacing the top bearing	219
8.4.4	Reconditioning the right-angle gear	220
8.5	Transmission	221
8.5.1	Replacing the shaft, bearings and sprockets	221
9	Engine	223
9.1	General	225
9.1.1	Engine, general	225
9.2	Replacing the engine	226
9.2.1	Removing the engine assembly	226
9.2.2	Fitting the engine assembly	228
10	Unloading auger - Grain tank	231
10.1	Unloading auger - horizontal	233
10.1.1	Removal	233
10.1.2	Assembly	233
10.2	Unloading auger - vertical	235
10.2.1	Removal	235
10.2.2	Assembly	235
10.2.3	Reconditioning the right-angle gear	236
10.3	Unloading tube - horizontal	237
10.3.1	Removal	237
10.3.2	Assembly	237
10.4	Unloading tube - vertical	238
10.4.1	Removal	238
10.4.2	Assembly	238
10.4.3	Replacing the swivel bearing	239
10.4.4	Replacing the hydraulic cylinder	240
10.4.5	Reconditioning of hydraulic cylinder	240

10.5 Unloading tube elbow	241
10.5.1 Removal	241
10.5.2 Assembly	241
10.5.3 Reconditioning the right-angle gear	242
10.6 Bottom auger and cover plate	244
10.6.1 Removal	244
10.6.2 Fitting	245
10.6.3 Replacing the bearings, safety clutch	245
10.7 Transmission	247
10.7.1 Replacing the unloading auger shaft, bearings	247
10.7.2 Replacing and reconditioning the magnetic clutch	248
10.8 Grain tank covers	250
10.8.1 Removal	250
10.8.2 Assembly	251
11 Drive unit	253
11.1 Radiator – intercooler	255
11.1.1 Removal	255
11.1.2 Fitting	256
11.2 Oil cooler	257
11.2.1 Removal	257
11.2.2 Assembly	257
11.3 Fuel cooler	258
11.3.1 Removal	258
11.3.2 Assembly	258
11.4 Condenser – air conditioning	259
11.4.1 Removal	259
11.4.2 Assembly	259
11.5 Rotary screen	260
11.5.1 Removal	260
11.5.2 Assembly	261
11.5.3 Adjusting the rotary screen and cleaning blade	262
11.5.4 Replacing the drive shaft and clutch	263
11.6 Dust aspirator	266
11.6.1 Removal	266
11.6.2 Assembly	267
11.7 Hydrostatic pump	268
11.7.1 Removal	268
11.7.2 Assembly	270
11.7.3 Tensioning device	271
11.8 Auxiliary hydraulic pump	272
11.8.1 Removal	272
11.8.2 Fitting	272
11.9 Hydraulic pump - Maxi Spreader	273
11.9.1 Removal	273
11.9.2 Assembly	273
11.10 Hydraulic oil tank	274
11.10.1 Removal	274
11.10.2 Fitting	274
11.11 Fuel tank	275
11.11.1 Removal	275
11.11.2 Fitting	275
11.11.3 Tank gauge	275
11.12 Diesel additive and dosing equipment	276
11.12.1 Removal	276
11.12.2 Assembly	276
11.12.3 Supply module	276
11.12.4 Dosing module	277
11.12.5 Tank sensor	277
11.13 Compressor – air conditioning	278
11.13.1 Removal	278
11.13.2 Assembly	278

11.14 Power take-off	279
11.14.1 Removal	279
11.14.2 Assembly	279
11.14.3 Replacing the clutch disc	280
11.14.4 Replacing the output shaft, bearing and hub	281
12 Transmissions	283
12.1 General	285
12.1.1 Transmissions, General	285
12.2 Countershaft	286
12.2.1 Removal	286
12.2.2 Assembly	288
12.2.3 Replacing the bearings	288
12.2.4 Reconditioning the safety clutch	289
12.3 Replacing the belts, right-hand side	290
12.3.1 Rear beater - counter drive, cylinder variator	290
12.3.2 Counter drive, variator - threshing cylinder	291
12.3.3 Rear beater - rotary separator	292
12.3.4 Fanning mill - fanning mill variator	292
12.3.5 Rear beater - fanning mill variator	293
12.3.6 Unloading auger shaft - unloading auger	293
12.3.7 Unloading auger shaft - rotary screen clutch	294
12.3.8 Unloading auger shaft - dust aspirator	295
12.3.9 Countershaft – counter drive, elevators	296
12.4 Replacing the chains, right-hand side	297
12.4.1 Counter drive, elevators - returns elevator	297
12.4.2 Counter drive, elevators - tank filling elevator	297
12.4.3 Counter drive, elevators - tank filling auger	298
12.4.4 Returns elevator - returns thresher	298
12.4.5 Reel drive	299
12.5 Replacing the belts, left-hand side	300
12.5.1 Countershaft - rear beater	300
12.5.2 Countershaft - counter drive, straw chopper	300
12.5.3 Counter drive - straw chopper	301
12.5.4 Engine - countershaft	301
12.5.5 Rear beater - countershaft, shaker shoe drive	303
12.5.6 Countershaft, shaker shoe drive - eccentric shaft	304
12.5.7 Countershaft, shaker shoe drive - straw walker crank	304
12.5.8 Rear beater - elevator chain top shaft / front shaft	305
12.5.9 Engine - unloading auger shaft	307
12.5.10 Engine - hydrostatic pump	307
12.5.11 PTO shaft – table countershaft	308
12.5.12 Table countershaft - knife drive	309
12.5.13 Countershaft - hydraulic pump, chaff spreader	309
12.6 Replacing the chains, left-hand side	310
12.6.1 Table countershaft - table auger	310
12.6.2 Table auger - belt rollers (PowerFlow)	310
12.6.3 Hydraulic motor, reversing - elevator countershaft	311
12.6.4 Bottom auger – unloading auger	312
13 Undercarriage	313
13.1 Auto Level final drive bracket	315
13.1.1 Removal	315
13.1.2 Assembly	316
13.1.3 Replacing the bushing	318
13.1.4 Replacing the hydraulic cylinder	319
13.1.5 Reconditioning of hydraulic cylinder	319
13.1.6 Adjusting the Auto Level potentiometer	320
13.2 Final drives	321
13.2.1 Removal	321
13.2.2 Assembly	322
13.2.3 Reconditioning the final drives	323

13.3 Gearbox	327
13.3.1 Removal	327
13.3.2 Assembly	328
13.3.3 Replacing the shifter cylinders and sensor	329
13.3.4 Adjusting the shifter cylinders and sensor	330
13.3.5 Replacing the lubrication pump	333
13.3.6 Replacing the shifter forks	334
13.3.7 Reconditioning the differential	335
13.3.8 Reconditioning the gearbox	338
13.4 Hydrostatic motor	342
13.4.1 Removal	342
13.4.2 Assembly	342
13.5 Brakes	343
13.5.1 Replacing the brake blocks	343
13.5.2 Replacement of brake discs	344
13.5.3 Bleeding the brakes	346
13.5.4 Brake pedals and main cylinder	346
13.5.5 Replacing the handbrake shoes	349
13.5.6 Adjustment of hydraulic hand brake	350
13.6 Rear axle	351
13.6.1 General	351
13.6.2 Removal	351
13.6.3 Assembly	352
13.6.4 Replacing the king pins and bushings	353
13.6.5 Replacing the steering cylinder	354
13.6.6 Reconditioning the hydraulic cylinder, rear axle	354
13.6.7 Adjusting the toe-in and steering deflection	355
14 Cab	359
14.1 Multi-function lever and control panel	361
14.1.1 Control panel	361
14.1.2 Armrest	362
14.1.3 Multi-function lever	363
14.2 Replacing the windscreen	365
14.2.1 Replacing the windscreen	365
14.3 Control panel in roof	366
14.3.1 Control panel in roof	366
14.4 Roof	367
14.4.1 Outer roof	367
14.4.2 Inspection doors	368
14.4.3 Replacing the windscreen wiper	368
14.4.4 Replacing the blower	369
14.4.5 Replacing the heating element/tap	370
14.4.6 Replacing evaporator	370
14.5 Troubleshooting – Climate control	371
14.5.1 Climate control faults in general	371
14.5.2 ECS – Electronic control unit	371
14.5.3 Troubleshooting table	371
15 Hydraulics	375
15.1 General	377
15.1.1 Hydraulics, general	377
15.1.2 Emptying and filling the hydrostatic system	379
15.1.3 Running in and bleeding the hydrostatic system	380
15.1.4 Running in and bleeding the auxiliary hydraulics	381
15.2 Hydraulic diagrams	382
15.2.1 Hydraulic diagrams	382
15.3 Hydrostatic system	385
15.3.1 Hydrostatic system	385
15.4 Gearshift	387
15.4.1 Gearshift	387

15.5 Handbrake	388
15.5.1 Hand brake	388
15.6 Auxiliary hydraulics	389
15.6.1 Auxiliary hydraulics	389
15.7 Cutting table	391
15.7.1 Cutting table	391
15.8 Auto Level	394
15.8.1 Auto Level - hydraulic cylinders	394
15.9 Reel	395
15.9.1 Reel	395
15.10 Steering	398
15.10.1 Steering - hydraulics	398
15.11 Cylinder variator	399
15.11.1 Cylinder variator - hydraulics	399
15.12 Unloading auger	400
15.12.1 Unloading auger - hydraulics	400
15.13 Reversing	401
15.13.1 Reversing - hydraulics	401
15.14 Chaff spreader	402
15.14.1 Chaff spreader - hydraulics	402
15.15 Maxi Spreader	403
15.15.1 Maxi Spreader - hydraulics	403
15.16 Troubleshooting - hydrostatic transmission	405
15.16.1 Hydrostatic transmission faults in general	405
15.16.2 Pump and motor specifications	405
15.16.3 Functional diagram, HPV pump - HMF motor	406
15.16.4 Connecting test equipment	408
15.16.5 Troubleshooting table	409
15.16.6 Checking the charge pump	410
15.16.7 Checking the high pressure valves	410
15.16.8 Checking the cold start valve	410
15.16.9 Checking the servo control	411
15.16.10 Checking the hydraulic pump	412
15.16.11 Checking the hydraulic motor	413
16 Electrical system	415
16.1 General	417
16.1.1 Electrical system, general	417
16.2 Description of FIELDSTAR	418
16.2.1 Description of FIELDSTAR	418
16.3 Electric box	419
16.3.1 Replacing the terminal	419
16.3.2 Replacing the job computers	419
16.4 Calibrations	422
16.4.1 Speed calibration	422
16.4.2 Calibrating the concave	422
16.4.3 Shaft alarm calibration	422
16.4.4 Calibrating the electrical sieves	423
16.4.5 Calibrating the electrical straw deflectors	423
16.4.6 Calibrating the Auto Level combine	423
16.4.7 Table calibration	424
16.5 Diagrams overview	426
16.5.1 Diagrams overview	426
16.6 Wiring diagrams	430
16.6.1 Wiring diagrams	430
16.7 Diagrams - computer input/output	444
16.7.1 Diagrams input/output	444
16.8 Diagramme ECU sensor connections	448
16.8.1 Diagramme ECU sensor connections, Stage 3B engine, 6 cylinders	448
16.9 Connectors	450
16.9.1 Connectors	450

16.10 W-connecting points	457
16.10.1 W-connecting points	457
16.11 Components	458
16.11.1 Components	458
16.12 Key to symbols	526
16.12.1 Key to symbols	526
16.13 Wiring overview	527
16.13.1 Wiring overview	527
17 Straw chopper	573
17.1 General	575
17.1.1 Replacing and calibrating the electric actuator – straw deflectors	575
18 General assembly instructions	577
18.1 Fitting gib-head keys	579
18.1.1 Fitting gib-head keys	579
18.2 Fitting tightening pins	580
18.2.1 Fitting tightening pins	580
18.3 Fitting hydraulic pipes and screw connections	581
18.3.1 Fitting hydraulic pipes and screw connections	581
18.4 Fitting a flanged bearing with locking collar	583
18.4.1 Fitting a flanged bearing with locking collar	583
18.5 Fitting sliding bushings	584
18.5.1 Fitting sliding bushings	584
18.6 Removing the revolution sensor	585
18.6.1 Removing the revolution sensor	585
18.7 Fitting tightening rings	586
18.7.1 Fitting tightening rings	586
19 Miscellaneous data	587
19.1 General	589
19.1.1 Miscellaneous data, general	589
19.2 Speeds - adjustment values	590
19.2.1 Speeds - adjustment values	590
19.3 Maintenance	591
19.3.1 Lubrication chart, intervals	591
19.3.2 Lubrication chart, right- and left-hand side	594
19.3.3 Lubrication chart, main crop elevator and front axle	596
19.3.4 Lubrication points, left-hand machine side	597
19.3.5 Lubrication points, right-hand machine side	611
19.3.6 Recommended lubricants	622
19.3.7 Gear	623
19.3.8 Air-conditioning	624

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com