

---

# *OPERATOR'S MANUAL*

---

*FENDT*

---

*FENDT 9470x*

---

*FENDT 9470x AL*

---



# Operator's Manual for Fendt 9470x Combine Series

<b>1</b>	<b>General Information</b>	11
1.1	<b>Dear Customer</b>	13
1.1.1	Appropriate Use	13
1.1.2	Changes and Improvements	13
1.1.3	Directives	13
1.1.4	Preface	14
1.1.5	EC Declaration of Conformity for Combine and Table	15
1.1.6	Product Identification	18
1.1.7	Sectional Drawing and Parts Identification	19
1.1.8	Disposal	21
<b>2</b>	<b>Safety</b>	23
2.1	<b>Safety</b>	25
2.1.1	General Safety Precautions	25
2.1.2	Attention - Warning Symbols	25
2.1.3	Safety Precautions	25
2.1.4	Road Transport	27
2.1.5	Warning/Instruction Decals	28
2.1.6	CE Marking and Type Plate on the Combine	31
2.1.7	Position of CE Markings and Type Plate	41
<b>3</b>	<b>Operation, Controls and Cab</b>	45
3.1	<b>Before Start</b>	47
3.1.1	Before Start	47
3.2	<b>Operator Cab</b>	49
3.2.1	Arrangement and Controls	49
3.2.2	Optional Extra	50
3.3	<b>Safety Precautions - on the Move</b>	51
3.3.1	Safety Precautions - on the Move	51
3.4	<b>Starting and Stopping the Engine</b>	52
3.4.1	Starting the engine	52
3.5	<b>Drive Controls</b>	55
3.5.1	Multifunction Lever	55
3.5.2	Adjustable Armrest and Control Panel	56
3.5.3	Gearshift	57
3.5.4	Reduced Engine Revolutions in Road Transport (Speed Matching System)	58
3.5.5	Steering column	58
3.5.6	Brakes	59
3.6	<b>Seats</b>	60
3.6.1	Adjustment of Operator Seat	60
3.6.2	Adjustment of air-suspended seat	60
3.6.3	EF declaration of conformity for the operator seat	61
3.6.4	Safety Switch in Operator Seat - (Operator Present Switch)	62
3.6.5	Instructor seat	63
3.7	<b>Mirrors</b>	64
3.7.1	Electrically adjustable rearview mirrors	64
3.7.2	Dead angle mirror	64
3.8	<b>Accessibility</b>	65
3.8.1	Ladder for Cab	65
3.8.2	Ladder for Engine Compartment	66
3.8.3	Cleaning the Windscreens	67

<b>3.9</b>	<b>Emergency Situations</b> .....	68
3.9.1	Emergency Exit .....	68
3.9.2	Fire Extinguisher .....	69
<b>3.10</b>	<b>Light and Lamps</b> .....	70
3.10.1	Lights .....	70
3.10.2	Main Light and Work Light .....	71
<b>3.11</b>	<b>Climate control</b> .....	72
3.11.1	Maintenance and overview .....	72
3.11.2	Operation of climate control .....	73
<b>3.12</b>	<b>Printer</b> .....	75
3.12.1	Exchanging Paper and Ribbon in Printer .....	75
3.12.2	Inserting the Paper Roll .....	75
3.12.3	Fitting the Ribbon .....	76
<b>3.13</b>	<b>Optional Extra</b> .....	77
3.13.1	Four-Wheel Drive .....	77
3.13.2	Reversing camera .....	79
3.13.3	Auto-Guide .....	79
<b>4</b>	<b>Operation, FIELDSTAR</b> .....	81
<b>4.1</b>	<b>Safety precautions</b> .....	83
4.1.1	Safety precautions, Operating FIELDSTAR .....	83
<b>4.2</b>	<b>FIELDSTAR</b> .....	84
4.2.1	DATAVISION, General Description .....	84
4.2.2	Operating FIELDSTAR on Terminal .....	86
4.2.3	Operating the Terminal by Remote Control in the Multi-Function Lever .....	87
4.2.4	Contrast and Brightness Control .....	88
4.2.5	Cleaning of terminal .....	88
4.2.6	Data card .....	89
4.2.7	DATAVISION, Menu Structure .....	89
<b>4.3</b>	<b>Harvest Menu</b> .....	91
4.3.1	Instrument Reading .....	91
<b>4.4</b>	<b>Main Menu</b> .....	95
4.4.1	Main menu structure .....	95
<b>4.5</b>	<b>Monitoring</b> .....	97
4.5.1	Monitoring in general .....	97
4.5.2	Shaft Speeds .....	99
4.5.3	Engine Monitoring/Alarm .....	99
4.5.4	Engine Safety Alarm .....	99
4.5.5	Information .....	100
4.5.6	Shaft Speeds .....	101
<b>4.6</b>	<b>Harvesting Data</b> .....	102
4.6.1	Standard data .....	102
4.6.2	Data Logging in General .....	103
4.6.3	Using Data Logging .....	104
4.6.4	Data Logging Setup .....	111
4.6.5	Using Markers .....	114
<b>4.7</b>	<b>Operator's Manual</b> .....	115
4.7.1	Harvest Settings .....	115
4.7.2	Routine Servicing .....	116
4.7.3	FIELDSTAR .....	116
<b>4.8</b>	<b>Diagnostics</b> .....	117
4.8.1	Troubleshooting in FIELDSTAR .....	117
<b>4.9</b>	<b>Coding</b> .....	124
4.9.1	Coding in general .....	124
4.9.2	Clock Adjustment .....	125
4.9.3	Language .....	125
4.9.4	Area Measuring .....	125
4.9.5	Table Calibration .....	127
4.9.6	Returns Volume .....	128
4.9.7	Grain Loss Monitor .....	128
4.9.8	Shaft alarm calibration .....	128
4.9.9	Concave Calibration .....	129

4.9.10	Constant Flow	129
4.9.11	Wheel Track and Auto Level Combine	129
4.9.12	Coding of Electrical Straw Deflectors	130
4.9.13	Lead Time and Lag Time	132
4.9.14	Calibration of actuator for electrical sieves	133
<b>4.10</b>	<b>Settings</b>	134
4.10.1	Harvest Settings	134
4.10.2	Table Settings	138
4.10.3	Machine Settings	141
<b>4.11</b>	<b>Returns Volume Monitor</b>	144
4.11.1	Returns volume	144
4.11.2	Coding	144
<b>4.12</b>	<b>Grain Loss Monitoring</b>	146
4.12.1	Sensors	146
4.12.2	Adjustment of Grain Loss Sensors	146
<b>4.13</b>	<b>Shaft Alarm Limits</b>	148
4.13.1	Shaft Alarm Calibration	148
<b>4.14</b>	<b>Yield Meter</b>	149
4.14.1	Yield Meter (Isotopic)	149
4.14.2	Micro-Trak Yield Meter	151
4.14.3	Yield Meter Calibration	153
<b>4.15</b>	<b>Moisture Meter</b>	155
4.15.1	Limitations in the use of the moisture meter	155
4.15.2	Continuous Moisture Measuring	155
4.15.3	Measuring Principle	155
4.15.4	Using the Moisture Meter	156
4.15.5	Cleaning the Moisture Meter	156
4.15.6	Calibration of moisture meter	157
<b>4.16</b>	<b>Cutting height control</b>	159
4.16.1	Adjustment and operation of cutting height control	159
4.16.2	Coding of table	162
<b>4.17</b>	<b>Field pressure control</b>	163
4.17.1	Adjustment and operation of field pressure control	163
<b>4.18</b>	<b>Interaction between the Table Controls</b>	165
4.18.1	Table controls, an outline	165
<b>4.19</b>	<b>Auto Level Table</b>	167
4.19.1	Principle of Auto Level table	167
4.19.2	Bleeding	168
4.19.3	Coding of Auto Level Table	169
4.19.4	Calibration of Table Angle	169
<b>4.20</b>	<b>Operation of Auto Level Table</b>	171
4.20.1	Using the Auto Level Table	171
<b>4.21</b>	<b>Ground sensors</b>	173
4.21.1	Checking and Adjusting the Ground Sensors	173
<b>4.22</b>	<b>Constant Flow</b>	175
4.22.1	Constant Flow functional description	175
4.22.2	Start-up and Adjustment of Constant Flow	176
4.22.3	Constant Flow Engagement	178
<b>5</b>	<b>Operation, Auto Level Combine</b>	181
<b>5.1</b>	<b>Safety precautions</b>	183
5.1.1	Safety precautions, operation of Auto Level Combine	183
5.1.2	Safety System	183
<b>5.2</b>	<b>Attachment of Auto Level Table</b>	184
5.2.1	Attachment of Table to Auto Level Combine	184
<b>5.3</b>	<b>Combinations</b>	185
5.3.1	Automatically or manually	185
5.3.2	Selecting Combination	185
5.3.3	Combinations for Auto Level combine and Auto Level table	185
5.3.4	Priority of hydraulic functions	187
<b>5.4</b>	<b>Auto Level</b>	188
5.4.1	Auto Level combine	188

5.4.2	Manual Control of Auto Level Combine	188
<b>5.5</b>	<b>Auto Level Combine/Table</b>	189
5.5.1	Combine	189
5.5.2	Transport	190
5.5.3	Auto Level Table	191
<b>5.6</b>	<b>Calibration</b>	192
5.6.1	Calibration of Auto Level Combine	192
5.6.2	Errors during Calibration	193
<b>5.7</b>	<b>Coding</b>	194
5.7.1	Coding of Auto Level Table	194
5.7.2	Zero Cutting Height	194
<b>5.8</b>	<b>Safety System</b>	195
5.8.1	Safety System, Auto Level	195
5.8.2	Automatic Control of the Tilt Sensor Function	195
5.8.3	About the system	196
5.8.4	Hose Breach Protection for Auto Level Hydraulics	196
<b>5.9</b>	<b>Troubleshooting</b>	197
5.9.1	Trouble shooting in general	197
5.9.2	Machine Not Levelling Correctly	198
<b>5.10</b>	<b>Servicing and User Tips</b>	200
5.10.1	Retrofit of new FIELDSTAR Auto Level Job Computer and Sensors	200
5.10.2	Unintentional Use of Manual Keys in Automatic Mode	200
5.10.3	Diagnostics - Auto Level Combine Functions and Sensors	201
<b>6</b>	<b>Engine</b>	203
<b>6.1</b>	<b>Safety precautions</b>	205
6.1.1	Safety Precautions, Engine	205
<b>6.2</b>	<b>Engines</b>	206
6.2.1	Engine Type	206
<b>6.3</b>	<b>Air-intake</b>	207
6.3.1	Filter System	207
<b>6.4</b>	<b>Cooling System</b>	208
6.4.1	Rotary Screen and Dust Aspirator	208
6.4.2	Coolers	209
6.4.3	Coolant	210
6.4.4	Checking the Fan Belt Tension	210
<b>6.5</b>	<b>Fuel System</b>	211
6.5.1	Fuel system	211
6.5.2	Filter Change	212
<b>6.6</b>	<b>SCR</b>	213
6.6.1	The SCR system in general	213
6.6.2	Components and functions	213
6.6.3	Filling and storing AdBlue	215
6.6.4	Filter Change	216
<b>6.7</b>	<b>Engine oil/change</b>	217
6.7.1	Oil and Filter Change	217
<b>6.8</b>	<b>Cleaning</b>	218
6.8.1	Cleaning of engine compartment	218
6.8.2	Vibration damper	218
<b>6.9</b>	<b>EEM3 Engine Management</b>	219
6.9.1	Electronic Engine Management and Monitoring	219
6.9.2	Engine Trouble Shooting (Self-Diagnosis)	220
6.9.3	EEM3 Codes	222
6.9.4	SCR failure codes	227
<b>7</b>	<b>Cutting Tables</b>	233
<b>7.1</b>	<b>Safety precautions</b>	235
7.1.1	Safety Precautions, Cutting Tables	235
<b>7.2</b>	<b>Attachment/Removal of Table</b>	236
7.2.1	Attachment of Table, Standard and Auto Level	236
7.2.2	Removal of Table	237
7.2.3	Supports	238

<b>7.3</b>	<b>Table trailer</b> .....	239
7.3.1	Attachment of combine and trailer .....	239
7.3.2	Table Trailer Brakes .....	239
<b>7.4</b>	<b>Reel</b> .....	240
7.4.1	Safety stop for reel .....	240
7.4.2	Reel Adjustment Up/Down, Fore/Aft .....	241
7.4.3	Bleeding .....	242
7.4.4	Reel Rotation .....	242
7.4.5	Reel tine bars .....	243
7.4.6	Adjustment of the Reel in the Table .....	243
<b>7.5</b>	<b>Knife</b> .....	244
7.5.1	Knife and Knife Drive .....	244
<b>7.6</b>	<b>Feeding</b> .....	245
7.6.1	Table auger .....	245
7.6.2	Cut-off strip and distribution strip .....	246
7.6.3	Replacement of Feathering Fingers .....	247
7.6.4	Auger Flight Extensions, 20-22-25-30' Tables .....	247
7.6.5	Reversing .....	248
<b>7.7</b>	<b>Transmission</b> .....	249
7.7.1	PowerFlow Table, Knife Drive and Table Auger .....	249
7.7.2	Slip Clutch for Table Auger .....	249
<b>7.8</b>	<b>PowerFlow Table</b> .....	250
7.8.1	PowerFlow belts .....	250
7.8.2	Inspection and Start-Up of PowerFlow Belts .....	250
7.8.3	Adjustment of belts .....	251
7.8.4	Scrapers, front .....	251
7.8.5	Scrapers, Rear, and Adjustment of Bearing Housings .....	252
7.8.6	Table bottom .....	252
7.8.7	Cleaning .....	253
<b>7.9</b>	<b>Crop Lifters</b> .....	254
7.9.1	Using Crop Lifters .....	254
<b>7.10</b>	<b>Vertical Knives, Rape Auger and Straw Dividers</b> .....	255
7.10.1	Vertical knife .....	255
7.10.2	Mounting of Vertical Knife .....	255
7.10.3	Rape auger .....	256
7.10.4	Folding torpedo dividers and bow dividers .....	256
7.10.5	Mounting of Straw Dividers .....	257
7.10.6	Adjustment of Torpedo Divider .....	257
<b>7.11</b>	<b>Fixed Fingers</b> .....	258
7.11.1	Fitting of fixed table auger fingers .....	258
7.11.2	Using Fixed Table Auger Fingers .....	258
7.11.3	High Table Sides .....	258
<b>7.12</b>	<b>Main crop elevator</b> .....	260
7.12.1	Elevator Chain .....	260
7.12.2	Transmission for Table .....	260
7.12.3	Stone Trap .....	261
7.12.4	Initial Adjustment of Cutting Height Indication .....	262
<b>8</b>	<b>Operation of Table and Threshing Unit</b> .....	263
<b>8.1</b>	<b>Safety precautions</b> .....	265
8.1.1	Safety Precautions, Operation of Machine and Cutting Table .....	265
<b>8.2</b>	<b>Operation of Table</b> .....	267
8.2.1	Table Height and Table Automatic Control .....	267
8.2.2	Cutting Height Control .....	268
8.2.3	Field Pressure Control .....	269
8.2.4	Preset cutting height .....	270
8.2.5	Auto Level Table .....	270
8.2.6	Table Engagement - Emergency Stop .....	271
<b>8.3</b>	<b>Threshing Unit Transmission</b> .....	272
8.3.1	Threshing unit engagement .....	272
8.3.2	Cylinder Variator .....	273
8.3.3	Turning Tool for Cylinder .....	273

<b>8.4</b>	<b>Concave Setting, Electrically Adjustable</b>	274
8.4.1	Operation of Concave	274
8.4.2	Concave Setting	274
<b>8.5</b>	<b>Threshing</b>	277
8.5.1	Concave filler plates	277
8.5.2	Rotors	277
<b>8.6</b>	<b>Straw Chopper and Spreader Hood</b>	279
8.6.1	Straw chopper	279
8.6.2	Adjustment of Spreader Hood	280
8.6.3	Counter Knives and Cross Bar	281
8.6.4	Replacement of Knives	283
<b>8.7</b>	<b>Fanning Mill and Sieves</b>	284
8.7.1	Fanning mill	284
8.7.2	Shaker shoe	284
8.7.3	Shaker Shoe with Electrical Sieves	285
8.7.4	Manual Adjustment of Sieves	285
8.7.5	Cleaning of main grain pan and sieves	286
8.7.6	Cleaning of main grain pan	287
8.7.7	Cleaning the Sieves	288
8.7.8	Shaker Shoe Light	290
8.7.9	Special sieves	290
<b>8.8</b>	<b>Internal Grain Transport</b>	291
8.8.1	Auger Housing/Elevators	291
8.8.2	Returns thresher	291
8.8.3	Tank filling auger	292
8.8.4	Grain tank	293
8.8.5	Unloading auger	295
8.8.6	Unloading Auger Clutch	296
8.8.7	Unloading tube	297
<b>8.9</b>	<b>Rotor Feeder</b>	298
8.9.1	Adjustment of Rotor Feeder	298
8.9.2	Rotor Feeder Concave	299
8.9.3	Reversing	299
<b>8.10</b>	<b>Straw hood</b>	300
8.10.1	Light in straw hood	300
<b>8.11</b>	<b>Chaff spreader</b>	301
8.11.1	Setting	301
<b>8.12</b>	<b>Maxi Spreader</b>	303
8.12.1	Adjustment and operation	303
8.12.2	Adjustment of sensors	304
<b>8.13</b>	<b>Maize Threshing</b>	305
8.13.1	Maize Threshing in General	305
8.13.2	Attachment of Maize Header	305
8.13.3	Area measuring	306
8.13.4	Main crop elevator	306
8.13.5	Concave/Initial Settings	307
8.13.6	Threshing cylinder	307
8.13.7	Rotor Feeder	307
8.13.8	Shaker shoe	308
8.13.9	Rotors	308
8.13.10	Bottom auger cover plate	309
8.13.11	Scrapers	309
8.13.12	Straw chopper	309
8.13.13	Maxi Spreader	310
<b>8.14</b>	<b>Harvest settings</b>	311
8.14.1	Suggested Harvest Settings	312
<b>8.15</b>	<b>Threshing</b>	316
8.15.1	Threshing Directions	317
<b>9</b>	<b>Transmissions</b>	319
<b>9.1</b>	<b>Safety precautions</b>	321
9.1.1	Safety Precautions, Transmissions	321

<b>9.2</b>	<b>Adjustment of Transmissions</b> .....	322
9.2.1	General .....	322
9.2.2	Threshing unit clutch .....	322
9.2.3	Hydrostatic transmission .....	323
<b>9.3</b>	<b>Transmissions</b> .....	324
9.3.1	Rear beater .....	324
9.3.2	Crop Elevator and Table .....	324
9.3.3	Straw chopper .....	325
9.3.4	Threshing cylinder .....	325
9.3.5	Unloading auger .....	326
9.3.6	Shaker shoe and chaff spreader counter drive .....	326
9.3.7	Countershaft for Rotors .....	327
9.3.8	Variator Belt for Rotors .....	327
9.3.9	Filling and Returns System Countershaft .....	328
9.3.10	Returns Elevator and Returns Thresher .....	328
9.3.11	Tank Filling Elevator and Tank Filling Auger .....	329
9.3.12	Dust aspirator .....	329
9.3.13	Rotary screen .....	330
9.3.14	Fanning mill .....	331
9.3.15	Rotor Feeder .....	331
9.3.16	Alternator and Fan .....	332
9.3.17	Climate control .....	332
<b>9.4</b>	<b>Transmission Diagrams</b> .....	333
9.4.1	Transmission Diagram, Left-Hand Side .....	333
9.4.2	Transmission Diagram, Right-Hand Side .....	335
<b>10</b>	<b>Hydraulics</b> .....	337
<b>10.1</b>	<b>Safety precautions</b> .....	339
10.1.1	Safety Precautions, Hydraulic System .....	339
<b>10.2</b>	<b>Hydraulic System</b> .....	340
10.2.1	Hydraulic system, standard combine .....	340
10.2.2	Hydraulic System, Four-Wheel Drive .....	341
<b>10.3</b>	<b>Oil change</b> .....	342
10.3.1	Draining and refilling hydraulic oil .....	342
<b>10.4</b>	<b>Filter Change</b> .....	343
10.4.1	Filter change in general .....	343
10.4.2	Return Oil Filter .....	343
10.4.3	Storage of Hydraulic System .....	344
<b>10.5</b>	<b>Auxiliary Hydraulics</b> .....	345
10.5.1	Auxiliary hydraulics in general .....	345
10.5.2	Functions and Auxiliary Hydraulics .....	345
10.5.3	Reel Adjustment Fore/Aft - Up/down .....	345
<b>10.6</b>	<b>Hydraulics Diagrams</b> .....	346
10.6.1	Hydraulics Diagram, Standard Combine .....	346
10.6.2	Hydraulics Diagram, Auto Level Combine .....	349
10.6.3	Hydraulics Diagram for Chaff Spreader .....	351
10.6.4	Hydraulics diagram for Maxi Spreader .....	352
<b>11</b>	<b>Maintenance</b> .....	355
<b>11.1</b>	<b>Safety precautions</b> .....	357
11.1.1	Safety Precautions, Maintenance .....	357
<b>11.2</b>	<b>Undercarriage</b> .....	359
11.2.1	Undercarriage in general .....	359
11.2.2	Wheel Nut Torques .....	359
11.2.3	Tyre Pressure .....	359
<b>11.3</b>	<b>Lubrication Intervals</b> .....	361
11.3.1	Lubrication chart, time intervals .....	361
11.3.2	Lubrication chart, right- and left-hand side .....	364
11.3.3	Lubrication chart, main crop elevator and front axle .....	366
11.3.4	Lubrication points, left-hand machine side .....	367
11.3.5	Lubrication points, right-hand machine side .....	382
11.3.6	Lubricants and Operating Fluids .....	397



<b>11.4 Maintenance Schedules</b> .....	398
11.4.1 Preliminary Service Inspections .....	398
11.4.2 Maintenance Required .....	399
<b>11.5 Oil Change, Gear</b> .....	402
11.5.1 Gearbox .....	402
11.5.2 Final drives .....	402
11.5.3 Right-angle gear for returns thresher .....	403
11.5.4 Right-Angle Gear for Rotors .....	403
<b>11.6 Climate control</b> .....	404
11.6.1 Diagram for Climate Control System .....	404
11.6.2 Maintenance .....	404
<b>11.7 Cleaning and Off-Season Storage</b> .....	405
11.7.1 Cleaning .....	405
11.7.2 Off-season Storage .....	406
11.7.3 Storage of Engine, Fuel System, SCR System and Hydraulic System .....	407
11.7.4 Periodical Start-Up .....	407
11.7.5 Removal of Crop Elevator .....	408
11.7.6 Removal of Elevator Chains .....	408
11.7.7 After Off-Season Storage .....	408
<b>11.8 Adjustment of Brakes</b> .....	409
11.8.1 Adjustment of Foot Brakes, Disc Brakes .....	409
11.8.2 Adjustment of Parking Brake .....	409
<b>12 Electrical System</b> .....	411
<b>12.1 Safety precautions</b> .....	413
12.1.1 Safety Precautions, Electric System .....	413
<b>12.2 Electrical System</b> .....	414
12.2.1 Charging system .....	414
12.2.2 Electric Boxes and Main Switch .....	415
12.2.3 External connectors 12V .....	416
<b>12.3 Electro-Hydraulic System</b> .....	418
12.3.1 Electro-Hydraulic System in General .....	418
<b>12.4 Key to Signatures for Wiring Harness</b> .....	419
12.4.1 Wire Codes .....	419
12.4.2 Component Codes .....	419
<b>12.5 Overview, Electric Box and Cab</b> .....	420
12.5.1 Position of Connectors in Electric Boxes .....	420
12.5.2 Fuses and Relays, Electric Box and Cab .....	421
<b>12.6 Wiring Diagrams</b> .....	423
12.6.1 Key to symbols .....	423
12.6.2 Diagrams Overview .....	424
12.6.3 Fuse Ratings .....	424
12.6.4 Components .....	425
12.6.5 Wiring Diagrams .....	434
<b>13 Specifications</b> .....	447
<b>13.1 Specifications</b> .....	449
13.1.1 Dimensions and Specifications .....	449

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)