

HYDRAULIC EXCAVATOR

**SHOP
MANUAL**

model

SK230(LC)VI

SK250(LC)VI

SK250NLCVI

INDEX

1	SPECIFICATION SECTION
2	MAINTENANCE SECTION
3	SYSTEM SECTION
4	DISASSEMBLY SECTION
5	TROUBLESHOOTING
6	ENGINE SECTION
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENT

SPECIFICATION

MAINTENANCE

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

OPT. E/G

KOBELCO

Book code No. S5LQ0011E①

SK230(LC)VI
SK250(LC)VI
SK250NLCVI

Index of Shop Manual

Book Code No.		Index No	Title
Distribution Year—Month			
S5LQ0111E 1999-12		MAINTENANCE SPECIFICATION	OUTLINE LQ01
S5LQ0211E 2000-02			SPECIFICATION LQ02
S5LQ0311E 1999-12			ATTACHMENT DIMENSION LQ03
S5LQ1111E 1999-12		MAINTENANCE	TOOLS LQ11
S5LQ1211E 2000-02			STANDARD MAINTENANCE TIME SCHEDULE LQ12
S5LQ1311E 1999-12			MAINTENANCE STANDARD AND TEST PROCEDURE LQ13
S5LQ2111E 1999-12		SYSTEM	MECHATRO CONTROL SYSTEM LQ21
S5LQ2211E 2000-02			HYDRAULIC SYSTEM LQ22
S5LQ2311E 2000-02			ELECTRICAL SYSTEM LQ23
S5LQ2411E① 2001-06			COMPONENTS SYSTEM LQ24
S5LQ2511E 1999-12			AIR-CONDITIONER SYSTEM LQ25
—			—
S5LQ3111E 2000-02		DISASSEMBLING	DISASSEMBLING AND ASSEMBLING LQ31
S5LQ3211E 2000-02			ATTACHMENT LQ32
S5LQ3311E① 2001-06			UPPER STRUCTURE LQ33
S5LQ3411E 2000-02			TRAVEL SYSTEM LQ34
S5LQ4111E 2000-02		TROUBLESHOOTING	MECHATRO CONTROL LQ41
S5LQ4211E 2000-02			HYDRAULIC LQ42
S5LQ4311E 2000-02			ELECTRICAL LQ43
S5LQ4411E 2000-02			ENGINE LQ44
S5LQ5111E 2000-02		E/G	ENGINE LQ51
		OPT.	MOUNTING THE BREAKER AND NIBBLER & BREAKER LQ63
LQ08-04501~ LL08-03001~			APPLICABLE MACHINES

KOBELCO

Book code No.

S5LQ01 11E

SHOP MANUAL

SK230 (LC)VI

SK250 (LC)VI **LQ01**

SK250 NL CVI

OUTLINE

TABLE OF CONTENTS

1. GENERAL PRECAUTIONS FOR MAKING REPAIRS 1
2. ESCAPING PROCEDURE IN CASE OF EMERGENCY 4
3. INTERNATIONAL UNIT CONVERSION SYSTEM 5

KOBELCO CONSTRUCTION MACHINERY CO., LTD.

Applicable Machines
LQ08-04501~
LL08-03001~

Revision	Date of Issue	Remarks
First edition	December, 1999	S5LQ0111E K

1. GENERAL PRECAUTIONS FOR MAKING REPAIRS



1.1 PREPARATION BEFORE DISASSEMBLING


- (1) Knowledge of operating procedure
Read Operator's Manual carefully to understand the operating procedure.
- (2) Cleaning machines
Clean machines of soil, mud, and dust before carrying into the service shop.
Carrying a soiled machine into the service shop, causes making less efficient work and damage of parts, and interferes with rust prevention and dust protection while reassembling.
- (3) Inspecting machines
Confirm the disassembling section before starting work, determine the disassembly procedure taking the conditions in work shop into account, and request to procure necessary parts in advance.
- (4) Recording
Record the following items to keep contact and prevent malfunction from recurring.
 - 1) Inspecting date, place
 - 2) Model name, Applicable machine No., Records on hour meter
 - 3) Trouble condition, place, cause
 - 4) Visible oil leakage, water leakage and damage
 - 5) Clogging of filters, etc., oil level, oil quality, oil contamination and looseness which can be inspected.
- (6) Examine the problems on the basis of operation rate with the last inspection date and records on hour meter.
- (5) Arrangement and cleaning in service shop
 - 1) Tools required for repair work.
 - 2) Specify places to put the disassembled parts on in advance.
 - 3) Prepare oil pans for leaking oil, etc.



1.2 SAFETY WHEN DISASSEMBLING AND ASSEMBLING

- (1) Safety
 - 1) Wear appropriate clothing, safety shoes, safety helmet, goggles, and clothes with long sleeves.
 - 2) Suspend warning tag "Don't operate" from lever, and begin preliminaries before getting down to work.
 - 3) Before starting inspection and maintenance which contain the danger of being caught in machine, stop the engine.

- 4) Confirm the position of first-aid kit and fire extinguisher, and also where to make contact for emergency measure and ambulance to prepare for accidents and fire.
- 5) Choose a hard, flat and safe place, and put attachment on the ground without fail.
- 6) Use crane, etc. to remove parts of heavy weight (20kg [44 lbs] or more).
- 7) Use proper tools, and change or repair defective tools.
- 8) Machine and attachment required to work in the lifting condition should be supported with supports or blocks securely.



1.3 DISASSEMBLING AND ASSEMBLING HYDRAULIC EQUIPMENT

- (1) Removing hydraulic equipment assy
 - 1) Before removing pipes, release the pressure of hydraulic oil tank, or open the cover on the return side to tank, and take out the filter.
 - 2) Put the oil in the removed pipes in reservoir taking care it is not spilled on the ground.
 - 3) Pipes with plugs or caps to prevent oil leaking, entry of dust, etc.
 - 4) Clean the outside surface of equipment, etc. before disassembling, and drain hydraulic oil and gear oil before putting them on working bench.
- (2) Disassembling hydraulic equipment
 - 1) Since performance and function of hydraulic equipment after disassembly and assembly results in immunity from responsibility on the manufacture's side, disassembly, assembly and conversion without permission are strictly prohibited.
 - 2) If it is unavoidably necessary to disassemble and convert, it should be carried out by experts or personnel authorized through service training.
 - 3) Make match mark on parts for reassembling.
 - 4) Before disassembling, read Disassembling Instruction in advance, and determine if the disassembly and assembly are permitted or not.
 - 5) For parts which are required to use jig and tools, don't fail to use the specified jig and tools.
 - 6) For parts which can not be removed in the specified procedure, never force removal. First check for the cause.

- 7) The removed parts should be put in order and tagged so as to install on proper places without confusion.
 - 8) For common parts, pay attention to the quantity and places.
- (3) Inspecting parts
- 1) Check that the disassembled parts are free from adherence, interference and non-uniform working face.
 - 2) Measure the wear of parts and clearance, and record the measured values.
 - 3) If an abnormality is detected, repair or replace the parts.

- (4) Reassembling hydraulic equipment
- 1) Before cleaning, turn the fan on or open doors to ventilate air.
 - 2) Before assembly, clean parts roughly first, and then completely.
 - 3) Remove with oil by compressed air, and apply hydraulic oil or gear oil, and then assemble them.
 - 4) Replace the removed O ring, back-up rings and oil seal with new ones, and apply grease oil on them before assembling.
 - 5) Removes stain and water on the surface on which liquid sealant are applied, decrease them, and apply liquid sealant on them.
 - 6) Before assembling, remove rust preventives on new parts.
 - 7) Use special tools to fit bearings, bushing and oil seal.
 - 8) Assemble parts matching to the marks.
 - 9) After completion, check that there is no omission of parts.

- (5) Installing hydraulic equipment
- 1) Confirm hydraulic oil and lubrication oil.
 - 2) Air release is required in the following cases ;
 - a. Change of hydraulic oil
 - b. Replacement of parts on suction pipe side
 - c. Removing and attaching hydraulic pump
 - d. Removing and attaching swing motor
 - e. Removing and attaching travel motor
 - f. Removing and attaching hydraulic cylinder



⚠ If hydraulic oil and lubricating oil are not filled and also air bleed is not performed, the hydraulic equipment may be damaged.

- 3) For air bleed of hydraulic pump and swing motor, loosen drain plug on the upper part, start engine, and run in low idling, then bleed air until hydraulic oil is oozed out. After completion of air bleed, tighten plug securely.
- 4) For air bleed of travel motor and hydraulic cylinder, starts engine and operate it for 10 minutes or more at no-load and low speed.

⚠ For cylinder, don't move it to the stroke end at beginning.

- 5) Air in pilot circuit can be bled out by only operating digging, swing and traveling motions thoroughly.
- 6) Check hydraulic oil level.
Move attachments to hydraulic oil check position, and check hydraulic oil level of tank. Refill oil if the oil level is lower than the minimum level.

How to check oil level of hydraulic oil tank



1.4 ELECTRICAL EQUIPMENT

- (1) The disassembly of electrical equipment is not allowed.
- (2) Handle equipment with care so as not to drop it or bump it.
- (3) Connector should be removed by unlocking while holding the connector.
Never stress in tension to the caulked section by pulling wire.
- (4) Check that connector is connected and locked completely.
- (5) Starter key off before removing and connecting connector
- (6) Starter key off before touching terminals of starter and alternator.
- (7) Remove battery grounding terminal before beginning work close to battery and battery relay with tools.
- (8) Wash machine with care so as not to splash water on electrical equipment and connector.


- (9) When water has entered in the waterproofed connector, the removing of water is not easy. So check the removed waterproofed connector with care to protect it from entry of water. If moisture adheres on it, dry it completely before connecting.



Battery electrolyte is dangerous.

The battery electrolyte is dilute sulfuric acid, and causes scald and loss of eyesight by adhering on eyes, skin and clothes. When the electrolyte has adhered on them, take an emergency measure immediately and see a doctor for medical advice.

- When it has adhered on skin ;
Wash with soap and water.
- When it has got in eyes ;
Wash in water for 10 minutes or more immediately.
- When it has spilled out in large quantity ;
Use sodium bicarbonate to neutralize, or wash away with water.
- When it was swallowed ;
Drink milk or water.
- When it has adhered on clothes ;
Wash it immediately.



1.5 HYDRAULIC PARTS

1) O ring

- Check that O ring is free from flaw and has elasticity before fitting.
- Even if the size of O ring is equal, the usage differs, for example in dynamic and static sections, the rubber hardness also differs according to the pressure force, and also the quality differs depending on the materials to be seated. So, choose proper O ring.
- Fit O ring so as to be free from distortion and bend.
- Floating seal should be put in pairs.

2) Flexible hose (F hose)

- Even if the connector and length of hose are the same, the parts differ according to the withstanding pressure. Use proper parts.

- Tighten it to the specified torque, and check that it is free from distortion, over tension, interference, and oil leakage.

1.6 WELD REPAIR

- (1) The weld repair should be carried out by authorized personnel in the specified procedure after disconnecting the grounding cable of battery. If the grounding cable is not disconnected, the electrical equipment may be damaged.
- (2) Remove parts which may cause flame due to the entry of spark beforehand.
- (3) Repair attachments which are damaged, giving particular attention to the plated section of piston rod to protect it from sparks, and don't fail to cover the section with fire clothes.

1.7 ENVIRONMENTAL ISSUES

- (1) Engine should be started and operated in the place where air can be sufficiently ventilated.
- (2) Industrial waste disposal
The following parts follows the regulation.
Waste oil, waste container
Battery
- (3) Asbestos parts
Breathing dust that may be generated when handling components containing asbestos fibers raises danger of getting lung cancer.
Don't raise dust by compressed air and breath it.

Parts to be handled with care :

Brake parts, gasket, etc.

- (4) Precautions for handling hydraulic oil
Hydraulic oil may cause inflammation of eyes.
Wear goggles to protect eyes on handling it.
 - When it has got in eyes ;
Wash eyes with water until the stimulus is gone.
 - When it was swallowed ;
Don't force him to vomit it, but immediately receive medical treatment.
 - When it has adhered on skin ;
Wash with soap and water.
- (5) Others
For spare parts, grease and oil, use KOBELCO genuine ones.

2. ESCAPING PROCEDURE IN CASE OF EMERGENCY

2.1 WHEN CAB DOOR DOES NOT OPEN ;

- (1) Escape from the front window.
- (2) Escape from skylight.
- (3) When front window and skylight do not open ;
A life hammer is provided on the right-hand side of the cab at all times. Escape by breaking the glass at the escape label (seal mark) at the back of the cab.

⚠ Break the window glass with care to protect eyes, and don't fail to break the window on which label "Emergency exit" is stuck.

2.2 WHEN IT IS IMPOSSIBLE TO GO OUT FROM THE SOFT GROUND BY ITSELF ;

- (1) Towing by other machine
There are holes to pass through shackle on the front and rear sides of track frame as in the right figure. Tow it with shackle and wire rope passing through those holes.

Wire dia ; $\varnothing 26(1.024") \times 4m(13'1")$ or more

⚠ Before starting towing, keep away from the wire rope between two machines, and move it slowly at low speed.




Fig. 2-1 Life hammer and "Emergency Exit" seal




Fig. 2-2 Towing by track frame

3. INTERNATIONAL UNIT CONVERSION SYSTEM

Introduction

Although this manual uses the JIS unit system. If you need SI unit, refer to following international system of units.


Given hereinunder are an excerpt of the units that are related to this manual :

1. Etymology of SI Units

French : Le Système International d' Unités

English: International System of Units

2. Construction of SI Unit System



(1) Basic Units

Table 3-1

QUANTITIES	DESIGNATION	SIGN
Length	Meter	m
Mass	Kilogram	kg
Time	Second	s
Current	Ampere	A
Thermodynamic temperature	Kelvin	K
Gram molecule	Mol	mol
Luminous intensity	Candela	cd

(2) Supplementary Units

Table 3-2

QUANTITIES	DESIGNATION	SIGN
Plane angle	Radian	rad
Solid angle	Steradian	sr

(3) Derived Units of Basic Units

Table 3-3

QUANTITIES	DESIGNATION	SIGN
Area	Square meter	m ²
Volume	Cubic meter	m ³
Velocity	Meter per second	m/s
Acceleration	Meter per second / second	m/s ²
Density	Kilogram per cubic meter	kg/m ³

(4) Derived Units bearing Peculiar Designations

Table 3-4

QUANTITIES	DESIGNATION	SIGN	DERIVED UNIT
Frequency	Hertz	Hz	1Hz=1s ⁻¹
Force	Newton	N	1N=1kgf·m/s ²
Pressure, Stress	Pascal	Pa	1Pa=1N/m ²
Energy, Work, Quantity of heat	Joule	J	1J=1N·m
Power, Motive power, Electric power	Watt	W	1W=1J/s
Charge, Quantity of electricity	Coulomb	C	1C=1A·s
Potential, Voltage, Electromotive force	Volt	V	1V=1J/C (1W/A)
Quantity of static electricity, Capacitance	Farad	F	1F=1C/V
Electric resistance	Ohm	Ω	1Ω=1V/A
Celcius temperature	Celcius degree or degree	°C	t°C=(t+273.15)K
Illuminance	lux	ℓX	1ℓX=1ℓ m/m ²

(5) Prefixes of SI

Table 3-5

DESIGNATION	PREFIX	
	SIGN	POWER
Giga-	G	10 ⁹
Mega-	M	10 ⁶
Kilo-	k	10 ³
Hecto-	h	10 ²
Deca-	da	10
Deci-	d	10 ⁻¹
Centi-	c	10 ⁻²
Milli-	m	10 ⁻³
Micro-	μ	10 ⁻⁶
Nano-	n	10 ⁻⁹
Pico-	p	10 ⁻¹²




(6) Unit Conversion Table

Table 3-6

QUANTITIES	JIS	SI	REMARKS
Mass	kgf	kg	
Force	kgf	N	1kgf=9.807N
Torque	kgf·m	N·m	kgf·m=9.807N·m
Pressure	kgf/cm ²	MPa	1kgf/cm ² =0.098MPa
Motive power	PS	kW	1PS=0.7355kW
Revolution	rpm	min ⁻¹	r/min ※1

※1 Units that are allowed to use

(7) Unit conversion logarithmic chart



KOBELCO

Book code No.

S5 **LQ02**_{11E}

SHOP MANUAL

SK230(LC)VI

SK250(LC)VI

SK250NLCVI **LQ02**

SPECIFICATION

TABLE OF CONTENTS


1. NAME OF COMPONENTS	1
2. GENERAL DIMENSIONS	2
3. WEIGHT OF COMPONENTS	4
4. TRANSPORTATION	5
5. MACHINE LIFTING PROCEDURE	8
6. WORKING RANGE	14
7. LIFTING DIAGRAM	16
8. SPECIFICATIONS AND PERFORMANCE	23
9. TYPE OF CRAWLER	24
10. TYPE OF BUCKET	25
11. COMBINATIONS OF ATTACHMENT	26
12. ENGINE SPECIFICATIONS	27

KOBELCO CONSTRUCTION MACHINERY CO., LTD.

Applicable Machines
LQ08-04501~
LL08-03001~

Revision	Date of Issue	Remarks
First edition	February, 2000	S5LQ0211E K

1. NAME OF COMPONENTS




2. GENERAL DIMENSION

Unit : mm (ft-in)


2.1 SK230VI • SK230LCVI

6.02m (19' 9") Boom+2.98m (9' 9") Standard Arm+1.0m³ (1.31cu.yd) Bucket+600mm (24") Shoe




2.2 SK230VI • SK230LCVI

6.02m (19' 9") Boom+2.50m (8' 2") Short Arm+1.2m³ (1.57cu.yd) Bucket+600mm (24") Shoe



2.3 SK230VI • SK230LCVI


6.02m (19' 9") Boom+3.66m (12') Long Arm+0.81m³ (1.06cu.yd) Bucket+600mm (24") Shoe



Unit : mm (ft-in)


2.4 SK250VI

6.02m (19' 9") Boom+2.98m (9' 9") Standard Arm+1.0m³ (1.31cu.yd) Bucket+600mm (24") Shoe



2.5 SK250LcVI • SK250NLCVI

6.02m (19' 9") Boom+2.98m (9' 9") Standard Arm+1.0m³ (1.31cu.yd) Bucket+600mm (24") Shoe



3. WEIGHT OF COMPONENTS

Unit : kg (lbs)

Item	Model	SK230VI	SK230LC VI SK250LC VI	SK250NLC VI
Machine complete		23,600 (52,000)	24,200 (53,350)	24,100 (53,130)
1. Upper frame assy (including the following :)		11,400 (25,130)	←	←
1.1 Upper frame		2,030 (4,480)	←	←
1.2 Counterweight		5,510 (12,150)	←	←
1.3 Cab		260 (570)	←	←
1.4 Engine		※ 480 (1,060)	←	←
1.5 Hydraulic oil tank		※ 143 (320)	←	←
1.6 Fuel tank		※ 91 (200)	←	←
1.7 Slewing motor (including reduction unit)		290 (640)	←	←
1.8 Control valve		280 (620)	←	←
1.9 Boom cylinder		※ 220 (490)×2	←	←
1.10 Pin (for mounting boom)		32 (71)	←	←
1.11 Pump		142 (310)	←	←
1.12 Radiator & oil cooler		97 (210)	←	←
2. Lower frame assy (including the following :)		8,300 (18,300)	8,900 (19,600)	8,800 (19,400)
2.1 Lower frame		3,210 (7,080)	3,510 (7,740)	3,370 (7,430)
2.2 Slewing bearing		364 (800)	←	←
2.3 Travel motor (including reduction unit)		300 (660)×2	←	←
2.4 Upper roller		22 (48)×4	←	←
2.5 Lower roller		35 (77)×14	35 (77)×16	←
2.6 Front idler		106 (230)×2	←	←
2.7 Idler adjuster		94 (210)×2	←	←
2.8 Sprocket		54 (120)×2	←	←
2.9 Swivel joint		30 (60)	←	←
2.10 Track link with 600mm (24in) shoes assy		1,370 (3,020)×2	1,490 (3,280)×2	←
Track link with 700mm (28in) shoes assy		1,500 (3,310)×2	1,630 (3,590)×2	←
Track link with 800mm (32in) shoes assy		1,600 (3,530)×2	1,770 (3,900)×2	←
Track link with 600mm (24in) with flat shoes assy		1,500 (3,310)×2	1,670 (3,680)×2	←
2.10.1 Track link assy		520 (1,150)×2	570 (1,260)×2	←
3. Attachment (including the following / STD :)		3,900 (8,600)	←	←
[6.02m (19ft-9in) Boom+2.98m (9ft-9in) Arm +1.00m ³ (1.3cu.yd) Bucket]				
3.1 Bucket assy (STD)		780 (1,720)	←	←
3.2 STD Arm assy (including the following :)		1,150 (2,540)	←	←
3.2.1 STD Arm		710 (1,570)	←	←
3.2.2 Bucket cylinder		※ 177 (390)	←	←
3.2.3 Idler link		25 (55)×2	←	←
3.2.4 Bucket link		98 (220)	←	←
3.2.5 Pin (2pcs. for mounting bucket cylinder / 2pcs. for mounting bucket)		80 (180)	←	←
3.3 Boom assy		2,140 (4,720)	←	←
3.3.1 Boom		1,670 (3,680)	←	←
3.3.2 Arm cylinder		※ 300 (660)	←	←
3.3.3 Pin (Mounting arm • Mounting arm cylinder)		57 (130)	←	←
4. Lubricant and water (including the following :)		550 (1,210)	←	←
4.1 Hydraulic oil		225 (500)	←	←
4.2 Engine oil		18 (40)	←	←
4.3 Fuel		285 (630)	←	←
4.4 Water		22 (48)	←	←


NOTE : Numerical values marked ※ indicate the dry weight.

4. TRANSPORTATION

4.1 OVERALL DIMENSIONS OF MACHINE ON A TRAILER

(1) 6.02m (19ft-9in) Boom+2.98m (9ft-9in) Arm+1.00m³ (1.31cu·yd) Bucket


Item	Model	SK230 VI	SK230Lc VI
Width 600mm (24in) shoes	mm(ft-in)	2,990 (9' 10")	3,190 (10' 6")
Weight	kg(lbs)	23,600 (52,000)	24,200 (53,350)



Unit : mm (ft-in)

(2) 6.02m (19ft-9in) Boom+2.98m (9ft-9in) Arm+1.00m³ (1.31cu·yd) Bucket

Item	Model	SK250 VI	SK250Lc VI
Width 600mm (24in) shoes	mm(ft-in)	2,990 (9' 10")	3,190 (10' 6")
Weight	kg(lbs)	23,600 (52,000)	24,200 (53,350)



Unit : mm (ft-in)

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com