

Combines

FENDT 5255 L - 6275 L

*FENDT 5255 L / 5255 L MCS - S/N => 555010001
ZN205550x03010222*

*FENDT 6275 L / 6275 L MCS - S/N => 565010001
ZN205650x03010384*



TABLE OF CONTENT

Preface	1
General Information - 00	2
Engine - 10	3
Drive transmission - 14	4
Transmission - 21	5
Front drive axle - 25	6
Hydrostatic transmission - 29	7
Brakes - 33	8
Hydraulic system - 35	9
Steering - 41	10
Axles and wheels - 44	11
Cab air conditioning system - 50	12
Electrical system - 55	13
Attachments/Headers - 58	14
Product feeding - 60	15
Threshing - 66	16
Separation - 72	17
Straw chopper - 73	18
Cleaning - 74	19
Tank - 80	20
Conversion	21

1 Preface

1.1	Introductory notes	1-3
1.2	Important warnings	1-4
1.3	Identification number	1-5

1.1 Introductory notes

- This manual is divided into sections numbered with two-digit numbers, each section having independent page numbering. For quick reference, these sections have the same identification number and description as the relevant Flat Time Rate Manual.
- The subjects covered and the information sought can easily be found using the index on the following pages.
- The information in this manual was updated on the date shown on the booklet. As AGCO is constantly improving its product range, some information may not be updated due to modifications made for technical or commercial reasons as well as for compliance with legal requirements in the various countries. If there are any inconsistencies, contact our AGCO Sales and Service Networks.

1.2 Important warnings

- **Warning: Some of the models listed in this manual are not marketed in your country. For more details, contact your dealer.**
- All repair and maintenance work listed in this manual must be carried out exclusively by the AGCO Service Network, in strict compliance with the instructions provided and using, where necessary, the special tools required.
- Anybody who carries out the above operations without scrupulously complying with the instructions shall be held personally liable for any damage caused as a result of their actions.
- The Manufacturer and all the organizations in its distribution chain, including (without limitation) national, regional or local dealers, reject any responsibility for damage due to the abnormal behavior of parts and/or components not approved by the Manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the Manufacturer. In any case, no warranty of any type is issued or imposed concerning the product manufactured or marketed by the Manufacturer for damage due to abnormal behavior of parts and/or components not approved by the Manufacturer.

LITERARY AND ARTISTIC PROPERTY OF AGCO CORPORATION

Reproduction of text and illustrations, even partially, is prohibited

PRINTED IN ITALY

1.3 Identification number



CAUTION: Some of the models listed in this manual are not marketed in your country

Model	Model identification code
FENDT 5255 L	X5AS
FENDT 5255 L MCS	X5BS
FENDT 6275 L	X6AS
FENDT 6275 L MCS	X6BS

Description of the combine harvester identification number - Type 1

a
b
c

Example: * 5550 * 5550 10001 *

d

a = Technical type

d = Identification number: **555010001** is made up of two parts:

- Part 1 (**b**), made up of 4 digits "5550", identifies the technical type (machine model).
- Part 2 (**c**), made up of 5 digits "10001", which increase in numerical order of production and identify the sequential number of the produced machine model.

*5550*55501.. ...*	For FENDT 5255 L/FENDT 5255 L MCS models
*5650*56501.. ...*	For FENDT 6275 L/FENDT 6275 L MCS models

Description of the combine harvester identification number - Type 2

a
b
c
d
e
f
g

Example: * ZN2 0 5550 X 0 3 010222 *

h

h = Identification number: **ZN205550X03010222** is made up of seven parts:

- a** Manufacturer code: ZN2 = AGCO S.P.A.
- b** Not used.
- c** Technical type.
- d** Random letter generated automatically.
- e** Not used.
- f** Production site code: 3 = Breganze.
- g** Sequential number.

ZN205550X03010222	For FENDT 5255 L/FENDT 5255 L MCS models
ZN205650X03010384	For FENDT 6275 L/FENDT 6275 L MCS models

FreeFlow grain header identification number

7116.. ...	For the 16 ft (m 4.80) model
7118.. ...	For the 18 ft (m 5.40) model
7120.. ...	For the 20 ft (m 6.00) model
7123.. ...	For the 23 ft (m 7.00) model
7125.. ...	For the 25 ft (m 7.60) model

PowerFlow grain header identification number

7018.. ...	For the 18 ft model
7020.. ...	For the 20 ft model
7022... ...	For the 22 ft model

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com