


YAMMAR

OPERATION MANUAL

TNV



OPERATION MANUAL

INDUSTRIAL ENGINES


TNV

2TNV70
3TNV70
3TNV76
3TNV82A
3TNV84
3TNV84T
3TNV88
4TNV84
4TNV84T
4TNV88
4TNV94L
4TNV98
4TNV98T
4TNV106
4TNV106T

Thank you for purchasing
YANMAR product.



Be sure to read this Operation Manual for you to use this product safely and correctly. Even after reading it, carefully keep it, making clear to all personnel concerned where it's kept so that the operator, mechanic or supervisor will have an access to it whenever he wants to read or refer to it.



TNV series

OPERATION MANUAL

2TNV70
3TNV70 • 3TNV76
3TNV82A
3TNV84 • 3TNV84T • 3TNV88
4TNV84 • 4TNV84T • 4TNV88
4TNV94L
4TNV98 • 4TNV98T
4TNV106 • 4TNV106T

P/N: 0ATNV-G00100

YAMAHA
®

**INDUSTRIAL
ENGINES**

INTRODUCTION

Welcome to the world of Yanmar Engines! Yanmar has been the leader in industrial diesel engines for over 90 years. We developed the world's first practical small-sized diesel engine in 1933. Our engineers are continuously developing new technology to keep Yanmar on the leading-edge of the industry. The TNV engine is only one example of the new technology we have developed. We are committed to maintaining our environment, and are proud of our history of innovation, quality and respect for operator safety.

To help you enjoy your Yanmar TNV engine for many years to come, please follow these recommendations:

- Read and understand this *Operation Manual* before you operate the machine to ensure that you follow safe operating practices and maintenance procedures.
 - Keep this *Operation Manual* in a convenient place for easy access.
 - If this *Operation Manual* is lost or damaged, order a new one from your authorized Yanmar industrial engine dealer or distributor.
 - Make sure this manual is transferred to subsequent owners. This manual should be considered a permanent part of the engine and remain with it.
- Constant efforts are made to improve the quality and performance of Yanmar products, so some details included in this *Operation Manual* may differ slightly from your engine. If you have any questions about these differences, please contact your authorized Yanmar industrial engine dealer or distributor.
 - The specifications and components (instrument panel, fuel tank, etc.) described in this manual may differ from ones installed on your machine. Please refer to the manual provided by the manufacturer of these components.

INTRODUCTION

RECORD OF OWNERSHIP

Take a few moments to record the information you need when you contact Yanmar for service, parts or literature.

Engine Model:

Engine Serial No.:

Date Purchased:

Dealer:

Dealer Phone:

SYMBOL EXPLANATION

The following symbols are used throughout this manual to identify specific engine model information



This symbol indicates information pertaining to the following indirect injection engines:

- 2TNV70
- 3TNV70
- 3TNV76



This symbol indicates information pertaining to the following direct injection engines:

- 3TNV82A
- 3TNV84
- 3TNV84T
- 3TNV88
- 4TNV84
- 4TNV84T
- 4TNV88
- 4TNV94L
- 4TNV98
- 4TNV98T
- 4TNV106
- 4TNV106T

TABLE OF CONTENTS

Yanmar Warranties	iii
Yanmar Limited Warranty.....	iii
What is Covered by this Warranty?	iii
How Long is the Warranty Period?	iii
What the Engine Owner Must Do:	iv
To Locate an Authorized Yanmar Industrial Engine Dealer or Distributor:	iv
What Yanmar Will Do:	iv
What is Not Covered by this Warranty?	v
Warranty Limitations:	v
Warranty Modifications:	v
Questions:	v
Retail Purchaser Registration.....	vi
Emission System Warranty	vii
Yanmar Co., Ltd. Limited Emission Control System Warranty - USA Only	vii
Your Warranty Rights and Obligations:	vii
Manufacturer's Warranty Period:.....	vii
Warranty Coverage:	viii
Warranted Parts:	viii
Exclusions:	ix
Owner's Warranty Responsibilities:.....	ix
Introduction	xi
Record of Ownership.....	xii
Symbol Explanation.....	xii
Table of Contents	xiii
Safety	1
Safety Statements	1

TABLE OF CONTENTS

Safety Precautions	2
Before You Operate	2
During Operation and Maintenance	2
Product Overview	15
Yanmar TNV Engine Features and Applications.....	15
Component Identification	16
Location of Labels	18
EPA / ARB Emission Control Regulations - USA Only.....	19
Emission Control Labels	19
EPA / ARB Labels	19
The 97/68/EC Directive Certified Engines.....	20
Engine Family	20
Function of Major Engine Components	21
Function of Cooling System Components	23
Gauges and Indicators	24
Gauges.....	24
Indicators.....	25
Controls	26
Key Switch.....	26
Glow Plugs	27
Inlet Air Heater	27
Governor Lever	28
Engine Stop Solenoid.....	28
Before You Operate	29
Diesel Fuel	34
Diesel Fuel Specifications	34
Filling the Fuel Tank	36
Priming the Fuel System	38
Engine Oil.....	39
Engine Oil Specifications	39
Engine Oil Viscosity.....	40
Checking Engine Oil.....	40
Adding Engine Oil.....	40
Engine Oil Capacity (Typical)	41
Engine Coolant.....	42
Engine Coolant Specifications.....	43
Filling Radiator With Engine Coolant.....	43
Daily Check of the Cooling System	44
Engine Coolant Capacity (Typical)	44

Daily Checks	45
Visual Checks.....	46
Check Diesel Fuel, Engine Oil and Engine Coolant Levels.....	46
Check Engine Speed Control	46
Check Operator's Console	46
Check Indicators.....	46
Engine Operation	49
Starting Engine.....	55
Cold Start Device	56
Checking the Engine During Operation.....	57
Adjust Engine Speed.....	59
Shutting Down the Engine.....	59
Periodic Maintenance	61
Precautions	74
The Importance of Periodic Maintenance.....	74
Performing Periodic Maintenance	74
The Importance of Daily Checks	74
Keep a Log of Engine Hours and Daily Checks	74
Yanmar Replacement Parts	74
Tools Required	74
Ask Your Authorized Yanmar Industrial Engine Dealer or Distributor For Help.....	74
Required EPA / ARB Maintenance USA Only.....	75
EPA / ARB Installation Requirements USA Only.....	75
Tightening Fasteners.....	75
Standard Torque Chart.....	75
Periodic Maintenance Schedule.....	76
Periodic Maintenance Chart 77	
Periodic Maintenance Procedures	78
After Initial 50 Hours of Operation	78
Every 50 Hours of Operation	84
Every 250 Hours of Operation	87
Every 500 Hours of Operation	92
Every 1000 Hours of Operation	98
Every 1500 Hours of Operation	100
Every 2000 Hours of Operation	101
Troubleshooting	103
Troubleshooting Chart.....	103
Troubleshooting Information.....	106
Long-Term Storage	107
Before You Place the Engine In Long-Term Storage.....	107
Returning the Engine to Service.....	108

TABLE OF CONTENTS

Specifications	109
General	109
Description of Model Number.....	109
Engine Speed Specifications.....	110
Engine General Specifications	110
Principal Engine Specifications	111
2TNV70	111
3TNV70	112
3TNV76	113
3TNV82A.....	114
3TNV84	115
3TNV84T	116
3TNV88	117
4TNV84	118
4TNV84T	119
4TNV88	120
4TNV94L	121
4TNV98	122
4TNV98T	123
4TNV106	124
4TNV106T	125


SAFETY


SAFETY STATEMENTS


Yanmar is concerned for your safety and your machine's condition. Safety statements are one of the primary ways to call your attention to the potential hazards associated with Yanmar TNV engine operation. Follow the precautions listed throughout the manual before operation, during operation and during periodic maintenance procedures for your safety, the safety of others and to protect the performance of your engine. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also, if you need to replace a part that has a label attached to it, make sure you order the new part and label at the same time.



This safety alert symbol appears with most safety statements. It means attention, become alert, your safety is involved! Please read and abide by the message that follows the safety alert symbol.

 DANGER
<p>Danger (the word "DANGER" is in white letters with a red rectangle behind it) - indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Danger is limited to the most extreme situations.</p>
000001en

 WARNING
<p>Warning (the word "WARNING" is in black letters with an orange rectangle behind it) – indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.</p>
000001en

 CAUTION
<p>Caution (the word "CAUTION" is in black letters with a yellow rectangle behind it) – indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.</p>
000001en

CAUTION
<p>Caution without the safety alert symbol indicates a potentially hazardous situation that can cause damage to the machine, personal property and / or the environment or cause the machine to operate improperly.</p>
000001en

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com