



CH3500 HARVESTER REPAIR MANUAL

GENERAL SPECIFICATIONS

GENERAL CAPACITIES

TORQUE SPECIFICATIONS

FLUID RECOMMENDATIONS

GENERAL INFORMATION

SERVICE POINTS

ENGINE SYSTEM

OPERATOR'S STATION

HYDROSTATIC TRANSMISSION

FINAL DRIVE

WHEEL AND TRACK

MAIN HYDRAULIC SYSTEM

STEERING SYSTEM

TOPPER SYSTEM

CROP DIVIDER SYSTEM

FEED ROLLER SYSTEM

BASECUTTER SYSTEM

CHOPPER SYSTEM

CLEANING SYSTEM

ELEVATOR SYSTEM

INDEX

CH3500 Harvester Repair Manual

CAMECO®

Table of Contents

GENERAL SPECIFICATIONS

Specifications	0001-1
John Deere 6081 Engine	0001-2
Description	0001-2
Preliminary Service Intervals	0001-2
Common Wear Parts	0001-2

GENERAL CAPACITIES

Harvester Capacities	0002-1
Tire Inflation Pressure	0002-1

TORQUE SPECIFICATIONS

Suggested Torque Values For Grades 5.6, 8.8, 10.9, 12.9 Zinc Plated Cap Screws	0003-1
Suggested Torque Values For Grades 5.6, 8.8, 10.9, 12.9 Zinc Plated Cap Screws	0003-1
Torque for Grade 2 NC Weld Studs	0003-1
Suggested Torque Values And Clamp Loads For Grades 2, 5 & 8 Cap Screws	0003-2
Grade or Property Class Head Marking for SI Bolts	0003-2
Conversion Factors	0003-2

FLUID RECOMMENDATIONS

John Deere Engine Coolant Requirements† ..	0004-1
John Deere Prediluted Antifreeze/ Summer Coolant	0004-1
John Deere Cool-Gard	0004-1
John Deere Antifreeze/Summer Coolant Concentrate	0004-1
John Deere Antifreeze/Summer Coolant	0004-1
Hydraulic Fluid	0004-2
Diesel Fuel	0004-2
Engine Break-in Oil (John Deere)	0004-2
Diesel Engine Oil	0004-3
Gear Oil—Pump Drive, Chopper Box and Basecutter	0004-3
Gear Oil—Final Drive	0004-3
Grease	0004-3

GENERAL INFORMATION

Straight O-Ring Boss Fittings	0005-1
Angled O-Ring Boss Fittings	0005-1
37° Flare Cone Fittings	0005-1
Hex Flats Recommended Rotation	0005-2
Four Bolt Flange Fittings	0005-2
Flange Metric Bolt Torque Chart	0005-3
Flange SAE Bolt Torque Chart	0005-3
Conversions	0005-4
Weight Measure	0005-4
Length Measure	0005-4
Metric (SI†) Measurements	0005-4
Metric to English	0005-4
English to Metric	0005-4
Multiplication Factors	0005-5
Temperature Conversion Chart	0005-5
Conversion Formulas	0005-5
Recommended Supplies	0005-6
Hydraulic Gauge Kit	0005-8
CH3500 Specialty Tools and Part Numbers ..	0005-9

SERVICE POINTS

Harvester Component Locations	0006-1
Harvester Service Point Locations	0006-2
Harvester Grease Point Locations	0006-3
Grease Point Locations	0006-4

ENGINE

Pump Drive	0100-1
Pump Drive Removal	0100-2
Disassembly	0100-2
Clean and Inspect	0100-3
Assembly	0100-3

OPERATOR'S STATION

Other Material	0200-1
Remove and Install Cab Windshield	0200-1
Remove and Install Cab Roof	0200-4
Remove and Install Instructional Seat	0200-6
Cab Door Latch Striker	0200-8

HYDROSTATIC TRANSMISSION

Hydrostatic Pump	0500-1
Hydrostatic Pump	0500-2
Manual and Electrical Displacement Control	0500-3
Suggested Tools And Supplies	0500-3
General Repair Instructions	0500-3
Manual and Electrical Displacement	
Control Replacement †	0500-3
Orifice Check Valve Replacement	0500-4
Charge Pressure Relief Valve Replacement ..	0500-4
Shaft Seal Replacement	0500-5
Multifunction Valve Cartridge Replacement	
(2 Per Pump)	0500-5
Charge Pump Disassembly	0500-5
Charge Pump Reassembly	0500-6
Variable Displacement Motor (Wheel)	0500-7
Shaft Seal Disassembly	0500-8
Inspect	0500-8
Assembly	0500-8
About Servicing The Motor	0500-9
Cartridge Disassembly	0500-10
Housing Disassembly	0500-11
Reconditioning and Replacement of	
Shaft Assembly	0500-12
Piston Ring Reconditioning and	
Replacement	0500-13
Reconditioning and Replacement of Bearing Plate,	
Valve Segment, and Cylinder Block	0500-14
4-Way Valve and Feedback Springs	0500-15
Housing Assembly	0500-16
Housing Assembly	0500-17
Fixed Displacement Motor (Track)	0500-18
Cartridge Assembly	0500-19
Reconditioning and Replacement of	
Piston Rings	0500-20
Cylinder Block Assembly	0500-21
Cylinder Block Assembly	0500-22
End Cap to Main Housing Assembly	0500-23
Track Fixed Displacement Motor	0500-24
Disassembly	0500-24

FINAL DRIVE

Safety Information	0600-3
Installation of the Gearbox to the harvester .	0600-3
Gearbox Lubrication	0600-3
Oil Filling	0600-4
Oil Draining and Replacement	0600-4
Disassembly	0600-5
Reassembly	0600-13
Reassembly	0600-14
Reassembly	0600-24
Brake Check	0600-24

WHEEL AND TRACK

Right Side View	0700-1
Track Assembly	0700-1
Track Assembly	0700-2
Track Alignment	0700-2
Roller Lubrication	0700-2
Idler Lubrication	0700-3
Track Shoe Tightening	0700-3
Track Shoe Inspection Torque	0700-3
Sprocket Tightening	0700-3
Rear Axle Maintenance	0700-3
Track Adjustment	0700-4
Front Idlers	0700-5
Lubrication	0700-5
Identifying Master Link For Chain Removal .	0700-6
Recoil Spring Repair	0700-6
Recoil Spring Adjustment	0700-6
Specifications	0700-6
Link Rail Wear	0700-7
Link Rail Measurement	0700-7
Rebuildability	0700-7
Link Percentage Worn Chart	0700-7
Sealed Track Bushings & Pins	0700-8
Bushing and Pin Wear	0700-8
Wear Measurement	0700-8
Wear Limits—Service and Destruction	0700-8
Track Bushing Allowable Wear Chart	0700-8
Internal Pitch Wear	0700-9
Measurement Technique	0700-9
Detrimental Effects of Excessive Pitch	0700-9
Allowable Wear	0700-9
Internal Pitch Percentage Worn Chart	0700-9
Track Rollers	0700-10
Track Roller Lubrication	0700-10
Seal Assembly	0700-10
Specifications	0700-10
Carrier Roller	0700-11
Carrier Roller Lubrication	0700-11
Carrier Roller Assembly	0700-11
Specifications	0700-11
Sprocket Wear Patterns	0700-12
Sprocket Replacement	0700-12
Tip Gouged	0700-12
Rolling Undercarriage	0700-13
Roller Wear Diagnosis	0700-13
How To Measure Roller Wear	0700-13
Specifications	0700-13
Carrier Roller Percentage Worn	0700-13
Track Roller Percentage Worn	0700-14
Rolling Undercarriage	0700-14
Flange To Boss Measurement	0700-14
Idler Tread Wear Measurement	0700-14
Swapping Idlers	0700-14
Check Idler Flange Wear	0700-15
Flange Top Wear	0700-15

Flange Side Wear	0700-15
Idlers Percentage Worn Chart	0700-15
Track Shoe Problems	0700-16
Grouser Wear Measurement	0700-16
Wear Limits—Service and Destruction	0700-16
Grouser Wear	0700-16
Plate Wear and Leading/Trailing Edge Wear	0700-17
Bolt Hole Wallowing Out	0700-17
Self-Locking Track Nut	0700-17
Sprocket Chain Roller Alignment	0700-18
Wheel Assembly	0700-19
Wheel Assembly	0700-20
Remove And Replace Front Wheel Bearings	0700-20
Suggested Tools	0700-20
Remove Rear Wheel Assembly	0700-20
To Remove And Mount Tire Onto	
Wheel Assembly	0700-20
Install Wheel Assembly	0700-21
Tire Pressure Specifications	0700-21

MAIN HYDRAULIC SYSTEM

Multiple Gear Pump	2000-1
World Multiple Gear Pump	2000-2
World Multiple Gear Pump (Piggyback)	2000-3
Multiple Gear Pump Repair	2000-4
Suggested Tools	2000-4
Repair Precautions	2000-4
Bushing Removal Tool	2000-4
Seal Removal Tool	2000-4
Bushing Installation Tool	2000-4
Special Steel Sleeve	2000-4
Seal Installation Tool	2000-5
Disassembly	2000-5
Clean and Inspect	2000-5
Assembly	2000-6
Start Up Procedure	2000-7
Recommended Test Procedure	2000-7
Suggested Tools	2000-10
External Relief Settings	2000-10
Overhaul	2000-10
Valve Bank Disassembly	2000-10
Front and Rear Feed Roller Valves	2000-11
Assembly Procedure	2000-12
Track Fixed Displacement Motor	2000-14
Seal Replacement	2000-14
Disassembly	2000-15
Clean and Inspect	2000-15
Assembly	2000-15

STEERING SYSTEM

Relief Valve Adjustment	2100-1
Relief Valve Repair	2100-1
Priority Valve	2100-1
Disassembly/Reassembly	2100-4
Troubleshooting	2100-6

Steering Linkage	2100-8
Remove and Install Steering Cylinder	2100-9
Repair Steering Cylinder	2100-10
Check Front Axle Toe-In	2100-12
Adjust Front Axle Toe-In	2100-13

TOPPER SYSTEM

Collector, Crop Divider, Feed Roller, and Elevator Motor	3000-2
Suggested Tools	3000-3
Collector Motor	3000-3
Disassembly	3000-3
Clean and Inspect	3000-4
Assembly	3000-5
Topper	3000-6
Topper Repair	3000-7
Collector Drum and Motor Removal	3000-7
Topper Assembly Removal	3000-7
Clean and Inspect	3000-7
Drum and Topper Assembly	3000-7
Shredder Topper	3000-8
Topper Repair	3000-9
Collector Drum and Motor Removal	3000-9
Topper Assembly Removal	3000-9
Clean and Inspect	3000-9
Drum and Topper Assembly	3000-10
Scroll Cylinder	3000-11
Suggested Tools	3000-12
Disassembly	3000-12
Clean And Inspect	3000-12
Assembly	3000-13
Topper Lift	3000-14
Disassemble and Assemble Topper	
Lift Cylinder	3000-14
Gear Motor	3000-16
Gear Motor Repair	3000-17
Suggested Tools	3000-17
Repair Precautions	3000-17
Bushing Removal Tool	3000-17
Seal Removal Tool	3000-17
Bushing Installation Tool	3000-17
Disassembly	3000-18
Clean And Inspect	3000-18
Assembly	3000-19
Start Up Procedure	3000-20
Recommended Test Procedure	3000-20

CROP DIVIDER SYSTEM

Crop Divider	3100-1
Crop Divider Removal	3100-2
Disassembly	3100-2
Clean and Inspect	3100-2
Assembly	3100-2
Crop Divider Shoe Assembly	3100-2
Crop Divider Shoe Removal	3100-2

FEEDROLLER SYSTEM

Knockdown Roller	3400-1
Removal	3400-2
Disassembly	3400-2
Clean And Inspect	3400-2
Assembly	3400-2
Buttlifter Roller (B1)	3400-3
Repair	3400-4
Clean and Inspect	3400-4
Assembly	3400-4
Bottom Feed Roller (B2, B3, B4, B5)	3400-5
Repair	3400-6
Clean and Inspect	3400-6
Assembly	3400-6
Top Floating Feed Roller (T1, T2, T3, T4, T5) .	3400-7
Repair	3400-8
Clean and Inspect	3400-8
Assembly	3400-8

BASECUTTER SYSTEM

Basecutter Gearbox	3500-1
Basecutter	3500-2
Gearbox Removal	3500-3
Gearbox Installation	3500-3
Gearbox Disassembly	3500-3
Leg Shaft Removal	3500-4
Clean and Inspect	3500-4
Before Assembly	3500-4
Basecutter High Drive Assembly	3500-5
Basecutter Lift Cylinder (Wheel)	3500-7
Wheel Basecutter Lift Cylinder Disassembly	3500-8
Clean and Inspect	3500-8
Reassembly	3500-9
Basecutter Lift Cylinder (Track)	3500-11
Suggested Tools	3500-12
Track Basecutter Lift Cylinder Disassembly .	3500-12
Clean and Inspect	3500-12
Reassembly	3500-13

CHOPPER SYSTEM

Remove	3600-2
Chopper Gearbox PreAssembly and Installation	3600-3
Top and Bottom Drum Installation	3600-4
Final Assembly of Chopper Box	3600-5
Differential Chopper Blade and Kicker	
Installation	3600-6
Differential Chopper Timing and	
Adjustments	3600-7
Chopper System	3600-8
Differential Chopper Timing	3600-8
Slip Clutch	3600-9
Disassembly	3600-10
Assembly (Flywheel, Slip Clutch	
Assembly and Adjustment)	3600-10

Field Setting of Slip Clutch	3600-11
Clean and Close Box	3600-11
Assembly Chopper Motors	3600-11
Assembly Chopper Deflector Shields and	
Adjustments	3600-11
Install and Adjust Sill Plate	3600-11
Chopper Motor Repair and Overhaul	3600-13
Shaft Seal and Cover	3600-13
Drive End Cover and Seal	3600-13
Distributor End Cover and Seal	3600-13
Distributor Housing and Seal Dismantling ...	3600-13
Assembly	3600-14
Distributor Piston Rings	3600-14
Crankshaft and Cylinder Block Assembly	3600-14
Inspection and Repair	3600-14
Assembly	3600-15
Procedure for Preloading Taper Roller	
Bearing on Motor	3600-15
Bearings	3600-16
Pistons and Piston Seals	3600-16
Piston Pads	3600-16
Testing	3600-16
Hydraulic Test	3600-17

CLEANING SYSTEM

Fan Assy	3700-1
Installing The Hub To Motor Shaft	3700-2
Installing Fan Blades, Doubler Plates, and	
Backing Plate	3700-2
Safety Start Up	3700-3
Variable Primary Extractor Pump	3700-4
Manual Displacement Control	3700-5
Suggested Tools	3700-5
Multi-Function Valve Adjustment	3700-5
Stroke Limiter Adjustment†	3700-6
Charge Relief Adjustment	3700-6
Minor Repair	3700-6
General Repair	3700-6
Manual Displacement Control Replacement .	3700-6
Orifice Check Valve Replacement	3700-7
Charge Pressure Relief Valve Replacement ..	3700-7
Shaft Seal Replacement	3700-8
Multi-Function Valve Cartridge Replacement	
(2 per pump)	3700-8
Charge Pump Disassembly	3700-8
Reassembly	3700-8
Primary Extractor Motor	3700-10
Tools Required	3700-11
Disassembly Shaft Seal	3700-12
Disassembly Shaft Seal continued	3700-13
Disassembly End Cover with Integral Shuttle	
and Low Pressure Relief Valve	3700-13
Disassembly of End Cover	3700-14
Disassembly of Rotating Group	3700-14
Reassembly	3700-17

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com