


384 and 238 Industrials Tractors

Operator's Manual

1093142R4



OPERATORS MANUAL



384 AND 238 INDUSTRIAL TRACTORS

1093 142 R4

CASE INTERNATIONAL EUROPE, Wheatley Hall Road, Doncaster, South Yorkshire, DN2 4PG

7/79 (Reprinted U.K. 7/86)

TO THE OWNER


The purpose of this manual is to assist you in realizing the benefits you anticipated when you purchased this International Harvester product.

The way you operate and the care you give this equipment will have much to do with its successful performance. This manual has been carefully prepared and the information arranged and illustrated to make it as easy as possible for you to find the information you wish. It will pay you to read the entire manual carefully before operating and keep it handy for future reference. Your International Dealer or Distributor will be glad to answer any further questions you may have on the operation or care of this product.


It is the policy of International Harvester Company to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to make such changes on products sold previously.

WARRANTY PERIOD

The Notes contained in this Operator's Manual for proprietary items, such as electrical and fuel injection equipment, have been compiled for use after the warranty period has expired. If attention, however small, is required to any of these items, whilst they are still within the warranty period, your International Dealer or Distributor should be informed.



3



4

TRACTOR DELIVERY SERVICE

PURCHASER'S COPY

When delivering the tractor, point out the following instructions in the Operator's Manual and explain any other points not fully understood.

1. Care of tractor during the first 50 working hours
2. Precautions to be taken against accidents
3. The use of correct oil, fuel and their storage
4. The lubricating of the whole machine according to the LUBRICATION CHART
5. Checking of all oil levels
6. Oil change periods
7. Servicing of aircleaner when engine lacks power or at maximum of 500 hours
8. Servicing of oil filter and crankcase breather filter, change at every oil change
9. Starting, driving and stopping methods and explanation of gear levers and instruments
10. Object of thermostat
11. Object of oil pressure and ammeter warning lights, temperature gauge and fuel gauge.
12. Care of cooling system, draining and cleaning
13. Tension of the fan belt and alternator belt
14. Checking and care of the fuel injection system

TRACTOR FIRST AFTER DELIVERY SERVICE (Continued)

DEALER'S COPY

TRANSMISSION

- | | | | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--------------------------|
| 1. Check oil level 24 litres (42 UK pints) capacity | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 2. Check engine and P.T.O. clutches, foot and parking brakes, adjust if necessary | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 3. Check tyre pressures. Refer to Tyre Chart for correct tyre pressure | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 4. Check all bolts and nuts, particularly wheel securing nuts | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 5. Check for oil leaks around transmission housing and rear axles | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 6. Check differential lock for correct operation | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |

ELECTRICAL

- | | | | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--------------------------|
| 1. Check starting circuit | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 2. Check lights and charging circuit | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 3. Check level of battery electrolyte and ensure filler plug holes are clear | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 4. Ensure all connections are secure and correctly located | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |

GENERAL

- | | | | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--------------------------|
| 1. Check all bolts and nuts for correct tightness | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 2. Grease in accordance with Lubrication Chart | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 3. Check for front tyre wear and if necessary reset toe-in | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 4. Test drive tractor | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |
| 5. Ensure the Operator/Owner fully understands the machine and its allied equipment | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | ... | <input type="checkbox"/> |

Appointment for second after delivery service was made for _____ Date

The signature below of the Purchaser (or his Agent) acknowledges that the first after delivery service has been carried out to his satisfaction, and that he has received instruction in the proper operation and maintenance of his machine.

Tractor Serial Number Date

.....
(Signature of Dealer's Representative)

.....
(Signature of Purchaser or his Agent)

Buy Now



Our support email:

ebooklibonline@outlook.com