

ORIGINAL INSTRUCTIONS - according to Directive 2006/42/EC, Annex I 1.7.4.1

# OPERATOR'S MANUAL

---

**Boomer™ 40**

**Boomer™ 50**

**With ROPS**

*Boomer™ 40 ROPS - PIN 2103014860 and above*

*Boomer™ 50 ROPS - PIN 2105013792 and above*

**Boomer™ 40**

**Boomer™ 50**

**With Cab**

**Stage IIIA**

**With Hydrostatic Transmission (HST) and Mechanical Transmission**

**Compact Tractor**

**Part number 47980830**

1<sup>st</sup> edition English

March 2016

*Replaces part number 47605437 and 47901424*



# Contents

---

## 1 GENERAL INFORMATION

|  |      |
|--|------|
| Note to the owner.....                           | 1-1  |
| Intended use.....                                | 1-2  |
| Electro-Magnetic Compatibility (EMC) .....       | 1-4  |
| Manual scope.....                                | 1-5  |
| Metric and Imperial units abbreviations .....    | 1-6  |
| Product Identification Number (PIN) (ROPS) ..... | 1-8  |
| Product Identification Number (PIN) (Cab).....   | 1-11 |
| Operator's manual storage .....                  | 1-13 |
| Machine orientation (ROPS) .....                 | 1-14 |
| Machine orientation (Cab) .....                  | 1-15 |
| Official documents.....                          | 1-16 |

## 2 SAFETY INFORMATION

|  |      |
|--|------|
| Safety alert symbol and signal word definition ..... | 2-1  |
| Safety rules .....                                   | 2-2  |
| Ecology and the environment .....                    | 2-13 |
| Safety features (ROPS) .....                         | 2-14 |
| Safety features (Cab).....                           | 2-15 |
| Safety aspects.....                                  | 2-16 |
| Tractor jacking points.....                          | 2-22 |
| Airborne noise emission (ROPS).....                  | 2-23 |
| Airborne noise emission (Cab) .....                  | 2-23 |
| Exhaust emission levels.....                         | 2-24 |
| Vibration levels (ROPS) .....                        | 2-25 |
| Vibration levels (Cab).....                          | 2-26 |
| Machine stability.....                               | 2-27 |
| Safety signs (ROPS) .....                            | 2-30 |
| Safety signs (Cab).....                              | 2-41 |
| Instructional signs .....                            | 2-51 |
| International symbols.....                           | 2-59 |

## 3 CONTROLS AND INSTRUMENTS

### ACCESS TO OPERATOR'S PLATFORM

|                       |     |
|-----------------------|-----|
| Cab door.....         | 3-1 |
| Cab side window ..... | 3-2 |
| Cab rear window ..... | 3-2 |

### OPERATOR'S SEAT

|   |     |
|---|-----|
| Seat belt .....   | 3-3 |
| Seat controls .....   | 3-4 |
| Roll Over Protective Structure (ROPS).....                  | 3-5 |
| Roll Over Protective Structure (ROPS) - front mounted ..... | 3-7 |

---

## FORWARD CONTROLS

|  |      |
|--|------|
| Instrument cluster - Identification .....        | 3-9  |
| Cruise control .....                             | 3-11 |
| Transmission shuttle shift lever .....           | 3-12 |
| Clutch pedal .....                               | 3-12 |
| Brake pedals .....                               | 3-13 |
| Foot throttle pedal .....                        | 3-14 |
| Hand throttle lever .....                        | 3-15 |
| Horn switch .....                                | 3-15 |
| Hazard light switch .....                        | 3-16 |
| Power Take-Off (PTO) switch .....                | 3-16 |
| Key switch .....                                 | 3-17 |
| Differential lock pedal .....                    | 3-18 |
| Hydrostatic transmission (HST) foot pedals ..... | 3-19 |
| Tilt steering lever .....                        | 3-19 |
| Multifunction light switch .....                 | 3-20 |
| Creeper speed selection lever .....              | 3-21 |

## LEFT-HAND SIDE CONTROLS

|   |      |
|---|------|
| Transmission range lever .....                  | 3-22 |
| Park brake (ROPS) tractors .....                | 3-22 |
| Front-wheel drive lever .....                   | 3-23 |
| Mid Power Take-Off (PTO) lever .....            | 3-24 |
| Rear PTO speed selection lever (Optional) ..... | 3-24 |
| Ground speed PTO (GSP) selection lever .....    | 3-25 |

## RIGHT-HAND SIDE CONTROLS

|  |      |
|--|------|
| Park brake cab tractors .....                        | 3-26 |
| Hydraulic Power Lift (HPL) - (ROPS) tractors .....   | 3-27 |
| Hydraulic Power Lift (HPL) - Cab tractors .....      | 3-28 |
| Draft control (ROPS) tractors .....                  | 3-29 |
| Draft control cab tractors .....                     | 3-30 |
| Rear remote control valve(s) - (ROPS) tractors ..... | 3-31 |
| Rear remote control valve(s) - cab tractors .....    | 3-32 |
| Mid mount control valve (ROPS) tractors .....        | 3-32 |
| Mid mount control valve cab tractors .....           | 3-35 |
| Transmission main shift lever .....                  | 3-37 |
| Hydrostatic transmission (HST) range lever .....     | 3-38 |
| Beacon switch .....                                  | 3-39 |
| Cab internal lighting .....                          | 3-39 |
| Cab external lighting .....                          | 3-40 |
| Front window wiper/washer .....                      | 3-41 |
| Rear window wiper/washer (optional) .....            | 3-42 |
| Auxiliary power outlet .....                         | 3-43 |

## OVERHEAD CONTROLS

|                           |      |
|---------------------------|------|
| Cab climate control ..... | 3-44 |
| Air conditioning .....    | 3-45 |
| Front sun shade .....     | 3-49 |

---

|                               |      |
|-------------------------------|------|
| Rear-view inside mirror ..... | 3-49 |
|-------------------------------|------|

## EXTERIOR CONTROLS

|                                 |      |
|---------------------------------|------|
| Rear-view outside mirrors ..... | 3-50 |
| Hood release latch .....        | 3-50 |

## 4 OPERATING INSTRUCTIONS

### COMMISSIONING THE UNIT

|  |      |
|--|------|
| Engine break-in procedure .....                          | 4-1  |
| Power Take-Off (PTO) operation .....                     | 4-2  |
| Ground speed PTO (GSP) operation .....                   | 4-4  |
| Three-point hitch .....                                  | 4-7  |
| Attaching three-point equipment .....                    | 4-8  |
| Extendible drawbar .....                                 | 4-11 |
| Hydraulic lift rocker .....                              | 4-12 |
| Hydraulic Power Lift (HPL) drop rate control valve ..... | 4-12 |

### STARTING THE UNIT

|   |      |
|---|------|
| Key switch .....                              | 4-13 |
| Cold starting aids .....                      | 4-14 |
| Starting the engine .....                     | 4-15 |
| Starting the tractor with jumper cables ..... | 4-20 |

### STOPPING THE UNIT

|                              |      |
|------------------------------|------|
| Stopping the engine .....    | 4-21 |
| Emergency stopping .....     | 4-22 |
| Brakes (ROPS) tractors ..... | 4-23 |
| Brakes cab tractors .....    | 4-25 |

### MOVING THE UNIT

|  |      |
|--|------|
| Steering wheel adjustment .....                          | 4-27 |
| Steering operation .....                                 | 4-29 |
| Transmission operation at low ambient temperatures ..... | 4-30 |
| Hydrostatic transmission (HST) operation .....           | 4-31 |
| 16 x 16 Synchronized transmission operation .....        | 4-33 |
| Creeper speed operation .....                            | 4-35 |

### PARKING THE UNIT

|                              |      |
|------------------------------|------|
| Parking (ROPS) tractor ..... | 4-37 |
| Parking cab tractor .....    | 4-39 |

## 5 TRANSPORT OPERATIONS

### ROAD TRANSPORT

|   |     |
|---|-----|
| External lighting (ROPS) tractors ..... | 5-1 |
| External lighting cab tractors .....    | 5-2 |

---

|   |      |
|---|------|
| Hazard warning lights operation (ROPS) tractors ..... | 5-3  |
| Hazard warning lights operation cab tractors.....     | 5-4  |
| Turn signal operation .....                           | 5-5  |
| Road lights operation (ROPS) tractors .....           | 5-7  |
| Road lights operation cab tractors.....               | 5-8  |
| Work lights operation (ROPS) tractors .....           | 5-9  |
| Work lights operation cab tractors.....               | 5-10 |
| Rear work light operation (ROPS) tractors .....       | 5-11 |
| Rear work lights operation cab tractors .....         | 5-12 |
| Driving the vehicle .....                             | 5-13 |

## SHIPPING TRANSPORT

|   |      |
|---|------|
| Carrying the tractor on a transporter ..... | 5-14 |
|---|------|

## RECOVERY TRANSPORT

|              |      |
|--------------|------|
| Towing ..... | 5-14 |
|--------------|------|

## 6 WORKING OPERATIONS

### GENERAL INFORMATION

|                                  |     |
|----------------------------------|-----|
| Tractor ballasting .....         | 6-1 |
| Tractor ballasting weights ..... | 6-2 |
| Liquid ballast .....             | 6-3 |

## 7 MAINTENANCE

### GENERAL INFORMATION

|   |      |
|---|------|
| General information .....   | 7-1  |
| Battery disconnect switch .....                                     | 7-2  |
| Diesel fuel .....   | 7-3  |
| Biodiesel fuel .....  | 7-4  |
| Refueling the tractor - (ROPS) .....                                | 7-5  |
| Refueling the tractor - Cab .....                                   | 7-6  |
| Organic Acid Technology (OAT) coolant.....                          | 7-7  |
| Change engine coolant to Organic Acid Technology (OAT) coolant..... | 7-8  |
| Consumables.....  | 7-10 |
| Torque - Minimum tightening torques for normal assembly .....       | 7-11 |

### MAINTENANCE CHART

|                        |      |
|------------------------|------|
| Maintenance chart..... | 7-16 |
|------------------------|------|

#### Every 10 hours or daily

|                                    |      |
|------------------------------------|------|
| Engine oil level - Check .....     | 7-17 |
| Engine cooling system - Check..... | 7-19 |

#### After the first 50 hours of operation

|  |      |
|--|------|
| Engine oil and oil filter - Change ..... | 7-20 |
| Fuel filter - Change .....               | 7-21 |

---

|   |      |
|---|------|
| Hydraulic oil filter - Replace .....                      | 7-21 |
| Hydrostatic Transmission (HST) oil filter - Replace ..... | 7-23 |
| Roll Over Protective Structure (ROPS) .....               | 7-24 |
| Wheel bolt / nut - Tighten .....                          | 7-25 |

## Every 50 hours

|   |      |
|---|------|
| Grease fittings .....   | 7-26 |
| Transmission fluid level - Check .....                          | 7-27 |
| Clutch pedal free play - Check .....                            | 7-27 |
| Brake pedal free play - Check .....                             | 7-29 |
| Hydrostatic transmission (HST) neutral adjustment - Check ..... | 7-30 |
| Fan belt tension - Check .....                                  | 7-31 |
| Wheels and tires pressure - Check .....                         | 7-31 |
| Front axle and differential oil level - Check .....             | 7-33 |
| Air cleaner - Clean .....                                       | 7-34 |
| Cab air filter - Check and cleaning .....                       | 7-36 |

## Every 100 hours

|                         |      |
|-------------------------|------|
| Fuel filter-Drain ..... | 7-37 |
|-------------------------|------|

## Every 300 hours

|   |      |
|---|------|
| Engine lubrication system - Change fluid .....            | 7-38 |
| Hydraulic oil filter - Replace .....                      | 7-38 |
| Hydrostatic Transmission (HST) oil filter - Replace ..... | 7-38 |
| Fuel filter - Change .....                                | 7-38 |
| Engine belts - Adjust .....                               | 7-38 |
| Roll Over Protective Structure (ROPS) .....               | 7-40 |
| Wheels bolt/nut .....                                     | 7-41 |
| Front wheels toe-in .....                                 | 7-41 |
| Air cleaner primary element - Replace .....               | 7-42 |

## Every 500 hours

|                                |      |
|--------------------------------|------|
| Cab air filter - Replace ..... | 7-43 |
|--------------------------------|------|

## Every 600 hours

|  |      |
|--|------|
| Front axle differential oil - Change fluid ..... | 7-44 |
| Transmission fluid - Change .....                | 7-46 |

## Every 1000 hours

|  |      |
|--|------|
| Air cleaner inner element - Replace .....    | 7-47 |
| Engine coolant - Draining and flushing ..... | 7-48 |

## General maintenance

|   |      |
|---|------|
| Fuel injection system - Bleed .....                     | 7-49 |
| Hydrostatic Transmission (HST) neutral adjustment ..... | 7-50 |

---

|   |      |
|---|------|
| Engine belts - Adjust .....                 | 7-52 |
| Roll Over Protective Structure (ROPS) ..... | 7-53 |
| Battery .....                               | 7-54 |
| Alternator .....                            | 7-54 |
| Fuses .....                                 | 7-55 |
| Maxi fuse .....                             | 7-58 |
| Headlight .....                             | 7-59 |
| Tail/brake light bulb .....                 | 7-60 |
| Front turn signal/hazard light bulb .....   | 7-62 |
| Wheels bolt/nut tighten .....               | 7-65 |
| Front wheels-toe-in-adjust .....            | 7-66 |
| Brake pedal free play - Adjust .....        | 7-67 |
| Clutch pedal free play - Adjust .....       | 7-68 |

## STORAGE

|                                       |      |
|---------------------------------------|------|
| Storage of tractor .....              | 7-69 |
| Removal of tractor from storage ..... | 7-71 |

## 8 TROUBLESHOOTING

### SYMPTOM(S)

|  |     |
|--|-----|
| Engine - Troubleshooting .....                   | 8-1 |
| Clutch - Troubleshooting .....                   | 8-2 |
| Hydraulic service brakes - Troubleshooting ..... | 8-2 |
| Hydraulic Lift System - Troubleshooting .....    | 8-2 |
| Steering - Troubleshooting .....                 | 8-3 |
| Hydrostatic transmission - Troubleshooting ..... | 8-3 |
| Electrical system - Troubleshooting .....        | 8-4 |

## 9 SPECIFICATIONS

|  |      |
|--|------|
| Wheel tread settings .....                 | 9-1  |
| Tire inflation pressures .....             | 9-2  |
| General specifications .....               | 9-3  |
| Tractor dimensions - (ROPS) tractors ..... | 9-9  |
| Tractor dimensions - Cab tractors .....    | 9-12 |

## 10 ACCESSORIES

|                          |      |
|--------------------------|------|
| Optional equipment ..... | 10-1 |
|--------------------------|------|

## 11 FORMS AND DECLARATIONS

|                                     |      |
|-------------------------------------|------|
| Delivery report - Owner Copy .....  | 11-3 |
| Delivery report - Dealer Copy ..... | 11-5 |

# 1 - GENERAL INFORMATION

## Note to the owner

This manual contains information concerning the adjustment and maintenance of your new equipment. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this equipment. Please have all operators read this manual carefully and keep it available for ready reference.

Your NEW HOLLAND dealer will instruct you in the general operation of your new equipment. (Refer to the 'Delivery Report' at the back of this manual.) Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your machine.

Your NEW HOLLAND dealer carries a complete line of genuine NEW HOLLAND service parts. These parts are manufactured and carefully inspected to ensure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and product identification number of your new equipment when ordering parts. Locate these numbers now and record them below. Refer to the 'General Information' section of this manual for the location of the model and product identification numbers of your machine.

### PLEASE RECORD THE FOLLOWING INFORMATION

**Model**

---

**Product Identification Number (PIN)**

---

**Date Purchased**

---

**Engine Model (As Applicable)**

---

**Engine PIN (As Applicable)**

---

## EC Declaration of Conformity

The manufacturer delivers the machine with a document called "EC Declaration of Conformity" which guarantees that the machine complies with the European Machinery Safety Directives. This document will usually be found on the machine when the machine is originally supplied to you. If not, it should be obtained from your dealer. The owner must carefully preserve this document to be able to present it to Safety Inspection Authorities when requested. The document as well as the operators manual should also stay with the machine if it is traded again.

### **WARNING**

**Illustrations in this manual may show protective shielding open or removed to better illustrate a particular feature or adjustment.**

**Replace all shields before operating the machine.**

**Failure to comply could result in death or serious injury.**

W0012A

**ATTENTION:** *The engine and fuel system on your machine is designed and built to government emission standards. Tampering by dealer, customers, operators, and end users is strictly prohibited by law. Failure to comply*

*could result in government fines, rework charges, invalid warranty, legal action, and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*

## Improvements

CNH America LLC is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.



## Intended use

### INTENDED USE OF YOUR TRACTOR

Your tractor is designed and made to pull, to carry, and to power a variety of mounted or towed equipment, although within some physical limits. The working speed and performance may depend on a number of various parameters, such as weather and terrain conditions. Though the tractor is designed to perform in combination with a variety of equipment in most crops and conditions, there may be a number of combinations of above parameters, for which there is severe degradation of performance of the tractor and/or its mounted or trailed equipment. If you notice degradation of performance, contact your dealer for assistance. He may have useful information for improvements, or a kit may be available to enhance the performance.

- Do not use the tractor for another purpose than intended by the manufacturer and outlined in this manual.
- Do not use the tractor beyond its limits of terrain gradient and stability as outlined further in this manual. Using the tractor beyond these limits may result in roll-over or tip-over. Observe the recommendations in this manual.
- Do not use the tractor on higher speeds than allowed by the load and the environment. A wet surface or other low adherence conditions may increase the braking distance or result in vehicle instability. Always adapt your traveling speed according to the load of the vehicle and the characteristics of the road.
- Do not use the tractor near or on soft verges of canals and brooks or banks and verges that are undermined by rodents. The tractor may sink sideways and roll-over.
- Do not use the tractor on brittle bridge heads and poor bridge floors. These constructions may collapse and cause roll-over of the tractor. Always check out the condition and carrying capacity of bridges and ramps prior to engage.
- Do not use the tractor without wearing the seat restraint system during activities where roll-over or tip-over hazards exist. The ROPS cab or ROPS structure will only be fully effective when the driver remains attached to his seat.
- Do not use equipment mounted on the tractor which is not correctly matching and firmly fixed. Such equipment may increase the risk for roll-over and hit the tractor when coming loose. Ensure that the dimensions of the three-point linkage interface of both the tractor and the equipment are matching according to the categories defined in ISO 730. Ensure that the dimensions and speed of the PTO shaft on the tractors are matching those of the equipment.
- Do not use the tractor in combination with equipment, without having consulted the specific Operators Manual provided with the equipment. The tractor is a universal tool to carry, tow, and drive a variety of equipment. This manual alone cannot provide you with all the information required for the safe operation of the combination.
- Do not use the tractor beyond its limits of dynamic stability. High speed, abrupt maneuvers, and fast and short cornering will increase the risk of roll-over.
- Do not use the tractor for pulling work, in cases where you do not know whether the load will yield, for instance when pulling stumps. The tractor may flip over when the stump is not yielding.
- Be extremely cautious when working with the tractor on forage silos without lateral concrete walls. Dual wheels or a wide track setting may improve the lateral stability of the tractor.
- Be cautious that the center of gravity of the tractor may increase when loads on the front-end loader or the three-point linkage are raised. In these conditions, the tractor may roll-over earlier than expected.
- Do not step down from the tractor without shutting down the PTO, shifting the transmission to park or neutral and applying the park brake, unless continued PTO operation is required for some equipment, such as pumps or wood chippers. The latter equipment may have an emergency stop device on the equipment itself, as human intervention is needed during operation. But other equipment, engaged and driven by the tractor will have no means to stop the power transmission, other than the PTO clutch of the tractor.
- You shall take the necessary precautions to always be aware of the possible presence of bystanders, certainly when maneuvering in confined areas, such as the farm yard and sheds. Keep people away from the tractor during work; ask bystanders to leave the field. There is not only the risk to be overrun by the tractor, but objects ejected by some equipment mounted on the tractor, such as a rotary mower, may cause harm. Stones may be thrown further than the mowed crop. Pay the necessary attention while operating next to public roads or footpaths. Thrown objects can get projected outside the field and hit unprotected people like bikers or pedestrians. Wait to cut the edge of the field till it is clear of bystanders.
- Do not allow riders on the tractor; do not allow people standing on the access way or step to the cab when the tractor is moving. Your view to the left will be obstructed and a rider risks to fall from the tractor during unforeseen or abrupt movements.
- Always stay clear from implements operating area and especially do not stand between tractor and trailed vehicle either three-point linkage when operating lift controls; ensure no bystanders are near these operating areas.
- Certain functions of your tractor, if equipped with a CVT transmission, are controlled by software and some of them are safety related. Do not attempt to modify or download software from spurious sources. Settings

and logics may be destroyed and affect seriously the function of the tractor. This may result in unpredictable and unsafe behavior of the tractor. Only your dealer is entitled to intervene on the software of the tractor. He has the appropriate tools and data sets for it and owns the officially released software versions and updates for your tractor.

- Your tractor may be equipped with a number of sensors to control safety functions. Tripping these sensors will result in a safe operation mode. Do not attempt to bypass any function on the tractor. You will be exposed to serious hazards, and moreover, the behavior of the tractor may become unpredictable.
- A tractor has only one operator station and is a one man operated vehicle. Other people on or around the tractor during normal operation are not allowed.
- The machine is designed and produced exclusively for agricultural use.
- The machine is not designed for light/heavy forestry applications; usage is prohibited for forestry applications.
- All other use will be considered to be contrary to the use specified by CNH AMERICA LLC, who cannot be held liable for damage to property or the machine, or for personal injuries which may result.
- Persons who risk improper use will therefore assume the responsibility for any consequences arising from such use.
- Compliance with the instructions for use, maintenance and repairs described in this manual, are the essential preconditions for the use specified by CNH AMERICA LLC.
- The machine must only be used, serviced, or repaired by personnel trained in the relevant working methods and safety regulations and who have been authorized to work on the machine.
- The user must also observe the rules concerning general safety and accident prevention, including the Highway Code when driving on public highways.
- Any arbitrary modifications made to this machine will release CNH AMERICA LLC from any liability resulting from damage or injury.
- CNH AMERICA LLC and all its distribution organizations, inclusive of, but not restricted to, national, regional, or local distributors, cannot be held liable for damage resulting from the malfunction of parts and/or components not approved by CNH AMERICA LLC.
- Under no circumstances will a guarantee be issued for products made or sold by CNH AMERICA LLC that are damaged as a result of the malfunction of parts and/or components not approved by CNH AMERICA LLC.
- The use of biodiesel blends meeting Specification Standards ASTM 6751 or EN14214 are approved for your engine up to B5 (5% blend ratio). It is highly recommended to use biodiesel fuel from accredited suppliers to maintain quality and consistency of the fuel.

## Electro-Magnetic Compatibility (EMC)

This machine complies strictly with the European Regulations on electro-magnetic emissions. However, interference may arise as a result of add-on equipment which may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- Ensure that each piece of non- NEW HOLLAND equipment fitted to the machine bears the CE mark.
- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the machine.
- The electro-magnetic field generated by the add-on system should not exceed **24 V/m** at any time and at any location in the proximity of electronic components.

Failure to comply with these rules will render the NEW HOLLAND warranty null and void.

## Manual scope

This manual gives information for use of this tractor, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance.

- Normal operation means the use of the tractor for the purpose intended by the manufacturer by an operator familiar with the tractor and the mounted or towed equipment and complying with the information for operation and safe practices, as specified by the manufacturer in this manual and by the signs on the tractor and the equipment.
- Normal operation includes the preparation and storage of the tractor, swinging components into work position and vice versa, adding or removing ballast and picking up and setting off attachments.
- Normal operation includes the adjustment and setting of the tractor and equipment, for the specific condition of the field and/or the crop.
- Routine service and maintenance means activities that must be done daily by an operator familiar with the tractor characteristics and complying with the information for routine service and safe practices, as specified by the manufacturer in this manual and by signs on the tractor, in order to maintain its proper function. Routine service includes activities such as fueling, cleaning, washing, topping up fluid levels, greasing, replacing of consumable articles such as lamp bulbs.
- This manual does not give all the information related to periodical service, converting and repairs to be carried out by professional service personnel. For some of the latter activities, there may be a need for appropriate facilities, technical skills and tools which are not supplied with the tractor, please refer to your dealer or authorized workshop.
- Periodical service means activities that must be done at defined intervals by trained personnel familiar with the tractor characteristics and which are complying with the information for periodical service and safe practices, as partly specified by the manufacturer in this manual and in other Company literature, in order to maintain the expected life time of the tractor.
- Converting means activities that must be done by professional service personnel familiar with the tractor characteristics and complying with the information for converting, as partly specified by the manufacturer in this manual, in assembly instructions or other Company literature, in order to fit the tractor to a specific configuration.
- Repair means activities that must be done by professional service personnel only familiar with the tractor characteristics and complying with the information for repair, as specified by the manufacturer in the dealer's workshop manual, in order to restore the proper function of the tractor after a failure or degradation of performance.

## Metric and Imperial units abbreviations

| Typical applications                       | Metric unit            |                 | Imperial unit         |                    |
|--|------------------------|-----------------|-----------------------|--------------------|
|  | Name                   | Symbol          | Name                  | Symbol             |
| <b>Area (Land area)</b>                    |                        |                 |                       |                    |
|  | hectare                | ha              | acre                  | ac                 |
|  | square meter           | m <sup>2</sup>  | square foot           | ft <sup>2</sup>    |
|  | square millimeter      | mm <sup>2</sup> | square inch           | in <sup>2</sup>    |
| <b>Electricity</b>                         |                        |                 |                       |                    |
|  | ampere                 | A               | ampere                | A                  |
|  | volt                   | V               | volt                  | V                  |
|  | microfarad             | μF              | microfarad            | μF                 |
|  | ohm                    | Ω               | ohm                   | Ω                  |
| <b>Force</b>                               |                        |                 |                       |                    |
|  | kilonewton             | kN              | pound                 | lb                 |
|  | newton                 | N               | pound                 | lb                 |
| <b>Force per length</b>                    |                        |                 |                       |                    |
|  | newton per meter       | N/m             | pound per foot        | lb/ft              |
|  |                        |                 | pound per inch        | lb/in              |
| <b>Frequency</b>                           |                        |                 |                       |                    |
|  | megahertz              | MHz             | megahertz             | MHz                |
|  | kilohertz              | kHz             | kilohertz             | kHz                |
|  | hertz                  | Hz              | hertz                 | Hz                 |
| <b>Frequency - Rotational</b>              |                        |                 |                       |                    |
|  | revolution per minute  | r/min           | revolution per minute | r/min <sup>a</sup> |
|  |                        | rpm             |                       | rpm                |
| <b>Length</b>                              |                        |                 |                       |                    |
|  | kilometer              | km              | mile                  | mi                 |
|  | meter                  | m               | foot                  | ft                 |
|  | centimeter             | cm              | inch                  | in                 |
|  | millimeter             | mm              | inch                  | in                 |
|  | micrometer             | μm              |                       |                    |
| <b>Mass</b>                                |                        |                 |                       |                    |
|  | kilogram               | kg              | pound                 | lb                 |
|  | gram                   | g               | ounce                 | oz                 |
|  | milligram              | mg              |                       |                    |
| <b>Mass per mass</b>                       |                        |                 |                       |                    |
|  | milligram per kilogram | mg/ kg          | parts per million     | ppm                |
| <b>Power</b>                               |                        |                 |                       |                    |
|  | kilowatt               | kW              | horsepower            | Hp                 |
|  | watt                   | W               | Btu per hour          | Btu/hr             |
|  |                        |                 | Btu per minute        | Btu/min            |
| <b>Pressure or stress (Force per area)</b> |                        |                 |                       |                    |
|  | kilopascal             | kPa             | pound per square inch | psi                |
|  |                        |                 | inch of mercury       | inHg               |
|  | pascal                 | Pa              | inch of water         | inH <sub>2</sub> O |
|  | megapascal             | MPa             | pound per square inch | psi                |
|  | millibar               | mbar            |                       |                    |
|  | bar                    | bar             |                       |                    |

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)