

ORIGINAL INSTRUCTIONS - according to Directive 2006/42/EC, Annex I 1.7.4.1

Quantum 75F
Quantum 85F
Quantum 95F
Quantum 105F
Tractor

OPERATOR'S MANUAL

Part number 48077089

4th edition English

December 2016

Replaces part number 47768226



Contents

1 GENERAL INFORMATION

Note to the Owner	1-1
Intended use.....	1-3
Electro-Magnetic Compatibility (EMC)	1-5
Manual scope and required training level	1-6
Metric and imperial units abbreviations.....	1-7
Identification plates	1-9
Approval data plate.....	1-11
Machine orientation.....	1-12
Component Identification	1-13
EC Declaration of Conformity	1-15

2 SAFETY INFORMATION

Safety rules and signal word definitions	2-1
Safety rules - General information	2-2
Safety rules – Maintenance	2-2
Safety rules - Wheels and tires	2-3
Safety rules – Explosions and fires	2-4
Safety rules - Fire extinguisher	2-4
Safety rules – Battery	2-5
Safety rules - Passenger seat	2-5
Safety rules - Power Take-Off (PTO)	2-5
Safety rules - Seat belts	2-6
Safety rules - Operator protective structure	2-6
Safety rules - HVAC system	2-8
Safety rules - Personal Protective Equipment (PPE)	2-8
Safety rules - "Do not use" sign	2-8
Safety rules - Hazardous chemicals	2-8
Safety rules - Near utilities	2-9
Safety rules - In the event of electrical storms	2-9
Safety rules – Mounting and dismounting the machine	2-9
Safety rules - Lifting and overhead loads	2-10
Commission directive 2010/52/EU	2-11
Noise level.....	2-18
Vibration levels	2-19
Machine stability.....	2-20
Towing the tractor for recovery	2-22
Tractor jacking points.....	2-23
Burn prevention.....	2-24
Emergency exit	2-25
Safety signs	2-26

3 CONTROLS AND INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

Getting in and out of the machine	3-1
---	-----

Getting to know the internal parts of the cab	3-2
---	-----

OPERATOR'S SEAT

Operator seat	3-5
---------------------	-----

FORWARD CONTROLS

Digital dashboard	3-7
Front controls	3-13

LEFT-HAND SIDE CONTROLS

Console Left-hand console - Control identification	3-16
Park lock	3-18

RIGHT-HAND SIDE CONTROLS

Console Right-hand console - Control identification	3-19
---	------

REARWARD CONTROLS

Console - Control identification	3-21
--	------

OVERHEAD CONTROLS

Heating system	3-21
Heating, ventilation or air-conditioning control	3-22
Cab air filter	3-24

EXTERIOR CONTROLS

Console - Control identification	3-25
--	------

DISPLAY SETTINGS

Instrument cluster - Program	3-27
------------------------------------	------

TRANSMISSION

Transmission - Operating 4WD models	3-34
---	------

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

Basic operating safety rules	4-1
Refueling	4-2

STARTING THE UNIT

Starting the engine	4-3
---------------------------	-----

STOPPING THE UNIT

Stopping the engine	4-5
---------------------------	-----

MOVING THE UNIT

Transmission with gear reducer and mechanical reversing mechanism	4-6
Transmission with gear reducer and electrohydraulic reversing mechanism	4-7
Transmission with additional gear reducer and mechanical reversing mechanism	4-8
Transmission with gear reducer, mechanical reversing mechanism and splitter	4-9
Transmission with gear reducer, electrohydraulic reversing mechanism and HI-LO control	4-10
Transmission with gear reducer, electrohydraulic reversing mechanism, HI-LO control and electrohydraulic clutch	4-11
Transmission with gear reducer, electrohydraulic reversing mechanism, HI-LO control and additional reducer	4-14

5 TRANSPORT OPERATIONS

ROAD TRANSPORT

Transporting the machine	5-1
--------------------------------	-----

RECOVERY TRANSPORT

Towing the tractor	5-2
--------------------------	-----

6 WORKING OPERATIONS

FOUR WHEEL DRIVE (4WD)

Four-wheel drive with electro-hydraulic control	6-1
---	-----

DIFFERENTIAL LOCK

Electrohydraulic differential lock	6-2
--	-----

REMOTE VALVES

General safety rules	6-3
Rear remote control valve(s)	6-4
Electrohydraulically controlled side hydraulic valves	6-8
Electrohydraulically controlled rear remote control valves	6-10
Side hydraulic valves	6-11

REAR POWER TAKE-OFF (PTO)

Power take off (PTO)	6-12
----------------------------	------

REAR HYDRAULIC LIFT

Hydraulic lift with mechanical control	6-16
Proportional control lever	6-17
Hydraulic lift with electronic control	6-19

FRONT HYDRAULIC LIFT

Hydraulic lift with mechanical control	6-24
--	------

REAR THREE-POINT HITCH

Operating Instructions	6-26
Attach the implement	6-30
Additional equipment attachment points	6-32

SWINGING DRAWBARS

Safety rules	6-34
Swinging drawbar	6-35

REAR TOW HITCH

Safety rules	6-36
Towing hitch	6-37

WHEELS AND TIRES

Wheels and tires	6-39
Tire types	6-43

WHEEL TRACK ADJUSTMENT

Wheel tread settings	6-45
Tire Combinations and Tread Positions	6-48

BALLAST

Ballast	6-51
---------------	------

7 MAINTENANCE

GENERAL INFORMATION

General safety before you service	7-1
Introduction	7-3
Various controls	7-4
Body maintenance	7-5
Break-in period	7-7
Fuel storage	7-8
General specification	7-9
Organic Acid Technology (OAT) coolant	7-10
Consumables	7-12
Capacities	7-14
Opening the hood	7-15

MAINTENANCE CHART

Maintenance chart	7-16
-------------------------	------

AS REQUIRED

Engine coolant level	7-18
Windscreen washer tank	7-18
Clutch pedal adjustment	7-18
Parking brake or parking lock - Adjust	7-19

Radiator - Cleaning	7-19
Tire pressure	7-20
Brake pedals	7-21

AT WARNING MESSAGE DISPLAY

Engine air filters	7-22
Fuel filter water drain	7-23
Brake fluid level.....	7-24

EVERY 10 HOURS OR EACH DAY

Engine oil level	7-25
------------------------	------

After first 50 hours

Maintenance - Tighten.....	7-26
Maintenance - Check.....	7-26
Maintenance - Replace.....	7-26
Maintenance - Cleaning	7-27
Maintenance - Test	7-27
Maintenance - Grease.....	7-27

EVERY 50 HOURS

Rear wheel hub.....	7-27
Lift and linkage	7-28
2WD steering cylinder	7-28
2WD front axle pivot.....	7-28
4WD transmission shaft	7-29
2WD right and left-hand stub axle.....	7-29

EVERY 100 HOURS

Transmission oil cooler	7-30
Air conditioning condenser	7-30
Intercooler	7-30
Cab air filter.....	7-31
Cab recirculated air filter	7-31

EVERY 200 HOURS

4WD front axle pivot.....	7-32
4WD transmission shaft	7-33
4WD front axle oil breather	7-34
4WD front axle swivel bearings.....	7-35

EVERY 300 HOURS

Alternator belt.....	7-36
Transmission oil filter	7-36
Oil filter models with power shuttle/dual command.....	7-36
Engine air filters	7-37
Transmission oil level.....	7-37
4WD front axle housing.....	7-37

4WD front axle final drives	7-38
2WD front wheels.....	7-38
EVERY 500 HOURS	
Engine oil and filter	7-39
Fuel filter.....	7-40
Fuel pre-filter	7-41
EVERY 600 HOURS	
Engine oil and filter	7-42
Fuel filter.....	7-43
Fuel pre-filter	7-44
Wheel nuts torque	7-45
EVERY 1200 HOURS OR ANNUALLY	
Cab air filters	7-46
Cab recirculated air filter	7-47
Engine air filters	7-47
Fuel tank.....	7-47
EVERY 1200 HOURS OR EVERY 2 YEARS	
Engine valves.....	7-48
Change transmission oil.....	7-48
Change the engine coolant fluid - Conventional type coolant	7-50
EVERY 1800 HOURS	
Fuel injectors - Check	7-53
EVERY 3600 HOURS OR EVERY 4 YEARS	
Change the engine coolant fluid - OAT type coolant	7-53
ELECTRICAL SYSTEM	
Battery	7-56
Mechanical battery isolator Negative (-) disconnect switch - Check	7-58
Fuses and relays	7-59
Fuses and relays location	7-60
Fuses and relays location	7-62
Fuses and relays location Fuses and relays on cab right hand upright	7-64
Headlight - Adjust.....	7-64
Headlight - Replace	7-65
STORAGE	
Tractor storage	7-66
CALIBRATIONS	
Dual command calibration.....	7-67
Electronic lift calibration	7-70

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

Display fault codes	8-1
TRUBLESHOOTING ENGINE	8-2
Electrical system - Troubleshooting	8-5
Hydraulic systems - Troubleshooting	8-6
Rear three-point hitch - Troubleshooting	8-7
Hydraulic service brakes - Troubleshooting	8-8
Cab climate control - Troubleshooting	8-9

ALARM(S)

Alarms	8-10
Alarms, cause, solutions	8-11

9 SPECIFICATIONS

Dimensions and weights	9-1
Maximum permitted loads on front and rear axle	9-6
Maximum permitted loads on drawbar	9-7
Maximum permitted loads on towing hitch	9-8
Speed table for 16x16 gearbox	9-9
Speed table for 16x16 gearbox	9-11
Speed table for 28x16 gearbox	9-13
Speed table for 32x16 gearbox	9-14
Speed table for 32x16 gearbox	9-16
Speed table for 32x16 gearbox	9-18
Speed table 44x16 gearbox	9-20
Consumables	9-21
Capacities	9-23
Technical data	9-24

10 ACCESSORIES

Radio	10-1
Hydraulic valve for trailer brakes Not available on all markets	10-6

1 - GENERAL INFORMATION

Note to the Owner

This manual contains information concerning the adjustment and maintenance of your new equipment. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this equipment. Please have all operators read this manual carefully and keep it available for ready reference.

The CASE IH dealer will provide instructions on the general operation of new equipment. The dealer's staff, assigned to maintenance, is available for any questions related to the operation of the machine.

Your CASE IH dealer carries a complete line of genuine CASE IH service parts. These parts are manufactured and carefully inspected to insure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and product identification number of your new equipment when ordering parts. Locate these numbers now and record them below. Refer to the 'General Information' section of this manual for the location of the model code and product identification numbers of your machine.

PLEASE RECORD THE FOLLOWING INFORMATION
Model :
Product Identification Number (PIN):



Warning symbol. It is used with and without signal words to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

⚠ WARNING

**Illustrations in this manual may show protective shielding open or removed to better illustrate a particular feature or adjustment.
Replace all shields before operating the machine.
Failure to comply could result in death or serious injury.**

W0012A

The machine has been designed and built according to the highest standards of quality and it complies with all current safety regulations. However, the risk of accidents can never be completely excluded. That is why it is essential to observe elementary safety rules and precautions.

Read this manual carefully, paying particular attention to the instructions concerning safety, operation and maintenance so as to avoid the risk of injury while operating or servicing the machine.

Do not use this machine for any application or purpose other than those described in this manual. If the machine is to be used for work involving the use of special attachments, accessories or equipment, consult your CASE IH Dealer in order to make sure that any adaptations or modifications made are in keeping with the machine's technical specifications and with prevailing safety requirements.

Any modification or adaptation which is not approved by the manufacturer may invalidate the machine's initial conformity with safety requirements.

The machine must undergo regular inspections, the frequency of which varies according to the type of use. Consult your authorized CASE IH dealer.

Always keep this manual in the operator's compartment (in the seat back, behind the operator's seat). Make sure it is always complete and in good condition. To receive extra copies of the manual or copies in languages other than that of your country of residence, please contact your CASE IH dealer.

The manufacturer is committed to the constant improvement of its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

NOTICE: *The information in this manual is provided on the basis of the information that was available at the time the manual was written. Settings, procedures, part numbers, software and other items may change, which may affect the maintenance of the machine. Ensure that you have complete and current information from your dealer before you start any machine operation. All data given in this book is subject to production variations.*

Engine tampering statement:

ATTENTION: *The fuel system and engine on your machine are designed and built to government emissions standards. Tampering by dealers, customers, operators and users is strictly prohibited by law. Failure to comply with this prohibition could result in government fines, rework charges, invalid warranty, legal action and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*

Intended use

NOTE: *Your tractor is designed according to European directives related to health and safety risks; though it has been designed to minimize all the potential risks it is mandatory to carefully read, understand and observe all the decals and labels and to always refer to information and prescriptions outlined in this manual to prevent all residual potential risks. If you need further assistance please do not hesitate to contact your dealer.*

Your tractor is designed and made to pull, carry and power a variety of mounted or towed equipment, although within some physical limits. The working speed and performance may depend on various factors, such as weather and terrain conditions. Though the tractor is designed to perform in combination with a variety of equipment, there may be a number of combinations of the above parameters for which there is severe degradation of performance of the tractor and/or its mounted or trailed equipment. If you notice degradation of performance, contact your dealer for assistance, he may have useful information for improvements, or a kit may be available to enhance the performance.

Please carefully read and consider the following precautions:

- Do not use the tractor for purposes other than those intended by the manufacturer and outlined in this manual.
- Do not use the tractor beyond its limits of terrain gradient and stability. Using the tractor beyond these limits may result in roll-over or tip-over. Observe the recommendations in this manual.
- Do not use the tractor at higher speeds than those allowed by the load and the environment. A wet surface or other low adherence conditions may increase the braking distance or result in vehicle instability. Always adapt your travelling speed according to the load of the vehicle and the characteristics of the road.
- Do not use the tractor near or on soft verges of canals and brooks or banks and verges that are undermined by rodents. The tractor may sink sideways and roll over.
- Do not use the tractor on unstable crossings or bridges and/or on soft surfaces or ones that are not strong enough. These constructions may collapse and cause roll-over of the tractor. Always inspect the condition and carrying capacity of bridges and ramps before crossing.
- Do not use equipment mounted on the tractor which is not correctly matching and firmly fixed. The use of implements or accessories that have not been approved or are not correctly connected may increase the risk of roll-over of the tractor if they come loose. Ensure that the dimensions of the three-point linkage interface of both the tractor and the equipment comply with the categories defined in ISO 730. Ensure that the dimensions and speed of the PTO shaft on the tractors match those of the equipment.
- Do not use the tractor in combination with equipment without having consulted the specific Operator's Manual provided with the equipment. The tractor is a universal tool to carry, tow and drive a variety of equipment. This manual alone cannot provide you with all the information required for the safe operation of the combination.
- Do not use the tractor for pulling work, in cases where you do not know whether the load will yield, for instance when pulling stumps; the tractor may flip over when the stump is not yielding.
- Be cautious that the centre of gravity of the tractor may increase when loads on the front-end loader or the three-point linkage are raised. In these conditions, the tractor may roll over earlier than expected.
- Do not step down from the tractor without shutting down the PTO, shifting the transmission to park or neutral and applying the park brake, unless continued PTO operation is required for some equipment, such as pumps or wood chippers. The latter equipment may have an emergency stop device on the equipment itself, as human intervention is needed during operation. But other equipment, engaged and driven by the tractor will have no means to stop the power transmission, other than the PTO clutch of the tractor.
- You must take the necessary precautions (e.g. assistance) to always be aware of the possible presence of bystanders, especially when manoeuvring in confined areas, such as the farm yard and sheds. Keep people away from the tractor during work. Ask bystanders to leave the field. There is not only the risk of being run over by the tractor, but objects ejected by some equipment mounted on the tractor, such as a rotary mower, may cause harm. Stones may be thrown further than the mowed crop. Pay the necessary attention while operating next to public roads or footpaths. Thrown objects can be projected outside the field and hit unprotected people such as cyclists or pedestrians. Wait to cut the edge of the field till it is clear of bystanders.
- Do not allow riders on the tractor; do not allow people to stand on the access step to the cab when the tractor is moving. Your view to the left will be obstructed and a rider risks falling from the tractor during unexpected or abrupt movements.
- Always stay clear from the implements operating area and especially do not stand between the tractor and the implement or the trailed vehicle when operating lift controls; ensure no bystanders are near these operating areas.
- Certain functions of your tractor are controlled by software and some of them are safety-related. Do not attempt to modify or download software not certified and distributed by the manufacturer. Electronic settings and logics may be destroyed and seriously affect the functioning of the tractor. This may result in unpredictable and unsafe behaviour of the tractor. Always refer to your dealer; he has the appropriate tools and data sets

- and owns the officially released software versions and updates for your tractor.
- Your tractor may be equipped with a number of sensors to control safety functions. Tripping these sensors will result in a safe operation mode. Do not attempt to bypass any function on the tractor. You will be exposed to serious hazards, and moreover, the behaviour of the tractor may become unpredictable.
 - The tractor has only one operator station and this is a one man operated vehicle. There is no need for other people on or around the tractor during normal operation. Do not allow riders on the tractor; do not allow people to stand near the access to the cab or on the step when the tractor is moving. Your view to the left will be obstructed and a rider risks falling from the tractor during unexpected or abrupt movements.

Electro-Magnetic Compatibility (EMC)

This machine complies strictly with the European Regulations on electro-magnetic emissions. However, interference may arise as a result of add-on equipment which may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- Ensure that each piece of non- CASE IH equipment fitted to the machine bears the CE mark.
- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the machine.
- The electro-magnetic field generated by the add-on system should not exceed **24 V/m** at any time and at any location in the proximity of electronic components.

Failure to comply with these rules will render the CASE IH warranty null and void.

Manual scope and required training level

Introduction to this manual

This manual gives information about the use of your CASE IH machine as intended and under the conditions foreseen by CASE IH during normal operation, routine service, and maintenance.

This manual does not contain all the information that relates to periodic service, conversions, and repairs that only trained service personnel can perform. Some of these activities may require appropriate facilities, technical skills, and/or tools that CASE IH does not supply with the machine.

The manual contains the chapters as shown on the Contents pages. See the Index at the end of this manual to locate specific items about your CASE IH machine.

Normal operation

Normal operation consists of the use of this machine for the purpose CASE IH intends by an operator that:

- Is familiar with the machine and any mounted equipment or towed equipment
- Complies with the information on operation and safe practices as specified by CASE IH in this manual and by the signs on the machine

Normal operation includes:

- Preparation and storage of the machine
- Addition and removal of ballast
- Connection and disconnection of mounted equipment and/or towed equipment
- Adjustment and configuration of the machine and equipment for the specific conditions of the job site, field, and/or crop
- Movement of components into and out of working positions

Routine service and maintenance

Routine service and maintenance consists of the daily activities necessary to maintain the proper machine function. The operator must:

- Be familiar with the machine characteristics
- Comply with the information on routine service and safe practices as specified by CASE IH in this manual and by the signs on the machine

Routine service can include:

- Fueling
- Cleaning
- Washing
- Topping up fluid levels

- Greasing
- Replacing consumable items such as light bulbs

Periodic service, conversions, and repairs

Periodic service consists of activities that are necessary to maintain the expected life of the CASE IH machine. These activities have defined intervals.

Trained service personnel familiar with the machine characteristics must perform these activities at the defined intervals. Trained service personnel must comply with the information on periodic service and safe practices as partly specified by CASE IH in this manual and/or other company literature.

Periodic service includes:

- Oil change service for the engine, hydraulic circuits, or transmission
- Periodic exchange of other substances or components as required

Conversion activities rebuild the CASE IH machine in a configuration that is appropriate for a specific job site, crop, and/or soil conditions (e.g., installation of dual wheels). Conversion activities must be done:

- By trained service personnel familiar with the machine characteristics
- By trained service personnel that comply with the information on conversion as partly specified by CASE IH in this manual, assembly instructions, and/or other company literature

Repair activities restore proper function to a CASE IH machine after a failure or degradation of performance. Dismantling activities occur during the scrapping and/or dismantling of the machine.

Trained service personnel familiar with the machine characteristics must perform these activities. Trained service personnel must comply with the information for repair as specified by CASE IH in the service manual.

Before you operate

Read this manual before you start the engine or operate this CASE IH machine. Contact your CASE IH dealer if:

- You do not understand any information in this manual
- You need more information
- You need assistance

All persons training to operate, or who will operate this CASE IH machine should be old enough to possess a valid local vehicle operating permit (or meet other applicable local age requirements). These persons must demonstrate the ability to operate and service the CASE IH machine in a correct and safe manner.

Buy Now



Our support email:

ebooklibonline@outlook.com