

ORIGINAL INSTRUCTIONS

OPERATOR'S MANUAL

T4.80LP

T4.90LP

T4.100LP

T4.110LP

Tractor

*PIN HLRT4**L*HLT00001 and above*

Part number 51587130
4th edition English
March 2019



Contents

1 GENERAL INFORMATION

Note to the Owner	1-1
Intended use.....	1-3
Electro-Magnetic Compatibility (EMC)	1-5
Manual scope and required training level	1-6
Metric and imperial units abbreviations.....	1-8
Identification plates	1-10
Approval data plate.....	1-16
Operator's manual storage	1-17
Machine orientation.....	1-18
Exhaust Gas Recirculation (EGR) system	1-19

2 SAFETY INFORMATION

Safety rules and signal word definitions	2-1
Safety rules - General information	2-2
Safety rules – Maintenance	2-3
Safety rules - Wheels and tires	2-4
Safety rules – Explosions and fires	2-5
Safety rules - Fire extinguisher	2-6
Safety rules – Battery	2-7
Safety rules – Operator presence system	2-8
Safety rules - Power Take-Off (PTO)	2-9
Safety rules - Seat belts	2-10
Safety rules - Operator protective structure	2-11
Safety rules - Category 2 cabin (standard)	2-13
Safety rules - Category 4 cabin (if equipped)	2-14
Safety rules - HVAC system	2-16
Safety rules - Personal Protective Equipment (PPE)	2-17
Safety rules - "Do not use" sign	2-18
Safety rules — Application of plant protection products	2-19
Safety rules - Hazardous chemicals	2-21
Safety rules - Near utilities	2-22
Safety rules - In the event of electrical storms	2-23
Safety rules – Mounting and dismounting the machine	2-24
Safety rules - Lifting and overhead loads	2-25
Ecology and the environment	2-26
Safety aspects in accordance with Regulation (EU) 1322/2014 - Annex XXII and subsequent amendments and modifications	2-27
Noise level.....	2-36
Vibration levels	2-37
Machine stability.....	2-38
Decals and plates - Safety signs	2-40
Towing the tractor for recovery	2-62
Tractor jacking points.....	2-63
Burn prevention.....	2-64
Emergency exit	2-65

Wheel chocks.....	2-66
-------------------	------

3 CONTROLS AND INSTRUMENTS

Access to operator's platform

Mounting and dismounting	3-1
Getting to know the internal parts of the cab	3-2
Clock adjustment	3-6

Operator's seat

Mechanical suspension seat	3-7
Air seat	3-8
Air seat – “PREMIUM” model	3-9
Safety belt	3-10

Forward controls

Instrument panel.....	3-11
Front controls	3-16

Left-hand side controls

Left-hand side controls	3-20
Left-hand side controls	3-21

Right-hand side controls

Right-hand side controls.....	3-22
-------------------------------	------

Overhead controls

Overhead controls	3-25
-------------------------	------

Exterior controls

Exterior controls	3-26
-------------------------	------

Display

Programming tractor functions	3-28
Ground speed calibration.....	3-29
Ground speed calibration.....	3-30
Calibrating tool width	3-31
Programming maintenance work	3-32
Activating/deactivating buzzer.....	3-34
Setting units of measurement	3-35
Viewing error codes	3-36
Alarms	3-37
Display warnings overview	3-38

4 OPERATING INSTRUCTIONS

Commissioning the unit

Basic operating safety rules	4-1
Refueling	4-2

Starting the unit

Engine starting system - Start	4-3
--------------------------------------	-----

Stopping the unit

Engine starting system - Stop	4-5
Electronic battery isolator - Overview	4-6

Moving the unit

Machine movement start-up.....	4-7
Idle speed management.....	4-8
Shuttle Command™ transmission (16x16)	4-9
Shuttle Command™ transmission and creeper (28x16)	4-11
Split Command™ transmission (32x16)	4-13
Transmission with Power Shuttle (16x16)	4-15
Dual Command™ transmission (32x16)	4-17
Dual Command™ transmission and creeper (44x16)	4-21

5 TRANSPORT OPERATIONS

Road transport

Transporting the machine	5-1
--------------------------------	-----

Recovery transport

Towing the tractor.....	5-1
-------------------------	-----

6 WORKING OPERATIONS

General information

Roll over protective structure (ROPS).....	6-1
--------------------------------------------	-----

Engine accelerator controls

Hand throttle control lever - Overview	6-2
Foot throttle control - Overview.....	6-2

Constant engine RPM

Constant engine RPM	6-3
---------------------------	-----

Clutch pedal

Clutch pedal	6-4
--------------------	-----

Brakes

Brake pedals - Safety rules	6-4
Service brakes.....	6-6
Parking brake.....	6-7
Park lock.....	6-8

Trailer braking systems

Brakes and controls - Operating.....	6-9
Hydraulic trailer brakes - Dual-line, compatible with trailers with universal single line	6-10
Brake control switch - Operating	6-12

Four-Wheel Drive (4WD)

Electro-hydraulic control - Operating	6-13
---------------------------------------------	------

Differential lock system

Differential lock	6-14
-------------------------	------

Air conditioning

Air-conditioning system.....	6-15
------------------------------	------

Cab pressurizing system

Cab pressurizing system - Operating.....	6-17
Air filter - Operating.....	6-25

Remote control valves

Remote control valves - Safety rules	6-27
Rear remotes valves - Overview	6-27
Mechanically controlled rear remote control valves	6-29
Electrohydraulically controlled rear remote control valves	6-31
Side hydraulic valves Models with 80 l/min to 64 l/min pump	6-35
Side hydraulic valves – Models with 80 l/min or 64 l/min pump	6-37

Rear Power Take-Off (PTO)

Two-speed rear Power Take-Off (PTO) - Grouped Safety Message	6-41
Rear Power Take-Off (PTO) - Overview	6-41
Power take-off speeds (PTO)	6-43
Synchronised power take-off	6-44
Non-synchronised power take-off	6-45

Front Power Take-Off (PTO)

Front Power Take-Off (PTO) - Safety rules.....	6-48
Front Power Take-Off (PTO) - Operating	6-49

Rear hydraulic lift	
Safety rules	6-50
Main lift system - Product overview	6-51
Rear hydraulic lift - Overview	6-52
Rear hydraulic lift with mechanical control - Models with cab	6-53
Rear hydraulic lift with mechanical control - Models without cab	6-56
Rear hydraulic lift with electronic control	6-58
Rear three-point hitch	
Rear three-point hitch - Safety rules.....	6-63
Rear three-point hitch - Operating.....	6-63
Rear three-point hitch - Operating — Configuring the tractor when towing a trailer with single or multiple axles	6-71
Three-point hitch front	
Front hitch - Safety rules	6-72
Front hitch - Operating	6-72
Towbar	
Drawbar - Safety rules.....	6-74
Towbar.....	6-75
Rear tow hitch	
Safety rules.....	6-76
Towing hook	6-77
Wheels and tires	
Wheels - General specification	6-80
Tires size	6-84
Track adjustment	
Adjustment of the front mudguards.....	6-86
Track adjustment	6-89
Front tracks diagram	6-91
Rear tracks diagram	6-92
Ballasting	
Ballast	6-93
Liquid ballast	6-95
Power sockets	
Power sockets Power sockets	6-97

Beacon

Beacon - Overview	6-98
-------------------------	------

7 MAINTENANCE

General information

General safety before you service	7-1
Introduction	7-3
Body maintenance	7-4
General specifications - Biodiesel fuels - Biodiesel fuels	7-6
General specification - Diesel fuel	7-8
Recommended engine oil for operating temperature ranges	7-9
Organic Acid Technology (OAT) coolant	7-10
Consumables	7-11
Capacities	7-12
Opening the engine bonnet	7-13
Removing the engine side shields	7-14

Maintenance planning

Maintenance chart	7-15
-------------------------	------

As required

Windshield washer fluid reservoir - Check	7-17
Road lamps – Adjustment	7-18
Clutch pedal - Adjust	7-19
Parking brake - Adjust	7-20
Oil cooler Transmission - Check	7-21
Radiator and intercooler - Control	7-22
Radiator and intercooler – Cleaning	7-23
Tires — Pressure check and general conditions	7-24
Engine air cleaner outer element - clean	7-25
Engine lubrication system - Replace oil	7-26
Fuel cooler - Cleaning	7-28
Expansion tank - Level make up	7-29
Cab climate control - Check	7-30
Air filter - Check category 2 - Check	7-31
Air filter - Check category 4 - Check	7-32

AT WARNING MESSAGE DISPLAY

Fuel filters - Drain fluid	7-33
Brake fluid - Level make up	7-35
Expansion tank - Check Coolant Level	7-36
Engine lubrication system - Check	7-37
Cab air filter category 4 - Replace	7-38
Air cleaner - Cleaning	7-39

Every 10 hours or daily

Engine lubrication system - Check	7-40
-----------------------------------------	------

Expansion tank - Check expansion tank fluid level	7-41
Air cleaner - Check	7-42
Brake pedals - Check coupling pin	7-43
Fuel filters - Check glass pre - filter	7-44

Initial 50 hours

Maintenance - Tighten.....	7-45
Maintenance - Check.....	7-45
Maintenance - Replace	7-46
Maintenance - Cleaning	7-46
Maintenance - Test	7-46
Maintenance - Grease.....	7-47

Every 50 hours

Front axle system - Grease.....	7-48
Drive shaft - Grease	7-49
Hydraulic lift and linkage - Greasing	7-50
Front three-point hitch - Greasing	7-50

Every 100 hours

Oil cooler and lines - Check drives	7-51
Oil cooler Drive line - Cleaning	7-52
Air conditioner condenser - Cleaning	7-54
Cab air recirculation filter - Cleaning	7-56
Alternator drive belt - Check.....	7-57
Air conditioning compressor belt - Check	7-58
Air filter - Cleaning category 2 - Clean	7-59

Every 200 hours

4WD front axle pivot - Greasing	7-60
4WD transmission shaft - Greasing	7-60
4WD front axle swivel bearings - Greasing	7-60

Every 300 hours

Hydraulic oil filter - Replace	7-61
Transmission oil filter - Replace	7-63
Drive line lubrication - Check the oil level	7-64
Engine air filter - Cleaning	7-65
Brake system - Control	7-66
Axle housing - Check.....	7-67
4WD front axle housing Check the oil level	7-68
4WD front axle final drives - Oil level check	7-68
4WD front axle steering knuckles	7-69

Every 600 hours

Front and rear wheel nuts - Check tightening torque	7-70
-----------------------------------------------------------	------

Oiling system - Oil and filter replacement (Models without cabs)	7-71
Oiling system - Oil and filter replacement (Models with cabs)	7-74
Fuel filters - Replace	7-76
Fuel filters - Cleaning glass first stage fuel filter	7-79
Air intake lines - Check	7-81
Front Power Take-Off (PTO) - Check	7-82
Front Power Take-Off (PTO) - Check Oil breather	7-83
Clutch hydraulic release control - Check - Control	7-84

Every 1200 hours or annually

Cab air filter category 2 - Replace	7-85
Cab air recirculation filter - Replace	7-86
Engine air filters - Replace	7-87
Blowby recirculation filter - Replace	7-88
Rear wheel hub - Greasing	7-89

Every 1200 hours or two years

Front axle housing oil, 4WD – Replacement	7-90
4WD front axle final drives - Change oil	7-91
Hydraulic system oil – Replacement	7-92
Engine cooling system - Change fluid (normal liquid)	7-93
Front Power Take-Off (PTO) - Change oil	7-98
Alternator drive belt - Replace	7-100
Air conditioning compressor belt - Replace	7-101

Every two years

Receiver-dryer - Replace	7-102
Brake fluid reservoir - Check	7-103
Fuel tank - draining	7-104

Every 3600 hours

Engine cooling system - Change fluid (OAT liquid)	7-105
Brake fluid reservoir - Change fluid	7-110

Electrical system

Battery access and service	7-111
Battery cut-off switch	7-115

Light adjustments

Road lamps – Replacement	7-116
Road lamps – Adjustment	7-117

Fuse and relay locations

Fuse and relay box - Overview	7-118
Fuse and relay box - Overview	7-119

Storage

Tractor storage	7-129
-----------------------	-------

Calibrations

Dual Command™ transmission - Calibrate	7-129
Electronic lift calibration	7-133

8 TROUBLESHOOTING

Fault code resolution

TROUBLESHOOTING ENGINE	8-1
Electrical system - Troubleshooting ELECTRICAL SYSTEM	8-3
Hydraulic systems - Troubleshooting HYDRAULIC SYSTEM	8-4
Couplers - Troubleshooting	8-5
Rear three-point hitch - Troubleshooting	8-6
Hydraulic service brakes - Troubleshooting	8-6
Cab climate control - Troubleshooting	8-6

Symptom(s)

SYMPTOM(S)	8-7
------------------	-----

9 SPECIFICATIONS

Dimensions and weights	9-1
Maximum permitted loads on front and rear axle	9-4
Maximum permitted loads on towing hitch	9-5
Maximum permitted loads on drawbar	9-6
Maximum permitted loads on three point hitch	9-7
Additional equipment attachment points	9-8
Mid-mounted implement mounting brackets	9-9
Speed table for 16x16 gearbox	9-10
Speed table for 28x16 gearbox	9-12
Speed table for 32x16 gearbox	9-15
Speed table 44x16 gearbox	9-18
Capacities	9-21
Consumables	9-22
General specification	9-23

10 ACCESSORIES

Tool box - Overview	10-1
Radio	10-2
Fuel cooler - Overview	10-7

1 - GENERAL INFORMATION

Note to the Owner

This manual contains information concerning the adjustment and maintenance of your new equipment. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this equipment. Please have all operators read this manual carefully and keep it available for ready reference.

The NEW HOLLAND dealer will provide instructions on the general operation of new equipment. The dealer's staff, assigned to maintenance, is available for any questions related to the operation of the machine.

Your NEW HOLLAND dealer carries a complete line of genuine NEW HOLLAND service parts. These parts are manufactured and carefully inspected to insure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and product identification number of your new equipment when ordering parts. Locate these numbers now and record them below. Refer to the 'General Information' section of this manual for the location of the model code and product identification numbers of your machine.

PLEASE RECORD THE FOLLOWING INFORMATION
Model :
Product Identification Number (PIN):



Warning symbol. It is used with and without signal words to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

⚠ WARNING

**Illustrations in this manual may show protective shielding open or removed to better illustrate a particular feature or adjustment.
Replace all shields before operating the machine.
Failure to comply could result in death or serious injury.**

W0012A

The machine has been designed and built according to the highest standards of quality and it complies with all current safety regulations. However, the risk of accidents can never be completely excluded. That is why it is essential to observe elementary safety rules and precautions.

Read this manual carefully, paying particular attention to the instructions concerning safety, operation and maintenance so as to avoid the risk of injury while operating or servicing the machine.

Do not use this machine for any application or purpose other than those described in this manual. If the machine is to be used for work involving the use of special attachments, accessories or equipment, consult your NEW HOLLAND Dealer in order to make sure that any adaptations or modifications made are in keeping with the machine's technical specifications and with prevailing safety requirements.

Any modification or adaptation which is not approved by the manufacturer may invalidate the machine's initial conformity with safety requirements.

The machine must undergo regular inspections, the frequency of which varies according to the type of use. Consult your authorized NEW HOLLAND dealer.

Always keep this manual in the operator's compartment (in the seat back, behind the operator's seat). Make sure it is always complete and in good condition. To receive extra copies of the manual or copies in languages other than that of your country of residence, please contact your NEW HOLLAND dealer.

The manufacturer is committed to the constant improvement of its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

NOTICE: *The information in this manual is provided on the basis of the information that was available at the time the manual was written. Settings, procedures, part numbers, software and other items may change, which may affect the maintenance of the machine. Ensure that you have complete and current information from your dealer before you start any machine operation. All data given in this book is subject to production variations.*

Engine tampering statement:

ATTENTION: *The fuel system and engine on your machine are designed and built to government emissions standards. Tampering by dealers, customers, operators and users is strictly prohibited by law. Failure to comply with this prohibition could result in government fines, rework charges, invalid warranty, legal action and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*

Intended use

NOTE: *Your tractor is designed according to European directives related to health and safety risks; though it has been designed to minimize all the potential risks it is mandatory to carefully read, understand and observe all the decals and labels and to always refer to information and prescriptions outlined in this manual to prevent all residual potential risks. If you need further assistance please do not hesitate to contact your dealer.*

Your tractor is designed and made to pull, carry and power a variety of mounted or towed equipment, although within some physical limits. The working speed and performance may depend on various factors, such as weather and terrain conditions. Though the tractor is designed to perform in combination with a variety of equipment, there may be a number of combinations of the above parameters for which there is severe degradation of performance of the tractor and/or its mounted or trailed equipment. If you notice degradation of performance, contact your dealer for assistance, he may have useful information for improvements, or a kit may be available to enhance the performance.

Please carefully read and consider the following precautions:

- Do not use the tractor for purposes other than those intended by the manufacturer and outlined in this manual.
- Do not use the tractor beyond its limits of terrain gradient and stability. Using the tractor beyond these limits may result in roll-over or tip-over. Observe the recommendations in this manual.
- Do not use the tractor at higher speeds than those allowed by the load and the environment. A wet surface or other low adherence conditions may increase the braking distance or result in vehicle instability. Always adapt your travelling speed according to the load of the vehicle and the characteristics of the road.
- Do not use the tractor near or on soft verges of canals and brooks or banks and verges that are undermined by rodents. The tractor may sink sideways and roll over.
- Do not use the tractor on unstable crossings or bridges and/or on soft surfaces or ones that are not strong enough. These constructions may collapse and cause roll-over of the tractor. Always inspect the condition and carrying capacity of bridges and ramps before crossing.
- Do not use equipment mounted on the tractor which is not correctly matching and firmly fixed. The use of implements or accessories that have not been approved or are not correctly connected may increase the risk of roll-over of the tractor if they come loose. Ensure that the dimensions of the three-point linkage interface of both the tractor and the equipment comply with the categories defined in ISO 730. Ensure that the dimensions and speed of the PTO shaft on the tractors match those of the equipment.
- Do not use the tractor in combination with equipment without having consulted the specific Operator's Manual provided with the equipment. The tractor is a universal tool to carry, tow and drive a variety of equipment. This manual alone cannot provide you with all the information required for the safe operation of the combination.
- Do not use the tractor for pulling work, in cases where you do not know whether the load will yield, for instance when pulling stumps; the tractor may flip over when the stump is not yielding.
- Be cautious that the centre of gravity of the tractor may increase when loads on the front-end loader or the three-point linkage are raised. In these conditions, the tractor may roll over earlier than expected.
- Do not step down from the tractor without shutting down the PTO, shifting the transmission to park or neutral and applying the park brake, unless continued PTO operation is required for some equipment, such as pumps or wood chippers. The latter equipment may have an emergency stop device on the equipment itself, as human intervention is needed during operation. But other equipment, engaged and driven by the tractor will have no means to stop the power transmission, other than the PTO clutch of the tractor.
- You must take the necessary precautions (e.g. assistance) to always be aware of the possible presence of bystanders, especially when manoeuvring in confined areas, such as the farm yard and sheds. Keep people away from the tractor during work. Ask bystanders to leave the field. There is not only the risk of being run over by the tractor, but objects ejected by some equipment mounted on the tractor, such as a rotary mower, may cause harm. Stones may be thrown further than the mowed crop. Pay the necessary attention while operating next to public roads or footpaths. Thrown objects can be projected outside the field and hit unprotected people such as cyclists or pedestrians. Wait to cut the edge of the field till it is clear of bystanders.
- Do not allow riders on the tractor; do not allow people to stand on the access step to the cab when the tractor is moving. Your view to the left will be obstructed and a rider risks falling from the tractor during unexpected or abrupt movements.
- Always stay clear from the implements operating area and especially do not stand between the tractor and the implement or the trailed vehicle when operating lift controls; ensure no bystanders are near these operating areas.
- Certain functions of your tractor are controlled by software and some of them are safety-related. Do not attempt to modify or download software not certified and distributed by the manufacturer. Electronic settings and logics may be destroyed and seriously affect the functioning of the tractor. This may result in unpredictable and unsafe behaviour of the tractor. Always refer to your dealer; he has the appropriate tools and data sets

- and owns the officially released software versions and updates for your tractor.
- Your tractor may be equipped with a number of sensors to control safety functions. Tripping these sensors will result in a safe operation mode. Do not attempt to bypass any function on the tractor. You will be exposed to serious hazards, and moreover, the behaviour of the tractor may become unpredictable.
- The tractor has only one operator station and this is a one man operated vehicle. There is no need for other people on or around the tractor during normal operation. Do not allow riders on the tractor; do not allow people to stand near the access to the cab or on the step when the tractor is moving. Your view to the left will be obstructed and a rider risks falling from the tractor during unexpected or abrupt movements.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com