

OPERATOR'S MANUAL

# MANURE SPREADER

MS1117



HSMFG0903 Rev.1

HPOMSP3

# TABLE OF CONTENTS

TABLE OF CONTENTS.....	INSIDE COVER
WARRANTY & NOTES.....	1
DEALER PRE-DELIVERY & DELIVERY CHECKLIST.....	3
SPECIFICATIONS.....	5
BOLT TORQUE CHART.....	6
BE ALERT SYMBOL.....	7
SAFETY RULES.....	8-9
DANGER - WARNING DECALS.....	10-11
OPERATION MS1117.....	12-13
ADJUSTMENTS.....	13-15
LUBRICATION GUIDE MS1117.....	15-17
DECAL LOCATION MS1117.....	18-19
TROUBLE SHOOTING.....	20
OPTIONAL EQUIPMENT.....	21
ORDERING PARTS - ABOUT IMPROVEMENTS.....	21
PARTS LISTS & DIAGRAMS MS1117.....	22-37
OPTIONAL PAN.....	22-23
OPTIONAL HYDRAULIC ENDGATE.....	30-31
OPTIONAL TOP BEATER.....	37
SERVICE RECORDS.....	38

**WARRANTY:**

Warranty coverage is provided by John Deere according to the terms of the Agricultural/Commercial & Consumer Equipment Warranty Statement. Carefully read the warranty statement on the back of your original purchase order for details on coverage and limitations of this warranty.

**NOTES**

---

**AFTER COMPLETION, DEALER SHOULD REMOVE AND RETAIN FOR RECORDS**

**FRONTIER  
DEALER PRE-DELIVERY CHECK LIST**

After the Manure Spreader has been completely set-up, check to be certain it is in correct running order before delivering to the customer. The following is a list of points to inspect. Check off each item as you have made the proper adjustments and found the item operating satisfactorily.

- PTO shields turn freely.
- All Shields and Guards are in place and fastened.
- All grease fittings have been lubricated and gearbox filled to proper level - See lubrication guide in this manual.
- All mechanisms are operating trouble free.
- All roller chains are at proper tension.
- All bolts and fasteners are tight.
- All decals are in place and legible.

_____	_____
(Dealer's Name)	Model Number
_____	_____
(Signature of Pre-Delivery Inspector)	Serial Number
_____	_____
	(Inspection Date)

**DEALER DELIVERY CHECK LIST**

This check list that follows is an important reminder of valuable information that should be passed on to the customer at the time this Manure Spreader is delivered.

Check off each item as you explain it to the customer.

This delivery check list, when properly filled out and signed assures the customer that the Pre-delivery service was satisfactorily performed.

- Explain to the customer that the pre-delivery inspection was made.
- Explain to the customer all the safety precautions they must exercise when operating this unit.
- Explain recommended loads for different types of materials.
- Explain to customer that regular lubrication is required for proper operation and long life of machine. Show customer the lubrication section of Operator Manual.
- Give the customer Operators Manual and make sure he reads and understands all operating and service instructions.
- Record Serial Number on page 21 of this Manual.

Date Delivered _____	Dealer's Name _____
	By _____
	_____
	Signature of Original Buyer

---

# FRONTIER MODEL MS1117 MANURE SPREADER

Your Frontier spreader has been manufactured of the finest quality materials and components. The performance you get from your machine is largely dependent upon how well you read and understand this manual and apply this knowledge. There is a right and a wrong way to do everything. Please do not assume that you know how to operate and maintain your spreader before reading this manual carefully. Keep this manual available for ready reference.

## SPECIFICATIONS

	<u><b>MS1117</b></u>
Top Flare Width. . . . .	63-1/2"
Inside Width. . . . .	54"
Inside Length. . . . .	11'-1"
Inside Depth. . . . .	25-3/4"
Overall Width w/9.00 x 20 Tires. . . . .	86-1/2"
Overall Length. . . . .	17'-8"
Overall Loading Height (Top of Flare). . . . .	47-1/2"
Overall Height w/Hyd. Endgate. . . . .	51"
Diameter of Beater. . . . .	27"
Weight w/9.00 x 20 Tires. . . . .	2030 Lbs
Capacity (Old Rating). . . . .	175 Bu.
Capacity - Cu. Ft. Struck Level. . . . .	105
Rear Hydraulic Endgate. . . . .	Optional
Semi Liquid Rear Pan. . . . .	Optional
Upper Beater. . . . .	Optional
Drive. . . . .	Two Speed Gearbox
Variable Speed Hydraulic Drive. . . . .	Not Available
Front Splash Panel. . . . .	Standard
PTO Speed. . . . .	540 RPM

**Note:**

Determine right and left side of spreader by viewing it from the rear. If instructions or parts lists call for hardened bolts see page 6 to identify.

**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)