

OPERATOR'S MANUAL


T7.170

T7.185

T7.200

T7.210

Range Command / Power Command Tractors



Part Number 84349877

1st edition English
December 2010



ORIGINAL INSTRUCTIONS - according to Directives 2006/42/EC, Annex I 1.7.4.1

OPERATOR'S MANUAL


T7.170

T7.185

T7.200

T7.210

Range Command / Power Command Tractors



Part Number 84349877

1st edition English
December 2010



Contents

1 GENERAL INFORMATION

CE DECLARATION OF CONFORMITY	1-1
METRIC AND IMPERIAL UNITS ABBREVIATIONS	1-3
TO THE OWNER	1-5
PRODUCT IDENTIFICATION	1-7
ENGINE IDENTIFICATION	1-8
DRIVELINE IDENTIFICATION	1-9
CAB IDENTIFICATION	1-10
PRODUCT IDENTIFICATION PLATE	1-10
ECOLOGY AND THE ENVIRONMENT	1-11
NOISE LEVEL	1-12
PROGRAMMING TRACTOR FUNCTIONS	1-12
BEFORE OPERATING THE TRACTOR	1-13
INTERNATIONAL SYMBOLS	1-14
VIBRATION LEVEL INFORMATION SHEET	1-15
MACHINE STABILITY	1-16
INSTRUCTOR'S SEAT	1-20
SELECTIVE CATALYTIC REDUCTION (SCR) SYSTEM	1-21

2 SAFETY INFORMATION

SAFETY DECALS	2-1
SAFETY PRECAUTIONS	2-9
BEFORE DRIVING THE TRACTOR	2-10
DRIVING THE TRACTOR	2-11
OPERATING THE TRACTOR	2-12
OPERATING THE P.T.O.	2-14
OPERATING THE EXTERNAL CONTROLS	2-14
SERVICING THE TRACTOR	2-15
DIESEL FUEL	2-17
PREVENTION OF FIRE OR EXPLOSION	2-18
FIRE EXTINGUISHER	2-19
PROTECTION OFFERED BY THE TRACTOR	2-20
INTENDED USE STATEMENT	2-23

3 CONTROLS/INSTRUMENTS

ACCESS TO OPERATOR'S PLATFORM

INTRODUCTION	3-1
CAB AIR FILTERS	3-5
IN CAB STORAGE (where fitted)	3-6
CABLE AND WIRING ROUTING	3-7
MOBILE TELEPHONE USAGE	3-7
IMPLEMENT MONITOR INSTALLATION	3-8
CAB AIR PRESSURISATION MONITOR (where fitted)	3-8

OPERATOR'S SEAT

AIR SUSPENSION SEAT DELUXE	3-10
SEAT BELT	3-14

INSTRUCTOR'S SEAT

INSTRUCTIONAL SEAT (where fitted)	3-15
---	------

FORWARD CONTROLS

KEY- START SWITCH	3-16
HAZARD WARNING LIGHT SWITCH	3-16
LIGHT-/ TURN LEVER	3-17
FOLLOW ME HOME LIGHTS	3-17
WINDSHIELD WIPER AND WASHER CONTROLS	3-18
ELECTRONIC PARK BRAKE	3-19
CLUTCH/ INCHING PEDAL	3-23
FOOT BRAKES	3-23
STEERING COLUMN	3-24

LEFT-HAND SIDE CONTROLS

HANDBRAKE	3-25
-----------------	------

RIGHT-HAND SIDE CONTROLS

SWITCH PANEL	3-26
--------------------	------

REARWARD CONTROLS

SWITCH PANEL C- PILLAR	3-27
BATTERY ISOLATOR SWITCH	3-28
CLIMATE CONTROLS	3-29
MANUAL TEMPERATURE CONTROL	3-31
AUTOMATIC TEMPERATURE CONTROL (ATC)	3-32

OVERHEAD CONTROLS

SWITCH PANEL WORKLIGHTS	3-33
RADIO/CASSETTE/CD PLAYER (where fitted)	3-33
INTERIOR LIGHT	3-33

INSTRUMENT CLUSTER

ANALOGUE/ DIGITAL INSTRUMENT CLUSTER	3-35
GAUGES	3-35
INDICATOR AND WARNING LIGHTS	3-35
DISPLAYS	3-38
KEYPAD ENHANCED	3-40
SELECTING OR CHANGING THE DISPLAY SETTINGS	3-42
GROUND SPEED CALIBRATION	3-43
PERFORMANCE MONITOR	3-48
ALARM FUNCTIONS	3-56
ACCESSING STORED ERROR CODES	3-58
WARNING AND ADVISORY SYMBOLS	3-59

4 OPERATING INSTRUCTIONS

COMMISSIONING THE UNIT

TRACTOR REFUELLING	4-1
--------------------------	-----

STARTING THE UNIT

STARTING THE ENGINE	4-3
GRID HEATER COLD START AID (where fitted)	4-4
FUEL HEATER (where fitted)	4-5
COOLANT IMMERSION HEATER (where fitted)	4-5
TRANSMISSION OIL HEATER (where fitted).....	4-6
BOOSTING THE BATTERY	4-7

STOPPING THE UNIT

STOPPING THE ENGINE.....	4-8
AUTOMATIC ENGINE SHUTDOWN	4-8
AUTOMATIC ENGINE SHUTDOWN WITH ENHANCED KEYPAD (where fitted)	4-9

MOVING THE UNIT

OPERATING IN COLD TEMPERATURES	4-10
--------------------------------------	------

5 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

CARRYING THE TRACTOR ON A TRANSPORTER.....	5-1
SECURE THE HIGH VISIBILITY ROOF PANEL.....	5-1

RECOVERY TRANSPORT

TOWING THE TRACTOR.....	5-2
-------------------------	-----

6 WORKING OPERATIONS

GENERAL INFORMATION

VARIABLE ENGINE POWER MANAGEMENT	6-1
CONSTANT ENGINE SPEED	6-3
DIFFERENTIAL LOCK	6-5
FOUR WHEEL DRIVE	6-7
FRONT AXLE SUSPENSION (where fitted)	6-9
AUTOMATED HEADLAND FUNCTIONS	6-10
QUICK GUIDE.....	6-10
RECORDING AND RE-PLAYING	6-12
EXPLANATION OF SYMBOLS.....	6-14
RECORDING A SEQUENCE	6-15
RE-PLAYING A SEQUENCE.....	6-17
FAST STEERING SYSTEM (where fitted)	6-19

TRANSMISSION

FOOT THROTTLE PEDAL	6-21
HAND THROTTLE	6-21
SHUTTLE LEVER	6-21
RANGECOMMAND TRANSMISSION	6-23
TRANSMISSION OPERATION.....	6-23
POWERSHIFT CONTROL LEVER.....	6-24
DRIVING THE TRACTOR.....	6-25

AUTO SHIFT FUNCTION	6-27
AUTO SHIFTING IN ROAD MODE	6-28
AUTO SHIFTING IN FIELD MODE.....	6-30
CHANGING THE FIELD MODE AUTO SHIFT POINT	6-33
CHANGING GEAR SHIFT THRESHOLD	6-34
PROGRAMMING REVERSE GEAR RATIOS	6-35
CREEPER GEARS (where fitted)	6-37
POWERCOMMAND TRANSMISSION.....	6-38
TRANSMISSION OPERATION.....	6-38
POWERSHIFT CONTROL LEVER.....	6-39
DRIVING THE TRACTOR.....	6-40
AUTO SHIFT FUNCTION	6-41
AUTO SHIFTING IN ROAD MODE	6-41
AUTO SHIFTING IN FIELD MODE.....	6-45
CHANGING GEAR SHIFT THRESHOLD	6-49
PROGRAMMING REVERSE GEAR RATIOS	6-50
CREEPER GEARS (where fitted)	6-52
ERROR CODES.....	6-53

REAR POWER TAKE-OFF

P.T.O. OPERATING PRECAUTIONS.....	6-54
CHANGING THE P.T.O. OUTPUT SHAFT	6-54
ATTACHING P.T.O. DRIVEN EQUIPMENT	6-55
P.T.O. OPERATION.....	6-56
THREE-SPEED P.T.O. SYSTEM.....	6-62
GROUND DRIVE P.T.O. (where fitted)	6-63
EXTERNAL P.T.O. CONTROLS.....	6-64
AUTO P.T.O. OPERATION	6-66

FRONT POWER TAKE OFF

P.T.O. OPERATION.....	6-68
-----------------------	------

REAR HITCH

ELECTRONIC DRAFT CONTROL	6-70
ELECTRONIC DRAFT CONTROL OPERATION	6-72
EXTERNAL HITCH CONTROLS.....	6-78

FRONT HITCH

SETTINGS AND ADJUSTMENTS	6-80
HITCH OPERATION.....	6-82
AUXILIARY FRONT COUPLERS (where fitted).....	6-86
EXTERNAL HITCH CONTROLS.....	6-88

HYDRAULIC REMOTE CONTROL VALVES

REMOTE CONTROL VALVES	6-89
OPERATING WITH REMOTE VALVES	6-91
CONNECTING REMOTE CYLINDERS	6-95
HYDRAULIC OIL LEVEL WHEN USING REMOTE HYDRAULIC EQUIPMENT	6-97

ELECTRO-HYDRAULIC REMOTE CONTROL VALVES (where fitted)

MID MOUNT REMOTE VALVES	6-99
JOYSTICK OPERATION WITH A FRONT LOADER.....	6-100

HYDRAULIC POWER BEYOND PORT	
HYDRAULIC POWER BEYOND FOR EXTERNAL SERVICES	6-102
THREE POINT HITCH	
ATTACHING THREE-POINT HITCH EQUIPMENT	6-105
LIFT ROD ADJUSTMENT	6-107
TOP LINK ADJUSTMENT	6-109
FLEXIBLE LINK END ADJUSTMENT	6-110
QUICK HITCH	6-111
LINKAGE STABILISER ADJUSTMENT	6-113
DRAWBARS AND TOWING ATTACHMENTS	
DRAWBARS AND TOWING ATTACHMENTS	6-116
SWINGING DRAWBARS	6-119
AUTOMATIC PICK-UP HITCH	6-122
REAR TOW HITCH	6-124
TRAILER BRAKING SYSTEMS	
AIR-OPERATED TRAILER BRAKES	6-130
AIR-OPERATED TRAILER BRAKES (Italy only)	6-133
TRAILER BRAKE BIAS CONTROL	6-134
AUXILIARY AIR SUPPLY CONNECTOR (where fitted)	6-134
HYDRAULIC TRAILER BRAKES	6-135
HYDRAULIC TRAILER BRAKES (Italy only)	6-136
WHEEL TRACK ADJUSTMENT	
FRONT WHEEL TRACK ADJUSTMENT	6-137
FRONT WHEEL ALIGNMENT	6-140
STEERING STOPS	6-141
FRONT AXLE OSCILLATION STOPS	6-141
FRONT FENDER	6-142
REAR WHEEL TRACK ADJUSTMENT	6-144
FLANGE TYPE AXLE (where fitted)	6-144
BAR TYPE AXLE (where fitted)	6-147
BALLASTING AND TYRES	
BALLASTING AND TYRES	6-151
IRON WEIGHTS (where fitted)	6-154
LIQUID BALLAST	6-157
TYRE INFLATION	6-159
TYRE PRESSURES AND PERMISSIBLE LOADS	6-160
AUXILIARY POWER CONNECTIONS	
DIAGNOSTIC SOCKET	6-162
TRAILER SOCKET ELECTRICAL	6-162
ELECTRICAL POWER CONNECTORS	6-163
INTERNAL POWER CONNECTORS	6-163
EXTERNAL POWER CONNECTORS	6-165

7 MAINTENANCE

GENERAL INFORMATION

INTRODUCTION	7-1
FUEL REQUIREMENT	7-2
BIODIESEL FUEL	7-4
ENGINE OIL CHANGE	7-6
PROTECTIVE DEVICES	7-7
LUBRICANTS AND COOLANTS Lubrications and Coolants	7-9
General specification	7-11
CAPACITIES	7-12

MAINTENANCE CHART

Maintenance Chart	7-13
-------------------------	------

WHEN THE WARNING LAMP LIGHTS

CHANGE THE ENGINE AIR CLEANER OUTER ELEMENT	7-15
DRAIN FUEL SYSTEM WATER SEPARATOR.....	7-16
CHECK BRAKE FLUID LEVEL.....	7-17

EVERY 10 HOURS OR EACH DAY

CHECK ENGINE COOLANT LEVEL.....	7-18
CHECK ENGINE OIL LEVEL.....	7-19
CHECK REMOTE CONTROL VALVE DRAIN BOTTLES	7-19
CHECK WINDSCREEN WASHER RESERVOIR	7-20
DRAIN AIR RESERVOIR ON AIR OPERATED TRAILER BRAKE	7-20

FIRST 50 HOURS

SERVICE OPERATIONS.....	7-21
-------------------------	------

EVERY 50 HOURS

CLEAN THE CAB AIR FILTER	7-22
CLEAN THE COOLER SECTION	7-24
ALL GREASE FITTINGS	7-25
CHECK FRONT AND REAR WHEEL NUTS.....	7-31
CHECK TYRE PRESSURES AND TYRE CONDITION.....	7-31

EVERY 100 HOURS

INSPECT POLY V-BELT	7-32
INSPECT COMPRESSOR DRIVE BELT.....	7-32

EVERY 300 HOURS

CHECK BATTERY FLUID LEVEL.....	7-33
ADJUST HANDBRAKE.....	7-34
CHECK TRANSMISSION/REAR AXLE AND HYDRAULIC OIL LEVEL	7-35
CHECK 4WD FRONT AXLE DIFFERENTIAL AND HUBS OIL LEVEL	7-36
CHECK FRONT P.T.O. GEARBOX OIL LEVEL	7-36

EVERY 600 HOURS

CHANGE ENGINE OIL AND FILTER	7-37
CHANGE FUEL PRE-FILTER AND FUEL FILTER ELEMENT.....	7-39
CHANGE THE ENGINE AIR CLEANER OUTER ELEMENT	7-40
CHANGE CHARGE PUMP OIL FILTER	7-41
CHECK ENGINE AIR INTAKE CONNECTIONS	7-42
CHECK TRANSMISSION OIL COOLER PIPE COUPLINGS	7-43
CHANGE DEF/ AdBlue FILTER.....	7-43

EVERY 1200 HOURS OR ANNUALLY

CHANGE CAB AIR FILTERS.....	7-44
CHANGE MAIN OIL FILTER CARTRIDGE.....	7-45
CHANGE TRANSMISSION/ REAR AXLE AND HYDRAULIC OIL.....	7-46
CHANGE 4WD DIFFERENTIAL OIL	7-47
CHANGE 4WD PLANETARY HUB OIL	7-48
CHANGE FRONT P.T.O. GEARBOX OIL	7-48

EVERY 1200 HOURS OR EVERY 2 YEARS

CHECK BATTERY FLUID LEVEL.....	7-49
CHANGE DEF/ AdBlue FILTER	7-50
CHANGE ENGINE AIR CLEANER INNER ELEMENT.....	7-51
CHANGE ENGINE BREATHER FILTER	7-52
CHECK VALVE TAPPET CLEARANCE.....	7-52
CHANGE ENGINE COOLANT FLUID	7-53
CHANGE AIR BRAKE DRIER RESERVOIR.....	7-57
CHANGE POLY V-BELTS.....	7-58

EVERY 36 MONTHS

SERVICE THE AIR CONDITIONER SYSTEM.....	7-60
CHECK BATTERY FLUID LEVEL.....	7-61

GENERAL MAINTENANCE

CLEANING THE TRACTOR.....	7-63
FUEL SYSTEM PRE- FILTER AND WATER TRAP.....	7-65
BLEEDING THE FUEL INJECTION SYSTEM	7-65
CHECK BRAKE PEDAL LATCHING/UNLATCHING	7-66
ADJUST CAB SUSPENSION (where fitted)	7-67
ADJUST AUTOMATICK PICK- UP HITCH	7-68
TRANSMISSION CLUTCH CALIBRATION	7-69
HEADLIGHT AND WORKLAMP ADJUSTMENT.....	7-74
BULB REPLACEMENT.....	7-75
FUSES AND RELAYS.....	7-79
PROTECTING THE ELECTRONIC AND ELECTRICAL SYSTEMS DURING BATTERY CHARGING OR WELDING	7-85
BATTERY REMOVAL AND INSTALLATION	7-86

STORAGE

TRACTOR STORAGE.....	7-87
PREPARATION FOR USE AFTER STORAGE	7-87

8 TROUBLESHOOTING

FAULT CODE RESOLUTION

INTRODUCTION	8-1
--------------------	-----

ALARM(S)

FAULT CODES AND SYMBOLS	8-2
-------------------------------	-----

SYMPTOM(S)

ENGINE	8-4
TRANSMISSION	8-5
HYDRAULICS	8-5
THREE POINT HITCH	8-6
BRAKES	8-6
CAB	8-7
ELECTRICAL SYSTEM	8-7

9 SPECIFICATIONS

GENERAL DIMENSIONS	9-1
MAXIMUM OPERATING ANGLE	9-4
TYPICAL OPERATING WEIGHTS	9-5
CAPACITIES	9-6
ENGINE	9-7
FUEL SYSTEM	9-7
AIR CLEANER SYSTEM	9-8
COOLING SYSTEM	9-8
TRANSMISSION	9-8
REAR POWER TAKE-OFF	9-9
FRONT POWER TAKE OFF	9-9
HYDRAULIC SYSTEM	9-10
THREE POINT HITCH	9-10
THREE POINT HITCH FRONT	9-12
FRONT REMOTE VALVE COUPLERS	9-12
BRAKES	9-12
STEERING	9-13
ELECTRICAL EQUIPMENT	9-13
GROUND SPEED CHART SEMI POWERSHIFT TRANSMISSION	9-14
GROUND SPEED CHART FULL POWERSHIFT TRANSMISSION	9-17
MINIMUM HARDWARE TIGHTENING TORQUES	9-20

10 ACCESSORIES

EXTERNAL REAR VIEW MIRRORS	10-1
AUXILIARY HEADLIGHTS	10-1
ROTATING BEACON	10-2

11 FORMS AND DECLARATIONS

Service record 1st 50 hour, Owner copy	11-1
Service record 1st 50 hour, Dealer copy	11-3

1 - GENERAL INFORMATION

CE DECLARATION OF CONFORMITY

Class of 2006/42/EC Annex II	BG Декларация ЕС за съответствие Според Директива 2006/42/ЕО	CZ Prohlášení o shodě ES Podle směrnice 2006/42/ES	DA EU-overensstemmelserklæring ifølge direktivet 2006/42/EF	DE EG-Konformitätserklärung laut Richtlinie 2006/42/EG	EL Αξιολόγηση Συμμόρφωσης ΕΚ Σύμφωνα με την Οδηγία 2006/42/ΕΚ	EN CE Declaration of conformity According to Directive 2006/42/EC	ES Declaración CE de conformidad de acuerdo con la Directiva 2006/42/CE	ET EU vastavõtmekäsitlus Vastavalt direktiivile 2006/42/EÜ	FI EY-vaatimustenmukaisuusvaatus direktiivin 2006/42/EY mukaan	FR Déclaration CE de conformité selon la directive 2006/42/CE	
1.A.1	№: [1]	№: [1]	№: [1]	№: [1]	№: [1]	№: [1]	№: [1]	№: [1]	№: [1]	№: [1]	
1.A.2	Представител на Глоубеп Гариол, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	Zastupnik Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	representant av Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	vertreten durch Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	απορροπαγωγός της Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	representé par Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	representat de Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	esindavajamuse Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	edustajajamuse Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	repsentatör av Gvoepee Gariol, CNH Europe Holding S.A., 13, Rue Aldinger, L-1118 Luxembourg	
1.A.3	Декларацията, поставяйки пълна отговорност, не пречи за Съюзния типичен трактор Търговски номер [2] Модел [3] Тип [4] Серия номер [5]	Полноотговорност за валиден съответствие, не пречи: Земеделия трактор Общодържавен [2] Модел [3] Тип [4] Серия номер [5]	erklærer på eget ansvar at produktet er i overensstemmelse med: Landbrugstraktor Handelsnavn [2] Model [3] Type [4] Serienummer [5]	erklären auf meine alleinige Verantwortung, dass das Produkt Landwirtschaftliche Zugmaschine Handelsbezeichnung [2] Modell [3] Typ [4] Serienummer [5]	επιβεβαιώνω, υπό αποκλειστική μου ευθύνη, ότι το προϊόν: Γεωργιακή Εξοπλισμός Γεωμετρικό μέγεθος [2] Μοντέλο [3] Τύπος [4] Σειριακός αριθμός [5]	Αξιολόγηση, υπακούοντας στην απόλυτη ευθύνη μου, σύμφωνα με το άρθρο 4 της Οδηγίας 2006/42/ΕΚ, ομολογώ ότι η συμμόρφωση [2] είναι:	declares under our sole responsibility, that the product: Agricultural tractor Trade Name [2] Model [3] Type [4] Serial Number [5]	declaramos, bajo nuestra exclusiva responsabilidad, que el producto: Tractor agrícola Denominación Comercial [2] Modelo [3] Tipo [4] Número de serie [5]	kiitatakse omalt vastutusest, et toode: Põllumasin Kaubanimi [2] Model [3] Tüüp [4] Seerianumber [5]	valustamine omalla vastuullamme, että tuote: Maatalustraktor Kaupanimi [2] Malli [3] Tyyppi [4] Sarjanimi [5]	déclare sous ma seule responsabilité, que le produit: Tracteur agricole Désignation commerciale [2] Modèle [3] Type [4] Numéro de série [5]
1.A.4	а) което се отнася до настоящата декларация, е съобразно с изискванията на Директива 2006/42/ЕО, променена с [6].	на която се отнася настоящата декларация, е в съответствие с изискванията на Директива 2006/42/ЕО, променена с [6].	hvorved denne erklæring henviser, opfylder alle de relevante bestemmelser i direktivet 2006/42/EF, ændret ved [6].	auf das sich diese Erklärung bezieht, erfüllt alle einschlägigen Bestimmungen der Richtlinie 2006/42/EG in der Fassung, abgeändert durch [6].	αυτός που αφορά στην παρούσα δήλωση συμμόρφωσης, συμμορφώνεται με τις απαιτήσεις της Οδηγίας 2006/42/ΕΚ, όπως έχει τροποποιηθεί από [6].	на която се отнася настоящата декларация, е в съответствие с изискванията на Директива 2006/42/ЕО, променена с [6].	to which this declaration refers, falls all the relevant provisions of the Directive 2006/42/EC, amended by [6].	al cual se refiere la presente declaración, es conforme a las disposiciones pertinentes de la Directiva 2006/42/CE, modificada por [6].	millega kõnealuse deklaratsiooni viitab, sisaldab kõik direktiivi 2006/42/EÜ ja selle paranduste nõuded [6].	johon tämä vaatus viittaa, vastaa direktiivin 2006/42/EY vaatimuksia ja muutoksia [6].	à la quelle se réfère la présente déclaration est conforme aux dispositions pertinentes de la Directive 2006/42/CE, amendée par [6].
1.A.7	ISO 30322-1 part 1 and 2 Other standards: none / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 parte 1 e 2 Outre normes: aucune / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 del 1 og 2 Andre standarder: ingen / Mærket er ikke angivet / Mærket er ikke angivet / Mærket er ikke angivet / Mærket er ikke angivet	ISO 30322-1 del 1 og 2 Andre normer: ingen / Mærket er ikke angivet / Mærket er ikke angivet / Mærket er ikke angivet / Mærket er ikke angivet	ISO 30322-1 del 1 og 2 Andre normer: ingen / Mærket er ikke angivet / Mærket er ikke angivet / Mærket er ikke angivet / Mærket er ikke angivet	ISO 30322-1 parte 1 e 2 Outre normes: aucune / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 part 1 e 2 Other standards: none / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 parte 1 e 2 Além normas: nenhuma / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 osa 1 ja 2 Muut standardit: ei mitään / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 osa 1 ja 2 Muut standardit: ei mitään / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole	ISO 30322-1 partie 1 et 2 Autre normes: aucune / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole / Määrättyä ei ole
1.A.9	Place and date of the declaration [7]	Lugar y fecha de la declaración [7]	Sted og dato for erklæringen [7]	Ort und Datum der Erklärung [7]	Όπου και υπογράφηκε η παρούσα δήλωση συμμόρφωσης [7]	Location and date of the declaration [7]	Lugar y fecha de la declaración [7]	Väljalastu isiku ning ja aegade [7]	Väljalastu isiku ning ja aegade [7]	Site et date de la déclaration [7]	
1.A.10	Name and signature of the authorized person [8]	Nombre y firma de la persona autorizada [8]	Bemyndigedes navn og underskrift [8]	Name und Unterschrift des Bevollmächtigten [8]	Όνομα και υπογραφή του αρμοδίου προσώπου [8]	Name and signature of the authorized person [8]	Nombre y firma de la persona autorizada [8]	Nimi ja allekirjotus [8]	Nimi ja allekirjotus [8]	Nome e firma della persona autorizzata [8]	



NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

NEW HOLLAND

Here above is provided a copy of the "EC" Declaration of Conformity (EC Declaration of Conformity acc to 2006/42/EC). The EC Declaration of Conformity is the manufacturer's declaration about equipment compliance to relevant EU provisions.

Please keep the original document in a safe place. Local authorities may require you to show this document in order to assure compliance of your equipment.

Translation of this declaration in your own country language is provided on the original document.

For your better and easier understanding of the document you'll find original text reproduced hereafter together with some notes.

Clause of 2006/42/EC Annex II	EN EC Declaration of conformity According to Directive 2006/42/EC.
1.A.1	We, [1]
1.A.2	Represented by Guiseppe Gavioli CNH Europe Holding S.A. 13, Rue Aldringen L- 1118 Luxembourg
1.A.3	declare under our sole responsibility, that the product: Agricultural tractor Trade Name: [2] Model: [3] Type: [4] Serial Number: [5]
1.A.4	to which this declaration relates, fulfils all the relevant provisions of the Directive 2006/42/EC, amended by [6]
1.A.7	For the relevant implementation of the provisions of the Directive, the following (harmonised) standards have been applied: • ISO 26322-1 part 1 or 2 Other standards: see Operators Manual
1.A.9	Place and date of the declaration: [7]
1.A.10	Name and signature of the authorised person: [8]

HEALTH AND SAFETY RELATED STANDARDS APPLIED TO YOUR TRACTOR

- ROPS PROTECTION is certified according to **EN 15694**.
- FOPS level on your tractor cab is certified according to **OECD Code 10**.
- HVAC (Heating, ventilation Air Conditioning) CAB is certified Category 1 according to **EN 15695-1**.
- HV (Heating, ventilation) cab is certified Category 1 according to **EN 15695-1**.
- NOISE EMISSION LEVELS are rated according to **77/311/EC**.
- VIBRATION LEVELS are rated according to **78/764/EEC**.

NOTE: See safety section 2 in this manual for further explanation and details on above mentioned standards and specific terminology.

METRIC AND IMPERIAL UNITS ABBREVIATIONS

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Area (Land area)				
	hectare	ha	acre	ac
	square meter	m²	square foot	ft²
	square millimeter	mm²	square inch	in²
Electricity				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	μF	microfarad	μF
	ohm	Ω	ohm	Ω
Force				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
Force per length				
	newton per meter	N/m	pound per foot	lb/ft
			pound per inch	lb/in
Frequency				
	megahertz	MHz	megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
Frequency - Rotational				
	revolution per minute	r/min	revolution per minute	r/min^a
		rpm		rpm
Length				
	kilometer	km	mile	mi
	meter	m	foot	ft
	centimeter	cm	inch	in
	millimeter	mm	inch	in
	micrometer	μm		
Mass				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		
Mass per Mass				
	milligram per kilogram	mg/ kg		
Power				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour	Btu/hr
			Btu per minute	Btu/min
Pressure or stress (Force per area)				
	kilopascal	kPa	pound per square inch	psi
			inch of mercury	inHg
	pascal	Pa	inch of water	inH₂O
	megapascal	MPa	pound per square inch	psi

1 - GENERAL INFORMATION

Typical applications	Metric unit		Imperial unit	
	Name	Symbol	Name	Symbol
Temperature (other than Thermodynamic)				
	degrees Celsius	°C	degrees Fahrenheit	°F
Time				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
Torque (includes Bending moment, Moment of force, and Moment of a couple)				
	newton meter	N m	pound foot	lb ft
			pound foot	lb in
Velocity				
	kilometer per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimeter per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
Volume (includes Capacity)				
	cubic meter	m³	cubic yard	yd³
				cu yd
	liter	l	cubic inch	in³
	liter	l	US gallon	US gal
			UK gallon	UK gal
			US quart	US qt
			UK quart	UK qt
	milliliter	ml	fluid ounce	fl oz
Volume per time (includes Discharge and Flow rate)				
	cubic meter per minute	m³/min	cubic foot per minute	ft³/min
	liter per minute	l/min	US gallon per minute	US gal/min
	milliliter per minute	ml/min	UK gallon per minute	UK gal/min
Sound power level and Sound pressure level				
	decibel	dB	decibel	dB

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com