


ORIGINAL INSTRUCTIONS - according to Directive 2006/42/EC, Annex I 1.7.4.1

# OPERATOR'S MANUAL

---

**Boomer 3040**  
**Boomer 3045**  
**Boomer 3050**  
Compact Tractor



**Part number 84382275**

4th edition English

September 2011

Replaces part number 84328431



# Contents

---

## 1 GENERAL INFORMATION

Note to the Owner .....	1-1
Directives .....	1-3
Foreword - About This Manual .....	1-5
Product overview .....	1-6
Vibration levels .....	1-8
Machine stability .....	1-9
Declaration of conformity .....	1-13
Metric and Imperial units abbreviations .....	1-16
CAB IDENTIFICATION .....	1-18
Machine orientation.....	1-20
Product Identification Number (PIN).....	1-21
Product Identification Number (PIN).....	1-22
International symbols .....	1-23
Electro-Magnetic Compatibility (EMC) .....	1-24

## 2 SAFETY INFORMATION

Safety rules and signal word definitions .....	2-1
Safety rules .....	2-2
Starting the tractor .....	2-4
Safety rules - Using The Tractor .....	2-6
Towing and transport .....	2-8
Hydraulic system safety .....	2-9
Safety rules - Front end loader applications .....	2-11
Using implements and agricultural machinery .....	2-12
Safety rules - Stopping The Tractor .....	2-13
SERVICING THE TRACTOR.....	2-14
Personal safety .....	2-16
Safety rules - Service area, fire extinguisher, first aid kit .....	2-17
Safety rules - Emergency exit .....	2-19
Safety rules General Information .....	2-20
Safety rules AIR CONDITIONING/VENTILATION .....	2-21
Safety signs .....	2-22
Road travel signs and decals.....	2-31
Roll over protective structure (ROPS).....	2-40
Foreword Ecology and the Environment .....	2-42

## 3 CONTROLS/INSTRUMENTS

### ACCESS TO OPERATOR'S PLATFORM

Doors .....	3-1
-------------	-----

### OPERATOR'S SEAT

Seat and seat belt (ROPS) .....	3-2
Seat and seat belt (cab) .....	3-3

---

## FORWARD CONTROLS

ENGINE SPEED CONTROL .....	3-4
Clock adjustment .....	3-6
Units of measure and conversion .....	3-10
ADIC programming .....	3-12
ADIC programming .....	3-13
Instrument panel.....	3-17
Indicator locations within the instrument panel .....	3-23
ANALOGUE INSTRUMENT PANEL .....	3-26
Steering wheel - Adjust.....	3-29
Windshield washer reservoir .....	3-30
WINDSHIELD WIPER AND WASHER CONTROLS .....	3-31
Steering wheel adjustment .....	3-32
Password setup .....	3-33

## LEFT-HAND SIDE CONTROLS

2WD-4WD SYSTEM - Operating .....	3-36
TRANSMISSION - Operating.....	3-37
TRANSMISSION - Operating.....	3-38
2WD-4WD SYSTEM - Operating Selection .....	3-39
2WD-4WD SYSTEM - Operating - Automatic FWD Supersteer (CVT) .....	3-40
Transmission shuttle shift lever.....	3-41
Differential lock command - Operating .....	3-43
TRANSMISSION Hydrostatic - Operating.....	3-44

## RIGHT-HAND SIDE CONTROLS

Throttle command - Operating - (Gear & HST) .....	3-46
Throttle command - Operating - (CVT) .....	3-47
Fuel shut-off - Open/Close FUEL SHUTOFF VALVE .....	3-48
Anti-stall switch - Transmission Control Settings And Adjustments (CVT) - Anti-Stall Switch .....	3-49
USER CONTROLS AND SEAT Control - Operating - Transmission Control Settings And Adjustments (CVT) - reactivity Switch .....	3-50
USER CONTROLS AND SEAT Control - Operating - Transmission Control Settings And Adjustments (CVT) - Speed Range Switch .....	3-52
USER CONTROLS AND SEAT Control - Operating - Transmission Control Settings And Adjustments (CVT) - 4WD Engagement Switch .....	3-53
USER CONTROLS AND SEAT Control - Operating - Transmission Control Settings And Adjustments (CVT) - Cruise Control .....	3-54
USER CONTROLS AND SEAT Control - Operating - Transmission Control Settings And Adjustments (CVT) - Cruise Preset .....	3-57
REAR PTO - Operating (Gear and HST) .....	3-61
REAR PTO - Operating Controls (Independent Type) - CVT .....	3-62
REAR PTO - Operating Shield and Cap .....	3-65
REAR PTO - Operating Shield and Cap .....	3-66
Hydraulic power lift (HPL) .....	3-67
Hydraulic power lift (HPL) - Position Control .....	3-68
LIFTING - Adjust - Position Control Adjustments .....	3-69
Top link - Static description - Rocker .....	3-70

---

Control valve - Static description - HPL Drop Rate Control Valve .....	3-71
Valve block - Static description - Hydraulic Manifold Block/Diverter Valve .....	3-72
Remote valve - Static description - Rear Remote Control Valves .....	3-73
Remote valve - Static description - Front Remote Control Valve (Optional) .....	3-74

## REARWARD CONTROLS

Auxiliary power connection - Static description.....	3-76
Rear window operation .....	3-77

## OVERHEAD CONTROLS

ENVIRONMENT CONTROL Heating, ventilation and air-conditioning - Static description - Heated/Ventilated and Air Conditioned Cab .....	3-78
Ventilation system - Static description - Air Filters .....	3-79
Heat command - Control - Heater Control .....	3-80
FAN CONTROL .....	3-81
Ventilation system - Operating - Cab Ventilation .....	3-82
ENVIRONMENT CONTROL Air-conditioning system - Operating .....	3-84
ENVIRONMENT CONTROL Air-conditioning system - Control - Cab Air Conditioning/Heating Controls .....	3-85
Cab internal lighting .....	3-86
Front sun shade .....	3-87

## EXTERIOR CONTROLS

Mirrors - Cab tractor .....	3-88
Mirrors - ROPS tractor .....	3-89

## 4 OPERATING INSTRUCTIONS

### COMMISSIONING THE UNIT

CVT transmission controls .....	4-1
Engine hood - Open/Close - Hood Latch .....	4-5
PTO operation Gear And HST .....	4-6
PTO operation (With Operator In Seat) - CVT .....	4-7
PTO operation (Without Operator In Seat) - CVT .....	4-8
Swinging drawbar .....	4-9
HITCH Rear hitch - Static description - Deluxe Three-Point Linkage .....	4-11
Operating precautions - Driving the Tractor .....	4-12

### STARTING THE UNIT

Starting the engine .....	4-13
Starting the engine - CVT .....	4-15
Starting the tractor with jumper cables .....	4-17
ENGINE - Running-in Procedure .....	4-18

### STOPPING THE UNIT

Brake - Operating - Pedals .....	4-19
PARKING BRAKE - Operating .....	4-21

---

ENGINE - Stop .....	4-22
---------------------	------

## MOVING THE UNIT

TRANSMISSION Continuously Variable Transmission (CVT) - Speeds .....	4-23
--	------

## 5 TRANSPORT OPERATIONS

### ROAD TRANSPORT

LIGHTING SYSTEM - Static description .....	5-1
HAZARD WARNING LIGHT SWITCH.....	5-3
Headlight and taillight switch .....	5-5
LIGHTING SYSTEM - Static description .....	5-6
Multifunction light switch - Gear & HST .....	5-9
Multifunction light switch - CVT .....	5-10
Preparation for towing - CVT .....	5-11
Towing the tractor.....	5-12

## 6 MAINTENANCE

### GENERAL INFORMATION

Engine hood - Open/Close - Hood Latch .....	6-1
STABILISING - Static description - Tractor weighting .....	6-2
Torque - Minimum tightening torques for normal assembly .....	6-7
Torque - Standard torque data for hydraulics .....	6-11
Basic instructions - Lubrication and Maintenance .....	6-14
Consumables - Recommended Lubricants and Coolants .....	6-15
Basic instructions - Lubrication Fittings .....	6-16
Refueling the tractor .....	6-17
Basic instructions - Biodiesel Fuel .....	6-19
Basic instructions - Hood Latch .....	6-20
Basic instructions - Maintenance .....	6-21
CHECK ENGINE OIL LEVEL.....	6-23
Air cleaner - Operation 2 .....	6-24
Cooling system - Operation 3 .....	6-25
Hydraulic fluid - Operation 4 .....	6-26
Basic instructions - First 50 Hours Only .....	6-27
Tires - Operation 5 .....	6-28
Battery - Operation 6 .....	6-29
Engine belts - Operation 7 .....	6-31
Front Axle Oil - Operation 8 and 9 .....	6-33
Clutch Pedal - Operation 10 .....	6-34
Fuel filter - Operation 11 .....	6-35
Steering clutch oil level - Operation 12 .....	6-38
4WD front axle pivot - Operation 13 .....	6-39
Air cleaner - Operation 14 .....	6-40
Fuel filter - Operation 15 .....	6-41
Changing engine oil - Operation 16 .....	6-42
Brake pedals - Operation 17 .....	6-43

---

Park brake - Operation 18 .....	6-44
Engine fan belt - Operation 19 .....	6-45
Wheel bolt torque - Operation 20 .....	6-46
Fuel filter - Operation 21 .....	6-47
Hydraulic fluid - Operation 22 .....	6-50
Hydraulic filter replace - Operation 23 .....	6-52
Transmission filter - Operation 24 .....	6-53
Front Axle Oil - Operation 25 .....	6-54
Roll Over Protective Structure (ROPS) - Operation 26 .....	6-56
Fuel injectors - Operation 27 .....	6-58
Engine valve clearance - Operation 28 .....	6-60
Steering clutch oil level - Operation 29 .....	6-61
Air cleaner - Operation 30-SEASONAL .....	6-62
Cooling system - Operation 31 .....	6-63
CHANGE ENGINE AIR CLEANER INNER ELEMENT - Operation 32-SPECIAL SERVICE .....	6-65
Alternator - Operation 33-GENERAL MAINTENANCE .....	6-66
Fuses - Operation 34 .....	6-67
Bulb replacement - Operation 35 .....	6-74
Front wheel toe-in - adjust - Operation 36 .....	6-83
Tractor storage - Operation 37 .....	6-84
Cab service .....	6-85
Wheel tread settings.....	6-86

## MAINTENANCE CHART

Maintenance Chart - and Lubrication Chart .....	6-87
Maintenance Chart - Cab .....	6-91
Maintenance Chart - Lubrication chart for 3040,3045,3050 - Supersteer - (Front wheel drive) .....	6-92

## 7 SPECIFICATIONS

ENGINE - General specification.....	7-1
Capacities .....	7-1
ENVIRONMENT CONTROL Air-conditioning system - General specification .....	7-1
General specification - Cooling system .....	7-2
ELECTRICAL POWER SYSTEM - General specification - Electrical system - CVT .....	7-3
ELECTRICAL POWER SYSTEM - General specification - Gear & HST .....	7-3
FUEL AND INJECTION SYSTEM - General specification .....	7-4
General specification - Brakes .....	7-4
STEERING - General specification.....	7-4
General specification - Power take-off .....	7-5
General specification - Hydraulic lift system .....	7-5
TRANSMISSION Hydrostatic - General specification .....	7-6
General specification - Gear transmission .....	7-6
General specification - Gear transmission speeds - Forward (creeper not engaged) .....	7-7
General specification - Gear transmission speeds - Forward (creeper engaged) .....	7-8
General specification - Gear transmission speeds - Reverse (creeper not engaged) .....	7-9
General specification - Gear transmission speeds - Reverse (creeper engaged) .....	7-10

---

TRANSMISSION - General specification..... 7-11  
 General specification - Clutch ..... 7-12  
 General specification - Brakes ..... 7-12  
 STEERING - General specification..... 7-12  
 Weight - Cast Iron Weights ..... 7-13  
 HITCH - General specification - 3 Point hitch ..... 7-14  
 General specification - Tires ..... 7-14  
 Torque - Wheel bolt torques ..... 7-14  
 Dimension - General dimensions ..... 7-15  
 Wheel tread settings..... 7-19  
 Weight ..... 7-20

**8 FORMS AND DECLARATIONS**

Delivery report - Dealer Copy ..... 8-1  
 Delivery report - Owner Copy ..... 8-4

# 1 - GENERAL INFORMATION

## Note to the Owner

This manual contains information concerning the adjustment and maintenance of your new equipment. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this equipment. Please have all operators read this manual carefully and keep it available for ready reference.

Your NEW HOLLAND AGRICULTURE dealer will instruct you in the general operation of your new equipment. (Refer to the 'Delivery Report' at the back of this manual.) Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your machine.

Your NEW HOLLAND AGRICULTURE dealer carries a complete line of genuine NEW HOLLAND AGRICULTURE service parts. These parts are manufactured and carefully inspected to insure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and product identification number of your new equipment when ordering parts. Locate these numbers now and record them below. Refer to the 'General Information' section of this manual for the location of the model and product identification numbers of your machine.

### PLEASE RECORD THE FOLLOWING INFORMATION

**Model**

\_\_\_\_\_

**Product Identification Number (PIN)**

\_\_\_\_\_

**Date Purchased**

\_\_\_\_\_

**Header Width (As Applicable)**


\_\_\_\_\_

**Engine Model (As Applicable)**

\_\_\_\_\_

**Engine PIN (As Applicable)**

\_\_\_\_\_

	<p>This is the safety alert symbol. It is used with and without signal words to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.</p>
---	---

### **WARNING**

**Illustrations in this manual may show protective shielding open or removed to better illustrate a particular feature or adjustment.**

**Replace all shields before operating the machine.**

**Failure to comply could result in death or serious injury.**

W0012A

**ATTENTION:** *The engine and fuel system on your machine is designed and built to government emission standards. Tampering by dealer, customers, operators, and end users is strictly prohibited by law. Failure to comply*

*could result in government fines, rework charges, invalid warranty, legal action, and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*


### **IMPROVEMENTS**

CNH is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.



1 - GENERAL INFORMATION

---



201001599 1

**Dealer's stamp**

## Directives

### INTENDED USE OF YOUR TRACTOR

Your tractor is designed and made to pull, to carry, and to power a variety of mounted or towed equipment, although within some physical limits. The working speed and performance may depend on a number of various parameters, such as weather and terrain conditions. Though the tractor is designed to perform in combination with a variety of equipment in most crops and conditions, there may be a number of combinations of above parameters, for which there is severe degradation of performance of the tractor and/or its mounted or trailed equipment. If you notice degradation of performance, contact your dealer for assistance. He may have useful information for improvements, or a kit may be available to enhance the performance.

- Do not use the tractor for another purpose than intended by the manufacturer and outlined in this manual.
- Do not use the tractor beyond its limits of terrain gradient and stability as outlined further in this manual. Using the tractor beyond these limits may result in roll-over or tip-over. Observe the recommendations in this manual.
- Do not use the tractor on higher speeds than allowed by the load and the environment. A wet surface or other low adherence conditions may increase the braking distance or result in vehicle instability. Always adapt your traveling speed according to the load of the vehicle and the characteristics of the road.
- Do not use the tractor near or on soft verges of canals and brooks or banks and verges that are undermined by rodents. The tractor may sink sideways and roll-over.
- Do not use the tractor on brittle bridge heads and poor bridge floors. These constructions may collapse and cause roll-over of the tractor. Always check out the condition and carrying capacity of bridges and ramps prior to engage.
- Do not use the tractor without wearing the seat restraint system during activities where roll-over or tip-over hazards exist. The ROPS cab or ROPS structure will only be fully effective when the driver remains attached to his seat.
- Do not use equipment mounted on the tractor which is not correctly matching and firmly fixed. Such equipment may increase the risk for roll-over and hit the tractor when coming loose. Ensure that the dimensions of the three-point linkage interface of both the tractor and the equipment are matching according to the categories defined in ISO 730. Ensure that the dimensions and speed of the PTO shaft on the tractors are matching those of the equipment.
- Do not use the tractor in combination with equipment, without having consulted the specific Operators Manual provided with the equipment. The tractor is a universal tool to carry, tow, and drive a variety of equipment. This manual alone cannot provide you with all the information required for the safe operation of the combination.
- Do not use the tractor beyond its limits of dynamic stability. High speed, abrupt maneuvers, and fast and short cornering will increase the risk of roll-over.
- Do not use the tractor for pulling work, in cases where you do not know whether the load will yield, for instance when pulling stumps. The tractor may flip over when the stump is not yielding.
- Be extremely cautious when working with the tractor on forage silos without lateral concrete walls. Dual wheels or a wide track setting may improve the lateral stability of the tractor.
- Be cautious that the center of gravity of the tractor may increase when loads on the front-end loader or the three-point linkage are raised. In these conditions, the tractor may roll-over earlier than expected.
- Do not step down from the tractor without shutting down the PTO, shifting the transmission to park or neutral and applying the park brake, unless continued PTO operation is required for some equipment, such as pumps or wood chippers. The latter equipment may have an emergency stop device on the equipment itself, as human intervention is needed during operation. But other equipment, engaged and driven by the tractor will have no means to stop the power transmission, other than the PTO clutch of the tractor.
- You shall take the necessary precautions to always be aware of the possible presence of bystanders, certainly when maneuvering in confined areas, such as the farm yard and sheds. Keep people away from the tractor during work; ask bystanders to leave the field. There is not only the risk to be overrun by the tractor, but objects ejected by some equipment mounted on the tractor, such as a rotary mower, may cause harm. Stones may be thrown further than the mowed crop. Pay the necessary attention while operating next to public roads or footpaths. Thrown objects can get projected outside the field and hit unprotected people like bikers or pedestrians. Wait to cut the edge of the field till it is clear of bystanders.
- Do not allow riders on the tractor; do not allow people standing on the access way or step to the cab when the tractor is moving. Your view to the left will be obstructed and a rider risks to fall from the tractor during unforeseen or abrupt movements.
- Always stay clear from implements operating area and especially do not stand between tractor and trailed vehicle either three-point linkage when operating lift controls; ensure no bystanders are near these operating areas.


- Certain functions of your tractor, if equipped with a CVT transmission, are controlled by software and some of them are safety related. Do not attempt to modify or download software from spurious sources. Settings and logics may be destroyed and affect seriously the function of the tractor. This may result in unpredictable and unsafe behavior of the tractor. Only your dealer is entitled to intervene on the software of the tractor. He has the appropriate tools and data sets for it and owns the officially released software versions and updates for your tractor.
- Your tractor may be equipped with a number of sensors to control safety functions. Tripping these sensors will result in a safe operation mode. Do not attempt to bypass any function on the tractor. You will be exposed to serious hazards, and moreover, the behavior of the tractor may become unpredictable.
- A tractor has only one operator station and is a one man operated vehicle. Other people on or around the tractor during normal operation are not allowed.
- The machine is designed and produced exclusively for agricultural use.
- The machine is not designed for light/heavy forestry applications; usage is prohibited for forestry applications.
- All other use will be considered to be contrary to the use specified by CNH AMERICA LLC, who cannot be held liable for damage to property or the machine, or for personal injuries which may result.
- Persons who risk improper use will therefore assume the responsibility for any consequences arising from such use.
- Compliance with the instructions for use, maintenance and repairs described in this manual, are the essential preconditions for the use specified by CNH AMERICA LLC.
- The machine must only be used, serviced, or repaired by personnel trained in the relevant working methods and safety regulations and who have been authorized to work on the machine.
- The user must also observe the rules concerning general safety and accident prevention, including the Highway Code when driving on public highways.
- Any arbitrary modifications made to this machine will release CNH AMERICA LLC from any liability resulting from damage or injury.
- CNH AMERICA LLC and all its distribution organizations, inclusive of, but not restricted to, national, regional, or local distributors, cannot be held liable for damage resulting from the malfunction of parts and/or components not approved by CNH AMERICA LLC.
- Under no circumstances will a guarantee be issued for products made or sold by CNH AMERICA LLC that are damaged as a result of the malfunction of parts and/or components not approved by CNH AMERICA LLC.

## Foreword - About This Manual


This manual gives information for use of this tractor, as intended and under the conditions foreseen by the manufacturer during normal operation and routine service and maintenance.

- Normal operation means the use of the tractor for the purpose intended by the manufacturer by an operator familiar with the tractor and the mounted or towed equipment and complying with the information for operation and safe practices, as specified by the manufacturer in this manual and by the signs on the tractor and the equipment.
- Normal operation includes the preparation and storage of the tractor, swinging components into work position and vice versa, adding or removing ballast and picking up and setting off attachments.
- Normal operation includes the adjustment and setting of the tractor and equipment, for the specific condition of the field and/or the crop.
- Routine service and maintenance means activities that must be done daily by an operator familiar with the tractor characteristics and complying with the information for routine service and safe practices, as specified by the manufacturer in this manual and by signs on the tractor, in order to maintain its proper function. Routine service includes activities such as fueling, cleaning, washing, topping up fluid levels, greasing, replacing of consumable articles such as lamp bulbs.
- This manual is not giving all the information related to periodical service, converting and repairs to be carried out by professional service personnel. For some of the latter activities, there may be a need for appropriate facilities, technical skills and tools which are not supplied with the tractor, please refer to your dealer or authorized workshop.
- Periodical service means activities that must be done at defined intervals by trained personnel familiar with the tractor characteristics and which are complying with the information for periodical service and safe practices, as partly specified by the manufacturer in this manual and in other Company literature, in order to maintain the expected life time of the tractor.
- Converting means activities that must be done by professional service personnel familiar with the tractor characteristics and complying with the information for converting, as partly specified by the manufacturer in this manual, in assembly instructions or other Company literature, in order to fit the tractor to a specific configuration.
- Repair means activities that must be done by professional service personnel only familiar with the tractor characteristics and complying with the information for repair, as specified by the manufacturer in the dealer's workshop manual, in order to restore the proper function of the tractor after a failure or degradation of performance.

## MANUAL STORAGE



86064813N 1



20108628 2

The Operator's Manual is located in the toolbox, which is mounted behind the step on cab tractors, **(1)**, and in front of the left-hand step on ROPS tractors, **(2)**. Keep the

Operator's Manual in the toolbox. The Operator's Manual must be available for use by all operators.

## Product overview

### Electro-magnetic Interference (EMC)

This product complies with the EEC directive 2004/108/EC and its amendments on Electromagnetic Interferences on electronic equipment if it is used in conjunction with equipment which bears the CE mark.

New Holland will take no liability for any problem arising as a result of its product working in an environment of other equipment which does not comply with the EEC directive.

This machine complies strictly with the European Regulations on electro-magnetic emissions. However, interference may arise as a result of add-on equipment which may not necessarily meet the required standards. As such interference can result in serious malfunction of the unit and/or create unsafe situations, you must observe the following:

- Ensure that each piece of non- NEW HOLLAND AGRICULTURE equipment fitted to the machine bears the CE mark.

- The maximum power of emission equipment (radio, telephones, etc.) must not exceed the limits imposed by the national authorities of the country where you use the machine.
- The electro-magnetic field generated by the add-on system should not exceed 24 V/m at any time and at any location in the proximity of electronic components. Failure to comply with these rules will render the NEW HOLLAND AGRICULTURE warranty null and void.

### AIRBORNE NOISE EMISSION

In line with the European directive (2003/10/EC) and national legislation, the noise levels at the operator's ear are measured in dBa, according to the ISO 5131 standard. The noise is measured with the engine and all mechanisms engaged and running at normal operating speed for the specified use of the product and without crop flow through the machine. These are maximum values which in normal operating conditions will never be exceeded.

#### WITHOUT CAB

Model	Drive line	Noise level at operator's ear - dB(A)	External noise level - dB(A)**
3040	24 x 24 transmission	85***	77
3040	Hydrostatic transmission	88*	80
3045	24 x 24 transmission	86***	79
3045	Hydrostatic transmission	88*	81
3050	24 x 24 transmission	86***	79

#### WITH CAB

Model	Drive line	Noise level at operator's ear - dB(A)*	External noise level - dB(A)**
3040	Hydrostatic transmission	82***	80
3040	CVT transmission	82***	80

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)