

**540 - 541
Wheel Tractors
540C - 541C
Wheel Tractors
Operator's Manual**

9-912

Reprinted

CASE






THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

M171B

If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

Operator's Instruction Manual

CASE

REGISTERED IN U. S. PATENT OFFICE



"540" - "541"

WHEEL TRACTORS

(with Tripl-Range Drive or Dual Range Shuttle)

"540C" - "541C"

WHEEL TRACTORS

(with Case-O-Matic Drive)

GASOLINE OR L.P.G. FUEL

J. I. Case Co.

RACINE, WISCONSIN - U. S. A.



NOTICE!

At the time your Case Dealer delivers your new tractor, he will acquaint you with its operation and maintenance as outlined in the "Dealer's Delivery Service Report". When your Dealer has completed these instructions, he will ask you to sign the report and will then hand you the yellow copy for your records.

NOTE: The "Dealer's Delivery Service Report" also contains a record of the Pre-Delivery Checkup which your Dealer made on your tractor.

AFTER DELIVERY CHECKUP

The Authorized Case Dealer from whom you purchased your new tractor will perform the "After Delivery Checkup" outlined on the following page, if you will arrange to bring your tractor to his Service Shop within - - -

60 days after date of delivery or 200 hours of operation (whichever occurs first).

NOTE: The only charge your dealer will make for this inspection will be for oil, filters or other accessories.

AFTER DELIVERY CHECKUP (Spark Ignition Tractors)

(Owner's Name)	(Date Checkup Performed)
(Owner's Address)	
(Dealership)	(Town)
Tractor has been operated.....hours	
(Tractor Model and Serial Number)	

- | | |
|--|--|
| <input type="checkbox"/> Check foot clutch. ("540"- "541")
<input type="checkbox"/> Check hand clutch (if used). ("540"- "541").
<input type="checkbox"/> Check converter pressure ("540C"- "541C").
<input type="checkbox"/> Check converter oil level ("540C"- "541C").
<input type="checkbox"/> Check direct and main drive clutch operation ("540C"- "541C").
<input type="checkbox"/> Check brakes.
<input type="checkbox"/> Operate Eagle Hitch hydraulic system and check oil level in torque tube.
<input type="checkbox"/> Check tire pressure.
<input type="checkbox"/> Tighten cylinder head and adjust tappets.
<input type="checkbox"/> Check power steering (if used).
<input type="checkbox"/> Check fluid level in steering reservoir (if used).
<input type="checkbox"/> Check distributor timing. | <input type="checkbox"/> Check spark plugs and distributor point gap.
<input type="checkbox"/> Check full governed no load engine speed.
<input type="checkbox"/> Tighten all bolts (including rims).
<input type="checkbox"/> Cooling system.
<input type="checkbox"/> Crankcase oil (Change oil and filter if necessary).
<input type="checkbox"/> Oil level in transmission and torque tube.
<input type="checkbox"/> Lubricate all pressure fittings and oil cups.
<input type="checkbox"/> Check air cleaner.
<input type="checkbox"/> Check steering, bearing adjustment and front wheel toe-in.
<input type="checkbox"/> Battery, starter, generator and lights.
<input type="checkbox"/> Check operation of all instruments. |
|--|--|

DEALER: Question purchaser carefully concerning his experience with tractor and answer any questions concerning maintenance or operation that are not clear to him.

Checkup.....
Performed by

Signed.....
Dealer

Original — Dealer
 Duplicate — Leave in Operator's Manual
 for Purchaser

Signed.....
Customer

AFTER DELIVERY CHECKUP (Spark Ignition Tractors)

(Owner's Name)	(Date Checkup Performed)
(Owner's Address)	
(Dealership)	(Town)
Tractor has been operated.....hours	
(Tractor Model and Serial Number)	

- | | |
|--|--|
| <input type="checkbox"/> Check foot clutch. ("540"- "541")
<input type="checkbox"/> Check hand clutch (if used). ("540"- "541").
<input type="checkbox"/> Check converter pressure ("540C"- "541C").
<input type="checkbox"/> Check converter oil level ("540C"- "541C").
<input type="checkbox"/> Check direct and main drive clutch operation ("540C"- "541C").
<input type="checkbox"/> Check brakes.
<input type="checkbox"/> Operate Eagle Hitch hydraulic system and check oil level in torque tube.
<input type="checkbox"/> Check tire pressure.
<input type="checkbox"/> Tighten cylinder head and adjust tappets.
<input type="checkbox"/> Check power steering (if used).
<input type="checkbox"/> Check fluid level in steering reservoir (if used).
<input type="checkbox"/> Check distributor timing. | <input type="checkbox"/> Check spark plugs and distributor point gap.
<input type="checkbox"/> Check full governed no load engine speed.
<input type="checkbox"/> Tighten all bolts (including rims).
<input type="checkbox"/> Cooling system.
<input type="checkbox"/> Crankcase oil (Change oil and filter if necessary).
<input type="checkbox"/> Oil level in transmission and torque tube.
<input type="checkbox"/> Lubricate all pressure fittings and oil cups.
<input type="checkbox"/> Check air cleaner.
<input type="checkbox"/> Check steering, bearing adjustment and front wheel toe-in.
<input type="checkbox"/> Battery, starter, generator and lights.
<input type="checkbox"/> Check operation of all instruments. |
|--|--|

DEALER: Question purchaser carefully concerning his experience with tractor and answer any questions concerning maintenance or operation that are not clear to him.

Checkup.....
Performed by

Signed.....
Dealer

Original — Dealer
 Duplicate — Leave in Operator's Manual
 for Purchaser

Signed.....
Customer

To the Purchaser of a Case Tractor,

The care you give your new Case Tractor will greatly determine the satisfaction and service life you will obtain from it. Use this manual as your guide. By observing the instructions and suggestions in this manual, your Case Tractor will serve you well for many years.

As an Authorized Case Dealer, we stock Genuine Case Parts, which are manufactured with the same precision and skill as the original equipment. Our factory trained staff is kept well informed on the best methods of servicing Case equipment and is ready and able to help you.

Should you require additional aid or information, contact us.


Your Authorized
CASE DEALER

HEINRICH'S EQUIPMENT
312 W. Main St.
Santa Maria, Calif.
Phone WALnut 5-5740

To insure efficient and prompt service, please furnish us with the Model and Serial Number of your tractor and Serial Number of your engine, in all correspondence or contacts.

TABLE OF CONTENTS

Serial Numbers	8
General Specifications	9-16
Lubrication	17-35
Pressure Fittings	20,21
Engine Lubrication	22-25
Transmission Lubrication	27
Steering Gear	27
Converter Reservoir Oil Level	29
Converter Oil Filter	30
Hydraulic System	31, 33
Independent P. T. O.	34
Belt Pulley – Rear Mounted	34
Power Steering	35
Operating Instructions	37-88
Pre-Starting Check List	38
Operating Controls and Instruments	40-45
Run-In Procedure	46
Engine Starting Procedure	47, 48
Stopping Engine	48
Cold Weather Operation	49
Dual-Range Shuttle	53
Tripl-Range Drive	54
Operating Case-O-Matic Drive	55-57
Differential Brakes	58
Independant P. T. O.	60
Constant-Running P. T. O.	61
Rear Wheel Spacing	64-67
Front Wheel Spacing	71-73
Eagle Hitch and Hydraulic System	74-77
Three-Point Hitch (With Swinging Draft Arms).....	78
Remote (Portable) Cylinder Attachment.....	79-80
Drawbar	82
Belt Pulley	83-86
Accessory Tractor Equipment	87-89
Important Checks During Operation	90-91
Service Suggestions	93-99
Fuel Recommendations	100
Preventive Maintenance	101-128
Cooling System	102-107
Fuel and Fuel System	109-111
Governor and Engine Speed	112
Valve Adjustment	113
Ignition and Electrical Equipment	115-122
Front Wheel Bearings	123
Flywheel Clutch	124
Adjusting P. T. O. Clutch	125
Differential Brakes	126
Tractor Storage	127-128
Index	129-130
Warranty	131
Safety Precautions	Rear Pages



MODEL "541C" GENERAL PURPOSE TRACTOR

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com