


**4694
Tractor**

Operators Manual

9-9851

Reprinted








If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

TO THE OWNER OF A CASE INTERNATIONAL TRACTOR

Use this manual as your guide. If you follow the instructions given in this manual, your Case International Tractor will work well for many years.

Your Dealer can assist you with Case Company made parts and persons with special training that know the best methods of repair and maintenance for your tractor.

Call your Dealer if you need any assistance or information.

Your Authorized Case Dealer



Figure 1

NOTE: *When you are in the tractor seat looking forward, the right hand and left hand of the tractor are the same as your right and left hand.*

TABLE OF CONTENTS

TO THE OWNER	I	OPERATING INSTRUCTIONS	37-154
TABLE OF CONTENTS	II,III	Run-In Procedure	37
SAFETY	IV-XVI	Before Starting the Engine	38
Safety Rules	IV	True Ground Speed Sensor	39
Before Starting	IV-VI	Digital Instrument Cluster	40-65
Operation	VI-XII	English/Metric Selection	41
Service	XIII-XVI	Engine Hour Meter	41
HAND SIGNALS	XVII-XVIII	Turn Signal Indicator	41
DECALS	XIX-XXII	Service Monitor and Indicators ..	42-48
SERIAL NUMBERS.....	1	Function Buttons	49-53
DIESEL ENGINE SPECIFICATIONS ...	2,3	Engine RPM Function	49
GENERAL SPECIFICATIONS	4-7	PTO RPM Function	49
TRAVEL SPEEDS	8,9	Timer Function	50
OVER ALL MEASUREMENTS	10	Area/Hour Function	51
TRANSPORT WEIGHT	10	Area Done Function	51
MAXIMUM GROSS MACHINE WEIGHT .	10	Wheel Slip Function	52,53
TIRE AND WHEEL EQUIPMENT	11-14	Ground Speed Function	53
TIRE INFLATION PRESSURE	12,13	Instrument Cluster	
AXLE STOP SPACERS	14	Programming	54-63
WHEEL TREAD POSITIONS	15-19	Programming Tire Size	55-60
DUAL WHEELS	20	Standard Code Number	55
FUEL SPECIFICATIONS	21	Dynamic Tire Code Number ..	56,57
FUEL CONDITIONER	22	Static Code Number	58-60
LUBRICATION	23-35	Programming	
Engine Hourmeter	23	Attachment Width	61,62
Lubrication Chart	24,25	Programming Rear Wheel	
Engine Lubrication	26	Position Monitor	62,63
Engine Oil Change	27,28	Automatic Shutdown System ...	64,65
Engine Oil Filters	28	Operating Controls	66-102
Rear Steering Valve Filter	29	Front Console	66-73
Rear Steering Hydraulic Oil Filter	30	Steering Column Tilt	74
Transmission Oil Level		Moving the Telescopic	
Check & Change	31	Steering Column	75
Hydraulic Oil Filters	31,32	Side Console	76-85
Planetary Oil Level Check & Change .	33	Park Brake Control	86
Differential Oil Level Check & Change .	34	Heater Stop Valve	87
Tractor Brakes	35	Fuel Tank Water Traps	87
TOWING	36	Cab Headliner Controls	88,89
		Cab Air Flow Control	90
		Cab Defroster Control	90
		Cab Air Flow Arrangements	91-93
		Air Conditioner Operation	94
		Cab Door Lock	94
		Ash Tray	94
		Rear View Mirrors	95
		Cab Window Lever	95
		Operators Seat	96,97
		Seat Belts	98
		Amber Warning Lamps, Direction	
		Turn Signals & SMV	99,100
		Implement Warning Lamps and	
		SMV Symbol	101
		Auxiliary Outlet Socket	102
		Normal Starting Procedure	103-105
		Stopping The Engine	105,106

TABLE OF CONTENTS

OPERATING INSTRUCTIONS

Cold Temperature Operation . . .	106,107
Cold Temperature Starting	108-111
Coolant Heater	108
Ether Starting Attachment	109,110
Starting Fluid Container Replacement	111
Power Shift Transmission	112,113
Power Takeoff	114-116
Operating PTO	114
Guards	115
Operating Safety	116
Drawbar	117-119
Three Point Hitch System	120
Hitch System Adjustments	121-123
Anti-Sway Chain	122
Hitch Operation	124-128
Hitch Control Lever	124
To Lift an Implement	124
To Lower an Implement	124
Electronic Hitch System	125,126
Controlling Maximum Depth	127
Stationary Depth Operation	127
Hydraulic Float Control	128
Hitch Coupler - Category III	129
Remote Hydraulic Control	130-135
Remote Control Levers	130,131
Variable Flow Control	132,133
Operating the Remote System	134,135
Hydraulic Hose Couplers	136
Hydraulic Hose Coupling	137
Remote Cylinder	138
Hydraulic Cylinder Jack Pads	139
Wheel Mounting	140
Wheel Rim Adjustment & Mounting . .	141
Wheel Positions and Clamp Adjustment	142
Dual Wheel Mounting	143
Power Adjustable Wheels	144-145
Tire Mounting	146
Loads Matched to Tractor	146
Tractor Ballast	147-154
Tractor Weight Distribution	147-149
Tractor and Equipment Weight . . .	150
Front End Weights	151
Tire Liquid Weight	152,153
Measuring Wheel Slip	154

PREVENTIVE MAINTENANCE

Hood and Side Panels	156
Cooling System	157-165
Pressure Cooling System	157
Coolant Solutions	158
Radiator Cleaning	158
Cooling System Service	159

PREVENTIVE MAINTENANCE (CONT'D)

Thermostat Check	160
Thermostat Replacement	160-162
Fan Belt Adjustment	163
Fan Belt Replacement	164
Water Filter and Conditioner	165
Fuel System	166-171
Service Intervals	166
Fuel Filter Replacement	167,168
Fuel Strainer	169,170
Air Removal	170,171
Air Induction System	172
Air Filter Service Interval	172
Air Filter Service Monitor	173
Air Filter	173
Air Filter Service	174,177
Aspirated Strata Tube Service	178-180
Tubes and Hose	181
Neutral Start Switch Service	182,183
Park Brake Adjustment	184
Electrical System	185-189
Head Lamps	185
Flood Lamps	185
Flashing Amber Warning Lamps . . .	186
Tail Lamps	186
Instrument Cluster Lamps	187
Fuse Panel	187
Head Lamp Adjustment	188
Batteries	190-192
Vent Caps	190
Removal & Installation of Batteries .	191
When Batteries Are Not in Use . . .	191
Battery Cables and Terminals	191
Auxiliary Battery Connections	192
Alternator Charging systems	189
Roll Over Protective Structure (ROPS)	193-195
Tractor Roll Over, Safety Rules and ROPS Label	194
Maintenance and Inspection	195
Operators Cab	196-210
Seat Belt Inspection and Maintenance	196
Preventive Maintenance	196-198
Air Filter Service	199-201
Operators Seat	202,203
Compressor Belt Adjustment	204
Compressor Belt Replacement	205
Compressor Belt Alignment	206
Refrigerant Check	207,208
Dome Lamp	209
Tool Box	209
Console Lamp	210

CASE TECHNICAL MANUALS

SAFETY

Safety Rules

Understand that your safety and the safety of other persons is measured by how you service, and operate this machine. Know the positions and operations of all controls before you try to operate. **MAKE SURE YOU CHECK ALL CONTROLS IN A SAFE AREA BEFORE STARTING YOUR WORK.**

READ THIS MANUAL COMPLETELY and make sure you understand the controls. All equipment has a limit. Make sure you understand the speed, brakes, steering, stability, and load characteristics of this machine before you start to operate.

The safety information given in this manual does not replace safety codes, insurance needs, federal, state and local laws. Make sure your machine has the correct equipment needed by the local laws and regulations.

J I Case is continuing to work for your safety by making tractors with better protection and by giving these rules for safe operation.



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

Before Starting



WARNING: Before starting engine study Operators Manual safety messages.

Read all safety signs on machine.

Clear the area of other persons.

Learn and practice safe use of controls before operating.

It is your responsibility to understand and follow manufacturers instructions on machine operation, service, and to observe pertinent laws and regulations.

Operator and Service Manuals may be obtained from your equipment dealer.



WARNING: Before starting the engine, be sure all operating controls are in neutral. This will ease starting loads on the starter and batteries and will eliminate the accidental start up of power driven equipment.

WARNING: *To help prevent injury:
BEFORE STARTING ENGINE - Put shields in place. Sit in the seat.
Place controls in neutral.*

**BEFORE OPERATING MACHINE - Clear people away. No riders.
Fasten seat belt.**



**WHEN OPERATING MACHINE - Keep away from power driven
parts. Avoid steep slopes, embankments, ditches and rough terrain.
Reduce speed when turning. In high speed travel, couple brake
pedals together where applicable. On road travel, use flashing warn-
ing lights where permitted and keep SMV emblem visible from rear.
WHEN MACHINE IS STOPPED - Engage park lock or brake. Lower
raised equipment to ground. Stop engine before dismounting to
service or clear machine(s).**



WARNING: *If the steering mode selector switch is turned to another
mode position while the tractor is not in operation, the rear wheels
can move when the tractor is started again. To prevent possible injury
from the rear tires moving, make sure no person is between the rear
tires and tractor frame before you start the tractor engine.*



CAUTION: *Check the machine for leaks or any parts that are broken,
not working correctly, or not there at all. Before you start the ma-
chine, tighten all caps, dipsticks, battery covers, etc.*



CAUTION: *To help prevent personal injuries during operation and
maintenance, use safety shoes, a hard hat, safety glasses or goggles
and good fitting clothing.*



CAUTION: *It is good practice to carry a fire extinguisher on the machine. Be sure that the extinguisher is properly maintained and be familiar with its proper use.*



CAUTION: *Provide a first aid kit for use in case of accident.*

Operation



WARNING *Operate controls only when seated in the Operator's seat.*



WARNING: *Securely fasten your seat belt if the machine has a ROPS frame or cab. The seat belt can help insure your safety if it is used and maintained.*



CAUTION *Never wear a seat belt loosely or with slack in the belt system. Never wear the belt in a twisted condition or pinched between the seat structural members.*



WARNING: *Operate the machine with the door closed to provide proper ROPS protection and to properly utilize the heating, ventilating or cooling systems.*



CAUTION: *To provide more secure hand and foot mobility, preventing slipping and possible injury, always face the machine when mounting and dismounting.*



WARNING: *Before leaving the machine, stop the engine, place all controls in neutral, and either set the parking brake or place range lever in PARK position as equipped.*



WARNING: *Travel speed should be such that complete control and machine stability is maintained at all times. Where possible, avoid operating near ditches, embankments and holes. Reduce speed when turning, crossing slopes, and on rough, slick, or muddy surfaces.*



WARNING: *Collision of high speed road traffic and slow moving machines can cause personal injury or death. On roads, use flasher/lights according to local laws. Keep SMV emblem visible.*



CAUTION *Stop, look and listen before entering a highway, stay on your side of the road and pull over to let faster traffic pass. Slow down and signal as you turn off.*



WARNING: *A frequent cause of personal injury or death is persons falling off and being run over. Do not permit others to ride. Only one person - the operator - should be on the machine when it is in operation.*

WARNING: *Engine can start with transmission in gear when neutral or safety start switch is by-passed:*

- 1. Do not connect across terminals on starter.*
- 2. Attach booster batteries according to safe method in Operators Manual. Then use recommended starting procedure from operators seat.*
- 3. When necessary, repair electrical system components promptly so that "jump starting" will not be attempted.*

Machine run-away can cause injury or death to operator and bystanders.



CAUTION: *Do not turn off the switch to stop the tractor with the transmission in gear when the engine is running. Power shift clutch friction could cause tractor movement on a smooth, level surface. If the ignition key is turned off for any reason, the engine should also be shutoff using the engine stop control.*



CAUTION: *With the engine running and the tractor in motion, if the ignition key switch is turned off and then back on, the tractor can move forward rapidly. The higher the throttle setting the more rapid the move forward will be. When the ignition key is turned off, electric solenoids close all valves to the hydraulic power shift clutches. When the key is turned back to on, oil will immediately flow to and close the clutches controlled by the power shift lever position and the tractor will move forward rapidly.*



WARNING: *Cab air filters remove dust in the air, but are not capable of removing chemicals used in spraying crops or in weed control. Many chemicals used for these purposes are toxic when improperly used, and can be hazardous to operators and others in the area. Follow the instructions of manufacturers of both the equipment and the chemicals regarding prohibitions against inhalation of dust or spray, personal hygiene practices, and other precautions noted by the manufacturers.*





CAUTION: *Make sure that the weight of a trailed vehicle that is not equipped with brakes, NEVER EXCEEDS the weight of the machine that is towing the vehicle. Stopping distance increases with increasing speed as the weight of the towed load increases, especially on hills and slopes.*



WARNING: *Extra weight and bad traction conditions such as mud or ice increase your stopping distance. Remember that liquid in the tires, weights on the machine or wheels, tanks filled with fertilizer, herbicides or insecticides - all these add weight and increase the distance you need in which to stop.*



WARNING *Stay off slopes too steep for safe operation. Shift down before you start up or down a hill with a heavy load. Avoid "free wheeling".*



WARNING: *Contact with overhead power lines can cause severe electrical burns or death from electrocution. Make sure there is enough clearance between raised equipment and overhead power lines.*



CAUTION: *Try to balance the load primarily on the implement wheels - as in loading a trailer or spreader. Avoid overloading the drawbar. Add front end weights for improved stability. Engage the clutch smoothly, avoid jerking and use the brakes cautiously to avoid jack-knifing.*



WARNING: *Rear upset can result if pulling from wrong location on tractor. Hitch only to the drawbar. Use 3 point hitch only with the implements designed for its use - not as a drawbar.*



WARNING *Be certain both latches are fully engaged across the implement lift pins before transporting or pulling the implement.*



WARNING *Lower or block hydraulically or mechanically elevated implements and other attachments before servicing or when leaving the equipment.*



CAUTION: *When remote cylinders are connected to the hydraulic system, cycle the control lever about three times to remove air from the cylinder and hoses. With air in the system raised equipment can drop accidentally and cause personal injury or machine damage.*



CAUTION *The implement should be lowered to the ground before uncoupling of the remote hydraulic hoses.*



CAUTION *Installing an adapter on the PTO shaft, to convert the shaft diameter or to convert the number of splines on the shaft, moves the driveline connection rearward. This exposes the front universal joint and attaching mechanism. Adapters must not be installed unless the original master shield on the tractor is extended with equivalent shielding.*

The use of an adapter is not recommended.



WARNING: *PTO driven machinery can cause serious injury. Before working on or near the PTO shaft, or servicing or clearing the driven machine, put the PTO lever in the **DISENGAGE** position and **STOP** the engine.*



WARNING *Rotating machine parts, stay clear, keep shields installed to help protect from clothing entanglement and injury. Wear close-fitted clothing.*



WARNING: *Whenever a PTO driven machine is in operation, the PTO guard must be in place for most operations to prevent injury to the operator or bystanders. Where attachments, such as pumps, are installed on the PTO shaft (especially if the tractor PTO guard is moved upward or removed) extended shielding equivalent to the PTO guard must be installed with the attachment. Install the PTO guard to its original position immediately when the attachment is removed. When the PTO is not in use, the tubular guard must be installed over the end of the PTO shaft.*



WARNING: *When doing stationary PTO work and dismantling from the tractor with the PTO running, keep clear of all moving parts as they are a potential safety hazard.*



WARNING: *If this tractor is equipped with a 1000 RPM PTO, be sure implements are matched for this drive speed. Center and lock drawbar when using PTO.*

Buy Now



Our support email:

ebooklibonline@outlook.com