



SERVICE MANUAL

LOADALL (ROUGH TERRAIN
VARIABLE REACH TRUCK)
525-60

EN - 9813/3900 - ISSUE 3 - 02/2018

This manual contains original instructions, verified by the manufacturer (or their authorized representative).

Copyright 2018 © JCB SERVICE
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

www.jcb.com

Foreword

The Operator's Manual

⚠
You and others can be killed or seriously injured if you operate or maintain the machine without first studying the Operator's Manual. You must understand and follow the instructions in the Operator's Manual. If you do not understand anything, ask your employer or JCB dealer to explain it.

Do not operate the machine without an Operator's Manual, or if there is anything on the machine you do not understand.

Treat the Operator's Manual as part of the machine. Keep it clean and in good condition. Replace the Operator's Manual immediately if it is lost, damaged or becomes unreadable.

Contents

01 - Machine

03 - Attachments, Couplings and Load Handling

06 - Body and Framework

09 - Operator Station

12 - Heating, Ventilating and Air-Conditioning (HVAC)

15 - Engine

18 - Fuel and Exhaust System

21 - Cooling System

24 - Brake System

25 - Steering System

27 - Driveline

30 - Hydraulic System

33 - Electrical System

72 - Fasteners and Fixings

75 - Consumable Products

78 - After Sales

00 - General

Introduction	15-3
Health and Safety	15-5
Technical Data	15-6
Component Identification	15-7
Operation	15-10
Diagram	15-14
Fault-Finding	15-15
Drain and Fill	15-18
Clean	15-19
Check (Pressure)	15-20
Remove and Install	15-20
Store and Recommission	15-22

Introduction

This section contains information about the complete engine assembly. For specific engine technical information refer to the technical data section.

Make sure that the correct engine service tools, consumables and torque figures are used when you perform service procedures.

Replacement of oil seals, gaskets, etc., and any component that show signs of wear or damage, is expected as a matter of course.

It is expected that components will be cleaned and lubricated where required, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid, engine oil and ingress of dirt.

Basic Description

The Kohler KDI engine is a 4 cylinder diesel engine in which the fuel is ignited by compression ignition (C.I.). The engine operates on a four stroke cycle.

The engine is started by an electric starter motor. The starter motor turns the engine via a pinion and teeth on the engine flywheel.

When the engine runs the crankshaft drives the camshaft through the gears. The camshaft opens and closes the inlet and exhaust valves and through push rods in time with the four stroke cycle. The engine has 16 valves, 2 inlet and 2 exhaust valves for each cylinder.

The crankshaft also drives a mechanical high pressure fuel pump via gears. The pump is part of the electronically controlled common rail fuel injection system.

Air is drawn into the engine through the inlet manifold and exhaust gases exit through the exhaust manifold. The engine uses a variable geometry turbocharger which pressurises the air at the inlet manifold.


A mechanical lubrication oil pump is driven by the crankshaft through gears. The pump pressurises and circulates oil for engine lubrication and cooling purposes.

A drive belt again driven by the crankshaft, drives a coolant circulation pump and alternator.

Internal

The following identifies the main internal components of a typical engine assembly. Some variants may differ in detail.


Figure 135.



- A** Crankshaft
- C** Intermediate gear
- E** Camshaft
- G** Push rod


- B** Crankshaft gear
- D** Camshaft gear
- F** Tappet
- H** Valve

Figure 136.



- A** Crankshaft
- B** Crankshaft gear
- C** Intermediate gear
- D** Camshaft control gear
- J** Camshaft phonic wheel
- K** Intermediate gear pin
- L** Phonic wheel positioning reference pin on camshaft

Figure 137.



- G** Rocker arm push rod
- H** Valve
- M** Articulation control valve
- N** Valve control bridge
- P** Hydraulic tappet
- Q** Rocker arm

Health and Safety

accordance with local regulations. Use authorised waste disposal sites.

Hot Components

Touching hot surfaces can burn skin. The engine and machine components will be hot after the unit has been running. Allow the engine and components to cool before servicing the unit.

Turning the Engine

Do not try to turn the engine by pulling the fan or fan belt. This could cause injury or premature component failure.

Notice: *The engine and other components could be damaged by high pressure washing systems. Special precautions must be taken if the machine is to be washed using a high pressure system. Make sure that the alternator, starter motor and any other electrical components are shielded and not directly cleaned by the high pressure cleaning system. Do not aim the water jet directly at bearings, oil seals or the engine air induction system.*

WARNING! *To bleed the injectors you must turn the engine. When the engine is turning, there are parts rotating in the engine compartment. Before starting this job make sure that you have no loose clothing (cuffs, ties etc) which could get caught in rotating parts. When the engine is turning, keep clear of rotating parts.*

Notice: *Clean the engine before you start engine maintenance. Obey the correct procedures. Contamination of the fuel system will cause damage and possible failure of the engine.*

Notice: *Do not exceed the correct level of engine oil in the sump. If the maximum is exceeded, the excess must be drained to the correct level. An excess of engine oil could cause the engine speed to increase rapidly without control.*

WARNING! *The engine has exposed rotating parts. Switch off the engine before working in the engine compartment. Do not use the machine with the engine cover open.*

WARNING! *Hot oil and engine components can burn you. Make sure the engine is cool before doing this job. Used engine crankcase lubricants contain harmful contaminants. In laboratory tests it was shown that used engine oils can cause skin cancer.*

Notice: *A drive belt that is loose can cause damage to itself and/or other engine parts.*

WARNING! *Do not open the high pressure fuel system with the engine running. Engine operation causes high fuel pressure. High pressure fuel spray can cause serious injury or death.*

CAUTION! *It is illegal to pollute drains, sewers or the ground. Clean up all spilt fluids and/or lubricants. Used fluids and/or lubricants, filters and contaminated materials must be disposed of in*

Technical Data

Table 46.

Description	
Engine Type	KDI 2504 TCR
Emission compliance	US-EPA Tier 4 final, EU Stage IIIB
Max. operating speed	2200 RPM (Revolutions Per Minute)
Power Output	55kW at 2200 RPM
Weight (Dry)	233kg
Number of cylinders	4
Nominal bore size	88mm
Stroke	102mm
Cylinder arrangement	In line
Combustion Cycle	4-stroke
Firing order	1-3-4-2
Displacement	2.482L
Compression ratio	17: 1
Direction of rotation (viewed from flywheel end)	Counterclockwise
Valves	4 per cylinder
Tappets	Hydraulic
Lubricating oil pressure (Dependent on engine temperature and speed)	1–2.8bar (14.5–40.6psi)
Filter type	Screw-on canister
Pressure to open by-pass valve	2.5 ± 0.5bar (36.2 ± 7.2psi)
Oil pressure switch setting	0.8 ± 0.1bar (11.6 ± 1.4psi) falling
Oil pump ⁽¹⁾	Integral unit with relief valve
Combustion system	Common rail direct Injection
High pressure fuel pump	High pressure with electronically controlled fuel metering


(1) The oil pump is a non-serviceable part

Component Identification

External

The following identifies the main components of a typical engine assembly visible from the exterior. Some variants may differ in detail.

Figure 138.



A Flywheel housing [Refer to: PIL 15-54-03.](#)

C Fuel filter [Refer to: PIL 18-09-00.](#)

E Dipstick [Refer to: PIL 15-45-09.](#)

G Oil cooler [Refer to: PIL 15-69-00.](#)

J High pressure fuel pump [Refer to: PIL 18-18-15.](#)

L Catalytic converter [Refer to: PIL 18-24-18.](#)

N Engine harness

B Flywheel [Refer to: PIL 15-54-00.](#)

D Fuel filter drain plug [Refer to: PIL 18-09-00.](#)


F Oil filter [Refer to: PIL 15-21-00.](#)

H PTO (Power Take-Off) cover (If installed)

K Inlet manifold [Refer to: PIL 18-24-03.](#)

M EGR (Exhaust Gas Recirculation) valve [Refer to: PIL 18-27-06.](#)

P ECM (Engine Control Module)

Figure 139.


A ThermostatRefer to: [PIL 21-12-00](#).

C Cooling pumpRefer to: [PIL 21-09-00](#).

E Crankshaft phonic wheelRefer to: [PIL 15-12-15](#).

G Timing gear caseRefer to: [PIL 15-51-21](#).

J Oil sump drain plugRefer to: [PIL 15-45-03](#).

L BedplateRefer to: [PIL 15-09-00](#).

N Starter motorRefer to: [PIL 15-75-00](#).

Q Cylinder headRefer to: [PIL 15-06-00](#).

B Oil filler capRefer to: [PIL 15-57-00](#).

D Drive beltRefer to: [PIL 15-18-03](#).

F Oil sumpRefer to: [PIL 15-45-00](#).


H AlternatorRefer to: [PIL 15-72-00](#).

K CrankcaseRefer to: [PIL 15-03-00](#).

M Crankcase ventilation filterRefer to: [PIL 15-27-00](#).

P Oil pressure sensorRefer to: [PIL 15-84-21](#).

R Outlet manifoldRefer to: [PIL 18-24-04](#).

Figure 140.


A Injector [Refer to: PIL 18-18-03.](#)

C Turbocharger actuator [Refer to: PIL 18-35-00.](#)

E Turbocharger link [Refer to: PIL 18-35-00.](#)

G Low pressure fuel return pipes [Refer to: PIL 18-96-06.](#)

J High pressure fuel pipes [Refer to: PIL 18-96-03.](#)

B Rocker cover [Refer to: PIL 15-42-06.](#)

D Turbocharger [Refer to: PIL 18-35-00.](#)

F Oil filler cap [Refer to: PIL 15-57-00.](#)

H EGR cooler [Refer to: PIL 18-27-09.](#)

K Fuel rail [Refer to: PIL 18-18-12.](#)

Operation

The Four Cylinder Cycle

This section describes the cycle sequence for the 4 cylinder engine.

With the crankshaft positioned as shown, the pistons in numbers 1 and 4 cylinders are at top dead centre and pistons in numbers 2 and 3 cylinders are at bottom dead centre.

It is important to note that number 1 cylinder is firing and about to start its Power stroke. Rotating the crankshaft a further full rotation would position the pistons as described but the engine would be at a different stage in its four stroke cycle, with number 1 cylinder about to start its Induction stroke.

Firing Order

A cylinder is said to be firing, when the fuel/air mixture ignites and the piston is about to start its power stroke.


From the stages described, it can be seen that number 1 cylinder will be next to fire. Number 3 cylinder is starting its compression stroke and is next in the cycle, followed by cylinders 4 and 2. The firing order is therefore; 1, 3, 4, 2.

The stages in the four stroke cycle for each cylinder are as follows:


Table 47. The Four Stroke Cycle

Cylinder number	Piston operation	Valve operation
1	The piston is at the top of its Compression stroke and is about to start its Power stroke.	Inlet and exhaust valves closed
2	The piston is at the bottom of its Power stroke and is about to start its Exhaust stroke.	Inlet valves closed, exhaust valves about to open
3	The piston is at the bottom of its Induction stroke and is about to start its Compression stroke.	Exhaust valves closed, inlet valves about to close.
4	The piston is at the top of its Exhaust stroke and is about to start its Induction stroke.	Valve Operation Exhaust valves about to close, inlet valves about to open

Figure 141. Typical Four Cylinder Engine



745620



- CYL1** Cylinder number 1
- CYL2** Cylinder number 2
- CYL3** Cylinder number 3
- A** Camshaft
- B** Camshaft lobe - Inlet valve operation
- C** Camshaft lobe - Exhaust valve operation
- 1** Exhaust valves
- 2** Inlet valves
- 3** Crankshaft
- 4** Crankshaft gear
- 5** Camshaft drive gear

- CYL4** Cylinder number 4
- F** Front of engine

Four Stroke Cycle

Induction

As the piston travels down the cylinder, it draws filtered air at atmospheric pressure and ambient temperature through an air filter and inlet valves into the cylinder.

Compression

When the piston reaches the bottom of its stroke, the inlet valves close. The piston then starts to rise up the cylinder compressing the air trapped in the cylinder. This causes the temperature and pressure of the air to rise. Fuel is injected into the cylinder when the piston is near to TDC (Top Dead Centre).

Power

The piston continues to rise after the start of fuel injection, causing a further increase in pressure and temperature.


The temperature rises to a point at which the fuel/air mixture ignites. A cylinder is said to be firing when the fuel/air mixture ignites.

This combustion causes a very rapid rise in both temperature and pressure. The high pressure generated propels the piston downwards turning the crankshaft and producing energy.

Exhaust


Once the piston has reached the bottom of its travel, the exhaust valves open and momentum stored in the flywheel forces the piston up the cylinder expelling the exhaust gases.

In a running engine, these four phases are continuously repeated. Each stroke is half a revolution of the crankshaft, thus, in one cycle of a four stroke engine, the crankshaft revolves twice.



- | | | | |
|------------|-----------------------------------------|------------|---------------------------------------|
| 1 | Induction stroke | 2 | Compression stroke |
| 3 | Power stroke | 4 | Exhaust stroke |
| A | Camshaft | B | Camshaft lobe - Inlet valve operation |
| C | Camshaft lobe - Exhaust valve operation | BDC | Bottom dead centre |
| TDC | TDC | | |

Figure 143.



717620

1 Induction stroke

3 Power stroke

A Camshaft

C Camshaft lobe - Exhaust valve operation

2 Compression stroke

4 Exhaust stroke

B Camshaft lobe - Inlet valve operation

Diagram

Electrical Operation and Schematics


The schematic diagram shows a typical system. For machine specific schematics, refer to electrical system- general, refer to (PIL 33-00).

The schematic is shown with the ignition switch set to position III and the transmission set to N. A

signal will be sent between the Transmission ECU (Electronic Control Unit) and Engine ECU via the CAN (Controller Area Network) bus to tell the Engine ECU that the transmission is in Neutral.

The engine ECU provides power to the engine compartment fusebox to energise the start relay, the fuel pump relay, the starter motor and the fuel pump.

Figure 144.



- A** Alternator
- C** Ignition switch
- E** Primary fuse
- G** Engine compartment fusebox
- J** Fuel pump relay
- L** Engine ECU

- B** Battery
- D** Starter motor
- F** RHC/LMS (Loadall Monitoring System) display
- H** Start signal relay
- K** Fuel pump

Drain and Fill

Oil

Oil is toxic. If you swallow any oil, do not induce vomiting, seek medical advice. Used engine oil contains harmful contaminants which can cause skin cancer. Do not handle used engine oil more than necessary. Always use barrier cream or wear gloves to prevent skin contact. Wash skin contaminated with oil thoroughly in warm soapy water. Do not use petrol, diesel fuel or paraffin to clean your skin.


CAUTION! It is illegal to pollute drains, sewers or the ground. Clean up all spilt fluids and/or lubricants. Used fluids and/or lubricants, filters and contaminated materials must be disposed of in accordance with local regulations. Use authorised waste disposal sites.

Engine oil replacement must be completed in accordance with the service schedules. Failure to replace the oil replacement at the recommended interval could cause serious engine failure.

Drain the oil when the engine is warm as contaminants held in suspension will then be drained with the oil.

1. Make the machine safe.
[Refer to: PIL 01-03-27.](#)
2. Park the machine on a hard level surface for accurate measurement of the oil level.
3. Get access to the engine.
4. Place a container of suitable size beneath the drain plug.
5. Remove the oil filler cap.

Figure 145.




- A Oil filler cap
- B Drain plug
- C O-ring

CAUTION! Oil will gush from the hole when the drain plug is removed. Keep to one side when you remove the plug.


6. Remove the oil dipstick.
7. Remove the oil sump drain plug and O-ring from both sides of the oil sump.
8. Drain the engine oil into an suitable container.
9. Clean and install the drain plug with a new O-ring. Tighten the plug to the correct torque value.
10. Through one of the filler points, fill the engine with the recommended oil to the MAX mark on the dipstick.

Figure 146.



- A Oil filler cap

Figure 147.



- D Dipstick
- E Maximum level mark
- F Minimum level mark

11. Wipe off any spilt oil, install the filler cap and make sure it is secure.
12. Operate the engine, until the oil pressure low warning light has extinguished.
13. Check for oil leakage.
14. When the oil has cooled, check the oil level again, and if necessary top up with clean engine oil.

Buy Now



Our support email:

ebooklibonline@outlook.com