

# BOMAG

## Operating instructions Maintenance instructions

---



**BW 125 ADH / BW 135 AD**

---

**BW 138 AD / BW 138 AC**

---

S/N 101 650 12.... > S/N 101 170 21....>  
S/N 101 650 14 .... > S/N 101 650 15 .... >



---

**Tandem Vibratory Roller**

---

**Combination Roller**

---

If the machine is equipped with a battery :

**CALIFORNIA**

**Proposition 65 Warning**

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

**Wash hands after handling.**

If the machine is equipped with a diesel engine :

**CALIFORNIA**

**Proposition 65 Warning**

The engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects, and other reproductive harm.

**BOMAG machines are products from the wide range of BOMAG compaction equipment.**

**BOMAG's vast experience in connection with state-of-the-art production and testing methods, such as lifetime tests of all important components and highest quality demands guarantee maximum reliability of your machine.**

This manual comprises:

- Safety regulations
- Operating instructions
- Maintenance instructions
- Trouble shooting

Using these instructions will

- help you to become familiar with the machine.
- avoid malfunctions caused by unprofessional operation.

Compliance with the maintenance instructions will

- enhance the reliability of the machine on construction sites,
- prolong the lifetime of the machine,
- reduce repair costs and downtimes.

BOMAG will not assume liability for the function of the machine

- if it is handled in a way that does not comply with the usual modes of use,
- if it is used for purposes other than the ones it is intended for, see safety regulations.

No warranty claims can be lodged in case of damage resulting from

- operating errors,
- insufficient maintenance and
- wrong fuels and lubricants.

**Please note!**

This manual was written for operators and maintenance personnel on construction sites.

Always keep this manual close at hand, e.g. in the tool compartment of the machine or in a specially provided container. These operating and maintenance instructions are part of the machine.

You should only operate the machine after you have been instructed and in compliance with these instructions.

Strictly observe the safety regulations.

Please observe also the guidelines of the Civil Engineering Liability Association "Safety Rules for the Operation of Road Rollers and Soil Compactors" and all relevant accident prevention regulations.

**For your own personal safety you should only use original spare parts from BOMAG.**

**In the course of technical development we reserve the right for technical modifications without prior notification.**

These operating and maintenance instructions are also available in other languages.

Furthermore, the spare parts catalogue is available from your BOMAG dealer against the serial number of your machine.

Your BOMAG dealer will also supply you with information about the correct use of our machines in soil and asphalt construction.

The above notes do not constitute an extension of the warranty and liability conditions specified in the general terms of business of BOMAG.

We wish you successful work with your BOMAG machine.

BOMAG GmbH

Printed in Germany

Copyright by BOMAG

## Foreword

### Please fill in

.....

Machine type (Fig. 1)

.....

Serial-number (Fig. 1 and 2)

.....

Engine type (Fig. 3)

.....

Engine number (Fig. 3)

### **i** Note

*Supplement the above data together with the commissioning protocol.*

*During commissioning our organisation will instruct you in the operation and maintenance of the machine.*

*Please observe strictly the safety regulations and all notes on risks and dangers!*




Fig. 1




Fig. 2




Fig. 3


<b>Technical Data</b>	<b>7</b>
<b>Safety regulations</b>	<b>15</b>
<b>Indicators and Controls</b>	<b>23</b>
3.1 General notes	27
3.2 Description of indicators and control elements	27
<b>Operation</b>	<b>35</b>
4.1 General notes	36
4.2 Inspections before starting operation	36
4.3 Starting the engine	37
4.4 Starting with jump wires	39
4.5 Driving the machine	39
4.6 Stopping the machine / applying the brake	41
4.7 Switching the vibration on and off	41
4.8 Switching the vibration on or off	43
4.9 Switching the pressure sprinkler system on or off	44
4.10 Stopping the engine/machine	45
4.11 Adjusting the driver's seat	46
4.12 Towing	46
4.13 Loading and transport	48
4.14 Foldable roll over protection structure (ROPS)	49
<b>Maintenance</b>	<b>51</b>
5.1 General notes on maintenance	52
5.2 Fuels and lubricants	53
5.3 Table of fuels and lubricants	55
5.4 Running-in instructions	56
5.5 Maintenance chart	57
5.6 Check the engine oil level	59
5.7 Checking the dry air filter	59
5.8 Checking the hydraulic oil level	60
5.9 Checking the hydraulic oil filter element	60
5.10 Checking the fuel level	61
5.11 Checking the water level	61
5.12 Checking the emulsion oil level	62
5.13 Lubricating the articulated joint	62
5.14 Cleaning cooling fins and engine oil cooler	63
5.15 Cleaning the hydraulic oil cooler	64
5.16 Adjusting the scrapers	64
5.17 Checking the battery condition, greasing the poles	65
5.18 Draining the slurry from the fuel tank	66
5.19 Changing the engine oil	67
5.20 Change the engine oil filter cartridge	68

## Table of Contents

5.21	Check, adjust the valve clearance	68
5.22	Checking, tensioning, changing the V-belt	70
5.23	Changing the fuel pre-filter	71
5.24	Change the fuel filter cartridge	72
5.25	Changing the hydraulic oil	73
5.26	Changing the hydraulic oil filter element	74
5.27	Checking the injection valves	75
5.28	Replacing the toothed belt	76
5.29	Checking the tire pressure	77
5.30	Cleaning, changing the dry air filter	77
5.31	Cleaning the water tank	78
5.32	Water sprinkler system, maintenance in the event of frost	79
5.33	Engine conservation	79
5.34	Tightening torques for screws with metric unified thread	80
<b>Trouble shooting</b>		<b>81</b>
6.1	General notes	82
6.2	Engine problems	83

## 1 Technical Data

## Technical Data



150 001

Fig. 4

Dimensions in mm	A	B	C	D	H	H2	K	L	O	S	W
<b>BW 125 ADH</b>	1790	1280	650	800	1900	2700	320	2590	40	17,0	1200
<b>BW 135 AD</b>	1790	1380	650	800	1900	2700	320	2590	40	17,0	1300
<b>BW 138 AD</b>	1790	1460	650	810	1905	2705	325	2600	40	22	1380

\*

**BW 125 ADH**

**BW 135 AD**

**BW 138 AD**

### Weights

Operating weight (CECE)	kg	3360	3560	4200
Mean axle load (CECE)	kg	1680	1780	2100
Mean static linear load (CECE)	kg/cm	14	13,7	15,2

### Dimensions

Oscillation angle	+/-°	13	13	13
Inner track radius	mm	3700	3650	3610



*		<b>BW 125 ADH</b>	<b>BW 135 AD</b>	<b>BW 138 AD</b>
<b>Travel characteristics</b>				
Travel speed I	km/h	0...5,0	0...5,0	0...5,0
Travel speed II	km/h	0...10	0...10	0...10
Max. gradability/with vibration (soil dependent)	%	40/30	40/30	40/30
<b>Drive</b>				
Engine manufacturer		Deutz	Deutz	Deutz
Type		F3L 2011	F3L 2011	F3L 2011
Cooling		Air-oil	Air-oil	Air-oil
Number of cylinders		3	3	3
Rated power ISO 9249	kW	34	34	34
Rated speed	rpm	2800	2800	2800
Fixed engine speed 1	rpm	2200	2200	2500
Fixed engine speed 2	rpm	2700	2700	2800
Fuel tank capacity	l	55	55	55
Electrical equipment	V	12	12	12
Drive system		hydrost.	hydrost.	hydrost.
Driven axles		front+rear	front+rear	front+rear
<b>Brakes</b>				
Service brake		hydrost.	hydrost.	hydrost.
Parking brake		hydr.-mech.	hydr.-mech.	hydr.-mech.
<b>Steering</b>				
Type of steering		Oscill.-articul.	Oscill.-articul.	Oscill.-articul.
Steering operation		hydrost.	hydrost.	hydrost.
Steering angle +/-	Degree	25	25	25
<b>Vibration system</b>				
Drive system		hydrost.	hydrost.	hydrost.
Frequency	Hz	50/60	50/60	46/52
Amplitude	mm	0,45	0,40	0,50
Vibrating drum		front+rear	front+rear	front+rear
<b>Water sprinkler system</b>				
Type of sprinkling		Pressure	Pressure	Pressure
Interval control		Standard	Standard	Standard
Water tank capacity	l	230	230	230

\* The right for technical modifications remains reserved

## Technical Data

The following noise and vibration values according to the EC-directive for machines, edition (98/37/EEC) and the noise emission regulation 2000/14/EC were measured at nominal engine speed and with the vibration switched on. The machine was standing on an elastic base.

During operation these values may vary because of the existing operating conditions.

### Noise value

The sound level according to enclosure 1, paragraph 1.7.4. f of the EC-machine regulation is **sound pressure level on the operator's stand:**

#### BW 125 ADH

$L_{pA} = 79 \text{ dB(A)}$

#### BW 135 AD

$L_{pA} = 83,5 \text{ dB(A)}$

#### BW 138 AD

$L_{pA} = 86 \text{ dB(A)}$

The noise emission value for the machine according to the noise emission regulation 2000/14/EG is **guaranteed sound capacity level of the machine:**

#### BW 125 ADH

$L_{WA} = 107 \text{ dB(A)}$

#### BW 135 AD

$L_{WA} = 107 \text{ dB(A)}$

#### BW 138 AD

$L_{WA} = 104 \text{ dB(A)}$

These sound values were determined according to ISO 3744 for the sound capacity level ( $L_{WA}$ ) and ISO 11204 for sound pressure level ( $L_{pA}$ ) at the place of the operator.

### Vibration value


The vibration values according to enclosure 1, paragraph 3. 6. 3. a of the EC-machine regulation are:

#### Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is  $\leq 0.5 \text{ m/sec}^2$ .

#### Hand-arm vibration values

The weighted effective acceleration value determined according to EN 500/ISO is  $\leq 2.5 \text{ m/sec}^2$ .



150 002

Fig. 5

Dimensions in mm	A	B	C	D	H	H2	K	L	O	S	W
<b>BW 138 AC</b>	1790	1460	650	810	1905	2705	325	2580	40	22	1380

\*

**BW 138 AC**

**Weights**

Operating weight (CECE)	kg	4000
Axle load, drum (CECE)	kg	2050
Axle load, wheels (CECE)	kg	1950
Mean static linear load	kg/cm	14,9

**Dimensions**

Oscillation angle	+/-°	13
Inner track radius	mm	3610

## Technical Data

\*

### BW 138 AC

#### Travel characteristics

Travel speed I	km/h	0...5,0
Travel speed II	km/h	0...10
Max. gradability/with vibration (soil dependent)	%	40/30

#### Drive

Engine manufacturer		Deutz
Type		F3L 2011
Cooling		Air-oil
Number of cylinders		3
Rated power ISO 9249	kW	34
Rated speed	rpm	2800
Fixed engine speed 1	rpm	2250
Fixed engine speed 2	rpm	2800
Fuel tank capacity	l	55
Electrical equipment	V	12
Drive system		hydrostatic
Driven axles		front+rear

#### Tires

Number of tires		4
Tire size		225/75 R16

#### Brakes

Service brake		hydrost.
Parking brake		hydr.-mech.

#### Steering

Type of steering		Oscill.-articul.
Steering operation		hydrost.
Steering angle +/-	Degree	25

#### Vibration system

Drive system		hydrost.
Frequency	Hz	46/52
Amplitude	mm	0,5
Vibrating drum		front

#### Water sprinkler system

Type of sprinkling		Pressure
Interval control		Standard
Water tank capacity	l	230
Emulsion tank capacity	l	20

\* The right for technical modifications remains reserved

**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)