

TRS21/21E/22/24/26/27/32 and TRX24/26 Walk-Behind Snowthrowers/Snowblowers

TECHNICAL MANUAL

**John Deere
Lawn & Grounds Care Division
TM1466 (20Jan95)
Replaces TM1466 (25Aug92)**

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

N This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, other materials needed to do the job and service parts kits.

Section 10, Group 15—Repair Specifications, consist of all applicable specifications, near tolerances and specific torque values for various components on each individual machine.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

FOS MANUALS—REFERENCE

TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

Contents

SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Repair Specifications
- Group 20—Fuels and Lubricants
- Group 25—Serial Number Locations

SECTION 20—4 AND 5-HP ENGINE REPAIR—TRS22 AND TRS/TRX24

- Group 05—Carburetor, Fuel Tank, and Muffler
- Group 10—Remove and Install Engine
- Group 15—Blower Housing, Cylinder Head, and Breather
- Group 20—Governor, Camshaft, and Tappets
- Group 25—Flywheel, Crankshaft and Piston Assembly
- Group 30—Cylinder Block
- Group 35—Recoil Starter

SECTION 21—8 AND 10-HP ENGINE REPAIR—TRS/TRX26, TRS27, TRS32

- Group 05—Carburetor, Fuel Tank, and Muffler
- Group 10—Remove and Install Engine
- Group 15—Blower Housing, Cylinder Head, and Breather
- Group 20—Governor, Camshaft, and Tappets
- Group 25—Flywheel, Crankshaft and Piston Assembly
- Group 30—Cylinder Block
- Group 35—Recoil Starter

SECTION 25—4 AND 5-HP ENGINE REPAIR—TRS21

- Group 05—Fuel System and Muffler
- Group 10—Engine
- Group 15—Recoil Starter

SECTION 40—ELECTRICAL

- Group 05—Electric Starter—4-Cycle Engines
- Group 06—Electric Starter
- Group 10—4 and 5-HP Ignition and Charging

System

- Group 15—8 and 10-HP Ignition and Charging System
- Group 20—4 HP (2-Cycle) Ignition System

SECTION 50—POWER TRAIN—TRS22, TRS/TRX24 & 26

- Group 05—Drive Belt Care and Maintenance
- Group 10—Power Train Repair
- Group 15—Blower and Auger Drive Repair

SECTION 55—POWER TRAIN—TRS27 AND 32

- Group 05—Drive Belt Care and Maintenance
- Group 10—Power Train Repair—TRS27 and 32 (S.N. —140000)
- Group 15—Blower and Auger Drive Repair
- Group 20—Power Train Repair—TRS27 and 32 (S.N. 140001—)

SECTION 85—AUGER DRIVE SYSTEM—TRS1

- Group 05—Drive Belt Care and Maintenance
- Group 10—Auger Drive Repair

SECTION 210—TEST AND ADJUSTMENT SPECIFICATIONS/OPERATIONAL CHECKOUT PROCEDURES

- Group 05—Test and Adjustment Specifications
- Group 10—Operational Checkout Procedures

SECTION 220—ENGINE—4-CYCLE ENGINES

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments

SECTION 225—ENGINE—2-CYCLE ENGINES

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1466-20Jan95

COPYRIGHT© 1995
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright© 1989 Deere & Company

10 **SECTION 230—FUEL SYSTEM—4-CYCLE ENGINES**

- Group 05—Component Location—4-Cycle Engine
- Group 10—Theory of Operation
- Group 15—Diagnosis and Adjustments—4-Cycle Engine

20 **SECTION 235—FUEL SYSTEM—2-CYCLE ENGINE**

- Group 05—Component Location—2-Cycle Engine
- Group 10—Theory of Operation
- Group 15—Diagnosis and Tests—2-Cycle Engine

21 **SECTION 240—ELECTRICAL SYSTEM—4-CYCLE ENGINES**

- Group 05—Component Location—4-Cycle Engine
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests and Adjustments—4-Cycle Engine

25 **SECTION 245—ELECTRICAL SYSTEM—2-CYCLE ENGINES**

- Group 05—Component Location—2-Cycle Engine
- Group 10—Theory of Operation
- Group 15—Diagnosis and Adjustments—2-Cycle Engine

40 **SECTION 250—POWER TRAIN—TRS22, TRS/TRX24 AND 26**

- Group 05—Component Location—TRS22, TRS/TRX24 and 26
- Group 10—Theory of Operation
- Group 15—Diagnosis and Adjustments—TRS22, TRS/TRX24 and 26

50 **SECTION 255—POWER TRAIN—TRS27, AND 32**

- Group 05—Component Location—TRS27 and 32
- Group 10—Theory of Operation
- Group 15—Diagnosis and Adjustments—TRS27 and 32

85 **SECTION 280—AUGER DRIVE SYSTEM—2 STAGE**

- Group 05—Component Location—2 Stage
- Group 10—Theory of Operation
- Group 15—Diagnosis and Adjustments—2 Stage

210 **SECTION 285—AUGER DRIVE SYSTEM—TRS21**

- Group 05—Component Location—Single Stage
- Group 10—Theory of Operation
- Group 15—Diagnosis and Adjustments—Single Stage

Section 10 GENERAL INFORMATION

Contents

Page

Group 05—Safety 10-05-1

Group 10—General Specifications

Machine Specifications

TRS21 and 22 10-10-1

TRS/TRX24 and 26 10-10-3

TRS27 and 32 10-10-6

Group 15—Repair Specifications

Repair Specifications

TRS21/21ES 10-15-1

TRS22 and TRS/TRX24 10-15-2

TRS/TRX26 10-15-5

TRS27 and 32 10-15-7

Inch Cap Screw Torque Values 10-15-10

Set Screw Seating Torque Chart 10-15-11

Group 20—Fuels and Lubricants

Two-Cycle Gasoline Engine Oil 10-20-1

Two-Cycle Engine Fuel 10-20-1

Fuel 10-20-2

Engine Oil 10-20-2

Gear Oil 10-20-3

Grease 10-20-3

Group 25—Serial Number Locations

Serial Number Information 10-25-1

Product Identification Number Location . . 10-25-1

Engine Serial Number Location 10-25-2

Group 30—Features and Accessories . . 10-30-1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com