

7600, 7700, and 7800 Tractors

John Deere Waterloo Works

OMAR113107 Issue A6

(This manual replaces OMAR113107 Issue E5)

European Edition

LITHO IN U.S.A.

ENGLISH

Introduction

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification or Identification Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

SETTING FUEL DELIVERY BEYOND PUBLISHED factory specifications or otherwise overpowering will result in loss of warranty protection for this machine.

BEFORE DELIVERING THIS MACHINE, your dealer performed a predelivery inspection. After operating for the first 100 hours, schedule an after-sale inspection with your dealer to ensure best performance.

THIS TRACTOR IS DESIGNED SOLELY for use in customary agricultural or similar operations. ("Intended Use") Use in any other way is considered as contrary to the intended use. The manufacturer accepts no liability for damage or injury resulting from this misuse, and these risks must be borne solely by the user. Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for the intended use.

THIS TRACTOR SHOULD BE OPERATED, serviced and repaired only by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention). The accident prevention regulations, all other generally recognized regulations on safety and occupational medicine and the road traffic regulations must be observed at all times. Any arbitrary modifications carried out on this tractor will relieve the manufacturer of all liability for any resulting damage or injury.



RW22106
-UN-03FEB93

RX7000E,IFC -19-02FEB94

Contents

	Page		Page
Safety	05-1	Starting the Engine	35-2
Safety Signs	10-1	Restarting the Engine	35-3
Controls and Instruments		Stopping the Engine	35-3
Command Console	15-1	Auxiliary Heaters	35-3
Function Indicators	15-1	Cold Weather Starting	35-4
Control Console	15-2	Starting Fluid	35-6
Instrument Panels		Booster Battery	35-6
Analog	15-4	Operating the Tractor	
Digital	15-6	Avoid Pesticides	40-1
Display Functions	15-8	Transmission	40-2
Calibrating Tire Size-with Radar	15-9	Creeper	40-5
Calibrating Radar	15-10	Mechanical Front-Wheel Drive	40-6
Performance Monitor	15-11	Differential Lock	40-6
Lights		Brakes	40-7
Operating Lights		Hydraulic Trailer Brakes	40-7
Road	20-1	Trailer Air Brakes	40-8
Field	20-2	Hitch	
Hazard	20-3	Hitch Components and Controls	45-1
Turn Signals, Horn, Head Lights	20-3	Hitch Operation	45-1
Seven-terminal Outlet	20-4	External Raise/Lower Switches	45-5
Operator Station		Attaching and Detaching Implements	45-6
Seat	25-1	Sway Blocks	45-9
Steering Wheel	25-2	Stabilizing System	45-9
Park Brake	25-2	Trailer Hitch	45-10
Heater/Air Conditioner	25-3	Pickup Hitch	45-10
Windshield Wiper	25-4	Electrohydraulic Depth Control	
Clock	25-4	Prepare Tractor	50-2
Accessory Electrical Outlet	25-4	Enable System	50-3
Steps	25-5	Attach Implement	50-5
Break-in Period		Check Operation	50-5
Engine	30-1	Detach Implement	50-6
Wheel Bolts	30-2	Restore Hitch Control	50-7
Operating the Engine		Check System	50-7
Pre-starting Checks	35-1	Remote Hydraulic Cylinders	
		Cylinder Hoses	55-1

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMAR113107 A6-19-19DEC95

COPYRIGHT© 1996
DEERE & COMPANY
European Office Mannheim
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright1995, 1994, 1993 Deere & Company

Contents

	Page		Page
Adjusting Metering Valve	55-2	Service	
SCV Operation	55-3	Service Chart Reference	85-1
Detent Relief Setting	55-6	Side Shields	85-1
Relief Valve Manual Lowering	55-7	Hood	85-2
Low-Pressure Return Circuit	55-8	Charging Batteries	85-3
Hydraulic Motor Return	55-9	High-Pressure Washers	85-3
Power-Beyond Valve	55-10	Service Interval Charts	85-5
Remote Cylinders	55-12		
Drawbar and PTO		Service/Daily or Every 10 Hours	
Drawbar	60-1	Engine Oil	90-1
PTO	60-3	Coolant	90-1
		Water Separator	90-2
Optimum Performance/Ballast		Transmission-Hydraulic Oil	90-2
Guidelines	65-1	Rear Axle Bearings	90-3
Power Hop	65-3	MFWD Axle	90-3
Measuring Wheel Slip	65-5	Front PTO Shaft	90-4
Determining Ballast	65-6	Trailer Air Brake Accumulator	90-4
Liquid Weight	65-7	Tires	90-4
Rear Cast Iron Weights	65-9		
Quik-Tatch Weights	65-9	Service/250 Hours	
		Engine Oil and Filter	95-1
Wheels, Tires, and Treads		Rear Window Hinge	95-1
Guidelines	70-1	Fuel Tank Sump	95-2
Inflation Pressures	70-2	Batteries	95-2
Inflation Pressures	70-3	Neutral Start System	95-4
Tire Combinations	70-4	Cab Air Filters	95-4
Tightening Wheel Bolts	70-5	Wheel Bolts	95-4
Toe-In	70-6	Hitch and Lift Links	95-5
Front Tread Setting	70-7	Pickup Hitch	95-5
Steering Stops	70-9	Trailer Hitch	95-5
Fenders	70-11	MFWD Axle	95-6
Cast Rear Wheels	70-12	MFWD Housing and Wheel Hub Oil	95-6
Steel Rear Wheels	70-13	Front PTO	95-6
Rear Tread Setting	70-14	Manual Brakes	95-7
Transport		Service/750 Hours	
Driving	75-1	Transmission Filter	100-1
Towing Loads	75-2	Hydraulic Filter	100-1
Towing Tractor	75-4	Rear Axle Bearings	100-2
Transporting	75-5	Air Intake	100-2
Mired Machine	75-6	Engine Idle Speeds	100-2
		Coolant Conditioner	100-3
		Engine Valve Clearance-7600 (initial)	100-3
		Fuel Tank Vent Filter	100-3
Fuel, Lubricants, and Coolant		Service/1500 Hours	
Fuel	80-1	Transmission-Hydraulic Oil	105-1
Engine Oil	80-3	Hydraulic Oil Suction Screen	105-1
Engine Coolant	80-5	MFWD Hub and Axle Housing Oil	105-2
Transmission-Hydraulic Oil	80-6	Front PTO Housing Oil	105-2
Gear Oil	80-7		
Grease	80-7		

Continued on next page

Contents

	Page		Page
Engine Valve Clearance-7600	105-3	Electrical System	135-9
Fuel Injection Nozzles	105-3	Operator Enclosure	135-11
Draft Link Support Shaft Bushing	105-3	Tractor Operation	135-12
Belt Tensioner	105-4		
Service/2000 Hours		Storage	140-1
Engine Valve Clearance-7700 and 7800 . . .	110-1	Specifications	
		Specifications	145-1
Service/Annual		Ground Speeds	145-4
Air Cleaner	115-1	Certificate of Conformity	145-9
PTO Shaft	115-1		
		Identification Numbers	150-1
Service/Two Years		Lubrication and Maintenance Charts	155-1
Flush Cooling System-Replace			
Thermostats	120-1	Glossary	160-1
Service/4500 Hours		Index	
Engine Crankshaft Damper	125-1		
Service/As Required			
Transmission Filter	130-1		
Hydraulic Filter	130-1		
Fuel Prefilter	130-2		
Fuel Filter-7600 and 7700	130-2		
Bleed Fuel System	130-3		
Water Separator	130-4		
Fuel Filter-7800	130-4		
Bleed Fuel System	130-4		
Bleed Brakes	130-5		
Engine Compartment	130-5		
Grille Screens, Radiator, and Condenser . . .	130-6		
Pre-Cleaner	130-6		
Air Cleaner	130-7		
Fan Belt	130-9		
Front Lights	130-10		
Head Lights	130-11		
Lamp Replacement	130-12		
Fuses and Relays	130-14		
Air Conditioner	130-16		
Alternator Replacement	130-17		
Troubleshooting			
Engine	135-1		
Transmission	135-4		
Hydraulic System	135-5		
Brakes	135-5		
Hitch	135-6		
Electrohydraulic Depth Control	135-7		
Selective Control Valves	135-8		

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389 -UN-07DEC68

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187 -19-30SEP88


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.




DX,READ -19-03MAR93


TS201 -UN-23AUG88



OPERATING THE TRACTOR SAFELY



TS213 -JUN-23AUG88



TS276 -JUN-23AUG88

Careless use of the tractor can result in unnecessary accidents. Be alert to hazards of tractor operation. Understand causes of accidents and take every precaution to avoid them. Most common accidents are caused from:

- Tractor roll-over
- Improper starting procedures
- Crushing and pinching during hitching
- Collisions with other motor vehicles
- Entanglement in PTO shafts
- Falling from tractor

Avoid accidents by taking the following precautions:

- Put transmission in PARK before dismounting. Leaving transmission in gear with engine stopped will NOT prevent the tractor from moving.
- Be sure everyone is clear of tractor and attached equipment before starting engine.
- Never try to get on or off a moving tractor.
- When tractor is left unattended, place in PARK, lower implements to the ground, stop the engine, and remove the key.
- Never go near an operating PTO or an operating implement.
- Always fasten your seat belt in a ROPS equipped tractor.

RX,HAZARD,S -19-20DEC95




PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.



DX,BYPAS1 -19-03MAR93


TS177 -UN-11JAN89

STOPPING AND PARKING TRACTOR

Tractor roll-over, collisions, runaway tractors, and people being crushed under machines and implements can happen when operators ignore safety.

To avoid these accidents, take some precautions:

- Signal before stopping, turning, or slowing down on public roads
- Pull over to side of road before stopping
- Slow down before braking
- Pump brakes when stopping on slippery surfaces
- Be careful when towing and stopping heavy loads
- Shift to park or apply parking brake
- Lower all equipment when leaving tractor
- Remove key



RX,STOP,PARK -19-21SEP92

TS230 -UN-24MAY89

USE SEAT BELT

Use a seat belt to minimize chance of injury from an accident such as a roll-over.



RX,ROPS1 -19-22SEP92


RW16064 -UN-05JAN89



KEEP ROPS INSTALLED PROPERLY

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



DX,ROPS3 -19-03MAR93


-UN-23AUG68
TS212

USE CAUTION ON HILLSIDES

Avoid holes, ditches, and obstructions which may cause tractor roll-over, especially on hillsides. Avoid sharp turns on hills.

Never drive near the edge of a gully or steep embankment.

Driving out of a ditch, mired condition, or up a steep slope could cause tractor to tip over rearward. Back out of these situations if possible.




RX,HILL,SIDE1 -19-22SEP92

-UN-07DEC68
RW13093

KEEP RIDERS OFF MACHINE

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.




DX,RIDER -19-03MAR93

-UN-23AUG68
TS290



AVOID EYE CONTACT WITH RADAR

Radar ground speed sensor emits a very low intensity microwave signal. It will not cause any ill effects during normal use. Although intensity is low, **DO NOT** look directly into face of sensor while in operation, to avoid any possible eye damage.




RX,SAFTY,RADAR1-19-21SEP92

TS266
-UN-23AUG88

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



DX,WEAR2 -19-03MAR93

TS206
-UN-23AUG88

HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



DX,FIRE1 -19-03MAR93


TS202
-UN-23AUG88

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

TS291
-UN-23AUG88



HANDLE STARTING FLUID SAFELY

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.



DX,FIRE3 -19-16APR92


TS1356 -UN-18MAR92

AVOID CONTACT WITH PESTICIDES

This enclosed cab does not protect against inhaling harmful pesticides. If pesticide use instructions require respiratory protection, wear an appropriate respirator inside the cab.

Before leaving the cab, wear personal protective equipment as required by the pesticide use instructions. When re-entering the cab, remove protective equipment and store either outside the cab in a closed box or some other type of sealable container or inside the cab in a pesticide resistant container, such as a plastic bag.

Clean your shoes or boots to remove soil or other contaminated particles prior to entering the cab.



DX,CABS -19-03MAR93

TS220 -UN-23AUG88

TS272

-UN-23AUG88

TS272



STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.




DX,PTO -19-12SEP95

TS1644 -UN-22AUG95

USE SAFETY LIGHTS AND DEVICES

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use hand signals or turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.



DX,FLASH -19-12SEP95


TS951 -UN-12APR90

USE A SAFETY CHAIN

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.

Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength rating equal to or greater than the gross weight of the towed machine. Do not use safety chain for towing.



DX,CHAIN -19-03MAR93


TS217 -UN-23AUG88



TRANSPORT TRACTOR SAFELY

Transport a disabled tractor on a flatbed carrier. Securely chain tractor to carrier.

If towing a tractor, never tow faster than 16 km/h (10 mph) with front or rear wheels raised or faster than 8 km/h (5 mph) with all wheels on the ground. Have an operator steer and brake tractor.



RX,HAUL,IT1 -19-20DEC95

RW22056 -UN-04DEC92


TOW LOADS SAFELY

Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control. Consider the total weight of the equipment and its load.

Observe these recommended maximum road speeds, or local speed limits which may be lower:

- If towed equipment does not have brakes, do not travel more than 32 km/h (20 mph) and do not tow loads more than 1.5 times the tractor weight.
- If towed equipment has brakes, do not travel more than 40 km/h (25 mph) and do not tow loads more than 4.5 times the tractor weight.

Ensure the load does not exceed the recommended weight ratio. Add ballast to recommended maximum for tractor, lighten the load, or get a heavier towing unit. The tractor must be heavy and powerful enough with adequate braking power for the towed load. Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.



DX,TOW -19-02OCT95

T5216 -UN-23AUG88

Buy Now



Our support email:

ebooklibonline@outlook.com