



4420 Combine



JOHN DEERE

OPERATORS MANUAL

4420 Combine


OMH116958 D4 English

John Deere Harvester Works
OMH116958 D4

LITHO IN U.S.A.
ENGLISH



INTRODUCTION

 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.


Your operator's manual contains SI metric equivalents which follow immediately after the U.S. customary units of measure.

"Right-hand" and "left-hand" sides are determined by facing in the direction the combine will travel when in use.

Record your combine serial numbers in the space provided in Specifications under Product Identification Number and Engine Serial Number.

The warranty on this combine appears on your copy of the purchase order which you should have received from your dealer when making your purchase. This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty.

Warranty and field improvements are a part of John Deere's product support program for customers who operate and maintain their equipment as described in this manual. Should the equipment be abused or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.





Contents

	Page
Introduction	Inside
Contents	1
Safety	2-5
Operator's Station	6-13
Engine Break-In	14-16
Prestarting Checks	15-16
Operating the Engine	17-21
Driving the Combine	22-23
Transporting	24
Lighting and Signals	25-28
Fuels and Lubricants	29-32
Lubrication and Maintenance	33-43
Fundamentals of Combine Harvesting	44-64
Headers	65-67
Feeder House	68-93
Separator	94-138
Grain Tank and Unloading Auger	139-145
Engine Service	146-159
Electrical System	160-165
Monitors	166-167
Hydraulic System	168-171
Power Train	172-184
Air Conditioner and Heater	185-188
Trouble Shooting	189-206
Storage	207-211
Crime Prevention Tips	211A-211B
Specifications	212-216
Index	217-219



Safety

SAFETY DECALS



H28488N




CAUTION, WARNING or DANGER: Decals with these headings and symbol indicate the possibility of personal injury.

IMPORTANT: Decals with this heading indicate the possibility of damage to the machine.

Decals are located in areas where they apply.

H28488

AVOID CONTACT WITH MOVING PARTS



H31200

H31200

A—Pinch Points
B—Belt Drive

Keep guards and shields in place at all times while operating the combine. Always disengage separator and shut off engine before removing guards or shields.


Keep hands, feet, and clothing away from power-driven parts.

Never clean, lubricate, or adjust the combine when it is running.

Sound horn. Everyone must be clear before starting engine or running combine.

Never attempt to clear obstructions off the header unless the separator is disengaged and the engine is shut off.

LEAVING COMBINE UNATTENDED



H37524

Before leaving the combine unattended, turn off engine and remove keys, support the header with either the hydraulic cylinder safety stop, or lower it to the ground. The gearshift lever must be in neutral and the parking brake engaged.


SERVICE TIRES

Failure to follow proper procedures when mounting a tire on a wheel or rim can produce an explosion which may result in serious injury or death. Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job. Have it done by your John Deere dealer or a qualified tire repair service.

When sealing tire beads on rims, never exceed 35 psi (2.40 kPa) (2.4 bar) or maximum inflation pressures specified by tire manufacturers for mounting tires. Inflation beyond this maximum pressure may break the bead, or even the rim, with dangerous explosive force. If both beads are not seated when the maximum recommended pressure is reached, deflate, reposition tire, re-lubricate bead, and reinflate.

Detailed tire mounting instructions, including necessary safety precautions, are contained in John Deere Fundamentals of Service (FOS) Manual 55, Tires and Tracks, available through your John Deere dealer. Such information is also available from the Rubber Manufacturers Association and from tire manufacturers.

- A—Use a safety cage if available.
- B—Do not stand over tire. Use a clip-on chuck and extension hose.



WASHING FRONT CAB WINDOW


T5-0123

To wash front window of cab, stand on ground and use a long handled squeegee or mop to reach top of window. Do not stand on feeder house or header top beam, as this could result in a fall.

SERVICING DRIVES AND DRIVE RELATED AREAS

Shut off engine and remove key before servicing combine in either a belt driven area or any area receiving power from a belt drive. Some drives, due to their clutching and declutching characteristics, can be engaged when the engine is running by the applying or removing of outside forces.

Replace any shields that were removed.



H37564

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com