

2012 Touring

SERVICE MANUAL

Part Number 99483-12

Chapter 1 Maintenance
Chapter 2 Chassis
Chapter 3 Engine
Chapter 4 Fuel System
Chapter 5 Drive
Chapter 6 Transmission
Chapter 7 Electrical

POLICE SERVICE SUPPLEMENT

Part Number 99855-12

Chapter 1 Maintenance
Chapter 2 Chassis
Chapter 3 Engine
Chapter 4 Fuel System
Chapter 5 Drive
Chapter 6 Transmission
Chapter 7 Electrical

FLHXSE3 SERVICE SUPPLEMENT

Part Number 99600-12

Chapter 1 Maintenance
Chapter 2 Chassis
Chapter 3 Engine
Chapter 4 Fuel System
Chapter 5 Drive
Chapter 6 Transmission
Chapter 7 Electrical

ELECTRICAL DIAGNOSTICS

Part Number 99497-12

Chapter 1 General Information
Chapter 2 Initial Diagnostics and Serial Data
Chapter 3 Starting and Charging
Chapter 4 Instruments
Chapter 5 Accessories, Horn, Lighting and Security
Chapter 6 Engine Management
Chapter 7 ABS
Chapter 8 Audio System

FLHTCUSE7 SERVICE SUPPLEMENT

Part Number 99500-12

Chapter 1 Maintenance
Chapter 2 Chassis
Chapter 3 Engine
Chapter 4 Fuel System
Chapter 5 Drive
Chapter 6 Transmission
Chapter 7 Electrical

TRIKE SERVICE SUPPLEMENT

Part Number 99601-12

Chapter 1 Maintenance
Chapter 2 Chassis
Chapter 3 Engine
Chapter 4 Fuel System
Chapter 5 Drive
Chapter 6 Transmission
Chapter 7 Electrical

2012 Touring (Continued)

FLTRXSE SERVICE MANUAL

Part Number 99525-12

[Chapter 1 Maintenance](#)

[Chapter 2 Chassis](#)

[Chapter 3 Engine](#)

[Chapter 4 Fuel System](#)

[Chapter 5 Drive](#)

[Chapter 6 Transmission](#)

[Chapter 7 Electrical](#)



**2012 Harley-Davidson Touring Models
Service Manual**

99483-12

©2011 H-D.

MAINTENANCE

1.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....1-1

1.2 GENERAL

Servicing a New Motorcycle.....	1-3
Safe Operating Maintenance.....	1-3
Shop Practices.....	1-3
Repair Notes.....	1-3
Safety.....	1-3
Removing Parts.....	1-3
Cleaning.....	1-3
Disassembly and Assembly.....	1-4
Checking Torques on Fasteners.....	1-4
Magnetic Parts Trays.....	1-4
Repair and Replacement Procedures.....	1-4
Hardware and Threaded Parts.....	1-4
Threadlocking Agents.....	1-4
Wiring, Hoses and Lines.....	1-4
Instruments and Gauges.....	1-4
Bearings.....	1-4
Bushings.....	1-4
Gaskets.....	1-4
Lip-Type Seals.....	1-4
O-Rings (Pre-Formed Packings).....	1-4
Gears.....	1-5
Shafts.....	1-5
Part Replacement.....	1-5
Exhaust System Leakage.....	1-5
Cleaning.....	1-5
Part Protection.....	1-5
Cleaning Process.....	1-5
Rust or Corrosion Removal.....	1-5
Bearings.....	1-5
Tool Safety.....	1-5
Air Tools.....	1-5
Wrenches.....	1-5
Pliers/Cutters/Pry Bars.....	1-5
Hammers.....	1-6
Punches/Chisels.....	1-6
Screwdrivers.....	1-6
Ratchets and Handles.....	1-6
Sockets.....	1-6
Storage Units.....	1-6

1.3 FUEL AND OIL

Fuel.....	1-7
Gasoline Blends.....	1-7
Engine Lubrication.....	1-7
Winter Lubrication.....	1-8

1.4 BULB REQUIREMENTS

General.....1-9

1.5 MAINTENANCE SCHEDULE

General.....1-11

1.6 ENGINE OIL AND FILTER

Checking Oil Level.....	1-16
Oil Level Cold Check.....	1-16
Oil Level Hot Check.....	1-16
Changing Oil and Oil Filter.....	1-17

1.7 AIR CLEANER AND EXHAUST SYSTEM

Removal.....	1-19
Installation.....	1-19
Exhaust System Leak Check.....	1-20

1.8 TIRES AND WHEELS

General.....	1-21
Tires.....	1-21
Tire Replacement.....	1-22
Inspection.....	1-22
When To Replace Tires.....	1-22
Wheel Bearings.....	1-22
Wheel Spokes.....	1-22
Identify Wheel Spoke Groups.....	1-23
Wheel Spoke Adjustment.....	1-23

1.9 PRIMARY CHAINCASE LUBRICANT

General.....	1-24
Changing Primary Chaincase Lubricant.....	1-24

1.10 TRANSMISSION LUBRICANT

Checking Transmission Lubricant Level.....	1-26
Changing Transmission Lubricant.....	1-26

1.11 CLUTCH

Adjustment.....	1-28
-----------------	------

1.12 DRIVE BELT AND SPROCKETS

General.....	1-30
Cleaning.....	1-30
Inspection.....	1-30
Sprockets.....	1-30
Drive Belt.....	1-30
Checking Drive Belt Deflection.....	1-31
Setting Belt Deflection.....	1-32
Adjustment.....	1-32
Assembly.....	1-33

1.13 COMPENSATOR SPROCKET ISOLATOR

Inspection.....	1-35
-----------------	------

1.14 CABLE AND CHASSIS LUBRICATION

General.....	1-36
Steering Head Bearings.....	1-36
Jiffy Stand.....	1-36
Miscellaneous Lubrication.....	1-36
Hinges, Latches, Etc.....	1-36

1.15 BRAKES

Fluid Inspection.....	1-37
-----------------------	------

1.16 BRAKE PADS AND DISCS

Inspection.....	1-38
Brake Pads.....	1-38
Brake Disc Thickness.....	1-38
Brake Disc Lateral Runout.....	1-38
Brake Pad Replacement.....	1-38
Rear Brake Caliper.....	1-38
Front Brake Calipers.....	1-40

1.17 SPARK PLUGS

Inspection.....	1-42
Spark Plug Cable Inspection.....	1-42

TABLE OF CONTENTS

1.18 SUSPENSION ADJUSTMENTS

General.....	1-44
--------------	------

1.19 STEERING HEAD BEARINGS

Lubrication.....	1-46
Checking.....	1-46
Adjustment.....	1-47

1.20 HEADLAMP ALIGNMENT

Headlamp Alignment.....	1-49
Headlamp Adjustment: Single Headlamp Models.....	1-49
Headlamp Adjustment: Dual Headlamp Models.....	1-50
Auxiliary Lamp Alignment.....	1-51

1.21 CRITICAL FASTENERS

Inspection.....	1-52
Checking Torques on Fasteners.....	1-52

1.22 BATTERY MAINTENANCE

General.....	1-54
Cleaning and Inspection.....	1-55
Battery.....	1-55
Disconnection and Removal.....	1-55
Installation and Connection.....	1-56
Voltmeter Test.....	1-56
Voltmeter Test.....	1-56
Charging Battery.....	1-56
Safety Precautions.....	1-56
Using a Battery Charger.....	1-57
Storage.....	1-58

1.23 ENGINE MOUNTS

Inspection.....	1-59
General.....	1-59
Stabilizer Link.....	1-59
Front Engine Mount.....	1-59
Rear Frame Fasteners.....	1-59

1.24 STORAGE

General.....	1-60
Placing in Storage.....	1-60
Removal from Storage.....	1-60

1.25 TROUBLESHOOTING

General.....	1-62
Engine.....	1-62
Starter Motor Does Not Operate or Does Not Turn Engine Over.....	1-62
Engine Turns Over But Does Not Start.....	1-62
Starts Hard.....	1-62
Starts But Runs Irregularly or Misses.....	1-62
A Spark Plug Fouls Repeatedly.....	1-63
Pre-Ignition or Detonation (Knocks or Pings).....	1-63
Overheating.....	1-63
Valve Train Noise.....	1-63
Excessive Vibration.....	1-63
Check Engine Light Illuminates During Operation.....	1-63
Lubrication System.....	1-63
Oil Does Not Return To Oil Reservoir.....	1-63
Engine Uses Too Much Oil Or Smokes Excessively.....	1-63

Engine Leaks Oil From Cases, Push Rods, Hoses, Etc.....	1-63
Low Oil Pressure.....	1-64
High Oil Pressure.....	1-64
Electrical System.....	1-64
Alternator Does Not Charge.....	1-64
Alternator Charge Rate Is Below Normal.....	1-64
Speedometer Operates Erratically.....	1-64
Transmission.....	1-64
Shifts Hard.....	1-64
Jumps Out Of Gear.....	1-64
Clutch Slips.....	1-64
Clutch Drags Or Does Not Release.....	1-64
Clutch Chatters.....	1-64
Handling.....	1-64
Irregularities.....	1-64
Brakes.....	1-65
Brake Does Not Hold Normally.....	1-65

CHASSIS

2.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	2-1
---	-----

2.2 SPECIFICATIONS

Specifications.....	2-7
Chassis Specifications.....	2-7
Tire Specifications.....	2-8

2.3 VEHICLE IDENTIFICATION NUMBER (V.I.N.)

Vehicle Identification Number: Touring Models.....	2-10
--	------

2.4 FRONT WHEEL

Removal.....	2-12
Cleaning and Inspection.....	2-13
Installation.....	2-14

2.5 REAR WHEEL

Removal.....	2-15
Cleaning and Inspection.....	2-16
Installation.....	2-17

2.6 REAR WHEEL COMPENSATOR

Isolator Replacement.....	2-19
Removal.....	2-19
Installation.....	2-19
Sprocket Bearing Replacement.....	2-19
Removal.....	2-19
Installation.....	2-19

2.7 WHEEL LACING: FRONT RIM

Wheel Lacing: Angle Flange Hub.....	2-21
-------------------------------------	------

2.8 WHEEL LACING: 16 INCH REAR RIM

Wheel Lacing: 16 In. Rear Wheel.....	2-23
--------------------------------------	------

2.9 CHECKING AND TRUING WHEELS

General.....	2-26
Checking Wheel Runout.....	2-26

TABLE OF CONTENTS

Checking Lateral Runout.....	2-26	2.16 BLEEDING BRAKES	
Checking Radial Runout.....	2-26	General.....	2-51
Laced Wheel Rim Offset.....	2-26	Procedure.....	2-51
Truing Laced Wheels.....	2-28	2.17 FRONT FORK	
Radial Runout.....	2-28	Changing Fork Oil.....	2-53
Lateral Runout.....	2-29	Draining.....	2-53
2.10 SEALED WHEEL BEARINGS		Filling.....	2-53
Inspection.....	2-30	Removal.....	2-54
Removal.....	2-30	Disassembly.....	2-54
Installation.....	2-31	Cleaning and Inspection.....	2-56
2.11 TIRES		Assembly.....	2-57
General.....	2-33	Installation.....	2-58
Removal.....	2-33	2.18 STEERING HEAD BEARINGS	
Cleaning, Inspection and Repair.....	2-33	Removal.....	2-59
Installation.....	2-34	Inspection.....	2-60
Tube Type Tires.....	2-34	Installation.....	2-61
Tubeless Tires: Cast Wheels.....	2-34	2.19 REAR AIR SUSPENSION	
Tubeless Tires: Laced Wheels.....	2-35	Check for Air Leaks.....	2-62
Checking Tire Runout.....	2-36	Compression Fitting.....	2-62
Lateral Runout.....	2-36	Air Valve Assembly.....	2-62
Radial Runout.....	2-36	Air Tubes.....	2-62
Wheel Balancing.....	2-36	2.20 REAR SHOCK ABSORBERS	
Static vs Dynamic.....	2-36	Removal.....	2-64
Weights.....	2-36	Cleaning and Inspection.....	2-64
2.12 FRONT BRAKE MASTER CYLINDER		Disassembly and Assembly.....	2-64
General.....	2-38	Installation.....	2-64
Removal and Disassembly.....	2-38	2.21 REAR FORK	
Removal.....	2-38	Removal.....	2-65
Disassembly.....	2-38	Disassembly and Assembly.....	2-65
Cleaning and Inspection.....	2-40	Bearing Removal.....	2-65
Assembly and Installation.....	2-40	Bearing Installation.....	2-66
Assembly.....	2-40	Pivot Shaft/Mount Disassembly.....	2-66
Installation.....	2-40	Installation.....	2-67
Front Brake Line: Non-ABS Equipped.....	2-40	2.22 CLUTCH CABLE	
Removal.....	2-40	Removal.....	2-68
Installation.....	2-41	Installation.....	2-68
2.13 FRONT BRAKE CALIPER		2.23 HANDLEBARS	
Removal.....	2-43	Adjustment.....	2-71
Installation.....	2-43	Removal.....	2-71
2.14 REAR BRAKE MASTER CYLINDER		Installation.....	2-72
General.....	2-44	Left Handgrip.....	2-73
Removal and Disassembly.....	2-44	Removal.....	2-73
Removal.....	2-44	Installation.....	2-73
Disassembly.....	2-45	Heated Handgrips.....	2-73
Cleaning and Inspection.....	2-46	Remove Left Handgrip.....	2-73
Assembly and Installation.....	2-47	Install Left Handgrip.....	2-74
Assembly.....	2-47	Remove Right Handgrip.....	2-74
Installation.....	2-47	Install Right Handgrip.....	2-74
Rear Brake Line: Non-ABS Equipped.....	2-47	Rubber Mounts.....	2-74
Removal.....	2-47	Removal.....	2-74
Installation.....	2-49	Installation.....	2-75
2.15 REAR BRAKE CALIPER			
Removal.....	2-50		
Installation.....	2-50		

TABLE OF CONTENTS

2.24 MIRRORS

All Models Except FLHX.....	2-76
Removal.....	2-76
Installation.....	2-76
FLHX.....	2-76
Removal.....	2-76
Installation.....	2-76

2.25 SEAT

Seat: Models without Tour-Pak.....	2-78
Removal.....	2-78
Installation.....	2-78
Seat: Models with Tour-Pak.....	2-79
Removal.....	2-79
Installation.....	2-79
Seat: Road King Models.....	2-79
Removal.....	2-79
Installation.....	2-79
Seat Retention Nut Replacement.....	2-80
Seat Bumper.....	2-80

2.26 SADDLEBAGS

Removal.....	2-81
Installation.....	2-81

2.27 SADDLEBAG SERVICE

Saddlebag Hardware.....	2-82
Removal.....	2-82
Installation.....	2-83
Saddlebag Guard/Support Rail.....	2-83
Removal.....	2-83
Installation.....	2-83

2.28 TOUR-PAK

Removal/Installation.....	2-85
Removal.....	2-85
Installation.....	2-85
Adjustment.....	2-86
Luggage Rack/Tour-Pak Support.....	2-86
Removal.....	2-86
Assembly and Installation.....	2-87

2.29 TOUR-PAK SERVICE

Lockset.....	2-88
Removal.....	2-88
Installation.....	2-88
Hinges.....	2-88
Removal.....	2-88
Installation.....	2-89
Latches/Lockset Catch.....	2-89
Removal.....	2-89
Installation.....	2-89
Catches.....	2-89
Removal.....	2-89
Installation.....	2-89
Tether.....	2-90
Removal.....	2-90
Installation.....	2-90
Tether Brackets.....	2-90
Removing Tether Bracket from Tour-Pak.....	2-90
Removing Tether Bracket from Tour-Pak Lid.....	2-90

Installing Tether Bracket on Tour-Pak Lid.....	2-90
Installing Tether Bracket on Tour-Pak.....	2-90
Luggage Rack.....	2-90

2.30 TOUR-PAK LIGHTS

General.....	2-92
Side Marker Lights (if equipped).....	2-92
Removal.....	2-92
Installation.....	2-92
Tour-Pak Lights Harness.....	2-92
Removal.....	2-92
Installation.....	2-92
Wrap-Around Lights (if equipped).....	2-93
Bulb Replacement.....	2-93
Removal.....	2-93
Installation.....	2-94

2.31 TOUR-PAK BACKREST

Passenger Backrest.....	2-95
Removal.....	2-95
Installation.....	2-95
Rubber Isolators.....	2-95
Removal.....	2-95
Installation.....	2-95
Passenger Backrest Flap.....	2-96
Removal.....	2-96
Installation.....	2-96

2.32 TOUR-PAK SPEAKER BOX

Speaker Box.....	2-97
Removal.....	2-97
Installation.....	2-97

2.33 LOWER FAIRING AND ENGINE GUARD

Lower Fairing.....	2-98
Removal.....	2-98
Disassembly.....	2-99
Assembly.....	2-99
Installation.....	2-100
Serrated Washer Replacement.....	2-100
Removal.....	2-100
Installation.....	2-100
Engine Guard.....	2-100
Removal.....	2-100
Installation.....	2-100

2.34 UPPER FAIRING AND WINDSHIELD: FORK MOUNTED FAIRING MODELS

Outer Fairing and Windshield.....	2-102
Removal.....	2-102
Installation.....	2-102

2.35 FAIRING CAP: FORK MOUNTED FAIRING MODELS

Fairing Cap.....	2-103
Removal.....	2-103
Installation.....	2-103

2.36 INNER FAIRING: FORK MOUNTED FAIRING MODELS

Removal.....2-104
Installation.....2-106

2.37 AIR DEFLECTORS

Air Deflectors.....2-108
Removal: Fork Mounted Fairing Models.....2-108
Removal: Frame Mounted Fairing Models.....2-108
Installation: Fork Mounted Fairing Models.....2-108
Installation: Frame Mounted Fairing Models.....2-108
Mid-Frame Air Deflectors.....2-108
Removal.....2-108
Installation.....2-108

2.38 UPPER FAIRING AND WINDSHIELD: FRAME MOUNTED FAIRING MODELS

Windshield.....2-110
Removal.....2-110
Installation.....2-110
Outer Fairing.....2-110
Removal.....2-110
Installation.....2-111

2.39 INSTRUMENT BEZEL: FRAME MOUNTED FAIRING MODELS

Bezel.....2-113
Removal.....2-113
Installation.....2-114

2.40 INSTRUMENT NACELLE: FRAME MOUNTED FAIRING MODELS

Instrument Nacelle.....2-115
Removal.....2-115
Installation.....2-116

2.41 INNER FAIRING: FRAME MOUNTED FAIRING MODELS

Removal.....2-117
Disassembly.....2-118
Installation.....2-119
Outer Fairing.....2-119
Inner Fairing.....2-119

2.42 GLOVE BOX DOOR AND HINGE: FRAME MOUNTED FAIRING MODELS

Glove Box Door and Hinge.....2-121
Removal.....2-121
Installation.....2-121

2.43 WINDSHIELD: ROAD KING MODELS

Windshield.....2-122
Removal.....2-122
Installation.....2-122
Windshield Window.....2-122
Removal.....2-122
Installation.....2-123

2.44 HEADLAMP NACELLE: ROAD KING MODELS

Removal.....2-125
Installation.....2-126

2.45 FRONT FENDER

Removal.....2-127
Installation.....2-127

2.46 REAR FENDER

Removal.....2-128
Fender Repair.....2-129
Mounting Hardware.....2-129
Lights and Harnesses.....2-129
Installation.....2-130

2.47 REAR FASCIA

Removal.....2-131
Installation.....2-131
Stud Plate.....2-131
Removal.....2-131
Installation.....2-131
Rear Fascia Lamp.....2-131
Removal.....2-131
Installation.....2-132

2.48 REAR FRAME

Rear Frame.....2-133
Removal.....2-133
Installation.....2-134
Thread Repair.....2-134

2.49 FOOTBOARDS AND FOOTRESTS

Rider Footboards.....2-135
Removal.....2-135
Installation.....2-135
Disassembly.....2-135
Assembly.....2-136
Passenger Footboard.....2-136
Removal.....2-136
Disassembly.....2-136
Assembly.....2-136
Installation.....2-136
Passenger Footrest: FLHX, FLTRX.....2-137
Removal.....2-137
Disassembly.....2-137
Assembly.....2-137
Installation.....2-137

2.50 JIFFY STAND

General.....2-138
Leg Removal.....2-138
Leg Installation.....2-138
Jiffy Stand Bracket.....2-139
Removal.....2-139
Installation.....2-139
Jiffy Stand Interlock Sensor.....2-139
Removal.....2-139
Installation.....2-140

TABLE OF CONTENTS

2.51 FRONT ENGINE MOUNT

Removal.....	2-141
Installation.....	2-141

ENGINE

3.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	3-1
---	-----

3.2 SPECIFICATIONS

Specifications.....	3-3
---------------------	-----

3.3 SERVICE WEAR LIMITS

General.....	3-5
--------------	-----

3.4 ENGINE OIL FLOW

Oil Feed.....	3-7
Top End.....	3-7
Bottom End.....	3-9
Oil Return.....	3-11
Oil Cooler Operation.....	3-12

3.5 OIL PUMP OPERATION

General.....	3-13
Operation.....	3-13

3.6 BREATHER OPERATION

General.....	3-15
--------------	------

3.7 OIL PRESSURE

Oil Pressure Indicator Lamp.....	3-16
Checking Oil Pressure.....	3-16

3.8 TROUBLESHOOTING

Diagnosing Valve Train Noise.....	3-18
Compression Test.....	3-18
Cylinder Leakdown Test.....	3-19
Diagnosing Smoking Engine or High Oil Consumption.....	3-19
Check Prior To Cylinder Head Removal.....	3-19
Check After Cylinder Head Removal.....	3-19

3.9 OIL COOLER

Removal.....	3-20
Installation.....	3-20

3.10 OIL COOLER ADAPTER

Removal.....	3-21
Disassembly.....	3-21
Assembly.....	3-21
Installation.....	3-21

3.11 HOW TO USE THIS SECTION

Top End Repair.....	3-23
Bottom End Repair.....	3-23
Typical Symptoms.....	3-23

3.12 TOP END SERVICE

Engine in Chassis.....	3-24
Engine Removed from Chassis.....	3-25

3.13 CAM COMPARTMENT SERVICE

Engine in Chassis.....	3-26
Engine Removed From Chassis.....	3-27

3.14 STRIPPING MOTORCYCLE FOR SERVICE

Procedure.....	3-28
Cam Compartment Service Only.....	3-28
Top End Service.....	3-28

3.15 ASSEMBLING MOTORCYCLE AFTER SERVICE

Procedure.....	3-29
After Top End Service.....	3-29
After Cam Compartment Service.....	3-29

3.16 REMOVING ENGINE FROM CHASSIS

Procedure.....	3-30
----------------	------

3.17 INSTALLING ENGINE IN CHASSIS

Procedure.....	3-31
----------------	------

3.18 TOP END OVERHAUL: DISASSEMBLY

General.....	3-32
Rocker Covers.....	3-32
Rocker Arm Support Plate.....	3-32
Push Rods, Lifters and Covers.....	3-34
Cylinder Head.....	3-35
Cylinder.....	3-36
Piston.....	3-36

3.19 BREATHER ASSEMBLY

Disassembly.....	3-38
Cleaning and Inspection.....	3-38
Assembly.....	3-38

3.20 ROCKER ARM SUPPORT PLATE

Disassembly.....	3-39
Cleaning and Inspection.....	3-39
Inspection.....	3-39
Rocker Shaft Fit.....	3-39
Rocker Arm Shaft to Bushing.....	3-40
Replace Rocker Arm Bushings.....	3-40
Assembly.....	3-41

3.21 PUSH RODS, LIFTERS AND COVERS

Disassembly.....	3-42
Cleaning and Inspection.....	3-42
Lifter Inspection.....	3-43
Assembly.....	3-43

3.22 CYLINDER HEAD

Disassembly.....	3-44
Cleaning.....	3-45
Inspection.....	3-45
Cylinder Head.....	3-45
Valve Guides.....	3-46
Valves.....	3-46
Valve Springs.....	3-46

TABLE OF CONTENTS

Tapered Keepers.....	3-46	Cleaning and Inspection.....	3-89
Valve Seats.....	3-46	Right Crankcase Half.....	3-90
Valve Guide Replacement.....	3-46	Main Bearing Removal.....	3-90
Removal.....	3-46	Main Bearing Installation.....	3-90
Installation.....	3-47	Piston Jets Removal.....	3-91
Valve and Seat Refacing.....	3-50	Piston Jets Installation.....	3-91
Assembly.....	3-52	Left Crankcase Half.....	3-91
3.23 CYLINDER		Main Bearing Removal.....	3-91
Cleaning.....	3-55	Main Bearing Installation.....	3-93
Inspection.....	3-55	Sprocket Shaft Bearing Inner Race.....	3-93
Deglazing Cylinder.....	3-57	Removal.....	3-93
Boring and Honing Cylinder.....	3-57	Installation.....	3-94
3.24 PISTON		Cylinder Studs.....	3-96
Disassembly.....	3-59	Removal.....	3-96
Piston Rings.....	3-59	Installation.....	3-96
Cleaning.....	3-59	Pipe Plug and Oil Fittings.....	3-97
Inspection.....	3-59	Removal.....	3-97
Assembly.....	3-61	Installation.....	3-97
Checking Piston Ring Gap.....	3-61	3.29 FLYWHEEL AND CONNECTING RODS	
Installing Piston Rings.....	3-61	General.....	3-98
3.25 TOP END OVERHAUL: ASSEMBLY		Symptoms.....	3-98
General.....	3-63	No Oil Pressure.....	3-98
Piston.....	3-63	Vibration.....	3-98
Cylinder.....	3-64	Inspection.....	3-98
Cylinder Head.....	3-66	Measuring Crankshaft Run-Out.....	3-99
Push Rods, Lifters and Covers.....	3-70	Crankshaft Installed.....	3-99
Rocker Arm Support Plate.....	3-71	Crankshaft Removed.....	3-99
Breather and Rocker Cover.....	3-72	3.30 CRANKCASE ASSEMBLY	
3.26 CAM COMPARTMENT AND COMPONENTS		Crankcase Assembly.....	3-101
Cam Support Plate and Cover Removal.....	3-74	3.31 OIL PAN	
Prepare Engine.....	3-74	Removal.....	3-103
Cam Chain and Sprockets Removal.....	3-74	Installation.....	3-103
Cam Support Plate Removal.....	3-75	FUEL SYSTEM	
Cam Support Plate Cleaning and Inspection.....	3-76	4.1 FASTENER TORQUE VALUES	
Oil Pressure Valve.....	3-76	Fastener Torque Values in this Chapter.....	4-1
Cam Support Plate.....	3-76	4.2 SPECIFICATIONS: FUEL SYSTEM	
Camshafts.....	3-76	Specifications.....	4-3
Removal.....	3-76	4.3 AIR CLEANER ASSEMBLY	
Installation.....	3-77	Removal.....	4-4
Oil Pressure Relief Valve.....	3-78	Installation.....	4-5
Removal.....	3-78	4.4 FUEL TANK	
Inspection.....	3-78	Removal.....	4-7
Installation.....	3-78	Purge and Disconnect Fuel Line.....	4-7
Cam Needle Bearings.....	3-79	Remove Tank.....	4-7
Removal.....	3-79	Installation.....	4-7
Installation.....	3-80	Vent Tube: Models Without EVAP System.....	4-8
Cam Support Plate and Cover Installation.....	3-82	Removal.....	4-8
3.27 OIL PUMP		Installation.....	4-8
Removal.....	3-87	Fuel Supply Check Valve/Tube.....	4-9
Cleaning and Inspection.....	3-87	Removal.....	4-9
Installation.....	3-88	Installation.....	4-9
3.28 CRANKCASE DISASSEMBLY AND REPAIR			
Crankcase Disassembly.....	3-89		

TABLE OF CONTENTS

4.5 FUEL TANK TOP PLATE

Removal.....	4-10
Installation.....	4-11

4.6 FUEL FILTER

Removal.....	4-12
Installation.....	4-12

4.7 FUEL PRESSURE REGULATOR

Removal.....	4-13
Installation.....	4-13

4.8 FUEL LEVEL SENDER

Removal.....	4-14
Installation.....	4-14

4.9 TWIST GRIP SENSOR

Removal.....	4-15
Installation.....	4-16
Twist Grip Sensor Jumper Harness.....	4-17
Removal.....	4-17
Installation.....	4-17

4.10 THROTTLE CONTROL ACTUATOR (TCA)

General.....	4-18
--------------	------

4.11 ENGINE TEMPERATURE SENSOR (ET)

Removal.....	4-19
Installation.....	4-19

4.12 INDUCTION MODULE

Removal.....	4-20
Installation.....	4-21

4.13 TEMPERATURE MANIFOLD ABSOLUTE PRESSURE SENSOR (TMAP)

General.....	4-22
Removal.....	4-22
Installation.....	4-22

4.14 OXYGEN SENSORS (O2)

General.....	4-23
Removal.....	4-23
Installation.....	4-24

4.15 FUEL INJECTORS

General.....	4-25
Removal.....	4-25
Installation.....	4-25

4.16 FUEL PUMP

General.....	4-27
Removal.....	4-27
Installation.....	4-27
Fuel Pump and Fuel Level Sender Wire Harness.....	4-28
Removal.....	4-28
Installation.....	4-28

4.17 FUEL PRESSURE TEST

General.....	4-29
Testing.....	4-29

4.18 EXHAUST SYSTEM

Mufflers.....	4-31
Removal.....	4-31
Installation.....	4-31
System Removal.....	4-31
System Installation.....	4-33

4.19 ACTIVE EXHAUST (HDI)

Exhaust Valve Actuator.....	4-35
Removal.....	4-35
Installation.....	4-35
Exhaust Valve Actuator Cable.....	4-35
Removal.....	4-35
Installation.....	4-35
Active Exhaust Valve.....	4-35
General.....	4-35

4.20 INTAKE LEAK TEST

General.....	4-36
Leak Tester.....	4-36
Parts List.....	4-36
Tester Assembly.....	4-36
Tester Adjustment.....	4-36
Procedure.....	4-36

4.21 EVAPORATIVE EMISSIONS CONTROL SYSTEM

General.....	4-38
Vapor Valve.....	4-38
Fuel Vapor Vent Tube.....	4-39
Removal.....	4-39
Installation.....	4-39
Canister-to-Solenoid Tube.....	4-39
Removal.....	4-39
Installation.....	4-39
Solenoid-to-Induction Module Tube.....	4-39
Removal.....	4-39
Installation.....	4-39
Purge Solenoid.....	4-40
Removal.....	4-40
Installation.....	4-40
Charcoal Canister.....	4-40
Removal.....	4-40
Installation.....	4-40

DRIVE

5.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	5-1
---	-----

5.2 SPECIFICATIONS: DRIVE

Specifications.....	5-2
---------------------	-----

5.3 PRIMARY CHAINCASE COVER

General.....	5-3
Removal.....	5-3

TABLE OF CONTENTS

Installation.....	5-3
5.4 DRIVE COMPONENTS	
Removal.....	5-5
Installation.....	5-7
5.5 PRIMARY CHAINCASE HOUSING	
Removal.....	5-10
Inspection.....	5-10
Mainshaft Bearing and Lip Seal.....	5-10
Removal.....	5-10
Installation.....	5-10
Mainshaft Bearing Inner Race.....	5-11
Removal.....	5-11
Installation.....	5-11
Shifter Shaft Bushings.....	5-12
Installation.....	5-12
5.6 CLUTCH	
Removal and Installation.....	5-14
Clutch Pack Only.....	5-14
Partial Disassembly.....	5-14
Cleaning And Inspection.....	5-14
Assembly.....	5-15
Clutch Pack and Bearing.....	5-16
Complete Disassembly.....	5-16
Assembly.....	5-17
5.7 TRANSMISSION SPROCKET	
Removal.....	5-19
Cleaning and Inspection.....	5-19
Installation.....	5-19
5.8 DRIVE BELT	
Removal and Adjustment.....	5-21
Adjustment.....	5-21
Removal.....	5-21
Installation.....	5-21
TRANSMISSION	

6.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	6-1
---	-----

6.2 SPECIFICATIONS: TRANSMISSION

Specifications.....	6-2
Service Wear Limits.....	6-2

6.3 TRANSMISSION

Power Flow.....	6-3
Neutral.....	6-3
1st Gear.....	6-3
2nd Gear.....	6-3
3rd Gear.....	6-3
4th Gear.....	6-3
5th Gear.....	6-3
6th Gear.....	6-3

6.4 SHIFTER LINKAGE

Shifter Rod.....	6-5
------------------	-----

6.5 CLUTCH RELEASE COVER

Removal and Disassembly.....	6-6
Cleaning and Inspection.....	6-6
Assembly and Installation.....	6-7

6.6 TRANSMISSION ASSEMBLY

Removal.....	6-8
Disassembly.....	6-9
Shifter Cam/Shifter Forks.....	6-9
Mainshaft.....	6-11
Countershaft.....	6-13
Removing Side Door Bearings.....	6-14
Cleaning and Inspection.....	6-15
Assembly.....	6-15
Installing Side Door Bearings.....	6-15
Countershaft.....	6-15
Mainshaft.....	6-16
Shifter Cam/Shifter Forks.....	6-16
Installation.....	6-18

6.7 MAIN DRIVE GEAR AND BEARING

Removal.....	6-20
Cleaning and Inspection.....	6-21
Needle Bearing Replacement.....	6-22
Mainshaft Seal Replacement.....	6-23
Installation.....	6-24
Installing Main Drive Gear Bearing.....	6-24
Installing Main Drive Gear.....	6-24
Installing Main Drive Gear Large Seal.....	6-25

6.8 TRANSMISSION CASE

Removal.....	6-27
Installation.....	6-27
Disassembly.....	6-28
Shifter Arm Assembly.....	6-28
Cleaning and Inspection.....	6-28
Assembly.....	6-29
Countershaft Needle Bearing Replacement.....	6-29
Shifter Pawl Lever Assembly.....	6-29

ELECTRICAL

7.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	7-1
---	-----

7.2 SPECIFICATIONS: ELECTRICAL

Specifications.....	7-5
---------------------	-----

7.3 VOLTAGE REGULATOR

Removal.....	7-6
Installation.....	7-6

7.4 ELECTRONIC CONTROL MODULE (ECM)

ECM.....	7-7
Removal.....	7-7
Installation.....	7-7

7.5 TURN SIGNAL AND SECURITY MODULE (TSM/TSSM/HFSM)

General.....	7-8
--------------	-----

TABLE OF CONTENTS

Removal.....	7-8
Installation.....	7-8
HFSM Antenna.....	7-9
Removal.....	7-9
Installation.....	7-9

7.6 IGNITION COIL

Removal.....	7-10
Installation.....	7-10

7.7 SYSTEM FUSES AND RELAYS

Main Fuse.....	7-11
Removal.....	7-11
Installation.....	7-11
Main Fuse Holder.....	7-11
Removal.....	7-11
Installation.....	7-11
System Fuses and Relays.....	7-11
Removal.....	7-11
Installation.....	7-11
Fuse Blocks.....	7-12
Removal.....	7-12
Installation.....	7-12

7.8 ELECTRICAL CADDIES

Top Caddy.....	7-13
Removal.....	7-13
Installation.....	7-13
Left Side Caddy.....	7-13
Removal.....	7-13
Installation.....	7-14
Battery Tray.....	7-16
Removal.....	7-16
Installation.....	7-16

7.9 SECURITY SIREN

Removal.....	7-17
Installation.....	7-17

7.10 STARTER

General.....	7-18
Removal.....	7-18
Drive Assembly.....	7-18
Disassembly.....	7-18
Inspection.....	7-19
Assembly.....	7-19
Solenoid.....	7-20
Cover and Plunger Removal.....	7-20
Short Post Contact: Starter.....	7-20
Long Post Contact: Battery Positive.....	7-20
Plunger and Cover Installation.....	7-21
Installation.....	7-21

7.11 HEADLAMP: ALL EXCEPT ROAD GLIDE

Headlamp: Single Headlamp Models.....	7-22
Removal.....	7-22
Bulb Replacement.....	7-22
Installation.....	7-23

7.12 HEADLAMP: ROAD GLIDE

Headlamp Adjuster Assembly.....	7-24
---------------------------------	------

Removal.....	7-24
Repair.....	7-24
Installation.....	7-24
Headlamp Bulb Replacement: Dual Headlamp Models.....	7-24
Removal.....	7-24
Bulb Replacement.....	7-24
Installation.....	7-25

7.13 AUXILIARY LAMPS AND BRACKETS

Auxiliary Lamp Bulb Replacement.....	7-26
Removal.....	7-26
Installation.....	7-26
Auxiliary Lamp Housing.....	7-27
Removal.....	7-27
Installation.....	7-28
Auxiliary Lamp Bracket.....	7-29
Removal.....	7-29
Installation.....	7-29
Adjustment.....	7-29

7.14 TAIL LAMP

Tail Lamp Bulb Replacement.....	7-30
Removal.....	7-30
Installation.....	7-30
Circuit Board/Chrome Base.....	7-30
Removal.....	7-30
Installation.....	7-31
Rear Fender Lights Harness: all except FLHX, FLTRX.....	7-31
Removal.....	7-31
Installation.....	7-32
Rear Fender Lights Harness: FLHX, FLTRX.....	7-33
Removal.....	7-33
Installation.....	7-33

7.15 FENDER TIP LAMPS

Front Fender Tip Lamp.....	7-35
Removal.....	7-35
Installation.....	7-35
Front Fender Tip Lamp Jumper Harness.....	7-35
Removal.....	7-35
Installation.....	7-36
Rear Fender Tip Lamp.....	7-38
Removal.....	7-38
Installation.....	7-38

7.16 TURN SIGNAL LAMPS

Turn Signal Bulb Replacement: Bullet Style.....	7-39
Turn Signal Bulb Replacement: Flat Lens Style.....	7-39
Front Turn Signal Lamp.....	7-40
Removal: Flat Lens Style.....	7-40
Installation: Flat Lens Style.....	7-40
Removal: Bullet Style, Fork Mounted.....	7-41
Installation: Bullet Style, Fork Mounted.....	7-42
Removal: Bullet Style, Fairing Mounted.....	7-42
Installation: Bullet Style, Fairing Mounted.....	7-43
Rear Turn Signal Lamp.....	7-43
Removal: FLHR/C, FLHTC/U, FLHTK.....	7-43
Installation: FLHR/C, FLHTC/U, FLHTK.....	7-44
Removal: FLHX, FLTRX, FLTRU.....	7-44
Installation: FLHX, FLTRX, FLTRU.....	7-44
Rear Turn Signal Lamps Bracket.....	7-46
Removal: FLHR/C, FLHTC/U, FLHTK.....	7-46

Installation: FLHR/C, FLHTC/U, FLHTK.....	7-46	7.26 STOPLIGHT SWITCHES	
Removal: FLHX, FLTRX, FLTRU.....	7-46	Front Stoplight Switch.....	7-68
Installation: FLHX, FLTRX, FLTRU.....	7-47	Removal/Installation.....	7-68
7.17 IGNITION/LIGHT KEY SWITCH AND FORK LOCK		Rear Stoplight Switch.....	7-68
Fairing Models.....	7-49	Removal.....	7-68
Removal.....	7-49	Installation.....	7-68
Installation.....	7-51	7.27 HORN	
Road King Models.....	7-52	Inspection.....	7-69
Ignition/Light Key Switch: Removal.....	7-52	Removal.....	7-69
Ignition/Light Key Switch: Installation.....	7-52	Installation.....	7-69
Fork Lock: Removal.....	7-52	7.28 CIGARETTE LIGHTER: FAIRING MODELS	
Fork Lock: Installation.....	7-52	Troubleshooting.....	7-70
7.18 FAIRING CAP SWITCHES: FORK MOUNTED FAIRING MODELS		Removal.....	7-70
Removal.....	7-54	Installation.....	7-70
Installation.....	7-55	7.29 GAUGES AND INSTRUMENTS: FAIRING MODELS	
7.19 INSTRUMENT NACELLE SWITCHES: FRAME MOUNTED FAIRING MODELS		2 Inch Diameter Gauges: Fuel Level, Ambient Air Temperature, Voltmeter, Oil Pressure.....	7-71
Removal.....	7-56	Removal.....	7-71
Left Side Switch.....	7-56	Installation.....	7-71
Right Side Switches.....	7-57	Tachometer.....	7-71
Installation.....	7-57	Removal.....	7-71
Left Side Switch.....	7-57	Installation.....	7-71
Right Side Switches.....	7-58	Speedometer.....	7-72
7.20 CRANKSHAFT POSITION SENSOR (CKP)		Removal.....	7-72
General.....	7-60	Installation.....	7-72
Removal.....	7-60	7.30 INDICATOR LAMPS: FAIRING MODELS	
Installation.....	7-60	Indicator Lamps.....	7-73
7.21 AUTOMATIC COMPRESSION RELEASE (ACR)		Removal.....	7-73
General.....	7-61	Installation.....	7-73
Removal.....	7-61	7.31 GAUGES AND INSTRUMENTS: ROAD KING MODELS	
Installation.....	7-61	Fuel Gauge.....	7-74
7.22 ALTERNATOR		Removal.....	7-74
Removal.....	7-63	Installation.....	7-74
Cleaning and Inspection.....	7-63	Speedometer.....	7-74
Installation.....	7-64	Removal.....	7-74
7.23 VEHICLE SPEED SENSOR (VSS)		Installation.....	7-75
VSS.....	7-65	7.32 INDICATOR LAMPS: ROAD KING MODELS	
Removal.....	7-65	Indicator Lamps.....	7-76
Installation.....	7-65	Removal.....	7-76
7.24 NEUTRAL SWITCH		Installation.....	7-76
Removal.....	7-66	7.33 ADVANCED AUDIO SYSTEM	
Installation.....	7-66	Radio.....	7-77
7.25 OIL PRESSURE SWITCH AND SENDER		Removal.....	7-77
Removal.....	7-67	Installation.....	7-77
Installation.....	7-67	Front Fairing Speakers.....	7-78
		Removal.....	7-78
		Installation.....	7-78
		Front Headset Receptacle.....	7-78

TABLE OF CONTENTS

Removal.....	7-78
Installation.....	7-78
Rear Headset Receptacle.....	7-79
Rear Passenger Switches.....	7-79
Removal.....	7-79
Installation.....	7-79
Rear Speakers.....	7-81
Removal.....	7-81
Installation.....	7-81
CB Module.....	7-81
Removal.....	7-81
Installation.....	7-81

7.34 WIRE TROUGH

Removal.....	7-82
Installation.....	7-83

7.35 MAIN WIRING HARNESS

Removal: All Models (Part 1).....	7-84
Removal: Road King Models (Part 2).....	7-84
Removal: Fork Mounted Fairing Models (Part 2).....	7-85
Removal: Frame Mounted Fairing Models (Part 2).....	7-86
Removal: All Models (Part 3).....	7-86
Installation: All Models (Part 1).....	7-88
Installation: Road King Models (Part 2).....	7-90
Installation: Fork Mounted Fairing Models (Part 2).....	7-91
Installation: Frame Mounted Fairing Models (Part 2).....	7-91
Installation: All Models (Part 3).....	7-91

7.36 INTERCONNECT HARNESS

Fork Mounted Fairing Models.....	7-92
Removal.....	7-92
Installation.....	7-93
Frame Mounted Fairing Models.....	7-95
Removal.....	7-95
Installation.....	7-97

7.37 RADIO ANTENNA CABLE

Models Equipped with Tour-Pak.....	7-99
Removal.....	7-99
Installation.....	7-99
Models without Tour-Pak.....	7-100
Removal.....	7-100
Installation.....	7-100

7.38 REAR AUDIO HARNESS: ULTRA MODELS

Removal.....	7-102
Installation.....	7-102

7.39 CB ANTENNA CABLE: ULTRA MODELS

Removal.....	7-104
Installation.....	7-104

7.40 HANDLEBAR SWITCH ASSEMBLIES

Removal.....	7-106
Right Handlebar Controls.....	7-106
Left Handlebar Controls.....	7-106
Disassembly.....	7-106
Right Side Handlebar Switches.....	7-106
Left Side Handlebar Switches.....	7-107

Specific Repair Procedures: Upper Switch Housings.....	7-107
Right Side Handlebar (All Models).....	7-107
Left Side Handlebar (All Models).....	7-108
Specific Repair Procedures: Right Side Lower Switch Housings.....	7-109
Preliminary Instructions.....	7-109
Turn-Right Signal Switch (All Models).....	7-109
Front Stoplight Switch (All Models).....	7-109
Mode Select Switch (Classic and Ultra Models).....	7-109
Cruise Set/Resume Switch (Road King Classic and Ultra Models).....	7-110
Final Instructions.....	7-111
Specific Repair Procedures: Left Side Lower Switch Housings.....	7-112
Preliminary Instructions.....	7-112
Turn-Left Signal Switch (All Models).....	7-112
Clutch Interlock Switch.....	7-112
Audio Control Switch (Classic and Ultra Models).....	7-114
CB Push-To-Transmit Switch (Ultra Models).....	7-114
Cruise On/Off Switch (Road King Classic Models).....	7-114
Final Instructions.....	7-115
General Repair Procedures.....	7-115
Installation.....	7-117
Right Handlebar Controls.....	7-117
Left Handlebar Controls.....	7-118

7.41 TSSM/HFSM MAINTENANCE

General.....	7-121
Fob Battery.....	7-121
Battery Replacement Schedule.....	7-121
Battery Replacement.....	7-121
Smart Siren (If Installed).....	7-121
Battery Replacement Schedule.....	7-121
Battery Replacement.....	7-121

7.42 PERSONAL IDENTIFICATION NUMBER (PIN)

General.....	7-123
Initial Pin Entry.....	7-123
Changing the Pin.....	7-123
Modifying an Existing Pin.....	7-123

7.43 H-DSSS ACTUATION

General.....	7-125
Sidecar Configuration.....	7-125
Actuation.....	7-125
Fob Assignment.....	7-125
Power Disruption and Configuring.....	7-125

7.44 TSM/HFSM: PASSWORD LEARN

General.....	7-126
Password Learn.....	7-126

APPENDIX A CONNECTOR REPAIR

A.1 AUTOFUSE UNSEALED ELECTRICAL CONNECTORS

Autofuse Unsealed Connector Repair.....	A-1
General.....	A-1
Disassembly.....	A-1

TABLE OF CONTENTS

Assembly.....	A-1	Inspecting Crimps.....	A-11
A.2 DELPHI 100W MICRO-PACK SEALED CONNECTOR		A.9 DELPHI MICRO 64 SEALED CONNECTORS	
Delphi 100W Micro-Pack Sealed Connector Repair.....	A-2	Delphi Micro 64 Sealed Connector Repair.....	A-12
General.....	A-2	General.....	A-12
Separating Socket Housing From ECM.....	A-2	Separating Pin and Socket Housings.....	A-12
Mating Socket Housing To ECM.....	A-2	Mating Pin and Socket Housings.....	A-12
Removing Socket Terminal.....	A-2	Removing Terminal.....	A-12
Installing Socket Terminal.....	A-2	Installing Terminal.....	A-13
Crimping Terminals.....	A-2	Preparing Wire Leads for Crimping.....	A-13
		Crimping Terminals.....	A-13
		Inspecting Crimps.....	A-13
A.3 DELPHI 150 METRI-PACK SEALED CONNECTORS		A.10 DELPHI GT 150 SEALED CONNECTORS	
Delphi 150 Metri-Pack Sealed Connector Repair.....	A-4	Delphi GT 150 Sealed Connector Repair.....	A-15
General.....	A-4	General.....	A-15
Separating Pin and Socket Housings.....	A-4	Separating Pin and Socket Housings.....	A-15
Mating Pin and Socket Housings.....	A-4	Mating Pin and Socket Housings.....	A-15
Removing Socket Terminal.....	A-4	Removing Socket Terminals.....	A-15
Inserting Socket Terminal.....	A-4	Installing Socket Terminals.....	A-15
A.4 DELPHI 280 METRI-PACK UNSEALED CONNECTORS		A.11 DELPHI GT 280 SEALED 73-TERMINAL ECM CONNECTOR	
Fuse Block Repair.....	A-6	Delphi GT 280 Sealed 73-Terminal ECM Connector.....	A-17
Removing Socket Terminals.....	A-6	Separating Socket Housing From ECM.....	A-17
Installing Socket Terminals.....	A-6	Mating Socket Housing To ECM.....	A-17
Crimping Terminals.....	A-6	Socket Terminal.....	A-17
		ECM Ground Terminal.....	A-17
A.5 DELPHI 480 METRI-PACK UNSEALED CONNECTORS		A.12 DEUTSCH DT SEALED CONNECTORS	
Delphi 480 Metri-Pack Unsealed Connector Repair.....	A-7	Deutsch DT Sealed Connector Repair.....	A-19
General.....	A-7	General.....	A-19
Separating Pin and Socket Housings.....	A-7	Separating Pin and Socket Housings.....	A-19
Mating Pin and Socket Housings.....	A-7	Mating Pin and Socket Housings.....	A-19
Removing Socket Terminals.....	A-7	Removing Socket Terminals.....	A-19
Installing Socket Terminals.....	A-7	Installing Socket Terminals.....	A-19
		Removing Pin Terminals.....	A-21
		Installing Pin Terminals.....	A-21
		Crimping Terminals.....	A-22
A.6 DELPHI 630 METRI-PACK UNSEALED CONNECTORS		A.13 DEUTSCH DT SEALED TERMINAL REPAIR	
Delphi 630 Metri-Pack Unsealed Connector Repair.....	A-8	Deutsch DT Sealed Terminal Crimps.....	A-23
Separating Pin and Socket Housings.....	A-8	Preparing Wire Leads for Crimping.....	A-23
Mating Pin and Socket Housings.....	A-8	Crimping Terminal to Lead.....	A-23
Removing Socket Terminal.....	A-8	Inspecting Crimps.....	A-23
Installing Socket Terminal.....	A-8		
A.7 DELPHI 800 METRI-PACK SEALED MAIN FUSE HOUSING		A.14 DEUTSCH DTM SEALED MINI TERMINAL REPAIR	
Delphi 800 Metri-Pack Sealed Main Fuse Housing Repair.....	A-9	Deutsch DTM Sealed Mini Terminal Crimps.....	A-24
Removing Socket Terminals.....	A-9	Preparing Wire Leads for Crimping.....	A-24
Installing Socket Terminals.....	A-9	Crimping a Mini Terminal to Wire Lead.....	A-24
		Inspecting Crimps.....	A-24
A.8 DELPHI METRI-PACK TERMINAL REPAIR		A.15 DEUTSCH DTM SEALED SOLID BARREL MINI TERMINAL REPAIR	
Metri-Pack Terminal Crimps.....	A-10	Deutsch DTM Sealed Solid Barrel Terminal Crimps.....	A-25
Matching Terminal To Crimper.....	A-10		
Preparing Wire Lead.....	A-10		
Crimping Wire Core.....	A-10		
Crimping Insulation/Seal.....	A-10		

TABLE OF CONTENTS

Preparing Wire Leads For Crimping.....	A-25
Adjusting Crimper Tool.....	A-25
Crimping a Barrel Contact To Wire Lead.....	A-25
Inspecting Crimps.....	A-25

A.16 JAE MX19 SEALED CONNECTORS

JAE MX19 Sealed Connectors.....	A-27
Connector Housings.....	A-27
Removing Terminals.....	A-27
Installing Terminals.....	A-27
Crimping Terminals.....	A-27

A.17 MOLEX CMC SEALED CONNECTORS

Molex CMC Sealed Connectors.....	A-28
Separating the Connector.....	A-28
Removing Terminals.....	A-28
Installing Terminals.....	A-28
Crimping Terminals.....	A-29

A.18 MOLEX MX 150 SEALED CONNECTORS

Molex MX 150 Sealed Connector Repair.....	A-30
Separating Pin and Socket Housings.....	A-30
Mating Pin and Socket Housings.....	A-30
Removing Terminals.....	A-30
Installing Terminals.....	A-30
Crimp Terminal to Lead.....	A-31
Prepare Lead.....	A-31
Prepare Tool.....	A-31
Position Terminal in the Punch/Die.....	A-32
Insert Stripped Lead.....	A-32
Crimp Terminal to Lead.....	A-33
Inspect Crimp.....	A-33

A.19 TYCO 070 MULTILOCK UNSEALED CONNECTOR

Tyco 070 Multilock Unsealed Connector Repair.....	A-34
General.....	A-34
Separating Pin and Socket Housings.....	A-34
Mating Pin and Socket Housings.....	A-34
Removing Terminals from Housing.....	A-34
Inserting Terminals into Housing.....	A-35
Preparing Wire Leads for Crimping.....	A-35
Crimping Terminals to Leads.....	A-36
Inspecting Crimped Terminals.....	A-37

A.20 SEALED SPLICE CONNECTORS

Sealed Splice Connector Repair.....	A-38
General.....	A-38
Preparing Wire Leads.....	A-38
Splicing Wire Leads.....	A-38
Inspecting Seals.....	A-38

APPENDIX B WIRING

B.1 CONNECTORS

Connector Locations.....	B-1
Function/Location.....	B-1
Place and Color.....	B-1
Connector Number.....	B-1

Repair Instructions.....	B-1
--------------------------	-----

B.2 WIRING DIAGRAMS

Wiring Diagram Information.....	B-7
Wire Color Codes.....	B-7
Wiring Diagram Symbols.....	B-7
2012 Touring Wiring Diagrams.....	B-9

APPENDIX C ABS

C.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	C-1
---	-----

C.2 ABS MODULE

Hydraulic Control Unit (HCU).....	C-2
Removal.....	C-2
Installation.....	C-3
Electronic Control Unit (ECU).....	C-3
Removal.....	C-3
Installation.....	C-3

C.3 WHEEL SPEED SENSORS

Front Wheel Speed Sensor.....	C-5
Removal.....	C-5
Installation.....	C-5
Rear Wheel Speed Sensor.....	C-6
Removal.....	C-6
Installation.....	C-6

C.4 ABS BRAKE LINES

Front Master Cylinder to ABS Module.....	C-7
Removal.....	C-7
Installation.....	C-8
ABS Module to Front Brake Calipers.....	C-8
Removal.....	C-8
Installation.....	C-9
Rear Master Cylinder to ABS Module.....	C-10
Removal.....	C-10
Installation.....	C-11
ABS Module to Rear Brake Caliper.....	C-12
Removal.....	C-12
Installation.....	C-12

APPENDIX D CONVERSIONS

D.1 METRIC CONVERSION

Conversion Table.....	D-1
-----------------------	-----

D.2 FLUID CONVERSIONS

United States System.....	D-2
Metric System.....	D-2
British Imperial System.....	D-2

D.3 TORQUE CONVERSIONS

United States System.....	D-3
Metric System.....	D-3

APPENDIX E GLOSSARY

E.1 GLOSSARY

Acronyms and Abbreviations.....E-1

REFERENCE MATERIAL

TOOLS.....I

TORQUE VALUES.....IX

INDEX.....XXV

NOTES

TABLE OF CONTENTS

SUBJECT	PAGE NO.
1.1 FASTENER TORQUE VALUES.....	1-1
1.2 GENERAL.....	1-3
1.3 FUEL AND OIL.....	1-7
1.4 BULB REQUIREMENTS.....	1-9
1.5 MAINTENANCE SCHEDULE.....	1-11
1.6 ENGINE OIL AND FILTER.....	1-16
1.7 AIR CLEANER AND EXHAUST SYSTEM.....	1-19
1.8 TIRES AND WHEELS.....	1-21
1.9 PRIMARY CHAINCASE LUBRICANT.....	1-24
1.10 TRANSMISSION LUBRICANT.....	1-26
1.11 CLUTCH.....	1-28
1.12 DRIVE BELT AND SPROCKETS.....	1-30
1.13 COMPENSATOR SPROCKET ISOLATOR.....	1-35
1.14 CABLE AND CHASSIS LUBRICATION.....	1-36
1.15 BRAKES.....	1-37
1.16 BRAKE PADS AND DISCS.....	1-38
1.17 SPARK PLUGS.....	1-42
1.18 SUSPENSION ADJUSTMENTS.....	1-44
1.19 STEERING HEAD BEARINGS.....	1-46
1.20 HEADLAMP ALIGNMENT.....	1-49
1.21 CRITICAL FASTENERS.....	1-52
1.22 BATTERY MAINTENANCE.....	1-54
1.23 ENGINE MOUNTS.....	1-59
1.24 STORAGE.....	1-60
1.25 TROUBLESHOOTING.....	1-62

NOTES

FASTENER TORQUE VALUES

1.1

FASTENER TORQUE VALUES IN THIS CHAPTER

The table below lists torque values for all fasteners presented in this chapter.

FASTENER	TORQUE VALUE		NOTES
Air cleaner cover bracket screws	108-132 in-lbs	12.2-14.9 Nm	1.5 MAINTENANCE SCHEDULE, General
Air cleaner cover bracket screws	108-132 in-lbs	12.2-14.9 Nm	1.7 AIR CLEANER AND EXHAUST SYSTEM, Installation
Air cleaner cover screw	36-60 in-lbs	4.1-6.8 Nm	1.5 MAINTENANCE SCHEDULE, General
Air cleaner cover screw	36-60 in-lbs	4.1-6.8 Nm	1.7 AIR CLEANER AND EXHAUST SYSTEM, Installation/Use Loctite Medium Strength Threadlocker 243 (Blue)
Auxiliary lamp flange nut	15-18 ft-lbs	20.3-24.4 Nm	1.20 HEADLAMP ALIGNMENT, Auxiliary Lamp Alignment
Battery terminal bolt	60-70 in-lbs	6.8-7.9 Nm	1.5 MAINTENANCE SCHEDULE, General
Battery terminal bolt	60-70 in-lbs	6.8-7.9 Nm	1.22 BATTERY MAINTENANCE, Battery
Battery terminal bolt	60-70 in-lbs	6.8-7.9 Nm	1.22 BATTERY MAINTENANCE, Battery
Brake caliper (front) mounting screws	28-38 ft-lbs	37.9-51.5 Nm	1.16 BRAKE PADS AND DISCS, Brake Pad Replacement/metric
Brake caliper (rear) mounting screws	43-48 ft-lbs	58.3-65.1 Nm	1.16 BRAKE PADS AND DISCS, Brake Pad Replacement/metric
Brake caliper pad pin	75-102 in-lbs	8.5-11.5 Nm	1.5 MAINTENANCE SCHEDULE, General
Brake caliper pad pin	75-102 in-lbs	8.5-11.5 Nm	1.16 BRAKE PADS AND DISCS, Brake Pad Replacement/Always use new pin
Brake caliper pad pin	75-102 in-lbs	8.5-11.5 Nm	1.16 BRAKE PADS AND DISCS, Brake Pad Replacement/Always use new pin
Clutch adjuster screw jam nut	72-120 in-lbs	8.1-13.6 Nm	1.5 MAINTENANCE SCHEDULE, General
Clutch adjuster screw jam nut	72-120 in-lbs	8.1-13.6 Nm	1.11 CLUTCH, Adjustment
Clutch cable adjustment jam nut	120 in-lbs	13.6 Nm	1.11 CLUTCH, Adjustment
Clutch inspection cover screw	84-108 in-lbs	9.5-12.2 Nm	1.9 PRIMARY CHAINCASE LUBRICANT, Changing Primary Chaincase Lubricant
Clutch inspection cover screws	84-108 in-lbs	9.5-12.2 Nm	1.5 MAINTENANCE SCHEDULE, General
Clutch inspection cover screws	84-108 in-lbs	9.5-12.2 Nm	1.11 CLUTCH, Adjustment
Engine oil drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.5 MAINTENANCE SCHEDULE, General
Engine oil drain plug	14-21 ft-lb	19.0-28.5 Nm	1.6 ENGINE OIL AND FILTER, Changing Oil and Oil Filter
Engine to front engine mounting bracket	36-40 ft-lbs	49-54 Nm	1.23 ENGINE MOUNTS, Inspection
Fork bracket pinch bolt	53-57 ft-lbs	71.9-77.3 Nm	1.19 STEERING HEAD BEARINGS, Adjustment
Fork stem nut	70-80 ft-lbs	94.9-108.4 Nm	1.19 STEERING HEAD BEARINGS, Adjustment
Fork stem nut	70-80 ft-lbs	94.9-108.4 Nm	1.19 STEERING HEAD BEARINGS, Adjustment
Front engine mount end cap fastener	42-48 ft-lbs	56.9-65.0 Nm	1.23 ENGINE MOUNTS, Inspection
Front master cylinder reservoir cover screws	10-12 in-lbs	1.1-1.4 Nm	1.5 MAINTENANCE SCHEDULE, General
Front master cylinder reservoir cover screws	10-12 in-lbs	1.1-1.4 Nm	1.16 BRAKE PADS AND DISCS, Brake Pad Replacement
Handlebar switch housing screw	35-45 in-lbs	4.0-5.1 Nm	1.5 MAINTENANCE SCHEDULE, General
Primary chaincase drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.5 MAINTENANCE SCHEDULE, General

FASTENER	TORQUE VALUE		NOTES
Primary chaincase drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.9 PRIMARY CHAINCASE LUBRICANT, Changing Primary Chaincase Lubricant
Rear axle cone nut (final)	95-105 ft-lbs	128.8-142.4 Nm	1.12 DRIVE BELT AND SPROCKETS, Setting Belt Deflection
Rear axle cone nut (preliminary)	15-20 ft-lbs	20-27 Nm	1.12 DRIVE BELT AND SPROCKETS, Setting Belt Deflection/For belt adjustment only
Rear frame-to-main frame fastener	40-50 ft-lbs	54.2-67.8 Nm	1.23 ENGINE MOUNTS, Inspection
Rear master cylinder reservoir cover screws	12-15 in-lbs	1.4-1.7 Nm	1.5 MAINTENANCE SCHEDULE, General
Rear master cylinder reservoir cover screws	12-15 in-lbs	1.4-1.7 Nm	1.16 BRAKE PADS AND DISCS, Brake Pad Replacement
Rear muffler fastener	96-144 in-lbs	10.9-16.3 Nm	1.12 DRIVE BELT AND SPROCKETS, Setting Belt Deflection
Spark plug	12-18 ft-lbs	16.3-24.4 Nm	1.5 MAINTENANCE SCHEDULE, General
Spark plug	12-18 ft-lbs	16.3-24.4 Nm	1.17 SPARK PLUGS, Inspection
Spoke nipple	55 in-lbs	6.2 Nm	1.5 MAINTENANCE SCHEDULE, General
Spoke nipple	55 in-lbs	6.2 Nm	1.8 TIRES AND WHEELS, Wheel Spokes
Top caddy mounting screw	72-96 in-lbs	8.1-10.9 Nm	1.5 MAINTENANCE SCHEDULE, General
Top caddy mounting screw	72-96 in-lbs	8.1-10.9 Nm	1.22 BATTERY MAINTENANCE, Battery
Top stabilizer link bolt	18-22 ft-lbs	24.4-29.9 Nm	1.23 ENGINE MOUNTS, Inspection
Top stabilizer link bolt	18-22 ft-lbs	24.4-29.9 Nm	1.23 ENGINE MOUNTS, Inspection
Transmission drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.5 MAINTENANCE SCHEDULE, General
Transmission drain plug	14-21 ft-lb	19.0-28.5 Nm	1.10 TRANSMISSION LUBRICANT, Changing Transmission Lubricant
Transmission filler/check plug	25-75 in-lbs	2.8-8.5 Nm	1.5 MAINTENANCE SCHEDULE, General
Transmission filler/dipstick	25-75 in-lbs	2.8-8.5 Nm	1.10 TRANSMISSION LUBRICANT, Checking Transmission Lubricant Level
Transmission filler plug/dipstick	25-75 in-lb	2.8-8.5 Nm	1.10 TRANSMISSION LUBRICANT, Changing Transmission Lubricant
Turn signal lamp to mounting bracket screws	36-60 in-lbs	4.1-6.8 Nm	1.20 HEADLAMP ALIGNMENT, Auxiliary Lamp Alignment

SERVICING A NEW MOTORCYCLE

WARNING

Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)

Service operations to be performed before customer delivery are specified in the applicable model year predelivery and set-up instructions.

The performance of new motorcycle initial service is required to keep warranty in force and to verify proper emissions systems operation. See [1.5 MAINTENANCE SCHEDULE](#).

SAFE OPERATING MAINTENANCE

NOTES

- Do not attempt to tighten engine head bolts or engine damage may result.
- During the initial break-in period, use only GENUINE HARLEY-DAVIDSON H-D 360 MOTORCYCLE OIL 20W50. Failure to use the recommended oil will result in improper break-in of the engine cylinders and piston rings.

A careful check of certain equipment is necessary after periods of storage, and frequently between regular service intervals, to determine if additional maintenance is required.

Check:

1. Tires for correct pressure, excessive wear or any signs of tire damage.
2. Drive belt tension and condition.
3. Brakes, steering and throttle for responsiveness.
4. Brake fluid level and condition. Hydraulic lines and fittings for leaks. Also, check brake pads and discs for wear.
5. Cables for fraying, crimping and free operation.
6. Engine oil and transmission fluid levels.
7. Headlamp, auxiliary lamp, tail lamp, brake lamp, horn and turn signal operation.

SHOP PRACTICES

Repair Notes

General maintenance practices are given in this section.

NOTES

- Repair = Disassembly/Assembly.
- Replacement = Substitute a **new** part for existing component.

All special tools and torque values are noted at the point of use.

All required parts or materials can be found in the parts catalog.

Safety

Safety is always the most important consideration when performing any job. Be sure you have a complete understanding of the task to be performed. Use common sense. Use the proper tools. Protect yourself and bystanders with approved eye protection. Don't just do the job - do the job safely.

Removing Parts

Always consider the weight of a part when lifting. Use a hoist whenever necessary. Do not lift heavy parts by hand. A hoist and adjustable lifting beam or sling are needed to remove some parts. The lengths of multiple chains or cables from the hoist to the part should be equal and parallel and should be positioned directly over the center of the part. Be sure that no obstructions will interfere with the lifting operation. Never leave a part suspended in mid-air.

WARNING

Be sure to check capacity rating and condition of hoists, slings, chains and cables before use. Exceeding capacity ratings or using lifting devices that are in poor condition can lead to an accident, which could result in death or serious injury. (00466c)

Always use blocking or proper stands to support the part that has been hoisted. If a part cannot be removed, verify that all bolts and attaching hardware have been removed. Check to see if any parts are in the way of the part being removed.

When removing hoses, wiring or tubes, always tag each part to verify proper installation.

Cleaning

If parts are to be reused, follow good shop practice and thoroughly clean the parts before assembly. Keep all dirt out of parts to promote better component operation and longer life. Seals, filters and covers are used in this vehicle to keep out extraneous dirt and dust. These items must be kept in good condition to guarantee satisfactory operation.

When instructed to clean fastener threads or threaded holes, proceed as follows: Clean all threadlocking material from fastener threads and threaded holes. Use a wire brush to clean fastener threads. Use a thread chaser or other suitable tool to clean threaded holes. Use PJ1 cleaner or equivalent to remove all traces of oil and contaminants from threads. Clean all threaded holes with low pressure compressed air.

Clean and inspect all parts as they are removed. Be sure all holes and passages are clean and open. After cleaning, cover all parts with clean lint-free cloth, paper or other material. Be sure the part is clean when it is installed.

Always clean around lines or covers before they are removed. Plug, tape or cap holes and openings to keep out dirt, dust and debris.

Always verify cleanliness of blind holes before assembly. Tightening a screw with dirt, water or oil in the hole can cause castings to crack or break.

Disassembly and Assembly

Always assemble or disassemble one part at a time. Do not work on two assemblies simultaneously. Be sure to make all necessary adjustments. Check your work when finished to be sure that everything is done.

Operate the vehicle to perform any final check or adjustments. If all is correct, the vehicle is ready to go back to the customer.

Checking Torques on Fasteners

Attempt to turn the fastener using a torque wrench set to the minimum torque specification for that fastener. If the fastener does not rotate, the fastener torque has been maintained. If the fastener rotates, remove it to determine if it has a threadlocking agent.

If it has a threadlocking agent, clean all threadlocking material from the threaded hole. Replace the fastener with a **new** one or clean the original fastener threads and apply the appropriate threadlocking product (see the specific procedure). Install and tighten the fastener to specification.

If the fastener does not use a threadlocking agent, install and tighten it to specification.

Magnetic Parts Trays

Magnetic parts trays are common in the service facility because they are convenient and can keep parts from becoming lost during a repair procedure. However, hardened steel parts can become magnetized when held in magnetic parts trays.

Metal fragments from normal wear are ordinarily washed away by the engine oil and trapped in the oil filter or by the magnetic drain plug. Magnetized parts in the engine can retain these fragments, potentially causing accelerated engine wear and damage.

Parts that will be returned to service inside the vehicle's powertrain such as gears, thrust washers and especially bearings should never be kept in magnetic parts trays.

REPAIR AND REPLACEMENT PROCEDURES

Hardware and Threaded Parts

Install thread repair inserts when threaded holes in castings are stripped, damaged or not capable of withstanding specified torque.

Replace bolts, nuts, studs, washers, spacers and small common hardware if missing or damaged. Clean up or repair minor thread damage with a suitable tap or die.

Replace all damaged or missing lubrication fittings.

Use Teflon pipe sealant or LOCTITE 565 PIPE SEALANT WITH TEFLON on pipe fitting threads.

Threadlocking Agents

Always follow specific service manual procedures when working with fasteners containing preapplied threadlocking agents when fastener replacement is recommended. When re-using fasteners containing threadlocking agents, be sure to completely remove all existing threadlocking agent from fastener threads with a wire brush or wire wheel. Also, be sure to remove residual threadlocking agent from fastener hole using an appropriate thread chasing device and compressed air.

Always use the recommended threadlocking agent for the specific procedure.

Wiring, Hoses and Lines

Hoses, clamps, electrical wiring, electrical switches or fuel lines if they do not meet specifications.

Instruments and Gauges

Replace damaged or defective instruments and gauges.

Bearings

Anti-friction bearings must be handled in a special way. To keep out dirt and abrasives, cover the bearings as soon as they are removed from the package.

When bearings are installed against shoulders, be sure that the chamfered side of the bearing always faces the shoulder. Lubricate bearings and all metal contact surfaces before pressing into place. Only apply pressure on the part of the bearing that makes direct contact with the mating part. Install bearings with numbered side facing out.

Always use the proper tools and fixtures for removing and installing bearings.

Only remove bearings if necessary. Removal usually damages bearings requiring them to be replaced with **new** parts.

Bushings

Do not remove a bushing unless damaged, excessively worn or loose in its bore. Press out bushings that must be replaced.

When pressing or driving bushings, be sure to apply pressure in line with the bushing bore. Use a bearing/bushing driver or a bar with a smooth, flat end. Never use a hammer to drive bushings.

Inspect the bushing and the mating parts for oil holes before installation, and be sure all oil holes are properly aligned during installation.

Gaskets

Always discard gaskets after removal. Replace with **new** gaskets. Never use the same gasket twice. Be sure that gasket holes match up with holes in the mating part. But be aware that sections of a gasket may be used to seal passages.

Lip-Type Seals

Lip seals are used to seal oil or grease and are usually installed with the sealing lip facing the contained lubricant. Seal orientation, however, may vary under different applications.

Seals should not be removed unless necessary. Only remove seals if required to gain access to other parts or if seal damage or wear dictates replacement.

Leaking oil or grease usually means that a seal is damaged. Replace leaking seals to prevent overheated bearings.

Always discard seals after removal. Do not use the same seal twice.

O-Rings (Pre-Formed Packings)

Always discard O-rings after removal. Replace with **new** O-ring. To prevent leaks, lubricate the O-rings before installation. Apply the same type of lubricant as that being sealed. Be sure

that all gasket, O-ring and seal mating surfaces are thoroughly clean before installation.

Gears

Always check gears for damaged or worn teeth.

Remove burrs and rough spots with a honing stone or crocus cloth before installation.

Lubricate mating surfaces before pressing gears on shafts.

Shafts

If a shaft does not come out easily, check that all nuts, bolts or retaining rings have been removed. Check to see if other parts are in the way before using force to remove.

Shafts fitted to tapered splines should be very tight. If shafts are not tight, disassemble and inspect tapered splines. Discard parts that are worn. Be sure tapered splines are clean, dry and free of burrs before putting them in place. Press mating parts together tightly.

Clean all rust from the machined surfaces of **new** parts.

Part Replacement

Always replace worn or damaged parts with **new** parts.

Exhaust System Leakage

In the event of an exhaust system leak at a muffler or header pipe connection location, disassemble and clean all mating surfaces. Replace any damaged components. If the leak still exists, disassemble and repair the leak by applying a bead of Permatex Ultra Copper or LOCTITE 5920 Flange Sealant (or an equivalent oxygen sensor/catalyst-safe alternative). Assemble components, wipe off any excess sealant and allow adequate curing time following sealant product instructions before operating vehicle.

CLEANING

Part Protection

Before cleaning, protect rubber parts (such as hoses, boots and electrical insulation) from cleaning solutions. Use a grease-proof barrier material. Remove the rubber part if it cannot be properly protected.

Cleaning Process

Any cleaning method may be used as long as it does not result in parts damage. Thorough cleaning is necessary for proper parts inspection. Strip rusted paint areas to bare metal before priming and repainting.

Rust or Corrosion Removal

Remove rust and corrosion with a wire brush, abrasive cloth, sand blasting, vapor blasting or rust remover. Use buffing crocus cloth on highly polished parts that are rusted.

Bearings

Wash bearings in a non-flammable petroleum cleaning solution. Never use a solution that contains chlorine. Knock out packed lubricant by tapping the bearing against a wooden block. Wash bearings again.

⚠ WARNING

Using compressed air to "spin dry" bearings can cause bearing to fly apart, which could result in death or serious injury. (00505b)

Cover bearings with a clean shop towel and allow to air dry. Do not spin bearings while they are drying. Never use compressed air to dry bearings.

When dry, coat bearings with clean oil. Wrap bearings in clean paper.

TOOL SAFETY

Air Tools

- Always use approved eye protection equipment when performing any task using air-operated tools.
- On all power tools, use only recommended accessories with proper capacity ratings.
- Do not exceed air pressure ratings of any power tools.
- Bits should be placed against work surface before air hammers are operated.
- Disconnect the air supply line to an air hammer before attaching a bit.
- Never point an air tool at yourself or another person.
- Protect bystanders with approved eye protection.

Wrenches

- Never use an extension on a wrench handle.
- If possible, always pull on a wrench handle and adjust your stance to prevent a fall if something suddenly releases.
- Always keep the wrench squarely installed on the fastener.
- Never use a hammer on any wrench other than a STRIKING FACE wrench.
- Discard any wrench with damaged or battered points.
- Never use a pipe wrench to bend, raise or lift a pipe.

Pliers/Cutters/Pry Bars

- Plastic- or vinyl-covered pliers handles are not intended to act as insulation. Do not use them on live electrical circuits.
- Do not use pliers or cutters for cutting hardened wire unless they were designed for that purpose.
- Always cut at right angles.
- Do not use any pry bar as a chisel, punch or hammer.

Hammers

- Never strike a hammer against a hardened object, such as another hammer.
- Always grasp a hammer handle firmly, close to the end.
- Strike the object with the full face of the hammer.
- Never work with a hammer which has a loose head or cracked handle.
- Discard hammer if face is chipped or mushroomed.
- Wear approved eye protection when using striking tools.
- Protect bystanders with approved eye protection.

Punches/Chisels

- Never use a punch or chisel with a chipped or mushroomed end. Dress mushroomed chisels and punches with a grinder.
- Hold a chisel or a punch with a tool holder if possible.
- When using a chisel on a small piece, clamp the piece firmly in a vise and chip toward the stationary jaw.
- Always wear approved eye protection when using these tools.
- Protect bystanders with approved eye protection.

Screwdrivers

- Do not use a screwdriver for prying, punching, chiseling, scoring or scraping.
- Use the right type of screwdriver for the job. Match the tip of a screwdriver to the fastener.
- Do not interchange POZIDRIV, PHILLIPS or REED AND PRINCE screwdrivers.
- Screwdriver handles are not intended to act as insulation. Do not use them on live electrical circuits.
- Do not use a screwdriver with rounded edges because it will slip. Redress with a grinder.

Ratchets and Handles

- Periodically clean and lubricate ratchet mechanisms with a light grade oil. Do not replace parts individually. Ratchets should be rebuilt with the entire contents of service kit.
- Never hammer on a ratchet or put a pipe extension on a ratchet handle for added leverage.
- Always support the ratchet head when using socket extensions, but do not put your hand on the head or you may interfere with the action of its reversing mechanism.
- When breaking a fastener loose, apply a small amount of pressure as a test to be sure the ratchet's gear wheel is engaged with the pawl.

Sockets

- Never use hand sockets on power or impact wrenches. Select only impact sockets for use with air or electric impact wrenches.
- Select the right size socket for the job.
- Always keep the wrench or socket squarely on the fastener.
- Replace sockets showing cracks or wear.
- Keep sockets clean.
- Always use approved eye protection when using power or impact sockets.

Storage Units

- Do not open more than one loaded drawer at a time. Close each drawer before opening another to prevent the cabinet from unexpectedly tipping over.
- Close lids and lock drawers and doors before moving storage units.
- Do not pull on a tool cabinet. Always push tool cabinets in front of you.
- Set the brakes on the locking casters after the cabinet has been rolled into position.

FUEL AND OIL

1.3

FUEL

Always use a good quality unleaded gasoline. Octane ratings are usually found on the pump. Refer to [Table 1-1](#).

⚠ WARNING

Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)

⚠ WARNING

Use care when refueling. Pressurized air in fuel tank can force gasoline to escape through filler tube. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00029a)

Modern service station pumps dispense a high flow of gasoline into a motorcycle fuel tank making air entrapment and pressurization a possibility.

Table 1-1. Octane Ratings

SPECIFICATION	RATING
Pump Octane (R+M)/2	91 (95 RON)

GASOLINE BLENDS

Your motorcycle was designed to get the best performance and efficiency using unleaded gasoline. Most gasoline is blended with alcohol and/or ether to create oxygenated blends. The type and amount of alcohol or ether added to the fuel is important.

NOTICE

Do not use gasoline that contains methanol. Doing so can result in fuel system component failure, engine damage and/or equipment malfunction. (00148a)

- Gasoline containing METHYL TERTIARY BUTYL ETHER (MTBE): Gasoline/MTBE blends are a mixture of gasoline and as much as 15% MTBE. Gasoline/MTBE blends can be used in your motorcycle.
- ETHANOL fuel is a mixture of ethanol (Grain alcohol) and unleaded gasoline. While ethanol does have an impact on fuel mileage, fuels with an ethanol content of up to 10% may be used in your motorcycle without affecting vehicle performance. U.S. EPA regulations currently indicate that fuels with 15% ethanol (E15) are restricted from use in motorcycles at the time of this publication. Motorcycles delivered in some countries are calibrated to operate with higher ethanol concentrations to meet the fuel standards in those countries.
- REFORMULATED OR OXYGENATED GASOLINES (RFG): Reformulated gasoline is a term used to describe gasoline blends that are specifically designed to burn

cleaner than other types of gasoline, leaving fewer tailpipe emissions. They are also formulated to evaporate less when you are filling your tank. Reformulated gasolines use additives to oxygenate the gas. Your motorcycle will run normally using this type of gas and Harley-Davidson recommends you use it when possible, as an aid to cleaner air in our environment.

- Do not use race gas. Use of these fuels will damage the fuel system.
- Harley-Davidson recommends using SCREAMIN' EAGLE SUPER OCTANE BOOST to raise fuel octane. This is the only octane booster that has been extensively tested and approved for use with Harley-Davidson engines and components.

Some gasoline blends might adversely affect the starting, driveability or fuel efficiency of the motorcycle. If any of these problems are experienced, try a different brand of gasoline or gasoline with a higher octane blend.

ENGINE LUBRICATION

⚠ CAUTION

Prolonged or repeated contact with used motor oil may be harmful to skin and could cause skin cancer. Promptly wash affected areas with soap and water. (00358b)

⚠ CAUTION

If swallowed, do not induce vomiting. Contact a physician immediately. In case of contact with eyes, immediately flush with water. Contact a physician if irritation persists. (00357c)

NOTICE

Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)

Engine oil is a major factor in the performance and service life of the engine. Always use the proper grade of oil for the lowest temperature expected before the next scheduled oil change. Your authorized dealer has the proper oil to suit your requirements. Refer to [Table 1-2](#).

This motorcycle was originally equipped with Genuine H-D 360 Multi-Grade 20W50 engine oil, and is the preferred oil under normal operating conditions. If operation under extreme cold or heat are expected, refer to [Table 1-2](#) for alternative choices.

If it is necessary to add oil and Harley-Davidson oil is not available, use an oil certified for diesel engines. Acceptable diesel engine oil designations include: SH, CH-4, CI-4 and CJ-4.

The preferred viscosities for the diesel engine oils in descending order are: 20W50, 15W40 and 10W40.

At the first opportunity, see an authorized dealer to change back to 100 percent Harley-Davidson oil.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com