



# 2016 Harley-Davidson Softail Models Service Manual

©2015 H-D.  
ALL RIGHTS RESERVED  
99482-16

Printed in the U.S.A.

VISIT THE HARLEY-DAVIDSON WEB SITE  
<http://www.harley-davidson.com>

## MAINTENANCE

---

### 1.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....1-1

### 1.2 GENERAL

Servicing a New Motorcycle.....	1-3
Safe Operating Maintenance.....	1-3
Disposal and Recycling.....	1-3
Shop Practices.....	1-3
Repair Notes.....	1-3
Safety.....	1-3
Removing Parts.....	1-3
Cleaning.....	1-3
Disassembly and Assembly.....	1-4
Checking Torques on Fasteners.....	1-4
Magnetic Parts Trays.....	1-4
Repair and Replacement Procedures.....	1-4
Hardware and Threaded Parts.....	1-4
Threadlocking Agents.....	1-4
Wiring, Hoses and Lines.....	1-4
Instruments and Gauges.....	1-4
Bearings.....	1-4
Bushings.....	1-4
Gaskets.....	1-4
Lip-Type Seals.....	1-4
O-Rings.....	1-5
Gears.....	1-5
Shafts.....	1-5
Part Replacement.....	1-5
Cleaning.....	1-5
Protecting Rubber Parts.....	1-5
Cleaning Process.....	1-5
Rust or Corrosion Removal.....	1-5
Bearings.....	1-5
Tool Safety.....	1-5
Air Tools.....	1-5
Wrenches.....	1-5
Pliers/Cutters/Pry Bars.....	1-6
Hammers.....	1-6
Punches/Chisels.....	1-6
Screwdrivers.....	1-6
Ratchets and Handles.....	1-6
Sockets.....	1-6
Storage Units.....	1-6

### 1.3 FUEL AND OIL

Fuel.....	1-7
Gasoline Blends.....	1-7
Engine Lubrication: Twin Cam 103.....	1-7
Engine Lubrication: Twin Cam 110.....	1-8
Winter Lubrication.....	1-8

### 1.4 MAINTENANCE SCHEDULE

General.....	1-9
--------------	-----

### 1.5 ENGINE OIL AND FILTER

Checking and Adding Oil.....	1-14
Changing Oil and Oil Filter.....	1-14

### 1.6 AIR CLEANER AND EXHAUST SYSTEM

Air Cleaner: All except FLSS, FLSTFBS.....	1-16
Removal.....	1-16
Installation.....	1-16
Air Cleaner: FLSTFBS.....	1-17

Rain Sock.....	1-17
Removal.....	1-17
Installation.....	1-17
Air Cleaner: FLSS.....	1-17
Removal.....	1-17
Installation.....	1-17
Cleaning Filter Element.....	1-18
Check Exhaust System Leakage.....	1-18
Exhaust System Leakage.....	1-18

### 1.7 TIRES AND WHEELS

General.....	1-19
Tires.....	1-19
Tire Replacement.....	1-20
Inspection.....	1-20
When To Replace Tires.....	1-20
Wheel Bearings.....	1-20
Wheel Spokes.....	1-20
Identify Wheel Spoke Groups.....	1-20
Adjust Wheel Spokes.....	1-21

### 1.8 PRIMARY CHAINCASE LUBRICANT

General.....	1-22
Change Primary Chaincase Lubricant.....	1-22

### 1.9 TRANSMISSION LUBRICANT

Check Transmission Lubricant.....	1-24
Change Transmission Lubricant.....	1-24

### 1.10 CLUTCH: MECHANICAL CLUTCH

Adjustment.....	1-26
-----------------	------

### 1.11 HYDRAULIC CLUTCH FLUID: HYDRAULIC CLUTCH

General.....	1-28
Inspect Fluid.....	1-28

### 1.12 DRIVE BELT AND SPROCKETS

General.....	1-29
Cleaning.....	1-29
Inspection.....	1-29
Sprockets.....	1-29
Drive Belt.....	1-29
Check Drive Belt Deflection.....	1-30
Adjusting Drive Belt Deflection.....	1-32

### 1.13 CABLE AND CHASSIS LUBRICATION

General.....	1-33
Cables and Hand Levers.....	1-33
Jiffy Stand.....	1-33
Steering Head Bearings.....	1-33

### 1.14 BRAKES

Fluid Inspection.....	1-34
Inspect Brake Lines.....	1-35

### 1.15 BRAKE PADS AND DISCS

Inspection.....	1-36
Brake Pads.....	1-36
Brake Disc.....	1-36
Brake Pad Replacement.....	1-36
Rear Brake Caliper.....	1-36
Front Brake Caliper.....	1-38

# TABLE OF CONTENTS

## 1.16 SPARK PLUGS

Removal.....	1-40
Inspection.....	1-40
Cleaning.....	1-40
Installation.....	1-41

## 1.17 STEERING HEAD BEARINGS

Adjustment: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS.....	1-42
Bearing Adjustment (Fall-Away).....	1-42
Adjustment: FXSB.....	1-43
Bearing Adjustment (Fall-away).....	1-43
Lubrication.....	1-44

## 1.18 BATTERY MAINTENANCE

General.....	1-45
Cleaning and Inspection.....	1-46
Voltage Test.....	1-46
Charging Battery.....	1-46
Safety Precautions.....	1-46
Using a Battery Charger.....	1-46
Battery Disconnection and Removal.....	1-47
Storage.....	1-47
Battery Installation and Connection.....	1-48

## 1.19 HEADLAMP ALIGNMENT

Headlamp Alignment.....	1-50
Headlamp Adjustment.....	1-50

## 1.20 SUSPENSION ADJUSTMENTS

Shock Absorbers.....	1-51
Calculate Number of Preload Turns.....	1-51
Adjustment.....	1-51

## 1.21 STORAGE

General.....	1-52
Placing in Storage.....	1-52
Removal from Storage.....	1-52

## 1.22 TROUBLESHOOTING

General.....	1-54
Engine.....	1-54
Starter Motor Does Not Operate or Does Not Turn Engine Over .....	1-54
Engine Turns Over But Does Not Start .....	1-54
Starts Hard.....	1-54
Starts But Runs Irregularly or Misses .....	1-54
A Spark Plug Fouls Repeatedly.....	1-55
Pre-Ignition or Detonation (Knocks or Pings).....	1-55
Overheating.....	1-55
Valve Train Noise.....	1-55
Excessive Vibration.....	1-55
Check Engine Light Illuminates During Operation.....	1-55
Lubrication System.....	1-55
Oil Does Not Return To Oil Tank.....	1-55
Engine Uses Too Much Oil Or Smokes Excessively.....	1-55
Engine Leaks Oil From Cases, Pushrods, Hoses, Etc.....	1-55
Low Oil Pressure.....	1-56
High Oil Pressure.....	1-56
Electrical System.....	1-56

Alternator Does Not Charge.....	1-56
Alternator Charge Rate Is Below Normal.....	1-56
Speedometer Operates Erratically.....	1-56
Transmission.....	1-56
Shifts Hard.....	1-56
Jumps Out Of Gear.....	1-56
Clutch Slips.....	1-56
Clutch Drags Or Does Not Release.....	1-56
Clutch Chatters.....	1-56
Handling.....	1-56
Irregularities.....	1-56
Brakes.....	1-56
Brake Does Not Hold Normally.....	1-56

## CHASSIS

### 2.1 FASTENER TORQUE VALUES

Fastener Torque Values in this Chapter.....	2-1
---------------------------------------------	-----

### 2.2 SPECIFICATIONS

Specifications.....	2-6
Chassis Specifications.....	2-6
Tire Specifications.....	2-7

### 2.3 VEHICLE IDENTIFICATION NUMBER

#### (V.I.N.)

Vehicle Identification Number.....	2-10
------------------------------------	------

### 2.4 FRONT WHEEL

Removal.....	2-12
Disassembly.....	2-12
Disc Wheel.....	2-12
Laced Wheel.....	2-12
Cleaning and Inspection.....	2-14
Assembly.....	2-14
Disc Wheel.....	2-15
Laced Wheel.....	2-15
Installation.....	2-15

### 2.5 REAR WHEEL

Removal.....	2-16
Disassembly.....	2-16
Cleaning and Inspection.....	2-17
Assembly.....	2-17
Installation.....	2-18

### 2.6 WHEEL LACING

Wheel Lacing: Angle Flange Hub.....	2-19
-------------------------------------	------

### 2.7 CHECKING AND TRUING WHEELS

General.....	2-21
Checking Wheel Runout.....	2-21
Checking Radial Runout.....	2-21
Checking Lateral Runout.....	2-21
Laced Wheel Rim Offset.....	2-22
True Laced Wheels.....	2-24
Adjust Radial Runout.....	2-24
Adjust Lateral Runout.....	2-24

# TABLE OF CONTENTS

<b>2.8 SEALED WHEEL BEARINGS</b>	
Inspect.....	2-26
Removal.....	2-26
Installation.....	2-27
<b>2.9 TIRES</b>	
General.....	2-29
Removal.....	2-29
Clean, Inspect and Repair.....	2-30
Install.....	2-30
Tube-Type Tires.....	2-30
Tubeless Tires: Cast Wheels.....	2-31
Check Tire Runout.....	2-31
Lateral Runout.....	2-31
Radial Runout.....	2-31
Balance Wheel.....	2-32
Static vs Dynamic.....	2-32
Weights.....	2-32
<b>2.10 VEHICLE ALIGNMENT</b>	
Axe Alignment.....	2-33
Checking Axe Alignment.....	2-33
Adjusting Axe Alignment.....	2-34
<b>2.11 FRONT BRAKE MASTER CYLINDER</b>	
General.....	2-35
Removal and Disassembly.....	2-35
Cleaning and Inspection.....	2-36
Assembly and Installation.....	2-36
<b>2.12 FRONT BRAKE CALIPER</b>	
Removal.....	2-38
Disassembly.....	2-38
Cleaning, Inspection and Repair.....	2-39
Assembly.....	2-40
Installation.....	2-40
<b>2.13 REAR BRAKE MASTER CYLINDER</b>	
General.....	2-41
Rear Brake Pedal.....	2-41
Pedal Height.....	2-41
Pedal Replacement.....	2-41
Pedal Pad.....	2-41
Removal.....	2-41
Disassembly.....	2-41
Cleaning and Inspection.....	2-42
Assembly.....	2-43
Installation.....	2-44
<b>2.14 REAR BRAKE CALIPER</b>	
Removal.....	2-47
Disassembly.....	2-47
Cleaning, Inspection and Repair.....	2-49
Assembly.....	2-49
Rear Brake Line Routing.....	2-50
Installation.....	2-50
<b>2.15 BRAKE LINES</b>	
Front Master Cylinder to Front HCU.....	2-52
Removal.....	2-52
Installation.....	2-52
HCU to Front Brake Caliper.....	2-52
Removal.....	2-52
Installation.....	2-53
Rear Master Cylinder to Rear HCU.....	2-53
Removal.....	2-53
Installation.....	2-54
Rear HCU to Rear Brake Caliper.....	2-55
Removal.....	2-55
Installation.....	2-56
<b>2.16 ABS: ELECTRONIC CONTROL UNIT (ECU)</b>	
Removal: All But FXSB.....	2-57
Installation: All But FXSB.....	2-57
Removal: FXSB.....	2-58
Installation: FXSB.....	2-58
<b>2.17 ABS: HYDRAULIC CONTROL UNIT (HCU)</b>	
Front Hydraulic Control Unit (HCU).....	2-59
Removal.....	2-59
Installation.....	2-59
Rear Hydraulic Control Unit (HCU).....	2-60
Removal.....	2-60
Installation.....	2-60
<b>2.18 BLEEDING BRAKES</b>	
General.....	2-62
Procedure.....	2-62
<b>2.19 FRONT FORK</b>	
General.....	2-64
Check For Oil Leak.....	2-64
Fork Oil Seals.....	2-64
Check Oil Leak.....	2-64
Replacing Fork Oil.....	2-64
Removal.....	2-65
Disassembly.....	2-65
Clean and Inspect.....	2-69
Assembly.....	2-69
Installation.....	2-69
<b>2.20 STEERING HEAD</b>	
Removal.....	2-71
FLSTC, FLSTF, FLSTFB, FLSTFBs, FLSTN, FLS, FLSS Models.....	2-71
FXSB Models.....	2-71
Inspection.....	2-72
All Models.....	2-72
Disassembly.....	2-72
Removing Lower Bearings From Fork Stem.....	2-72
Steering Head Bearing Race Removal.....	2-72
Assembly.....	2-72
Installation.....	2-73
FLSTC, FLSTF, FLSTFB, FLSTFBs, FLSTN, FLS, FLSS Models.....	2-73
FXSB Model.....	2-73

# TABLE OF CONTENTS

---

<b>2.21 BELT GUARD AND DEBRIS DEFLECTOR</b>		<b>2.30 HANDLEBAR: FLSTC, FLSTN, FLS, FLSS</b>	
Removal.....	2-74	Removal.....	2-92
Belt Guard.....	2-74	Installation.....	2-93
Debris Deflector.....	2-74		
Installation.....	2-74	<b>2.31 HANDLEBAR: FLSTF, FLSTFB, FLSTFBS</b>	
Belt Guard.....	2-74	Removal.....	2-94
Debris Deflector.....	2-74	Installation.....	2-95
<b>2.22 REAR SHOCK ABSORBERS</b>		<b>2.32 HANDLEBAR: FXSB</b>	
General.....	2-75	Removal.....	2-96
Removal.....	2-75	Installation.....	2-96
Installation.....	2-75		
Shock Disposal.....	2-76	<b>2.33 FRONT FENDER</b>	
		Removal.....	2-98
<b>2.23 REAR FORK</b>		Installation.....	2-98
Removal.....	2-78		
Cleaning and Inspection.....	2-79	<b>2.34 REAR FENDER: FLSTC</b>	
Pivot Bearing Replacement.....	2-79	Removal.....	2-99
Installation.....	2-80	Installation.....	2-99
		<b>2.35 REAR FENDER: FLSTF, FLSTFB, FLSTFBS</b>	
<b>2.24 CLUTCH CONTROL: MECHANICAL CLUTCH</b>		Removal.....	2-101
Removal.....	2-81	Installation.....	2-101
Installation.....	2-81		
<b>2.25 CLUTCH MASTER CYLINDER AND RESERVOIR: HYDRAULIC CLUTCH</b>		<b>2.36 REAR FENDER: FLS, FLSS</b>	
Remove.....	2-83	Removal.....	2-102
Disassemble.....	2-83	Installation.....	2-102
Cleaning and Inspection.....	2-84	License Plate Bracket Assembly and Installation: FLS, FLSS (all but Domestic and California models).....	2-102
Assemble.....	2-84	License Plate Bracket Assembly and Installation: FLS, FLSS (Domestic and California models).....	2-103
Install.....	2-85	Fender Installation.....	2-103
<b>2.26 CLUTCH HAND LEVER: HYDRAULIC CLUTCH</b>		<b>2.37 REAR FENDER: FXSB</b>	
Removal.....	2-86	Removal.....	2-105
Installation.....	2-86	Installation.....	2-106
<b>2.27 CLUTCH FLUID LINE: HYDRAULIC CLUTCH</b>		<b>2.38 REAR FENDER: FLSTN</b>	
Replacement.....	2-87	Removal.....	2-107
Removal.....	2-87	Disassembly.....	2-107
Installation.....	2-87	Assembly.....	2-108
<b>2.28 BLEEDING CLUTCH FLUID LINE: HYDRAULIC CLUTCH</b>		Installation.....	2-109
Drain and Fill.....	2-89		
Drain.....	2-89	<b>2.39 REAR FENDER WIRE CONDUIT</b>	
Fill.....	2-89	Installation.....	2-110
Bleed Fluid Line and Secondary Clutch Actuator.....	2-90		
<b>2.29 LEFT HANDLEBAR GRIP</b>		<b>2.40 FOOTBOARDS AND FOOTRESTS</b>	
Removal and Installation.....	2-91	Rider Footboards.....	2-111
Removal.....	2-91	Removal.....	2-111
Installation.....	2-91	Installation.....	2-111
		Rider Footrests.....	2-111
		Removal.....	2-111
		Installation.....	2-111
		Passenger Footrests.....	2-111
		Removal.....	2-111
		Installation.....	2-112

## TABLE OF CONTENTS

<b>2.41 JIFFY STAND</b>	
Cleaning.....	2-113
Sensor: HDI Models.....	2-113
Removal.....	2-113
Installation.....	2-113
<b>2.42 FORK LOCK</b>	
Removal.....	2-115
Installation.....	2-115
<b>2.43 SEAT AND STRAP RETENTION NUT</b>	
Replacement.....	2-116
<b>2.44 SEAT: FLS, FLSS, FXSB</b>	
Replacement.....	2-117
Removal.....	2-117
Installation.....	2-117
<b>2.45 SEAT: FLSTN, FLSTF, FLSTFB, FLSTFBS, FLSTC</b>	
Removal and Installation.....	2-118
<b>2.46 LUGGAGE RACK: FLSTN</b>	
Removal and Installation.....	2-119
<b>2.47 SADDLEBAGS: FLSTC</b>	
Removal.....	2-120
Installation.....	2-120
<b>2.48 WINDSHIELD: FLSTC</b>	
Removal.....	2-122
Installation.....	2-122
<b>2.49 SAREE GUARD: INDIA MODELS</b>	
Upper Saree Guards: All Models Except FXSB.....	2-123
Removal.....	2-123
Installation.....	2-123
Upper Saree Guards: FXSB.....	2-123
Removal.....	2-123
Installation.....	2-123
Lower Saree Guard.....	2-123
Removal.....	2-123
Installation.....	2-123
<b>2.50 FRONT LICENSE PLATE BRACKET</b>	
Removal and Installation.....	2-124
<b>2.51 MEDALLIONS, BADGES AND TANK EMBLEMS</b>	
Removal.....	2-125
Installation.....	2-125
<b>ENGINE</b>	
<b>3.1 FASTENER TORQUE VALUES</b>	
Fastener Torque Values in this Chapter.....	3-1
<b>3.2 SPECIFICATIONS</b>	
Specifications.....	3-4
<b>3.3 SERVICE WEAR LIMITS</b>	
General.....	3-7
<b>3.4 ENGINE OIL FLOW</b>	
Oil Feed.....	3-10
Top End.....	3-11
Bottom End.....	3-12
Chain Guide Bracket.....	3-14
Oil Return.....	3-14
<b>3.5 OIL PUMP OPERATION</b>	
General.....	3-15
Operation.....	3-15
<b>3.6 BREATHER OPERATION</b>	
General.....	3-17
<b>3.7 OIL PRESSURE</b>	
Oil Pressure Indicator Lamp.....	3-18
Checking Oil Pressure.....	3-18
<b>3.8 TROUBLESHOOTING</b>	
Diagnosing Valve Train Noise.....	3-20
Compression Test.....	3-20
Cylinder Leakdown Test.....	3-21
Diagnosing Smoking Engine or High Oil Consumption.....	3-21
Check Before Cylinder Head Removal:.....	3-21
Check After Cylinder Head Removal:.....	3-21
<b>3.9 HOW TO USE THIS SECTION</b>	
Top End Repair.....	3-22
Bottom End Repair.....	3-22
Typical Symptoms.....	3-22
<b>3.10 TOP END SERVICE</b>	
Engine in Chassis.....	3-23
Engine Removed from Chassis.....	3-24
<b>3.11 CAM COMPARTMENT SERVICE</b>	
Replace Camshaft.....	3-25
Engine Removed From Chassis.....	3-26
<b>3.12 STRIPPING MOTORCYCLE FOR SERVICE</b>	
Procedure.....	3-27
Cam Compartment Service Only.....	3-27
Complete Top End Service.....	3-27
<b>3.13 ASSEMBLING MOTORCYCLE AFTER SERVICE</b>	
Procedure.....	3-28
After Complete Top End Service.....	3-28
After Cam Compartment Service Only.....	3-28
<b>3.14 REMOVING ENGINE FROM CHASSIS</b>	
Procedure.....	3-29

# TABLE OF CONTENTS

<b>3.15 INSTALLING ENGINE IN CHASSIS</b>	Cylinder Bore Finished Size.....	3-58
Procedure.....		
<b>3.16 TOP END OVERHAUL: DISASSEMBLY</b>	<b>3.24 PISTON: TWIN CAM 103</b>	
General.....	Disassembly.....	3-59
Rocker Covers.....	Piston Rings.....	3-59
Rocker Arm Support Plate.....	Cleaning.....	3-59
Pushrods, Lifters and Covers.....	Inspection.....	3-59
Cylinder Head.....	Assembly.....	3-61
Cylinder.....	Checking Piston Ring Gap.....	3-61
Piston.....	Installing Piston Rings.....	3-61
<b>3.17 BREATHER ASSEMBLY</b>	<b>3.25 PISTON: TWIN CAM 110</b>	
Disassembly.....	Checking Piston Clearance.....	3-63
Cleaning and Inspection.....		
Assembly.....	<b>3.26 TOP END OVERHAUL: ASSEMBLY</b>	
<b>3.18 ROCKER ARM SUPPORT PLATE</b>	General.....	3-64
Disassembly.....	Piston.....	3-64
Cleaning, Inspection and Repair.....	Cylinder.....	3-65
Inspection.....	Cylinder Head.....	3-67
Rocker Shaft Fit.....	Pushrods, Lifters and Covers.....	3-70
Rocker Arm Shaft to Bushing.....	Rocker Arm Support Plate.....	3-71
Replace Rocker Arm Bushings.....	Breather and Rocker Cover.....	3-72
Assembly.....		
<b>3.19 PUSHRODS, LIFTERS AND COVERS</b>	<b>3.27 CAM COMPARTMENT AND COMPONENTS</b>	
Disassembly.....	Cam Support Plate and Cover Removal.....	3-74
Clean and Inspect.....	Prepare Engine.....	3-74
Inspect Lifters.....	Cam Chain and Sprockets Removal.....	3-74
Assemble.....	Cam Support Plate Removal.....	3-75
<b>3.20 CYLINDER HEAD: TWIN CAM 103</b>	Cam Support Plate Cleaning and Inspection.....	3-76
Determining Service.....	Oil Pressure Relief Valve.....	3-76
Disassembly.....	Cam Support Plate.....	3-76
Cleaning.....	Camshafts.....	3-76
Inspection.....	Removal.....	3-76
Cylinder Head.....	Installation.....	3-77
Valve Guides.....	Oil Pressure Relief Valve.....	3-78
Valves.....	Removal.....	3-78
Valve Springs.....	Inspection.....	3-79
Tapered Keepers.....	Installation.....	3-79
Valve Seats.....	Cam Needle Bearings.....	3-79
Valve Guide Replacement.....	Removal.....	3-79
Removal.....	Installation.....	3-81
Installation.....	Cam Support Plate and Cover Installation.....	3-82
Valve and Seat Refacing.....		
Assembly.....		
<b>3.21 CYLINDER HEAD: TWIN CAM 110</b>	<b>3.28 OIL PUMP</b>	
Cylinder Head Repair.....	Removal.....	3-87
<b>3.22 CYLINDER: TWIN CAM 103</b>	Cleaning and Inspection.....	3-87
Cleaning.....	Installation.....	3-88
Inspection.....		
Deglazing Cylinder.....		
Boring and Honing Cylinder.....		
<b>3.23 CYLINDER: TWIN CAM 110</b>	<b>3.29 CRANKCASE DISASSEMBLY AND REPAIR: TWIN CAM 103</b>	
Inspection.....	Crankcase Disassembly.....	3-89
	Counterbalancer Assembly.....	3-89
	Cleaning and Inspection.....	3-91
	Right Crankcase Half.....	3-92
	Chain Guide Screen.....	3-92
	Main Bearing Removal.....	3-92
	Main Bearing Installation.....	3-93
	Piston Jets Removal.....	3-93
	Piston Jets Installation.....	3-93
	Left Crankcase Half.....	3-94

# TABLE OF CONTENTS

Main Bearing Removal.....	3-94	<b>4.2 SPECIFICATIONS: FUEL SYSTEM</b>	
Main Bearing Installation.....	3-95	Specifications.....	4-3
Sprocket Shaft Bearing Inner Race.....	3-95		
Removal.....	3-95		
Installation.....	3-96		
Cylinder Studs.....	3-98	<b>4.3 FUEL PRESSURE TEST</b>	
Removal.....	3-98	General.....	4-4
Installation.....	3-98	Testing.....	4-4
Pipe Plugs and Oil Fittings.....	3-98		
Removal/Installation.....	3-98	<b>4.4 INTAKE LEAK TEST</b>	
		General.....	4-6
<b>3.30 CRANKCASE DISASSEMBLY AND REPAIR: TWIN CAM 110</b>		Leak Tester.....	4-6
General.....	3-99	Parts List.....	4-6
		Assemble Tester .....	4-6
<b>3.31 FLYWHEEL AND CONNECTING RODS</b>		Adjust Tester.....	4-6
Symptoms.....	3-100	Procedure.....	4-6
Overview.....	3-100		
No Oil Pressure.....	3-100	<b>4.5 AIR CLEANER</b>	
Vibration.....	3-100	Air Cleaner: All But FLSTFBS, FLSS.....	4-8
Inspection.....	3-100	Removal.....	4-8
Measuring Crankshaft Runout.....	3-100	Installation.....	4-8
Crankshaft Installed.....	3-100	Replace Insert: With Screw Access.....	4-8
Crankshaft Removed.....	3-101	Replace Insert: Without Screw Access.....	4-8
		Snorkel.....	4-8
<b>3.32 COUNTERBALANCER ASSEMBLY REPAIR</b>		Air Cleaner: FLSTFBS.....	4-9
Cleaning, Inspection and Repair.....	3-102	Removal.....	4-9
General.....	3-102	Installation.....	4-9
Balance Shaft Removal.....	3-102	Air Cleaner: FLSS.....	4-10
Bearing Removal.....	3-103	Removal.....	4-10
Balance Shaft Installation.....	3-103	Installation.....	4-10
Balance Shaft Support Bearings Removal.....	3-104		
Balance Shaft Support Bearings Installation.....	3-104	<b>4.6 FUEL SUPPLY LINE</b>	
Front and Rear Balance Sprockets.....	3-105	Purge Fuel Supply Line.....	4-11
Hydraulic Tensioners.....	3-105	Disconnect Fuel Supply Line.....	4-11
Chain Tensioner Guides.....	3-105		
Balance Shaft Support.....	3-105	<b>4.7 CONSOLE: FXSB</b>	
Balance Chain.....	3-106	Removal.....	4-12
		Installation.....	4-12
<b>3.33 CRANKCASE ASSEMBLY</b>			
Counterbalancer Assembly Installation.....	3-107	<b>4.8 FUEL TANK</b>	
Crankcase Assembly.....	3-110	General.....	4-13
		Removal.....	4-13
<b>3.34 OIL TANK: ALL BUT FXSB</b>		Cleaning and Inspection.....	4-14
Removal and Disassembly.....	3-113	Installation.....	4-15
Oil Tank.....	3-113	Fuel Supply Check Valve/Tube.....	4-15
Oil Line Fittings/Retainers.....	3-115	Removal.....	4-15
Installation.....	3-116	Installation.....	4-15
<b>3.35 OIL TANK: FXSB</b>		<b>4.9 TWIST GRIP SENSOR (TGS)</b>	
Removal and Disassembly.....	3-117	Remove.....	4-17
Oil Tank.....	3-117	Install.....	4-17
Oil Line Fittings/Retainers.....	3-119		
Installation.....	3-120		
		<b>4.10 THROTTLE CONTROL ACTUATOR (TCA)</b>	
		General.....	4-19
<b>FUEL SYSTEM</b>			
		<b>4.11 INDUCTION MODULE</b>	
<b>4.1 FASTENER TORQUE VALUES</b>		Removal.....	4-20
Fastener Torque Values in this Chapter.....	4-1	Installation.....	4-21

# TABLE OF CONTENTS

<b>4.12 TEMPERATURE MANIFOLD ABSOLUTE PRESSURE SENSOR (TMAP)</b>	
Removal.....	4-22
Installation.....	4-22
<b>4.13 HEATED OXYGEN SENSORS (HO2)</b>	
General.....	4-23
Removal.....	4-23
Front HO2 Sensor.....	4-23
Rear HO2 Sensor.....	4-23
Installation.....	4-23
Front HO2 Sensor.....	4-23
Rear HO2 Sensor.....	4-23
<b>4.14 FUEL INJECTORS</b>	
General.....	4-25
Removal.....	4-25
Installation.....	4-25
<b>4.15 ENGINE TEMPERATURE SENSOR (ET)</b>	
General.....	4-27
Removal.....	4-27
Installation.....	4-27
<b>4.16 FUEL PUMP AND FUEL GAUGE SENDING UNIT</b>	
General.....	4-28
Removal.....	4-28
Vapor Valve.....	4-29
Disassembly and Assembly.....	4-30
Fuel Filter.....	4-30
Regulator.....	4-30
Inlet sock.....	4-31
Fuel Pump.....	4-31
Installation.....	4-32
<b>4.17 EXHAUST SYSTEM</b>	
Mufflers: FLSTC, FXSB.....	4-33
Removal.....	4-33
Assembly.....	4-33
System: FLSTC, FXSB.....	4-33
Removal.....	4-33
Installation.....	4-33
Mufflers: FLSTN, FLSTF, FLSTFB, FLSTFBs, FLS, FLSS.....	4-35
Removal.....	4-35
Assembly.....	4-35
System: FLSTN, FLSTF, FLSTFB, FLSTFBs, FLS, FLSS.....	4-35
Removal.....	4-35
Installation.....	4-35
<b>4.18 EVAPORATIVE EMISSIONS CONTROL SYSTEM</b>	
General.....	4-37
Charcoal Canister.....	4-38
Removal.....	4-38
Installation.....	4-38
Purge Solenoid.....	4-38
Removal.....	4-38
Installation.....	4-22
Hose Routing and Replacement.....	4-38
Fuel Tank Vent Hose.....	4-38
Purge Solenoid-to-Induction Module Tube.....	4-38
Charcoal Canister-to-Purge Solenoid Tube.....	4-39
Vent Tube-to-Charcoal Canister Tube.....	4-39
<b>DRIVE</b>	
<b>5.1 FASTENER TORQUE VALUES</b>	
Fastener Torque Values in this Chapter.....	5-1
<b>5.2 SPECIFICATIONS: DRIVE</b>	
Specifications.....	5-2
<b>5.3 PRIMARY CHAINCASE COVER</b>	
Removal.....	5-3
Installation.....	5-3
<b>5.4 DRIVE COMPONENTS</b>	
Removal.....	5-4
Installation.....	5-6
<b>5.5 CLUTCH RELEASE BEARING AND PUSH ROD: HYDRAULIC CLUTCH</b>	
Removal.....	5-9
Installation.....	5-9
Measure Release Plate Movement.....	5-9
Install Clutch Inspection Cover.....	5-9
<b>5.6 PRIMARY CHAINCASE HOUSING</b>	
Removal.....	5-11
Inspection.....	5-11
Mainshaft Bearing and Seal.....	5-11
Removal.....	5-11
Installation.....	5-11
Mainshaft Bearing Inner Race.....	5-12
Removal.....	5-12
Installation.....	5-12
Installation.....	5-13
<b>5.7 MECHANICAL CLUTCH</b>	
Removal and Installation.....	5-15
Clutch Pack Only.....	5-15
Partial Disassembly.....	5-15
Cleaning And Inspection.....	5-15
Assembly.....	5-16
Clutch Pack and Bearing.....	5-17
Complete Disassembly.....	5-17
Assembly.....	5-18
<b>5.8 HYDRAULIC CLUTCH</b>	
Clutch Pack Only.....	5-19
Partial Disassembly.....	5-19
Cleaning And Inspection.....	5-19
Assembly.....	5-19
<b>5.9 TRANSMISSION SPROCKET</b>	
Removal.....	5-21
Cleaning and Inspection.....	5-22

# TABLE OF CONTENTS

Installation.....	5-22	Shifter Cam/Shifter Forks.....	6-23
<b>5.10 DRIVE BELT</b>		Installation.....	6-25
Removal.....	5-24		
Inspection.....	5-24	<b>6.9 MAIN DRIVE GEAR AND BEARING</b>	
Installation.....	5-24	Removal.....	6-27
<b>TRANSMISSION</b>		Cleaning and Inspection.....	6-28
		Needle Bearing Replacement.....	6-29
<b>6.1 FASTENER TORQUE VALUES</b>		Mainshaft Seal Replacement.....	6-30
Fastener Torque Values in this Chapter.....	6-1	Installation.....	6-31
		Installing Main Drive Gear Bearing.....	6-31
<b>6.2 SPECIFICATIONS: TRANSMISSION</b>		Installing Main Drive Gear.....	6-31
Specifications.....	6-2	Installing Main Drive Gear Large Seal.....	6-32
Service Wear Limits.....	6-2		
<b>6.3 TRANSMISSION</b>			
Power Flow.....	6-4	<b>6.10 TRANSMISSION CASE</b>	
Neutral.....	6-4	Removal.....	6-34
First Gear.....	6-4	Installation.....	6-34
Second Gear.....	6-4	Disassembly.....	6-35
Third Gear.....	6-4	Shifter Arm Assembly.....	6-35
Fourth Gear.....	6-4	Cleaning and Inspection.....	6-35
Fifth Gear.....	6-4	Assembly.....	6-36
Sixth Gear.....	6-4	Countershaft Needle Bearing Replacement.....	6-36
<b>6.4 SHIFTER</b>		Shifter Pawl Lever Assembly.....	6-36
Adjustment.....	6-6		
Shifter Rod Adjustment.....	6-6		
Shift Lever Replacement.....	6-6		
<b>6.5 CLUTCH RELEASE COVER:</b>			
<b>MECHANICAL CLUTCH</b>			
Removal and Disassembly.....	6-8	<b>ELECTRICAL</b>	
Cleaning and Inspection.....	6-8		
Assembly and Installation.....	6-9	<b>7.1 FASTENER TORQUE VALUES</b>	
<b>6.6 TRANSMISSION SIDE COVERS:</b>		Fastener Torque Values in this Chapter.....	7-1
<b>HYDRAULIC CLUTCH</b>			
Removal.....	6-10	<b>7.2 SPECIFICATIONS: ELECTRICAL</b>	
Installation.....	6-10	Specifications.....	7-4
<b>6.7 SECONDARY CLUTCH ACTUATOR:</b>			
<b>HYDRAULIC CLUTCH</b>		<b>7.3 ELECTRICAL PANEL</b>	
Replacement.....	6-12	General.....	7-5
Validate Repair.....	6-12	Removal: All But FXSB.....	7-5
<b>6.8 TRANSMISSION ASSEMBLY</b>		Installation: All Except FXSB.....	7-6
Removal.....	6-14	Removal: FXSB.....	7-6
Disassembly.....	6-15	Installation: FXSB.....	7-6
Shifter Cam/Shifter Forks.....	6-15		
Mainshaft.....	6-17	<b>7.4 ELECTRONIC CONTROL MODULE (ECM)</b>	
Countershaft.....	6-19	General.....	7-8
Removing Bearing Housing Bearings.....	6-20	Removal: All But FXSB.....	7-8
Cleaning and Inspection.....	6-21	Installation: All But FXSB.....	7-8
Assembly.....	6-21	Removal: FXSB.....	7-8
Installing Bearing Housing Bearings.....	6-21	Installation: FXSB.....	7-8
Countershaft.....	6-22		
Mainshaft.....	6-22	<b>7.5 BODY CONTROL MODULE (BCM)</b>	
		General.....	7-9
		BCM Configuration.....	7-9
		Removal: All Except FXSB.....	7-9
		Installation: All Except FXSB.....	7-9
		Removal: FXSB.....	7-9
		Installation: FXSB.....	7-10
		<b>7.6 H-DSSS ACTIVATION</b>	
		Activation.....	7-11
		Fob Assignment.....	7-11
		<b>7.7 PERSONAL IDENTIFICATION NUMBER (PIN)</b>	
		General.....	7-12

# TABLE OF CONTENTS

Changing The PIN.....	7-12
Modifying an Existing PIN.....	7-12
<b>7.8 HD-SSS MAINTENANCE</b>	
Fob Battery.....	7-14
Battery Replacement Schedule.....	7-14
Battery Replacement.....	7-14
Smart Siren (If Installed).....	7-14
Battery Replacement Schedule.....	7-14
Battery Replacement.....	7-14
<b>7.9 SECURITY SIREN</b>	
Removal: All But FXSB.....	7-15
Installation: All But FXSB.....	7-15
Removal: FXSB.....	7-15
Installation: FXSB.....	7-16
<b>7.10 FUSES</b>	
Removal.....	7-17
Installation.....	7-17
<b>7.11 IGNITION AND LIGHT SWITCH</b>	
General.....	7-18
Removal and Installation: All Except FXSB.....	7-18
Removal and Installation: FXSB.....	7-19
<b>7.12 BATTERY CABLES</b>	
Routing Procedure.....	7-20
<b>7.13 STARTER</b>	
General.....	7-22
Removal.....	7-22
Drive Assembly.....	7-22
Disassembly.....	7-22
Inspection.....	7-22
Assembly.....	7-23
Solenoid.....	7-23
Remove Cover and Plunger.....	7-23
Short Post Contact: Starter.....	7-23
Long Post Contact: Battery Positive.....	7-24
Install Plunger and Cover.....	7-24
Installation.....	7-24
<b>7.14 HEADLAMP</b>	
General.....	7-26
Headlamp Assembly Removal and Installation.....	7-26
Removal.....	7-26
Installation.....	7-26
Bulb Removal and Installation.....	7-26
FXSB Models.....	7-27
FLSTC, FLSTF, FLSTFB, FLSTFBs, FLSTN, FLS, FLSS Models.....	7-27
<b>7.15 TAIL LAMP: ALL BUT FLSTN</b>	
General.....	7-29
Bulb Replacement.....	7-29
Base Replacement.....	7-29
<b>7.16 TAIL LAMP: FLSTN</b>	
Bulb Replacement.....	7-31
Tail Lamp Replacement.....	7-31
<b>7.17 AUXILIARY LAMPS: FLSTC, FLSTN</b>	
Auxiliary Lamp Bulb.....	7-33
Removal.....	7-33
Installation.....	7-33
FLSTC Models.....	7-33
Auxiliary Lamp Bracket Removal.....	7-33
Auxiliary Lamp Bracket Installation.....	7-34
Auxiliary Lamp Housing Removal.....	7-34
Auxiliary Lamp Housing Installation.....	7-34
FLSTN Models.....	7-36
Auxiliary Lamp Bracket Removal.....	7-36
Auxiliary Lamp Bracket Installation.....	7-36
Auxiliary Lamp Housing Removal.....	7-37
Auxiliary Lamp Housing Installation.....	7-37
Adjustment: FLSTC/FLSTN Models.....	7-38
<b>7.18 TURN SIGNALS AND RUNNING LIGHTS</b>	
Bulb Replacement: Bullet Style.....	7-40
Bulb Replacement: Flat Lens Style.....	7-40
Lamp Replacement.....	7-40
All Models.....	7-40
Front Turn Signals: FLSTC, FLSTN.....	7-40
Front Turn Signals: FLSTF, FLSTFB, FLSTFBs, FLS, FLSS, FXSB.....	7-40
Rear Turn Signals: All But FLSTN, FLS, FLSS, FXSB.....	7-41
Rear Turn Signals: FLS, FLSS.....	7-42
Rear Turn Signals: FXSB.....	7-43
Rear Turn Signals: FLSTN.....	7-44
<b>7.19 CRANK POSITION SENSOR (CKP)</b>	
General.....	7-46
Removal.....	7-46
Installation.....	7-46
<b>7.20 AUTOMATIC COMPRESSION RELEASE (ACR)</b>	
General.....	7-47
Removal.....	7-47
Installation.....	7-47
<b>7.21 IGNITION COIL</b>	
Inspect Spark Plug Cables.....	7-49
Removal.....	7-49
All But FXSB.....	7-49
FXSB.....	7-49
Installation.....	7-49
All Except FXSB.....	7-49
FXSB.....	7-50
<b>7.22 SPARK PLUG CABLES</b>	
General.....	7-52
Removal.....	7-52
Installation.....	7-52
<b>7.23 VOLTAGE REGULATOR</b>	
Disassembly.....	7-53
Installation.....	7-53

# TABLE OF CONTENTS

<b>7.24 ALTERNATOR</b>	
Removal.....	7-54
Cleaning and Inspection.....	7-54
Installation.....	7-54
<b>7.25 FUEL GAUGE</b>	
General.....	7-56
Removal.....	7-56
Installation.....	7-56
<b>7.26 SPEEDOMETER</b>	
General.....	7-58
Removal: All But FXSB.....	7-58
Installation: All Except FXSB.....	7-58
Removal: FXSB.....	7-58
Installation: FXSB.....	7-59
<b>7.27 VEHICLE SPEED SENSOR (VSS)</b>	
General.....	7-60
Removal.....	7-60
Installation.....	7-60
<b>7.28 WHEEL SPEED SENSORS</b>	
Front Wheel Speed Sensor.....	7-61
Removal.....	7-61
Installation.....	7-61
Rear Wheel Speed Sensor.....	7-62
Removal.....	7-62
Installation.....	7-63
<b>7.29 INDICATOR LAMPS</b>	
General.....	7-64
Removal: All But FXSB.....	7-64
Installation: All But FXSB.....	7-64
Removal: FXSB.....	7-65
Installation: FXSB.....	7-65
<b>7.30 NEUTRAL SWITCH</b>	
General.....	7-66
Removal.....	7-66
Installation.....	7-66
<b>7.31 OIL PRESSURE SWITCH</b>	
General.....	7-67
Removal.....	7-67
Installation.....	7-67
<b>7.32 REAR STOP LAMP SWITCH</b>	
General.....	7-68
Removal.....	7-68
Installation.....	7-68
<b>7.33 HORN</b>	
Inspection.....	7-69
Removal and Installation: All But FXSB.....	7-69
Removal and Installation: FXSB.....	7-70
<b>7.34 ACTIVE EXHAUST</b>	
General.....	7-71
Removal.....	7-71
Repair.....	7-71
Installation.....	7-71
<b>7.35 MAIN WIRING HARNESS</b>	
Removal.....	7-72
Installation.....	7-73
<b>7.36 HANDLEBAR CONTROL MODULES</b>	
General.....	7-75
Repair Procedures.....	7-75
<b>7.37 RIGHT HAND CONTROL MODULE</b>	
Removal.....	7-76
Installation.....	7-76
Front Brake Switch Replacement.....	7-78
<b>7.38 LEFT HAND CONTROL MODULE</b>	
Removal.....	7-79
Installation.....	7-80
Clutch Switch Replacement.....	7-81
<b>APPENDIX A WIRING</b>	
<b>A.1 CONNECTORS</b>	
Connector Locations.....	A-1
Function/Location.....	A-1
Place and Color.....	A-1
Connector Number.....	A-1
Repair Instructions.....	A-1
<b>A.2 WIRING DIAGRAMS</b>	
Wiring Diagram Information.....	A-5
Wire Color Codes.....	A-5
Wiring Diagram Symbols.....	A-5
2016 Softail Wiring Diagrams.....	A-7
<b>APPENDIX B REFERENCE</b>	
<b>B.1 LENGTH CONVERSION</b>	
Conversion Table.....	B-1
<b>B.2 FLUID CONVERSION</b>	
United States System.....	B-2
Metric System.....	B-2
British Imperial System.....	B-2
<b>B.3 TORQUE CONVERSION</b>	
United States System.....	B-3
Metric System.....	B-3
<b>B.4 GLOSSARY</b>	
Acronyms and Abbreviations.....	B-4
<b>REFERENCE MATERIAL</b>	
<b>TOOLS.....</b>	
<b>TORQUE VALUES.....</b>	

## TABLE OF CONTENTS

---

INDEX.....	XXI
------------	-----

SUBJECT	PAGE NO.
1.1 FASTENER TORQUE VALUES.....	1-1
1.2 GENERAL.....	1-3
1.3 FUEL AND OIL.....	1-7
1.4 MAINTENANCE SCHEDULE.....	1-9
1.5 ENGINE OIL AND FILTER.....	1-14
1.6 AIR CLEANER AND EXHAUST SYSTEM.....	1-16
1.7 TIRES AND WHEELS.....	1-19
1.8 PRIMARY CHAINCASE LUBRICANT.....	1-22
1.9 TRANSMISSION LUBRICANT.....	1-24
1.10 CLUTCH: MECHANICAL CLUTCH.....	1-26
1.11 HYDRAULIC CLUTCH FLUID: HYDRAULIC CLUTCH.....	1-28
1.12 DRIVE BELT AND SPROCKETS.....	1-29
1.13 CABLE AND CHASSIS LUBRICATION.....	1-33
1.14 BRAKES.....	1-34
1.15 BRAKE PADS AND DISCS.....	1-36
1.16 SPARK PLUGS.....	1-40
1.17 STEERING HEAD BEARINGS.....	1-42
1.18 BATTERY MAINTENANCE.....	1-45
1.19 HEADLAMP ALIGNMENT.....	1-50
1.20 SUSPENSION ADJUSTMENTS.....	1-51
1.21 STORAGE.....	1-52
1.22 TROUBLESHOOTING.....	1-54

## **NOTES**

---

## FASTENER TORQUE VALUES IN THIS CHAPTER

The table below lists torque values for all fasteners presented in this chapter.

FASTENER	TORQUE VALUE	NOTES
Air cleaner cover bracket screws	108-132 <b>in-lbs</b>	12.2-14.9 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: All except FLSS, FLSTFBS
Air cleaner cover screw	36-60 <b>in-lbs</b>	4.1-6.8 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: All except FLSS, FLSTFBS/Apply LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue).
Air cleaner cover screw	36-60 <b>in-lbs</b>	4.1-6.8 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: FLSS/Apply LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue).
Air cleaner cover screw: FLSTFBS	36-60 <b>in-lbs</b>	4.0-6.8 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: FLSTFBS/Apply LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue).
Air cleaner element	55-60 <b>in-lbs</b>	6.2-6.8 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: FLSS/Apply LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue).
Air cleaner element screw: FLSTFBS	55-60 <b>in-lbs</b>	6.2-6.8 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: FLSTFBS/Apply LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue).
Air cleaner trim insert screws: FLSTFBS	27-32 <b>in-lbs</b>	3.1-3.6 Nm 1.6 AIR CLEANER AND EXHAUST SYSTEM, Air Cleaner: FLSTFBS
Axle nut, rear	95-105 ft-lbs	128.8-142.4 Nm 1.12 DRIVE BELT AND SPROCKETS, Adjusting Drive Belt Deflection
Battery negative terminal fastener	60-72 <b>in-lbs</b>	6.8-8.1 Nm 1.18 BATTERY MAINTENANCE, Battery Installation and Connection
Battery positive terminal fastener	60-72 <b>in-lbs</b>	6.8-8.1 Nm 1.18 BATTERY MAINTENANCE, Battery Installation and Connection
Brake caliper, rear, mounting fasteners	16-20 ft-lbs	21.7-27.1 Nm 1.15 BRAKE PADS AND DISCS, Brake Pad Replacement
Brake caliper, rear, pad pin	80-120 <b>in-lbs</b>	9.0-13.6 Nm 1.15 BRAKE PADS AND DISCS, Brake Pad Replacement
Brake caliper mounting bolts, front	28-38 ft-lbs	38.0-51.5 Nm 1.15 BRAKE PADS AND DISCS, Brake Pad Replacement
Brake master cylinder, front, reservoir cover screws	8.9-17.7 <b>in-lbs</b>	1.0-1.2 Nm 1.14 BRAKES, Fluid Inspection
Brake master cylinder, rear, reservoir cover screws	6.0-8.0 <b>in-lbs</b>	0.7-0.9 Nm 1.14 BRAKES, Fluid Inspection
Brake pad screws, front	130-173 <b>in-lbs</b>	14.7-19.6 Nm 1.15 BRAKE PADS AND DISCS, Brake Pad Replacement
Clutch adjuster screw jamnut	72-120 <b>in-lbs</b>	8.1-13.6 Nm 1.10 CLUTCH: MECHANICAL CLUTCH, Adjustment
Clutch cable adjustment jamnut	120 <b>in-lbs</b>	13.6 Nm 1.10 CLUTCH: MECHANICAL CLUTCH, Adjustment

FASTENER	TORQUE VALUE		NOTES
Clutch inspection cover screws	84-108 <b>in-lbs</b>	9.5-12.2 Nm	1.8 PRIMARY CHAINCASE LUBRICANT, Change Primary Chaincase Lubricant/Torque sequence
Clutch inspection cover screws	84-108 <b>in-lbs</b>	9.5-12.2 Nm	1.10 CLUTCH: MECHANICAL CLUTCH, Adjustment
Clutch reservoir cover screws	12-15 <b>in-lbs</b>	1.4-1.7 Nm	1.11 HYDRAULIC CLUTCH FLUID: HYDRAULIC CLUTCH, Inspect Fluid
Engine oil drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.5 ENGINE OIL AND FILTER, Changing Oil and Oil Filter
Fork bracket pinch bolt, lower	30-35 ft-lbs	40.7-47.5 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FXSB
Fork bracket pinch bolt, lower	30-35 ft-lbs	40.7-47.5 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FXSB
Fork bracket pinch screw, upper: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS	25-30 ft-lbs	33.9-40.7 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS
Fork bracket pinch screws, lower: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS	55-60 ft-lbs	74.6-81.4 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS
Fork stem nut, FXSB	70-80 ft-lbs	94.9-108.4 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FXSB
Fork stem nut: FXSB	70-80 ft-lbs	94.9-108.4 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FXSB
Headlamp horizontal adjustment fastener	30-35 ft-lbs	40.7-47.5 Nm	1.19 HEADLAMP ALIGNMENT, Headlamp Adjustment
Headlamp vertical adjusting bolt: Except FXSB	35-45 ft-lbs	47.5-61.0 Nm	1.19 HEADLAMP ALIGNMENT, Headlamp Adjustment
Headlamp vertical adjusting bolt: FXSB	25-30 ft-lbs	33.9-40.7 Nm	1.19 HEADLAMP ALIGNMENT, Headlamp Adjustment
Primary chaincase drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.8 PRIMARY CHAINCASE LUBRICANT, Change Primary Chaincase Lubricant
Rear back panel screw	20-30 <b>in-lbs</b>	2.3-3.4 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS
Spark plug	12-18 ft-lbs	16.3-24.4 Nm	1.16 SPARK PLUGS, Installation
Spoke nipple	55 <b>in-lbs</b>	6.2 Nm	1.7 TIRES AND WHEELS, Wheel Spokes
Starter nut	70-90 <b>in-lbs</b>	7.9-10.2 Nm	1.18 BATTERY MAINTENANCE, Battery Installation and Connection
Transmission drain plug	14-21 ft-lbs	19.0-28.5 Nm	1.9 TRANSMISSION LUBRICANT, Change Transmission Lubricant
Transmission filler plug/dipstick	25-75 <b>in-lbs</b>	2.8-8.5 Nm	1.9 TRANSMISSION LUBRICANT, Check Transmission Lubricant
Transmission filler plug/dipstick	25-75 <b>in-lbs</b>	2.8-8.5 Nm	1.9 TRANSMISSION LUBRICANT, Change Transmission Lubricant
Windshield mounting screw	96-120 <b>in-lbs</b>	10.8-13.6 Nm	1.17 STEERING HEAD BEARINGS, Adjustment: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS

## SERVICING A NEW MOTORCYCLE

### !WARNING

Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)

Perform necessary set-up tasks before customer delivery. See applicable model year predelivery and set-up instructions.

The performance of new motorcycle initial service is required to keep warranty in force and to verify proper emissions systems operation. See 1.4 MAINTENANCE SCHEDULE.

## SAFE OPERATING MAINTENANCE

### NOTES

- Do not attempt to tighten engine head bolts or engine damage may result.
- During the initial break-in period, use only GENUINE HARLEY-DAVIDSON H-D 360 MOTORCYCLE OIL 20W50. Failure to use the recommended oil results in improper break-in of the engine cylinders and piston rings.

Inspect motorcycle regularly for more maintenance needs. Routinely check components between regular maintenance intervals. Always inspect motorcycle after periods of storage before riding.

Check:

1. Tires for correct pressure, excessive wear or any signs of tire damage.
2. Drive belt tension and condition.
3. Brakes, steering and throttle for responsiveness.
4. Brake fluid level and condition. Hydraulic lines and fittings for leaks.
5. Check brake pads and discs for wear.
6. Cables for fraying, crimping and free operation.
7. Engine oil and transmission fluid levels.
8. Headlamp, auxiliary/fog lamp, tail lamp, stop lamp, horn and turn signal operation.

## DISPOSAL AND RECYCLING

Help protect our environment! Many communities maintain facilities for recycling used fluids, plastics and metals. Dispose of or recycle used oil, lubricants, fuel, coolant, brake fluid and batteries in accordance with local regulations. Many Harley-Davidson parts and accessories are made of plastics and metals which can also be recycled.

## SHOP PRACTICES

### Repair Notes

General maintenance practices are given in this section.

### NOTES

- Repair = Disassembly/Assembly.
- Replacement = Substitute a new part for existing component.

All special tools and torque values are noted at the point of use.

All required parts or materials can be found in the parts catalog.

## Safety

Safety is always the most important consideration when performing any job.

- Always have a complete understanding of the task.
- Use common sense.
- Use the proper tools.
- Protect yourself and bystanders with approved eye protection.

Do not just do the job, do the job safely.

## Removing Parts

Always consider the weight of a part when lifting. Use a hoist whenever necessary. Do not lift heavy parts by hand. If a hoist and adjustable lifting beam or sling are needed to remove some parts, verify that:

- The lengths of multiple chains or cables from the hoist to the part are equal and parallel.
- Slings, chains and cables are positioned directly over the center of the part.
- No obstructions interfere with the lifting operation.
- Parts are not left suspended.

### !WARNING

Be sure to check capacity rating and condition of hoists, slings, chains and cables before use. Exceeding capacity ratings or using lifting devices that are in poor condition can lead to an accident, which could result in death or serious injury. (00466c)

Always use blocking or proper stands to support the part that has been hoisted. If a part cannot be removed, verify that all bolts and attaching hardware have been removed. Verify that no parts are in the way of the part being removed.

When removing hoses, wiring or tubes, always tag each part to verify proper installation.

## Cleaning

Always clean around lines or covers before they are removed. Plug, tape or cap holes and openings to keep out dirt, dust and debris. Clean and inspect all parts as they are removed. Verify that all holes and passages are clean and open. After cleaning, cover all parts with clean lint-free cloth, paper or other material. Verify that the part is clean when installed.

Thoroughly clean all parts to be reused before assembly. Clean parts promote better component operation and longer life. Seals, filters and covers used in this vehicle keep out

extraneous dirt and dust. Keep these items in good condition to guarantee satisfactory operation.

When instructed to clean fastener threads or threaded holes, always:

- Clean all threadlocking material from fastener threads and threaded holes.
- Use a wire brush to clean fastener threads.
- Use a thread chaser or other suitable tool to clean threaded holes.
- Use PJ1 cleaner or equivalent to remove all traces of oil and contaminants from threads.
- Clear all threaded holes with low pressure compressed air.

Always verify cleanliness of blind holes before assembly. Tightening a screw with dirt, water or oil in the hole can cause castings to crack or break.

## Disassembly and Assembly

Always assemble or disassemble one part at a time. Do not work on two assemblies simultaneously. Make all necessary adjustments. Inspect your work when finished to verify that everything is done.

Operate the vehicle to perform any final check or adjustments. If all is correct, the vehicle is ready to go back to the customer.

## Checking Torques on Fasteners

Check torque using a torque wrench set to the minimum specification for that fastener. If the fastener does not rotate, the fastener torque has been maintained. If the fastener rotates, remove it to determine if it has a threadlocking agent.

If it has a threadlocking agent, clean all material from the threaded hole. Replace the fastener with a **new** one or clean the original fastener threads and apply the appropriate threadlocking product. Install and tighten the fastener to specification.

If the fastener does not use a threadlocking agent, install and tighten it to specification.

## Magnetic Parts Trays

Magnetic parts trays are common in the service facility. They are convenient and can keep parts from becoming lost during a repair procedure. However, hardened steel parts can become magnetized when held in magnetic parts trays.

Metal fragments from normal wear are usually trapped in the oil filter or by the magnetic drain plug. Magnetized parts in the engine can retain these fragments, potentially causing accelerated engine wear and damage.

Never place parts from inside the vehicle's powertrain on a magnetic parts tray.

## REPAIR AND REPLACEMENT PROCEDURES

### Hardware and Threaded Parts

Install thread repair inserts when threaded holes in castings are stripped, damaged or not capable of withstanding specified torque.

Replace bolts, nuts, studs, washers, spacers and small common hardware if missing or damaged. Clean up or repair minor thread damage with a suitable tap or die.

Replace all damaged or missing lubrication fittings.

Use LOCTITE 565 THREAD SEALANT on pipe fitting threads.

## Threadlocking Agents

Always follow specific service manual procedures when working with fasteners containing preapplied threadlocking agents when fastener replacement is recommended. When reusing fasteners containing threadlocking agents, thoroughly clean all fasteners and threaded holes. Always use the recommended threadlocking agent for the specific procedure.

## Wiring, Hoses and Lines

Replace hoses, clamps, electrical wiring, electrical switches or fuel lines if they do not meet specifications.

## Instruments and Gauges

Replace damaged or defective instruments and gauges.

## Bearings

Always use the proper tools and fixtures when servicing bearings.

Anti-friction bearings must be handled in a special way. To keep out dirt and abrasives, cover the bearings as soon as they are removed from the package.

When bearings are installed against shoulders, always verify that the chamfered side of the bearing faces the shoulder. Lubricate bearings and all metal contact surfaces before pressing into place. Only apply pressure on the part of the bearing that makes direct contact with the mating part. Install bearings with numbered side facing out.

Only remove bearings if necessary. Removal usually damages bearings requiring replacement with **new** parts.

## Bushings

Do not remove a bushing unless damaged, excessively worn or loose in its bore. Press out bushings requiring replacement.

When pressing or driving bushings, always apply pressure in line with the bushing bore. Use a bearing/bushing driver or a bar with a smooth, flat end. Never use a hammer to drive bushings.

Verify that all oil holes are properly aligned during installation.

## Gaskets

Always discard gaskets after removal. Replace with **new** gaskets. Never use the same gasket twice. Verify that gasket holes match up with holes in the mating part. Be aware that sections of a gasket may be used to seal passages.

## Lip-Type Seals

Lip seals are used to seal oil or grease and are usually installed with the sealing lip facing the contained lubricant. Seal orientation, however, may vary under different applications.

Do not remove seals unless necessary. Only remove seals to gain access to other parts or if seal damage or wear dictates replacement.

Leaking oil or grease usually means that a seal is damaged. Replace leaking seals to prevent overheated bearings.

Always discard seals after removal. Do not use the same seal twice.

## O-Rings

Always discard O-rings after removal. Since many O-rings are similar in size and appearance, always use **new** O-rings, keeping them packaged until use to avoid confusion. To prevent leaks, lubricate the O-rings before installation with the same type of lubricant as that being sealed. Verify that all gasket, O-ring and seal mating surfaces are thoroughly clean before installation.

## Gears

Always check gears for damaged or worn teeth.

Remove burrs and rough spots with a honing stone or crocus cloth before installation.

Lubricate mating surfaces before pressing gears on shafts.

## Shafts

If a shaft does not come out easily, check that all nuts, bolts or retaining rings have been removed. Check to see if other parts are in the way before using force to remove.

Shafts fitted to tapered splines should be very tight. If shafts are not tight, disassemble and inspect tapered splines. Discard parts that are worn. Verify that tapered splines are clean, dry and free of burrs before putting them in place. Press mating parts together tightly.

Clean all rust from the machined surfaces of **new** parts.

## Part Replacement

### WARNING

**Harley-Davidson parts and accessories are designed for Harley-Davidson motorcycles. Using non-Harley-Davidson parts or accessories can adversely affect performance, stability or handling, which could result in death or serious injury. (00001b)**

Always install **new** genuine Harley-Davidson parts and accessories. This provides best service life and maintain compliance with noise and emissions regulations.

Installing non-Harley-Davidson, off-road or competition parts can void warranty or result in an unsafe vehicle.

## CLEANING

### Protecting Rubber Parts

Before cleaning, protect rubber parts (such as hoses, boots and electrical insulation) from cleaning solutions. Use a grease-proof barrier material. Remove the rubber part if it cannot be properly protected.

### Cleaning Process

Any cleaning method may be used as long as it does not result in parts damage. Thorough cleaning is necessary for proper parts inspection. Strip rusted paint areas to bare metal before priming and repainting.

Never use cleaners containing chlorine or ammonia on plastic parts. Chlorine causes parts to become distorted and brittle resulting in cracks. Ammonia causes cloudiness and brittleness in windshields and non-painted parts to form a white haze.

## Rust or Corrosion Removal

Remove rust and corrosion with a wire brush, abrasive cloth, sand blasting, vapor blasting or rust remover. Use buffing crocus cloth on highly polished parts that are rusted.

## Bearings

Wash bearings in a non-flammable petroleum cleaning solution. Never use a solution that contains chlorine. Knock out packed lubricant by tapping the bearing against a wooden block. Wash bearings again.

### WARNING

**Using compressed air to "spin dry" bearings can cause bearing to fly apart, which could result in death or serious injury. (00505b)**

Cover bearings with a clean shop towel and allow to air dry. Do not spin bearings while they are drying. Never use compressed air to dry bearings.

When dry, coat bearings with clean oil. Wrap bearings in clean paper.

## TOOL SAFETY

### Air Tools

- Always use approved eye protection equipment when performing any task using air-operated tools.
- On all power tools, use only recommended accessories with proper capacity ratings.
- Do not exceed air pressure ratings of any power tools.
- Place bits against work surface before air hammers are operated.
- Disconnect the air supply line to an air hammer before attaching a bit.
- Never point an air tool at yourself or another person.
- Protect yourself and bystanders with approved eye protection.

### Wrenches

- Never use an extension on a wrench handle.
- If possible, always pull on a wrench handle and adjust your stance to prevent a fall if something suddenly releases.
- Always keep the wrench squarely installed on the fastener.
- Never use a hammer on any wrench other than a STRIKING FACE wrench.
- Discard any wrench with damaged or battered points.
- Never use a pipe wrench to bend, raise or lift a pipe.

## Pliers/Cutters/Pry Bars

- Plastic- or vinyl-covered pliers handles are not intended to act as insulation. Do not use them on live electrical circuits.
- Do not use pliers or cutters for cutting hardened wire unless they were designed for that purpose.
- Always cut at right angles.
- Do not use any pry bar as a chisel, punch or hammer.

## Hammers

- Never strike a hammer against a hardened object, such as another hammer.
- Always grasp a hammer handle firmly, close to the end.
- Strike the object with the full face of the hammer.
- Never work with a hammer which has a loose head or cracked handle.
- Discard hammer if face is chipped or mushroomed.
- Wear approved eye protection when using striking tools.
- Protect yourself and bystanders with approved eye protection.

## Punches/Chisels

- Never use a punch or chisel with a chipped or mushroomed end. Dress mushroomed chisels and punches with a grinder.
- Hold a chisel or a punch with a tool holder if possible.
- When using a chisel on a small piece, clamp the piece firmly in a vise and chip toward the stationary jaw.
- Always wear approved eye protection when using these tools.
- Protect yourself and bystanders with approved eye protection.

## Screwdrivers

- Do not use a screwdriver for prying, punching, chiseling, scoring or scraping.
- Use the right type of screwdriver for the job. Match the tip of a screwdriver to the fastener.
- Do not interchange POZIDRIV, PHILLIPS or REED AND PRINCE screwdrivers.
- Screwdriver handles are not intended to act as insulation. Do not use them on live electrical circuits.
- Do not use a screwdriver with rounded edges because it will slip. Redress with a grinder.

## Ratchets and Handles

- Periodically clean and lubricate ratchet mechanisms with a light grade oil. Do not replace parts individually. Rebuild ratchets with the entire contents of service kit.
- Never hammer on a ratchet or put a pipe extension on a ratchet handle for added leverage.
- Always support the ratchet head when using socket extensions. Do not put your hand on the head or you may interfere with the action of its reversing mechanism.
- When breaking a fastener loose, apply a small amount of pressure as a test to make sure that the ratchet's gear wheel is engaged with the pawl.

## Sockets

- Never use hand sockets on power or impact wrenches. Select only impact sockets for use with air or electric impact wrenches.
- Select the right size socket for the job.
- Always keep the wrench or socket squarely on the fastener.
- Replace sockets showing cracks or wear.
- Keep sockets clean.
- Always use approved eye protection when using power or impact sockets.

## Storage Units

- Do not open more than one loaded drawer at a time. Close each drawer before opening another to prevent the cabinet from unexpectedly tipping over.
- Close lids and lock drawers and doors before moving storage units.
- Do not pull on a tool cabinet. Always push tool cabinets in front of you.
- Set the brakes on the locking casters after the cabinet has been rolled into position.

# FUEL AND OIL

## FUEL

Always use a good quality unleaded gasoline. Octane ratings are usually found on the pump. Refer to Table 1-1.

### WARNING

**Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)**

### WARNING

**Use care when refueling. Pressurized air in fuel tank can force gasoline to escape through filler tube. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00029a)**

Modern service station pumps dispense a high flow of gasoline into a motorcycle fuel tank. This can cause air entrapment and pressurization.

Table 1-1. Octane Rating

SPECIFICATION	RATING
Pump Octane (R+M)/2	91 (95 RON)

## GASOLINE BLENDS

Your motorcycle was designed to get the best performance and efficiency using unleaded gasoline. Most gasoline is blended with alcohol and/or ether to create oxygenated blends. The type and amount of alcohol or ether added to the fuel is important.

### NOTICE

**Do not use gasoline that contains methanol. Doing so can result in fuel system component failure, engine damage and/or equipment malfunction. (00148a)**

- Gasoline/METHYL TERTIARY BUTYL ETHER (MTBE) blends are a mixture of gasoline and as much as 15 percent MTBE. Gasoline/MTBE blends use in your motorcycle is approved.
- ETHANOL fuel is a mixture of ethanol (grain alcohol) and unleaded gasoline and can have an impact on fuel mileage. Fuels with an ethanol content of up to 10 percent may be used in your motorcycle without affecting vehicle performance. U.S. EPA regulations currently indicate that fuels with 15 percent ethanol (E15) are restricted from use in motorcycles at the time of this publication. Some motorcycles are calibrated to operate with higher ethanol concentrations to meet the fuel standards in certain countries.
- REFORMULATED OR OXYGENATED GASOLINES (RFG) describes gasoline blends that are specifically

designed to burn cleaner than other types of gasoline. This results in fewer tailpipe emissions. They are also formulated to evaporate less when filling the tank. Reformulated gasolines use additives to oxygenate the gas. Your motorcycle will run normally using this type of fuel. Harley-Davidson recommends using it whenever possible as an aid to cleaner air in our environment.

- Do not use racing fuel or fuel containing methanol. Use of these fuels will damage the fuel system.
- Using fuel additives other than those approved for use by Harley-Davidson may damage the engine, fuel system and other components.

Some gasoline blends might adversely affect starting, driveability or fuel efficiency. If any of these problems are experienced, try a different brand of gasoline or gasoline with a higher octane blend.

## ENGINE LUBRICATION: TWIN CAM 103

### CAUTION

**Prolonged or repeated contact with used motor oil may be harmful to skin and could cause skin cancer. Promptly wash affected areas with soap and water. (00358b)**

### CAUTION

**If engine oil is swallowed, do not induce vomiting. Contact a physician immediately. In case of contact with eyes, immediately flush with water. Contact a physician if irritation persists. (00357d)**

### NOTICE

**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**

Engine oil is a major factor in the performance and service life of the engine. Use the proper grade of oil for the lowest temperature expected before the next oil change. Refer to Table 1-2.

This motorcycle was originally equipped with GENUINE HARLEY-DAVIDSON H-D 360 MOTORCYCLE OIL 20W50. H-D 360 is the preferred oil under normal operating conditions. If operation under extreme cold or heat are expected, refer to Table 1-2 for alternative choices.

If H-D 360 is not available, add oil certified for diesel engines. Acceptable designations include: CH-4, CI-4 and CJ-4. The preferred viscosities, in descending order are: 20W50, 15W40 and 10W40.

At the first opportunity, see an authorized dealer to change back to 100 percent Harley-Davidson oil.

**Table 1-2. Recommended Engine Oils**

TYPE	VISCOSITY	RATING	LOWEST AMBIENT TEMPERATURE	COLD-WEATHER STARTS BELOW 50 °F (10 °C)
Screamin' Eagle SYN3 Full Synthetic Motorcycle Lubricant	SAE 20W50	HD 360	Above 30 °F (-1 °C)	Excellent
Genuine Harley-Davidson H-D 360 Motorcycle Oil	SAE 20W50	HD 360	Above 40 °F (4 °C)	Good
Genuine Harley-Davidson H-D 360 Motorcycle Oil	SAE 50	HD 360	Above 60 °F (16 °C)	Poor
Genuine Harley-Davidson H-D 360 Motorcycle Oil	SAE 60	HD 360	Above 80 °F (27 °C)	Poor
Genuine Harley-Davidson H-D 360 Motorcycle Oil	SAE 10W40	HD 360	Below 40 °F (4 °C)	Excellent

## **ENGINE LUBRICATION: TWIN CAM 110**

### **CAUTION**

**Prolonged or repeated contact with used motor oil may be harmful to skin and could cause skin cancer. Promptly wash affected areas with soap and water. (00358b)**

### **CAUTION**

**If engine oil is swallowed, do not induce vomiting. Contact a physician immediately. In case of contact with eyes, immediately flush with water. Contact a physician if irritation persists. (00357d)**

### **NOTICE**

**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**

SCREAMIN' EAGLE SYN3 FULL SYNTHETIC MOTORCYCLE LUBRICANT 20W50 is provided for engine lubrication.

If SYN3 is not available, use GENUINE HARLEY-DAVIDSON H-D 360 20W50 MOTORCYCLE OIL. Although H-D 360 is compatible with SYN3, we suggest the mixture of fluids be changed as soon as possible.

If H-D 360 is not available, the third choice is an oil certified for diesel engines. Acceptable diesel engine oil designations include: CH-4, CI-4 and CJ-4. The preferred viscosities for

diesel engine oils, in descending order are: 20W50, 15W40 and 10W40.

We again suggest the mixture of the fluids be changed as soon as possible. At the first opportunity, see a Harley-Davidson dealer to change back to 100 percent Harley-Davidson oil. DO NOT add diesel engine oil to the primary chaincase or transmission.

To switch lubricant to H-D 360, completely drain the SYN3 before filling with H-D 360. It is not required to flush out any residual lubricant. Refer to Table 1-2.

## **WINTER LUBRICATION**

Change engine oil often in colder climates. If motorcycle is frequently used for trips less than 15 mi (24 km), in ambient temperatures below 60 °F (16 °C), reduce oil change intervals to 1500 mi (2400 km).

### **NOTE**

*Lower ambient temperatures require more frequent oil changes.*

Water vapor is a normal by-product of combustion. During cold-weather operation, some water vapor condenses to liquid form on the cool surfaces inside the engine. In freezing weather this water becomes slush or ice. If the engine is not warmed to operating temperature, accumulated slush or ice blocks the oil lines and causes engine damage. Over time, water will accumulate, mix with the engine oil and form a sludge that is harmful to the engine.

If the engine is allowed to warm to normal operating temperature, most of the water evaporates and exits through the crankcase breather.

**Thank you so much for reading.**

**Please click the “Buy Now!”  
button below to download the  
complete manual.**

***Buy Now***



**After you pay.**

**You can download the most  
perfect and complete manual in  
the world immediately.**

**Our support email:**

**ebooklibonline@outlook.com**