

Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## Disassembly and Assembly

### C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i02848648

## Flywheel Housing - Remove and Install

SMCS - 1157-010

### Removal Procedure (Engines with Flywheel Housing)

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	138-7573	Link Bracket	1

#### Start By:

- a. Remove the flywheel. Refer to Disassembly and Assembly, "Flywheel - Remove".

---

#### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

1. Support the engine with a suitable lifting device or support the engine on blocks that are positioned on a flat level surface.
  2. Install tool (A) and a suitable lifting device to the flywheel housing. Support the weight of the housing (2).
-




Illustration 1  
Typical example

g01123577

3. Remove the setscrews (1) that fasten the flywheel housing (2) to the cylinder block.




Illustration 2

g01126979

4. Use the tool (A) and the lifting device to remove the flywheel housing (2) from the engine.

# Installation Procedure (Engines with Flywheel Housing)

Table 2

Required Tools			
Tool	Part Number	Part Description	Qty
A	138-7573	Link Bracket	1


---

## NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---




---

Illustration 3

g01123556

Typical example

1. Clean the mating face of the flywheel housing (2). Inspect the crankshaft rear seal (4) for leaks. Inspect the dowels (5) for damage. If the crankshaft rear seal or the dowels are damaged, use new parts for replacement. Refer to Disassembly and Assembly, "Crankshaft Rear Seal - Remove" and Disassembly and Assembly, "Crankshaft Rear Seal - Install".
-



---

Illustration 4

g01126979

Typical example

2. Use tool (A) and the lifting device to align the flywheel housing (2) to the dowels (5). Install the flywheel housing to the engine.
3. Install the setscrews (1) that fasten the flywheel housing to the cylinder block.

For C1.1 engines, tighten the setscrews to a torque of 50 N·m (37 lb ft). For C1.5 and C2.2 engines, tighten the setscrews to a torque of 25 N·m (18 lb ft).

4. Remove tool (A) and the lifting device from the flywheel housing.

**End By:**

- a. Install the flywheel. Refer to Disassembly and Assembly, "Flywheel - Install".
-

Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## Disassembly and Assembly C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i02848649

# Crankshaft Pulley - Remove and Install

SMCS - 1205-010

## Removal Procedure

### Start By:

- a. Remove the fan drive belt. Refer to Disassembly and Assembly, "V Belts Remove and Install" for more information.

Table 1

Required Tools			
Tool	Part Number	Description	Qty
A	8S-2264	Puller Group	1
	6V-3668	Bolt	3

---




Illustration 1

g00827213

1. Remove the nut (5) and the washer (3) from the crankshaft pulley (2).




Illustration 2

g00827241

2. Install tool (A). Use tool (A) in order to remove the crankshaft pulley (2) from the crankshaft (4).

3. Remove the woodruff key (1) from the crankshaft (4).

## Installation Procedure




Illustration 3

g00827213

**Note:** Inspect the following components for damage: the taper of the crankshaft, the woodruff key and the bore of the crankshaft pulley. Replace any components that are damaged. Ensure that the taper of the crankshaft and the bore of the crankshaft pulley are clean and dry before assembly.

1. Install the woodruff key (1) to the crankshaft (4).
2. Install the crankshaft pulley (2) to the crankshaft (4).
3. Install the washer (3) to the crankshaft (4).
4. Lubricate the nut (5) with clean engine oil and install the nut.

For C1.1 engines, tighten the nut (5) to a torque of 123 N·m (91 lb ft). For C1.5 and C2.2 engines, tighten the nut (5) to a torque of 304 N·m (224 lb ft).

### End By:

- a. Install the V-belt to the engine. Refer to Disassembly and Assembly, "V Belts Remove and Install".
-

Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## Disassembly and Assembly C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i02237294

### Crankshaft Front Seal - Remove

SMCS - 1160-011

### Removal Procedure for the Front Oil Seal that is Installed in the Engine

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1U-8145	Drill Bit	1
B	1U-7600	Slide Hammer Puller Gp	1

#### Start By:

- Remove the crankshaft pulley. Refer to Disassembly and Assembly, "Crankshaft Pulley - Remove and Install".

---

#### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

#### NOTICE




Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

Dispose of all fluids according to local regulations and mandates.

---




---

Illustration 1  
typical example

g00827263

1. Use Tooling (A) and carefully drill three evenly spaced holes (1) in crankshaft front seal (2).
-



---

Illustration 2

g01037807

Typical example

2. Carefully remove the crankshaft front seal by alternating the position of Tooling (B) from one hole to another hole. This will allow you to evenly remove the crankshaft front seal from housing (3).

**Note:** Do not damage the flange of the crankshaft during the removal process of the crankshaft front seal.

---

### NOTICE

**Ensure that the main lip is used in order to remove the crankshaft front seal. Do not damage the edge of the housing for the crankshaft front seal.**

---

## Removal Procedure for the Front Oil Seal from a Disassembled Front Cover

### Start By:

- a. Remove the crankshaft pulley. Refer to Disassembly and Assembly, "Crankshaft Pulley - Remove and Install".
- b. Remove the housing (Front). Refer to Disassembly and Assembly, "Housing (Front) - Remove".

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

### **NOTICE**

**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.**

**Dispose of all fluids according to local regulations and mandates.**

---

1. If the front cover has been removed from the engine, use a suitable hydraulic press in order to remove the oil seal from the front cover. Ensure that the front cover is supported correctly in order to prevent damage to the cover while the oil seal is being removed.
- 

### **NOTICE**

**Ensure that the main lip is used in order to remove the crankshaft front seal. Do not damage the edge of the housing for the crankshaft front seal.**

---

---

Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## Disassembly and Assembly C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i02237296

# Crankshaft Front Seal - Install

SMCS - 1160-012

## Installation Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	5P-3537	Seal Guide	1

---


### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---



---

Illustration 1  
typical example

g01128190

1. Clean housing (3) for crankshaft front seal (2) and inspect the housing for any damage.
2. Lubricate the lip of crankshaft front seal (2) with clean engine oil.
3. Position crankshaft front seal (2) in housing (3) for the crankshaft front seal.

---

### NOTICE

**Ensure that the lip of the crankshaft front seal that is spring loaded is facing toward the inside of the front housing and that it is square with the bore of the housing for the crankshaft front seal.**

---

4. Use Tooling (A) to install new crankshaft front seal (2).
5. Apply clean engine oil on the area of the crankshaft pulley that will be in contact with crankshaft front seal (2).

### End By:

- a. Install the crankshaft pulley. Refer to Disassembly and Assembly, "Crankshaft Pulley - Remove and Install".
-

Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## **Disassembly and Assembly C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines**

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i03631161

### **Housing (Front) - Remove**

SMCS - 1151-011

### **Removal Procedure**

#### **Start By:**

- A. Remove the fuel injection pump. Refer to Disassembly and Assembly, "Fuel Injection Pump - Remove".
- B. Remove the crankshaft pulley. Refer to Disassembly and Assembly, "Crankshaft Pulley - Remove and Install".

---

#### **NOTICE**

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

#### **NOTICE**

**If the front housing is not installed, do not turn the crankshaft.  
Damage to the engine may occur.**

---


---

#### **NOTICE**

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.



Typical example

1. Remove the setscrews and the nuts (5) from the front housing (4) .
2. Turn the mechanical stop lever (3) to the full clockwise position so that the spring is held under tension.
3. Remove the front housing (4) from the front of cylinder block (6) .

**Note:** Identify the position of the locating pin (2) and the locating hole (1) for installation.

4. Remove the joint for the front housing (not shown). Discard the joint.
  5. Inspect the front housing assembly (4) for wear or damage. If the front housing assembly is damaged, use new parts for replacement.
-



Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## **Disassembly and Assembly C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines**

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i05967169

### **Housing (Front) - Disassemble**

SMCS - 1151-015

### **Disassembly Procedure**

#### **Start By:**

- a. Remove the engine front housing. Refer to Disassembly and Assembly, "Housing (Front) - Remove".

---

#### **NOTICE**

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

#### **NOTICE**

**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.**

**Dispose of all fluids according to local regulations and mandates.**

---



## **WARNING**

**Personal injury can result from being struck by parts propelled by a released spring force.**

**Make sure to wear all necessary protective equipment.**

**Follow the recommended procedure and use all recommended tooling to release the spring force.**

---

**Note:** If the original front housing will be replaced by a different item, refer to Systems Operation, Testing and Adjusting, "Governor" before disassembling the front housing.

### **Removal of the Throttle Control**

---




Illustration 1

g01114167

Typical example

1. Remove the spring (5) from the lever (8) for the throttle control.
2. Loosen the nut (1) and the bolt (4) that secures the arm (3) to the lever (8) for the throttle control.

**Note:** Identify the position of the arm in relation to the lever for installation. Do not remove the nut (1) and the washers (2) from the bolt (4).

3. Remove the arm (3) from the lever (8).
4. Remove the C-clip (6) from the lever (8).
5. Remove the lever (8) from the front housing (9).
6. Remove the O-ring (7) from lever (8). Discard the O-ring.

7. Check the components for wear or damage. Replace any components that are worn or damaged.

## Removal of the Stop Control



**Personal injury can result from being struck by parts propelled by a released spring force.**

**Make sure to wear all necessary protective equipment.**

**Follow the recommended procedure and use all recommended tooling to release the spring force.**




Illustration 2

g01114517

Typical example

1. Remove the nut (16) and remove the washer (17) that secures the lever (18) to the arm (24) for the stop control.
2. Remove the lever (18) from the arm (24) for the stop control.

**Note:** Identify the position of the lever (18) on the shaft (24) for installation.

3. Remove the nut (19) from the arm (24) for the stop control. Remove the washer (20) and remove the spring (21) from the arm (24).
4. Remove the arm (24) for the stop control from the front housing.
5. Remove the C-clip (23) and the O-ring (22) from the arm (24). Discard the O-ring.

## Removal of the PTO Cover




Illustration 3  
Typical example

g01114513

1. Remove the nuts (25) and the bolts (31) from the PTO cover.
2. Remove the plates (26) and (30).
3. Remove the joint (27) and discard the joint.
4. Remove the O-ring (29). Discard the O-ring.
5. Check the condition of all parts. Replace any parts that are damaged or worn.

Product: COMPACTOR

Model: CB-22B COMPACTOR 2B2

Configuration: CB22B Compactor 2B200001-UP (MACHINE) POWERED BY C1.5 Engine

## Disassembly and Assembly C1.1, C1.5 and C2.2 Engines for Caterpillar Built Machines

Media Number -KENR8103-03

Publication Date -01/02/2015

Date Updated -09/06/2016

i02736676

## Housing (Front) - Assemble

SMCS - 1151-016

## Assembly Procedure


Table 1

Required Tools		
Tool	Part Number	Part Description
A	9S-3263	Thread Lock Compound

**Note:** If the engine front housing is replaced, ensure that a new emissions label is installed.

## Installation of the Throttle Control

---



---

Illustration 1  
Typical example

g01114382

1. Install the O-ring (6) to the shaft of the lever (7).
2. Lubricate the O-ring (6) and the shaft of the lever (7) with clean engine oil. Install the lever (7) into the front housing (8).
3. Install the C-clip (5) onto the shaft of the lever (7).
4. Install the arm for the throttle control (3) onto the lever (7). Tighten the nut (1) and bolt (4) to a torque of 9 N·m (7 lb ft).

## Installation of the Stop Control

---

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)