

Product: VIBRATORY COMPACTOR

Model: CS-44B VIBRATORY COMPACTOR CS3

Configuration: CS44B, CP44B Vibratory Soil Compactor CS300001-UP (MACHINE) POWERED BY C3.4 Engine

Disassembly and Assembly CP44B and CS44B Vibratory Soil Compactors Machine Systems

Media Number -UENR6599-05

Publication Date -01/08/2015

Date Updated -23/05/2017

i07021168

Axle (with Brakes) - Disassemble

SMCS - 3260-015; 3278-015

Disassembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	8B-7551	Bearing Puller Gp	1
B	220-8428	Spanner Wrench	1
C	1P-0523	Driver Gp.	1
D	-	Loctite 270	-

Start By:

- a. Remove the axle.
 1. Drain the oil from the differential into a suitable container. The capacity of the differential is approximately 12 L (3 US gal).
 2. Remove the bolts and the axle propel motor from the gearbox. Install the cover and the bolts.
-




Illustration 1

g06164352

3. Drain the oil from the wheel hub into a suitable container. The capacity of the wheel hub is approximately 1.3 L (0.3 US gal).
4. Remove screws (2) and end cover (1).




Illustration 2

g06164360

5. Remove bolts (3), washers (4), planetary gears (5), and the 84 needle bearings from end cover (1).




Illustration 3

g06164369

6. Remove O-ring seal (9) from ring gear (6).
7. Remove shaft (7).
8. Remove bolts (8).



Illustration 4

g06164370

9. Install two bolts (10) to ring gear (6), as shown. Turn the bolts evenly in order to remove the ring gear (6). Discard bolts (10).




Illustration 5

g06164377

10. Using Tooling (A) remove hub (12).
 11. Remove the lip seal and bearing (11) from hub (12).
-




Illustration 6

g06164394

12. Use two people to remove housing (14). The weight of housing (14) is approximately 41 kg (90 lb). Remove bolts (15) and housing (14).
13. Remove bearing (13) from housing (14).




Illustration 7

g06164409

14. Remove coupling (16) from shaft (17).
15. Remove steel discs (18), friction discs (19), and shaft (17) from the axle.



Illustration 8

g06164431

16. Attach a suitable lifting device to housing (20). The weight of housing (20) is approximately 50 kg (110 lb). Remove bolts (21) and remove housing (20).
17. Remove gear assembly (22).




Illustration 9

g06164758



Illustration 10

g06164764

 **WARNING**

Sudden release of spring force can cause injury.

To prevent the possibility of injury, follow the procedure to relieve the spring pressure.

18. Remove O-ring seal (25) from housing (20).
19. Put housing (20) in a suitable press. Apply pressure on spring washers (24). Remove retaining ring (23).
20. Release the pressure on spring washers (24) and remove the spring washers (24) from housing (20).




Illustration 11

g06164772




Illustration 12

g06164775

 **WARNING**

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

-
21. Remove retaining rings (26). Remove bolts (28) and piston assemblies (27).
-




Illustration 13

g06164802

22. Remove O-ring seals (29) from piston assemblies (27).




Illustration 14

g06164853

23. Remove bolt (30) and retainer (31).



Illustration 15

g06164858

24. Remove O-ring seals (33) from brake piston (32).
25. Repeat steps to the other side of the axle.
-




Illustration 16

g06164285

26. Drain the oil from the gearbox into a suitable container. The capacity of the gearbox is approximately 1.2 L (0.3 US gal).
27. Remove eight bolts (36) and cover assembly (37).
28. Remove bolts (34) and cover (35).



Illustration 17

g06203548

29. Remove O-ring seal (38) from cover (37).




Illustration 18

g06203561

30. Remove gear (40).

31. Remove gear (39).




Illustration 19

g06203698

32. Use Tooling (A) and a suitable press to remove bearing (41) from gear (39).




Illustration 20

g06203701

33. Use Tooling (A) and a suitable press to remove bearing (42) from gear (39).




Illustration 21

g06203705

34. Use Tooling (A) and a suitable press to remove bearing (43) from gear (22).




Illustration 22

g06204036

 **WARNING**

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

35. Remove retaining ring (45). Use Tooling (A) to remove bearing (44) from gear (22).



Illustration 23

g06203707

36. Remove bolts (47) and remove cover (46).



Illustration 24

g06203934

37. Remove the differential (48).



Illustration 25

g06201230

38. Remove bolts (49) and ring gear (50).



Illustration 26

g06201273

39. Separate the differential (48).




Illustration 27

g06201325

40. Remove clutch pack (51) and spider gear (52).



Illustration 28

g06201333

41. Remove spider gear assembly (53).



Illustration 29

g06201374

42. Remove spider gear (54).



Illustration 30

g06201632

43. Remove clutch pack (55).




Illustration 31

g06201650

44. Note the orientation of friction discs (56) and clutch plates (57).




Illustration 32

g06201692

45. Disassemble spider gears (53).




Illustration 33

g06201696

46. Remove washers (58), spider gears (59), and shaft (60).




Illustration 34

g06201773

47. Use Tooling (B) and a suitable press to remove bearing (61) from differential (48).




Illustration 35

g06198590




Illustration 36

g06198613

48. Straighten tab (62) on locking nut (63). Use Tooling (E) to remove locking nut (63).
49. Remove pinion shaft (64).




Illustration 37

g06201825




Illustration 38

g06201831

50. Use Tooling (A) and a suitable press to remove bearing cone (66) from the pinion shaft (65)
Note: Tooling (A) is on the bearing race.




Illustration 39

g06201883

51. Remove shim (68) and bearing (69) from shaft (67). Note the orientation of the shim for assembly procedure.




Illustration 40

g06201889



Illustration 41

g06201891

52. Remove bearing cups (70) and (71).
-

Product: VIBRATORY COMPACTOR

Model: CS-44B VIBRATORY COMPACTOR CS3

Configuration: CS44B, CP44B Vibratory Soil Compactor CS300001-UP (MACHINE) POWERED BY C3.4 Engine

Disassembly and Assembly CP44B and CS44B Vibratory Soil Compactors Machine Systems

Media Number -UENR6599-05

Publication Date -01/08/2015

Date Updated -23/05/2017

i07021374

Axle (with Brakes) - Assemble

SMCS - 3260-016; 3278-016

Assembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	8B-7551	Bearing Puller Gp	1
B	220-8428	Spanner Wrench	1
C	1P-0523-	Driver Gp.	1
D	—	Loctite 270	—

1. Inspect all parts and clean all parts. If any parts are worn or damaged, use new Caterpillar parts for replacement.
2. Inspect all seals. Damaged seals must be replaced. Use new Caterpillar seals for replacement.



Illustration 1

g06201891



Illustration 2

g06201889

3. Install bearing cups (71) and (70).




Illustration 3

g06201883

4. Install bearing (69) and shim (68) onto shaft (67). Heat the bearing (69) to install.




Illustration 4

g06198613




Illustration 5

g06198590

5. Install pinion shaft (52).
6. Use Tooling (E) to install locking nut. Bend tab (50) on the locking nut.




Illustration 6

g06201696

7. Install spider gears (59) and washers (58) onto shaft (60).




Illustration 7

g06201692

8. Assemble spider gears (53).




Illustration 8

g06201650

9. Install clutch plates (57) and friction discs (56).




Illustration 9

g06201632

10. Install clutch pack (55).



Illustration 10

g06201374

11. Install spider gear (54).



Illustration 11

g06201333

12. Install spider gear assembly (53).




Illustration 12

g06201325

13. Install spider gear (52) and clutch pack (51).



Illustration 13

g06201273

14. Heat bearing (69) to install onto differential (48). Connect the differential (48).
-



Illustration 14

g06201230

15. Install ring gear (50) and install bolts (49).



Illustration 15

g06203934

16. Install the differential (49).



Illustration 16

g06203707

17. Apply Tooling (E) to the axle housing. Install cover (47) and bolts (48). Tighten bolts (48) to a torque of 120 N·m (89 lb ft).

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com