

Product: TRACK-TYPE TRACTOR

Model: D6H TRACK-TYPE TRACTOR 1KD

Configuration: D6H & D6H LGP SERIES II TRACTOR / POWERSHIFT / 1KD05500-UP (MACHINE) POWERED BY 3306 ENGINE

Disassembly and Assembly D6H TRACTOR POWER TRAIN

Media Number -SEN3242-03

Publication Date -01/11/2004

Date Updated -10/01/2017

SEN32420031

Transmission (Direct Drive)


SMCS - 3050-011; 3050-012; 3060-015; 3060-016

Remove Transmission (Direct Drive)


Tools Needed		A	B	C
FT1952	Axle Removal Tool	1		
FT1897	Adapter		1	
5P9736	Link Bracket		3	
8S9906	Ratchet Puller			2
8S9089	Bolt		1	
1F7958	Nut		3	
0S1595	Bolt		2	
5P8245	Washer		2	

Start By:


- a. remove main drive shaft
- b. remove gear shift controls



1. Remove plug (1) from the bottom of the transmission and bevel gear case and drain the power train oil. Loosen the bolts that hold transmission suction screen cover (2) in place and drain the oil from the transmission case. Total oil drained will be approximately **129 liters (33.5 U.S. gal.)**. Install plug (1) and tighten the suction screen cover bolts.




2. Remove drive shaft yoke (2). Use forcing bolts and remove retainer (3) and the O-ring seal from the transmission and bevel gear case.




3. Remove the final drive cover and sun gear retainer from the final drive carrier.

4. Use tooling (A) and remove the inner and outer axle on each side of the machine.



5. Remove the cover and disconnect the two wires from the switch (6). Remove the clamp and move tube (4) out of the way.

6. Loosen bolt (5) and disconnect the linkage from the clutch control valve.



7. Remove the cover and gasket, and install tooling (B). Attach a hoist to tooling (B).
8. Attach tooling (C) to both roller frames and to tooling (B) as shown.

 **WARNING**

Because of the internal ramps, the transmission must roll down; it is necessary to use tooling (C) to control the transmission as it is separated from the transmission and bevel gear case. To prevent possible personal injury, it is necessary to make the transmission roll out slowly until it reaches the roller stops at the end of the tube assemblies.

 **WARNING**


Four bolts (7) fasten the rear cover to the transmission. To prevent possible personal injury, four bolts (7) must be installed to remove the transmission.

9. Remove the 21 bolts that hold the transmission to the transmission and bevel gear case. Four bolts (7) should not be removed because they hold the rear cover to the transmission.

10. The weight of the transmission is **955 kg (2100 lb)**. Use forcing screws if necessary, and separate the transmission from the transmission and bevel gear case. Use tooling (C) and the hoist and slowly roll the transmission out to the roller stops on the tube assemblies.

 **WARNING**

The transmission must be supported when the hoist is moved from the rear tube adapter [tooling (B)] to the top of the transmission. To prevent possible personal injury, make sure the support is on a solid footing so the transmission will not fall when the hoist is removed from tooling (B).



11. Put a floor jack (9) or wood blocks in position to support the transmission. Lower the transmission onto the support.


12. Remove the hoist from tooling (B). Attach the hoist to the top of the transmission. Remove tooling (C). Remove the transmission from the tube assemblies.

13. Remove large diameter O-ring seal (10) from the outer diameter of the transmission case. Remove four O-ring seals (9) and (11) from the transmission and bevel gear case.

Install Transmission

Tools Needed		A	B	C
FT1952	Axle Removal Tool	1		
FT1897	Adapter		1	
5P9736	Link Bracket		3	
8S9906	Ratchet Puller			2
8S9089	Bolt		1	
1F7958	Nut		3	
5P8245	Washer		2	
OS1595	Bolt		2	

1. Put clean oil on all of the O-ring seals.




2. Install O-ring seal (10) onto the transmission. Install four O-ring seals (9) and (11) onto the transmission and bevel gear case.
3. Attach a hoist to the top of the transmission.
4. Put the transmission in position so the rollers are on the tube assemblies.

 **WARNING**

The transmission must be supported when the hoist is moved from the top of the transmission to the rear tube adapter [tooling (B)]. To prevent possible personal injury, make sure the support is on a solid footing so the transmission will not fall when the hoist is removed from the top of the transmission.

5. Put a floor jack or wood blocks in position to support the transmission. Lower the transmission onto the support.
6. Install tooling (B) onto the transmission cover. Attach tooling (C) to both roller frames and tooling (B).




7. Remove the hoist from the top of the transmission and attach it to tooling (B).
8. Keep the transmission level with the hoist. Pull the transmission evenly into the transmission and bevel gear case with tooling (C).

NOTE: It may be necessary to pull the transmission into the pilot diameter with longer bolts.


9. Install bolts (8) that hold the transmission into the transmission and bevel gear case.

10. Remove tooling (C). Remove tooling (B) and install the cover and gasket on the rear of the transmission.




11. Put tube (4) in position. Connect the wires to switch (6) and install the cover. Install the clamp that holds tube (4) in position.

12. Align the key on the shaft with the slot in the lever and install it. Tighten bolt (5).



13. Use two guide bolts and put the O-ring seal and retainer (3) in position. Install the six bolts and tighten them to a torque of $59 \pm 7 \text{ N}\cdot\text{m}$ ($44 \pm 5 \text{ lb ft}$).

14. Install drive shaft yoke (2).



15. Use tooling (A) and install the inner and outer axles on both sides. Make sure the first inner axle is not installed too far, or the opposite side inner axle will not go in far enough.

16. Install the O-ring and the cover on the final drive.

17. Fill the power train system with oil. See the Operation And Maintenance Guide for the correct oil and capacity.

End By:

- a. install main drive shaft
- b. install gear shift controls

Disassemble Transmission (Direct Drive)


Tools Needed		A	B	C	D	E	F	G
5P9736	Link Bracket	1		3				
1A5822	Bolt, 1/2"-13 x 70 mm (2 3/4 in)	1						
5P8245	Washer, 1/2"	2						
1F7958	Nut, 1/2"	1						
1P1863	Pliers		1					
8S9906	Ratchet Puller			1				
6V4072	Spanner				1			
1P2321	Puller					1		
1P510	Driver Group						1	
1P520	Driver Group							1

Tools Needed		H	J	K	L	M	N	O
1P2321	Puller							1
1P510	Driver Group	1						1
8B7551	Bearing Puller	1						
8H663	Bearing Puller		1			1		
8T2838	Spanner			1				
2D1201	Forged Eyebolt, 5/8"				1			
8B7548	Push-Puller Group					1		
5P5197	Pliers						1	
6V9061	Pump Group							1
1P820	Hydraulic Puller							1
8B7549	Legs							2
5F7342	Adapter							2
1B4207	Nut							2
3P465	Plate							4



Tools Needed		P
Tools Needed		P
2P8312	Pliers	1

Start By:

- a. remove transmission (direct drive)
- b. remove clutch




1. Set the transmission on wood blocks.
2. Remove two O-ring seals (2). Remove orifice (1) from the transmission.




3. Install two 1/2 " - 13 x 50.8 mm (2 in) long bolts (4) to hold cover (5) in position when bolts (3) are removed.

4. Remove four bolts (3).

5. Install four 1/2 " - 13 guide bolts (6).




6. Remove the cotter pin and pin (7).



7. The weight of cover (5) with clutch control valve (8) installed is **160 kg (350 lb)**. Separate the cover from the transmission a distance of 25.4 mm (1 in), and install tooling (A).


8. Attach a hoist to tooling (A), and remove cover (5) from the transmission.




9. Remove three O-ring seals (9), one O-ring seal (10), and one O-ring seal (12).


10. Remove two tubes (11) from the plate assembly.

11. Remove the O-ring seals from the two tubes.



12. Remove the eight bolts and three tube assemblies (13).






13. Remove three bolts (15).

14. Remove two bolts (17), tube assembly (14), and the clips.


15. Remove the two bolts and plate (18).

16. Remove bolt (16) and the transmission brake assembly.




17. Remove the two bolts and clips that hold tube assembly (19) in place. Disconnect tube assembly (19) from tube assembly (20), and remove tube assembly (19).

18. Remove the four bolts and tube assembly (20).





19. Remove tube assembly (22) from the transmission.

20. Remove 11 bolts (21) and the shifting assembly from the transmission.



21. Remove support assembly (23) from the shifting assembly.




22. Pull on shafts (25), and remove them from bracket assembly (24).

23. Remove four cotter pins (26).

24. Remove four plungers (27) and four springs (28) from bracket assembly (24).


25. Pins (29) prevent plungers (27) from rotating during operation. Remove pins (29) if necessary.




26. Remove cotter pin (30) and the washer.

27. Remove shaft (31) from bracket assembly (24).



28. Remove pin (33), and remove lever (32) from shaft (31).



29. If necessary, use a hammer and a punch, and remove pins (36). Remove guides (34) and forks (35) from shafts (25).



30. Remove the six bolts and cage assembly (37) and input shaft (38) from the transmission.




31. Use tool (B), and remove retaining ring (39). Remove input shaft (38) from cage (37).

NOTE: Lip-type seal (41) will be damaged if it is removed.

32. If necessary, remove lip-type seal (41) from cage (37).


33. Remove O-ring seal (43) from the cage.

34. Remove spiral retaining ring (42) and bearing (40) from cage (37).




35. Install tooling (C), and attach a hoist. The weight of the transmission is **775 kg (1705 lb)**. Raise the transmission, and remove the six bolts and two support assemblies (44) from the transmission.

36. Use tooling (C), and lower the end of the transmission. Put the transmission in a vertical position on wood blocks. Remove tooling (C).




37. Remove 18 bolts and three cages (45) from the plate assembly.




38. Install tooling (C) onto plate assembly (47), and attach a hoist.

39. Remove 21 bolts (46).


40. The weight of plate assembly (47) with the pinion gear is **100 kg (220 lb)**. Remove plate assembly (47) with the pinion gear from the transmission.



41. Put plate assembly (47) with the pinion gear up on wood blocks.
42. Remove bolt (49) and retainer (50).
43. Remove the bearings and reverse idler gear (48) from the idler shaft.



44. Remove six bolts (52) that hold idler shaft (51) to plate assembly (47).




45. Install two 5P9736 Link Brackets [part of tooling (C)] to the plate assembly, and attach a hoist. Raise plate assembly (47) to be vertical.

46. Remove the four bolts and cover assembly (53).



47. Remove seal ring (54) from cover assembly (53).



48. Bend lockwasher (57) tab away from the groove in nut (56). Use tool (D), and remove nut (56).


49. Remove lockwasher (57) and washer (55) from the pinion assembly.




WARNING

To prevent possible personal injury from parts that may fall, make sure the pinion and gear assembly is supported before cage (58) is removed.

50. The weight of the pinion and gear assembly is **24 kg (53 lb)**. Put a nylon strap around the pinion and gear assembly, and attach a hoist. Use two 3/8 "-16 NC **forcing screws** in cage (58), and remove the bearing assembly, the ring, and cage (58). Remove the pinion and gear assembly from the plate assembly.




51. Use tooling (E) and remove bearing (59), spacer (60), and reverse gear assembly (61) from the pinion assembly.




52. Use tooling (F), and remove bearing (62) from reverse gear assembly (61).




53. Remove collar (64), hub (63) and forward gear assembly (65) from pinion assembly (66).




54. Use tooling (G), and remove bearing (67) from forward gear assembly (65).



55. Remove bearing (68) from pinion assembly (66).




56. Remove input transfer gear shaft (69) with brake plate (70), the input transfer gear, and the bearings from the transmission.



57. Use tooling (H) and a press, and remove bearing (71) and input transfer gear (72) from input transfer gear shaft (69).

58. Remove brake plate (70) from shaft (69).


59. Turn shaft (69) over, and use tooling (J) to remove bearing (73).




60. Bend the tab of lockwasher (75) away from the groove in nut (74). Use tool (K), and loosen nut (74) while preventing the bevel gear from rotating, but do not remove it.

61. The weight of cage (76), the bevel gear, and the shaft is **46 kg (101 lb)**. Put a bar in position, and attach a lifting strap and a hoist.


62. Remove the 13 bolts from cage (76). Use two 1/2 "-13 NC **forcing screws**, and remove cage (76), the shims and the bevel gear from the transmission. Use the bar to counterbalance the weight of the bevel gear and shaft as they are removed.



63. Remove nut (74), lockwasher (75) and the washer from the bevel gear shaft and cage (76).




64. The weight of bevel gear (77) and shaft is **25 kg (55 lb)**. Use tooling (F) and a press, and remove bevel gear (77) and the shaft from cage (76).




65. Remove the 12 bolts that hold bevel gear (77) to bevel gear shaft (78).


66. Use tooling (F) and a press, and remove bevel gear shaft (78) from bevel gear (77).




67. Use tooling (J) and a press, and remove bearing (79) from bevel gear shaft (78).



68. Turn bevel gear shaft (78) over, and use tooling (J), and remove bearing (80) from bevel gear shaft (78).




69. Remove two bearing cups (81) and the ring that goes between them from cage (76).



70. Install tooling (L) into the end of two gear and shaft assemblies (82) and (83). Attach a hoist as shown. The weight of gear and shaft assembly (82) is **86 kg (190 lb)**. The weight of gear and shaft assembly (83) is **75 kg (165 lb)**.


NOTE: Both gear and shaft assemblies (82) and (83) must be removed from transmission case (84) together. The gear and shaft assemblies cannot be removed separately.

71. Slowly, raise both gear and shaft assemblies (82) and (83) at the same time. Move the shaft assemblies slightly to avoid catching on the inside of transmission case (84), and remove them from the transmission case.




72. The following steps are for disassembly of input shaft and gear assembly (83).

a. Use tooling (M), and remove bearing (85) from the input shaft.




b. Use tool (N), and remove retaining ring (87) from input shaft (86).



c. Remove spacer (88), input transfer gear (89), and pinion gear (95) from input shaft (86).


d. Remove spacer (90), pinion gear (96), pinion gear (91), and spacer (97) from the input shaft.

e. Remove pinion gear (92), pinion gear (98), spacer (93), and pinion gear (99) from input shaft (86).




f. If necessary, use tooling (M), and remove bearing (94) from input shaft (86).

g. Use tool (N), and remove retaining ring (100) from the input shaft.




73. The following steps are for disassembly of countershaft and gear assembly (82).

a. Use tool (N), and remove one retaining ring (101) from each end of countershaft and gear assembly (82).




b. Install tooling (O), and remove bearing (102) from the countershaft and gear assembly. Use tooling (O), and remove the bearing at the other end of countershaft and gear assembly (82).




c. Remove reverse pinion gear (103), spacer (106), forward pinion gear (107) and sixth gear assembly (104) from countershaft (105).

d. Remove first gear assembly (109) and collar (108) from the countershaft.




3. Use tool (P), and remove retaining ring (115). Remove hub (113) and second gear assembly (112).

g. Use tool (P), and remove retaining ring (114). Remove hub (110) and fifth gear assembly (111).



i. Use tool (N), and remove retaining ring (117).


j. Remove third gear assembly (116) and collar (118) from countershaft (105).



k. Use tool (P), and remove retaining ring (120).


l. Remove hub (122) and fourth gear assembly (119).

m. Use tool (P), and remove retaining ring (121) from countershaft (105).



74. Remove the six bolts. Use forcing screws, and remove cage (123) from the transmission case.


75. Remove the six bolts, use forcing screws, and remove cage assembly (124) from the transmission case.




76. Remove seal ring (125) from cage assembly (124).

77. Remove bearing cup (126) from cage assembly (124).

78. Repeat Step 75 and Step 76 on cage assembly (45), that was removed from the other end of countershaft (82) in Step 36.



79. Remove bearing cup (127) from cage (123).



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com