



Check the valve residual (L3)

Commercially available tools:

- Depth gauge

Special tools:

- Support stand: 120900
- base plate: 120910




WARNING

If the wear limit of the inserted valve seat and/or the valve is reached, replace them.


Check the valve residual

- Disassemble the cylinder head.
[See para. Disassembly and assembly of the cylinder head \(L3\)](#)
- Assemble the support stand (1) on the base plate (2).
- Assemble the cylinder head on the support stand.




1.

- Measure the valve residual from the centre of the valve head with respect to the sealing surface of the cylinder head.
[See para. Test and adjustment data \(L3\)](#)



2.

- Disassemble the cylinder head from the support stand (1).
 - Disassemble the base plate support stand (2).
 - Assemble the cylinder head.
- [See para. Disassembly and assembly of the cylinder head \(L3\)](#)



3.



Crankshaft check (L3)

Commercially available tools:

- Magnetic stand for measurements
- Palmer
- Internal bore meter
- Prisms
- Hardness tester

Special tools:

- Dial gauge: 100400



Note

Perform modification on the outer side, on the flywheel side of the crankshaft. H = polished main bearing pin P = polished big end bearing pin. In the event of crankshaft wear, have the crankshaft repaired at one of our service centres.

Check the hardness of the main journal

- Disassemble the crankshaft.
[See para. Assembly and disassembly of the crankshaft \(L3\)](#)
- Rest the crankshaft on the prisms.



© 426029




1.

- Measure the hardness of the crankpin with the hardness tester.
[See para. Test and adjustment data \(L3\)](#)



Note

The measurement values must be converted using the tester table.



© 305601




2.



Note

Measurement diagram of the main journals on points 1 and 2 in surfaces a and b.



© 364242

3.

Check the diameter of the main bearing pins

- o Measure the main bearing pins with the palmer.
See para. Test and adjustment data (L3)



Note

Measurement points, see diagram.



© 426038

1.


Check the diameter of the connecting rod pins

- o Measure the main journal with the palmer.
See para. Test and adjustment data (L3)



Note

Measurement points, see diagram.




© 426048

1.

Check the coaxiality

- o Apply the magnetic stand for measurements.
- o Insert the dial gauge.
- o Apply the preloaded probe on the main bearing pins (arrow) and adjust the dial gauge to "0".
- o Uniformly turn the crankshaft and check the coaxiality.
See para. Test and adjustment data (L3)
- o Remove the magnetic stand for measurements.
- o Disassemble the dial gauge.



© 426058


1.


Measuring the length of the flanged bearing

- o Adjust the palmer to 32 mm.
- o Push the internal bore meter between the test surfaces of the palmer and bring to "0".


1.

- o Measure the width of the flanged bearing using the internal bore meter between the support surfaces of the thrust rings.
 - o Make a note of dimension (a).
- See para. Test and adjustment data (L3)

	<p>Note</p> <p>The measurement (a) is necessary to determine endfloat.</p>
---	---



© 358252




© 426069

2.

Check the endfloat

- o Apply the thrust ring halves on the flanged bearing cover (arrows).
- o Measure the width with the palmer.
- o Make a note of dimension (b).


	<p>Note</p> <p>The measurement (b) is necessary to determine endfloat.</p>
---	---




© 358272

1.

- o Determine the endfloat.
- See para. Test and adjustment data (L3)

	<p>Note</p> <p>Use the corresponding halves of the thrust ring (arrow).</p>
---	--

See para. Test and adjustment data (L3)



© 358272

Calculation example:

Target:	Endfloat
Measured value:	(a) = 32.2 mm
	(b) = 32.1 mm
Calculation:	Dimension (a) - dimension (b)
The results of all this are:	= 0.1 mm

2.

Visual inspection

- Inspect the sliding surfaces (1) of the crankshaft O-rings.
- Inspect the ring gear (2).
- Assemble the crankshaft.
See para. Assembly and disassembly of the crankshaft (L3)



© 426078



1.

T,\$77.21.B0.04.00.00.01 - v1



Replace the crankshaft O-ring (flywheel end) (L3)

Commercially available tools:

- Bradawl: 8198
- Assembly lever: 9017

Special tools:

- Assembly tool: 142830
- Self-tapping screw
- Washer


Removal of the crankshaft oil seal

- Remove the flywheel.
[See para. Assembly and disassembly of the flywheel \(L3\)](#)
- Using a bradawl, make a hole about 3 mm in diameter in the old crankshaft oil seal.




WARNING

Do not damage the gearbox cover or the crankshaft.



1.

- Insert a self-tapping screw (1) with washer.



2.

- Extract the crankshaft O-ring using the assembly lever.
- Carefully examine the crankshaft O-ring sliding surfaces.



3.

Fit the crankshaft O-ring


- Fit guide bush (1).

- o Tighten screws (2).



Note

The holes in the guide bush must be aligned with the threaded holes in the crankshaft flange.



1.

- o Lightly oil the lip of the crankshaft O-ring.
- o Carefully place the crankshaft O-ring on the sliding surface.



Note

The seal lip should be facing the engine crankcase.




2.

- o Distanzscheiben (1) ansetzen.




Note

Falls eine Einlaufrille am Kurbelwellenflansch vorhanden ist, besteht die Möglichkeit den Kurbelwellendichtring in drei Einbautiefen zu montieren: - Erstmontage = 2 Scheiben - 1. Reparatur - Einbaustufe = 1 Scheibe - 2. Reparatur - Einbaustufe = 0 Scheiben.




3.

- o Fit installation bush (1).
- o Push the crankshaft O-ring to the support.



4.

- o Insert bearing (1).
- o Screw in nut (2);



5.


- Screw in the nut until it seats against installation bush (1).



Note

The crankshaft oil seal is now installed at the correct depth.

- Remove the installation tool.
- Fit the flywheel.
See para. Assembly and disassembly of the flywheel (L3)



6.



Replace the crankshaft O-ring (opposite end to flywheel) (L3)

Commercially available tools:

- Bradawl: 8198
- Assembly lever: 9017

Special tools:

- Assembly tool: 142670
- Self-tapping screw
- Washer

Removal of the crankshaft oil seal

- Remove the torsional vibration damper
[See para. Disassembly and assembly of the torsional vibration damper \(L3\)](#)
- Using a bradawl, make a hole about 3 mm in diameter in the old crankshaft oil seal.




WARNING

Be careful not to damage the front cover or the crankshaft.




1.

- Insert a self-tapping screw (1) with washer.



2.


- Extract the crankshaft O-ring using the assembly lever.
- Carefully examine the crankshaft O-ring sliding surfaces.



3.

Assembly of the crankshaft O-ring

- Remove tightening bush (1).




1.

- o Fit guide bush (1).




Note

Check that locating dowel (2) is aligned with hole (3).



2.

- o Tighten (1) the screws.




3.

- o Lightly oil the lip of the crankshaft O-ring.
- o Carefully place the crankshaft O-ring on the sliding surface.



Note

The seal lip should be facing the engine crankcase.



4.

- o Fit spacer (1).



Note

If the crankshaft flange has an entry groove, the O-ring can be installed at three different depths: First assembly = 2 washers, 1st repair - assembly level = 1 washer - 2nd repair - assembly level = 0 washers.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com