

Service and Parts Manual

TOYOTA



Model

6HBW20

Serial No.

10011 and Up

Date: 10/01/95

Table of Contents

	Page
General Information	1
General Maintenance Instructions	1
Maintenance Practices	1
Specifications	2
Hydraulic	2
Component Identification	3
Standard Torque Data For Bolts	6
Conversion Table	7
Decals	8
Decimal Equivalent Chart	10
Planned Maintenance (PM)	11
Inspection Form	11
PM Schedule and Procedure	11
Daily Inspection	11
Monthly PM Service (or 100 Hrs.)	12
Semiannual Service (or 500 Hrs.)	12
Annual PM Service (or 1000 Hrs.)	12
Lubrication Points	13
Fill Points	14
PM Chart	15
Lubrication Equivalency Chart	16
Scheduled Maintenance	17
Batteries	17
Battery Cleaning	17
Electrolyte Process	17
Battery Cleaning Procedure	17
Battery Electrical Leakage To Frame Test	18
Battery Charging	18
Charging Process	18
Hydrometer Use	19
Procedure	19
Voltage Check	19
Adding Water To Battery	20
Guidelines	20
Battery History Record	20
Motors	21
Motor Cleaning	21
Brush Care	22
Maintenance Schedule	22
Motor Maintenance Inspection Chart	22
Brush Replacement	24
Motor Overheating	25
Motor Test for Open Circuit	26
Motor Open Circuit Test Procedure	26
Short Circuit Test - Motors	27
Short Circuit Test	27
Armature Shorts	27
Motor Grounds Test	28
Grounds - General	28

	Page
Hydraulic	29
Oil Selection	29
Changing Reservoir Fluid	29
Power Section	30
Special Tools	30
Flush Grease Fitting Adapter	30
Battery-Pak Lifter	30
Bearing Installation Tool	30
Control Head Unit	31
Removal and Installation	31
Head Unit Removal	31
Cold Storage Requirements	31
Control Handle Removal	32
Travel Control Switches	33
Horn, Lift/Lower Switches	33
Load Wheel	34
Repair and Replacement	34
Pull Rod Bushings Removal and Replacement	35
Carrier Frame Linkage and Bushings	35
Drive Wheel	36
Removal	36
Installation	37
Drive Unit	38
Removal	38
Installation	39
Axe Seal Removal	40
Installation	40
Drive Unit Assembly	41
Drive Unit	42
Disassembly	42
Assembly	43
Drive Motor	44
Removal	44
Drive Motor Brush Replacement	44
Drive Motor Disassembly	44
Installation	45
Controller Assembly	47
Throttle Potentiometer Setting	47
Example	47
Battery Replacement	48
Battery Wiring Hookup	49
Brake	50
Brake Adjustment	50
Brake Interlock Switch	51
Brake Linkage Removal	51
Brake Linkage Installation	51
Brake Shoe Removal and Installation	52

Table of Contents

	<u>Page</u>
Lift/Lower	53
Description	53
Theory of Operation	53
Lift	53
Hydraulic	53
Electrical	54
Control Circuits	54
Power Wring	54
Lower	55
Hydraulic and Electrical	55
Equipment Recommended for Normal Servicing	56
Pump and Motor	57
Removal and Installation	57
Pump Motor Brush Removal	57
Relief Valve	59
Removing Solenoid Valve	59
Installing Solenoid Valve	59
Removing Pump and Motor Assembly	59
Removing Reservoir	59
Removing the Pump	59
Installing the Pump	60
Installing the Reservoir	60
Check Valve	60
Cylinder Assembly Removal Installation	60
Cylinder Removal	60
Hydraulic Cylinder	69
Cylinder Disassembly	61
Inspection	61
Cylinder Assembly	62
Cylinder Installation	63
Lift Limit Switch	63
Troubleshooting	64
No Lift	64
Forks Do Not Lower	66
Forks Will Not Hold Load	66
Traction System	67
Transistor Control (Motor Controller)	67
Current Limiting	68
Low Voltage Cutback	68
Thermal Protection	68
Runaway Protection	69
Static Return to Neutral Protection	69
Plugging	69
Controller Keyswitch Input	69
Controller Thumbwheel Throttle Inputs	69
"Emergency Reverse" Plug Breaking Inhibit	69
Traction System Adjustments	70
Adjustment Panel	70
Potentiometer Adjustments	70
Theory	71
Preparing to Travel	71

Table of Contents

	Page
Directional/Speed Control Forward	72
Directional/Speed Control Reverse	73
Emergency Reverse	74
Contactor Tip/Bar Replacement	75
Troubleshooting	76
Vehicle is dead - nothing operates	76
No travel - horn and lift/lower operates OK	76
No forward travel - forward contactor does not energize	77
No forward travel - forward contactor closed	78
No reverse travel - reverse contactor does not energize, forward travel operates	79
No reverse travel - reverse contactor closed	80
No Emergency Reverse	81
Troubleshooting	82
Wiring Inspection Procedure	84
Miscellaneous Troubleshooting	85
Battery Charger	86
Electrical Testing	86
Equipment Required	86
Instrudions	86
Acceptable Charge Values	86
Open Circuit Voltage Test	87
Short Circuit Amperage Test	87
Testing Components	88
Diodes	88
Capacitor	88
Timer	89
Overcharging Problems	89
Charger and Battery not Properly Matched	89
Defective Battery or Poor DC Connection	89
Battery Charts	90
Controller	91
Description	91
Low Current	93
High Current	94
Adjustment Panel	94
Manually Adjustable Potentiometers	94
Programmer Connector	94
Status LED	94
Power Wiring	95
Control Wiring	95
0-5kΩ Throttle ("Type 3")	96
Plug Current in Over-Temperature	96.1
High Speed Parameter	96.1
Ramp Shap Parameter	96.1
Initial Check	97
Programming and Adjustment	99
Programming	99
Manual Adjustments	100
Current Limit Setting	100
Plug Current Adjustment	101
Acceleration Adjustment	101

Table of Contents

	Page
Maintenance	102
Safety	102
Cleaning	102
Diagnostic History	102
Diagnostics and Troubleshooting	103
LED Diagnostics	103
Programmer Diagnostics	104
Programmer Operation	106
Operating Modes	108
Peace-of-mind Programming	111
Programmer Self Test	111
Programmer Menus	112
Diagnostics and Special Diagnostics 'Menu'	113
Appendix	114
Hydraulic Schematic	114
Electrical Schematic	115
Motor Controller Specifications	116
Glossary	117
Alphabetical Index	123

Figure	Title	Page
1	Component Identification	3
2	Component Identification (Cont'd.)	4
3	Component Identification (Cont'd.)	5
4	Standard Torque Data for Bolts	6
5	Standard Decal Placement	8
6	Bilingual Decal Placement	9
7	Decimal Equivalent Chart	10
8	Lubrication Points	13
9	Hydraulic Fill Points	14
10	Example of Cleaning Motor	21
11	Measuring Brush Spring Tension	23
12	Minimum Brush Lengths	24
13	Motor Terminals and Circuits	26
14	Flush Grease Fitting Adaptor	30
15	Battery-Pack Lifter	30
16	Bearing/Sealing Ring Installation Tool	30
17	Control Head Unit	31
18	Control Handle Removal	32
19	Control Head - Exploded View	33
20	Load Wheel	34
21	Disassembly of Lower Link	35
22	Drive Tire Removal	36
23	Tire Hub Removal	36
24	Wheel Hub Installation	37
25	Drive Tire Installation	37
26	Removing Drive Unit	38
27	Drive Unit Installation	39
28	Replacing Axle Seal	40
29	Drive Unit Assembly	41
30	Cover Removed	42
31	Gear Removal	42
32	Brake Lever Placement	45
33	Battery Replacement Showing One Top Battery Swiveled Toward Forks	48
34	Battery Wiring Hookup	49
35	Brake Lever Adjustment	50
36	Brake Interlock Switch	51
37	Hydraulic Schematic - Lift	53
38	Electrical Schematic - Lift Mode	54
39	Hydraulic Schematic - Lower	55
40	Electrical Schematic - Lower Mode	55
41	Hydraulic Motor, Pump, and Reservoir	57
42	Lift Cylinder - Exploded View	61
43	Lift Limit Switch	63
44	Control System (Simplified)	67
45	Motor Current Chart	69
46	Adjustment Panel	70
47	Travel Direction Reference	71
48	Electrical Schematic - Forward	72
49	Electrical Schematic - Reverse	73
50	Electrical Schematic - Emergency Reverse	74
51	Contactor - Exploded View	75
52	Programmer and Motor Controller	91
53	Motor Controller Connector	93
54	Motor Controller	94
55	Adjustment Panel	94

Figure	Title	Page
56	16 Pin Connector	95
57	SK Throttle (Type 3)	96
57.1	Active Throttle	96.1
57.2	Active Throttle	96.2
57.3	Active Throttle	96.2
58	Manual Adjustments	100
59	LED Diagnostics	103
60	Programmer	106
61	Hydraulic Schematic	114
62	Electrical Schematic	115

Tool List	Description
00590-04661-71	Diagnostic Service Tool (Programmer)
00590-04667-71	Pin Extractor
00590-04668-71	Pin Extractor
00590-04669-71	Pin Extractor
00590-04670-71	Pin Extractor
00590-04671-71	Crimping Tool
00590-04672-71	Extraction Tool
00590-04673-71	Model 1141 FasTest Accessory
00590-04674-71	Model 1142 Tester
00590-04675-71	Curtis Battery Book One
00590-04676-71	Bearing/Sealing Ring Installation Tool
00590-04677-71	Battery Pack Lifter

General Information

General Maintenance Instructions Industrial vehicles may become hazardous if adequate maintenance is neglected. Only trained technicians, using approved procedures, in adequate maintenance facilities should work on this or any other industrial vehicle.

Maintenance Practices

1. Follow a scheduled lubrication, maintenance, and inspection schedule.
2. Only qualified, authorized technicians are permitted to inspect, maintain, **adjust**, and repair this vehicle.

CAUTION

REMOVE RINGS, WATCHES, AND ALL JEWELRY BEFORE DOING ANY WORK ON VEHICLE.

3. Before working on vehicle:
 - a. Lower load handling mechanism completely to the floor.
 - b. All controls must be in neutral.
 - c. Release any trapped pressure in hydraulic systems.
 - d. Block the wheels to prevent movement of the vehicle.
 - e. Disconnect battery connector
 - f. Elevate drive tire off floor.

WARNING

USE EXTREME CARE WHENEVER THE VEHICLE IS JACKED UP FOR ANY REASON. KEEP HANDS AND FEET CLEAR FROM BENEATH VEHICLE WHILE JACKING. USE JACK STANDS OR SOLID BLOCKS TO SUPPORT VEHICLE - DO NOT RELY ON JACKS.

- g. Before working on load handler, support to prevent movement.
4. After working on vehicle, test all controls and functions to assure proper operation.
5. Work in a clean, dry, well ventilated area.
6. Avoid fire hazards. Have adequate fire fighting equipment in the maintenance area.
7. **DO NOT** use open flame or sparking devices around the battery. The gasses given off by the battery are highly explosive.
8. Use extreme caution when using flammable cleaning solutions.

More information pertaining to operating and maintenance procedures may be obtained from:

American National Standards Institute
1430 Broadway
New York, NY 10018

Ask for ANSI B56.1 - 1988

Specifications

Model:	6HBW20
Battery Voltage:	24
Wheel:	
Drive:	10.5 x 5" Rubber
Load:	3.25 x 5" Polyurethane (2)
Install load wheels with at least 1 shim on each side and a maximum of $\frac{1}{16}$ " (1.58mm) end play.	

Transmission	
Fluid: Standard Use	80W-90W
Cold Storage	"DEXTRON II" ATF
Fluid Capacity:	0.8 Quart (0.75 liter)
Torque Requirement:	Torque drive tire retaining nut to 250 FT./LBS. (350Nm) (While rotating drive tire)
Torque pivot bearing retaining nut to Zero (0) end play on pivot bearings while pivoting transmission.	

Hydraulic

Lift/Lower System	
Fluid: Standard Use	10W-40W
Cold Storage	"Dextron II" ATF
Reservoir Capacity:	1 Quart (0.9 liters)
Relief Valve Setting:	2600 psi \pm 50 psi (177 Barf 3.4 bar)


General Information**Component Identification**

Figure 63 Component Identification



General Information**Component Identification
(Cont'd.)**

Figure 64 Component Identification (Cont'd.)


General Information

Figure 65 Component Identification (Cont'd.)

Standard Torque
Data For Bolts


GRADE IDENTIFICATION MARKING	NONE					
	SAE Grade 2 Bolts Tightening Torque		SAE Grade 5 Bolts Tightening Torque		SAE Grade 8 Bolts Tightening Torque	
SIZE	Dry	Lub.	Dry	Lub.	Dry	Lub.
4-40	5	4	8	6	12	9
4-48	6	5	9	7	13	10
6-32	10	8	16	12	23	17
6-40	12	9	18	13	25	19
8-32	19	14	30	22	41	31
8-36	20	15	31	23	43	32
10-24	27	21	43	32	60	45
10-32	31	23	49	38	68	51
1/4-20	66	49	96	75	144	108
1/4-28	76	56	120	86	168	120
	ft. lb.	ft. lb.	ft. lb.	ft. lb.	ft. lb.	ft. lb.
5/16-18	11	8	17	13	25	18
5/16-24	12	9	19	14	25	20
3/8-16	20	15	30	23	45	35
3/8-24	23	17	35	25	50	35
7/16-14	30	24	50	35	70	55
7/16-20	35	25	55	40	80	60
1/2-13	50	35	75	55	110	80
1/2-20	55	40	90	65	120	90
9/16-12	70	55	110	80	150	110
9/16-18	80	60	120	90	170	130
5/8-11	100	75	150	110	220	170
5/8-18	110	85	170	130	240	180
3/4-10	175	130	260	200	380	280
3/4-16	195	145	300	220	420	320
7/8-9	165	125	430	320	600	460
7/8-14	185	140	470	350	660	500
1-8	250	190	640	480	900	680
1-12	270	200	700	530	1000	740
1 1/8-7	350	270	800	600	1280	960
1 1/8-12	400	300	880	660	1440	1080
1 1/4-7	500	380	1120	840	1820	1360
1 1/4-12	550	420	1240	920	2000	1500
1 3/8-6	660	490	1460	1100	2380	1780
1 3/8-12	740	560	1680	1260	2720	2040
1 1/2-6	870	650	1940	1460	3160	2360
1 1/2-12	980	730	2200	1640	3560	2660

Figure 66 Standard Torque Data for Bolts

Conversion Table

To Convert...	Multiply by...
Inches to Millimeters	25.4
Inches to Centimeters	2.54
Feet to Meters	0.305
Yards to Meters	0.914
Miles to Kilometers	1.609
Millimeters to Inches	0.039
Centimeters to Inches	0.394
Meters to Feet	3.281
Meters to Yards	1.094
Kilometers to Miles	0.621
Square inches to Square Centimeters	6.452
Square Feet to Square Meters	0.093
Square Yards to Square Meters	0.836
Square Centimeters to Square Inches	0.155
Square Meters to Square Feet	10.155
Square Meters to Square Yards	1.196
Fahrenheit to Celsius	(°F - 32) ÷ 1.8
Celsius to Fahrenheit	(°C X 1.8) + 32
PSI to Pascals (Pa)	6894.757
PSI to Bar	PSI ÷ 14.7

General Information**Decals**

The following pages show proper mounting and location of decals.

NOTE: See the Parts Manual for decal description and ordering information.




Figure 61 Standard Decal Placement

- Decals:**
1. Emergency Disconnect
 2. Caution-Bilingual
 3. No Riding
 4. Spec Plate U.S.
 5. Pocket Manual
 6. Warning
 7. Cold Storage (located next to lift pump.)

Thank you so much for reading.

**Please click the “Buy Now!”
button below to download the
complete manual.**

Buy Now



After you pay.

**You can download the most
perfect and complete manual in
the world immediately.**

Our support email:

ebooklibonline@outlook.com