

New Leader Technical Support Manual

For Model

John Deere 4920 G4
L3020 and L3220 w/Multapplier



Effective 12/05

Highway Equipment Company
1330 76th Ave SW
Cedar Rapids, IA 52404-7052

Building the Best Since 1939

Index

Section 1: Safety

P.1-13

Section 3: Processor Operation

P.2-6 General Processor Installation

P.7-8 Theoretical Operating Values

P.9-10 SP.6 Menu Tree

P.11-12 DP.6 Menu Tree

P.13 DP.6 As Applied Mapping Tree

P.14 DP.6 VRT Mapping Tree

P.15-20 Interface Module and cable Pin outs

P. 21 Calibration Constants and Formulas

Section 4: Hydraulics

P.2-3 Hydraulic Principles

P.4-6 Hydraulic System Types

Mark Series Valve

P.7-8 Theory of Operation

P.9-11 Testing

P 12-15 Valve Components

Hydraulic System and Components

P.16-17 JD Basic Hydraulic Layout

P.18-19 Raven Servo Valve Setup

P.20 Main Relief Valve Setup

P.21 Secondary Relief on JDL3220

P.22-23 PWM Valve Theory, Schematic & Troubleshooting

P.24 50/50 Flow Divider

P.25 Dump Description & Operation

P.26 Load Sense Valve

P.27 Spinner Motor Breakdown

P.28 Conveyor Motor Breakdown

Section 5: Spreader Components

P.2-8 Conveyor Selection, Types & Adjustments

P.9-14 Misc. Components

P.15-16 Bin Level Sensor

Section 6: Spread Pattern

G4 Spread Pattern Testing

SAFETY

PREFACE**PLEASE ! ALWAYS THINK SAFETY FIRST !!**

The purpose of this manual is to familiarize the person (or persons) using this unit with the information necessary to properly install, operate, and maintain this system. These instructions cannot replace the following: the fundamental knowledge that must be possessed by the installer or operator, the knowledge of a qualified person, or the clear thinking necessary to install and operate this equipment. Since the life of any machine depends largely upon the care it is given, we suggest that this manual be read thoroughly and referred to frequently. If for any reason you do not understand the instructions, please call your authorized dealer or our Cedar Rapids, Iowa, Product Support Department at (319) 363-8281.

It has been our experience that by following these installation instructions, and by observing the operation of the spreader, you will have sufficient understanding of the machine enabling you to troubleshoot and correct all normal problems that you may encounter. Again, we urge you to call your authorized dealer or our Cedar Rapids Product Support Department if you find the unit is not operating properly, or if you are having trouble with repairs, installation, or removal of this machine.

We urge you to protect your investment by using genuine HECO parts and our authorized dealers for all work other than routine care and adjustments.

Highway Equipment Company reserves the right to make alterations or modifications to this equipment at any time. The manufacturer shall not be obligated to make such changes to machines already in the field.

This Safety Section should be read thoroughly and referred to frequently.

ACCIDENTS HURT !!!

ACCIDENTS COST !!!

ACCIDENTS CAN BE AVOIDED !!!

SAFETY



TAKE NOTE! THIS SAFETY ALERT SYMBOL FOUND THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY AND THAT OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.

In this manual and on the safety signs placed on the unit, the words “DANGER,” “WARNING,” “CAUTION,” and “IMPORTANT” are used to indicate the following:



DANGER

Indicates an imminently hazardous situation that, if not avoided, **WILL** result in death or serious injury. This signal word is to be limited to the most extreme situations and typically for machine components that, for functional purposes, cannot be guarded.



WARNING

Indicates a potentially hazardous situation that, if not avoided, **COULD** result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



CAUTION

Indicates a potentially hazardous situation that, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

IMPORTANT!

Is used for informational purposes in areas which may involve damage or deterioration to equipment but generally would not involve the potential for personal injury.

The need for safety cannot be stressed strongly enough in this manual. At Highway Equipment Company, we urge you to make safety your top priority when operating any equipment. We firmly advise that anyone allowed to operate this machine be thoroughly trained and tested, to prove they understand the fundamentals of safe operation.

The following guidelines are intended to cover general usage and to assist you in avoiding accidents. There will be times when you will run into situations that are not covered in this section. At those times the best standard to use is common sense. If, at any time, you have a question concerning these guidelines, please call your authorized dealer or our factory at (319) 363-8281.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com