

**324
and 328
Mower-Conditioners**

**John Deere Arc-lès-Gray
OMCC49842 Issue A9**

European Version

Printed in Germany

ANGLAIS

Contents

	Page		Page
Identification View	00-1	Transporting Mower-Conditioner	
Safety	05-1	Observe local transport regulation	30-1
Safety Decals		Pivoting mowing unit into transport position	30-2
Operator's manual	10-1	Operating Mower-Conditioner	
Repair and maintenance	10-1	Pre-operation checklist	35-1
Cutterbar	10-1	Breaking-in mower-conditioner	35-2
Cutterbar curtains	10-2	Starting and driving mower-conditioner	35-3
Mowing unit	10-2	Front safety curtain	35-4
Swinging area	10-2	Pivoting mowing unit into working position	35-5
Preparing the Tractor		Setting machine frame to correct operating height	35-6
Tractor PTO Speed	15-1	Setting machine ground pressure	35-7
Preparing tractor for hitching	15-2	Adjusting cutting height	35-9
Stabilizer chain	15-3	Adjusting conditioning intensity	35-10
Setting draft links for hitching mower-conditioner	15-3	Adjusting conditioning hood	35-11
Rockshaft selector	15-3	Adjusting rotor speed	35-12
Preparing the Mower-Conditioner		Checking conditioning effect	35-14
Checking and lubricating mower-conditioner	20-1	Adjusting windrow width	35-14
Attaching and Detaching		Operating in adverse field conditions	35-15
PTO Speed	25-1	Lubrication and Maintenance	
Preparing mower-conditioner for attaching	25-1	Service intervals	40-1
Attaching to the tractor	25-2	Grease	40-1
Connecting hydraulic hoses	25-3	Gear Oil	40-2
Setting selective control valves	25-3	Every 10 hours	40-3
Tractor electrical connection	25-3	Cutterbar	40-4
Adjusting telescoping hook-up	25-4	Draining cutterbar	40-4
Connecting telescoping hook-up	25-5	Refilling cutterbar	40-5
Attaching frame positioner rope	25-6	Checking cutterbar oil level	40-6
Checking machine level	25-7	Central gearbox	40-6
Detaching mower-conditioner	25-8	Draining central gearbox	40-7
Detaching stop chain	25-8	Refilling central gearbox	40-7
Detaching telescoping hook-up	25-9	Checking central gearbox oil level	40-8
Detaching hydraulic hoses	25-10	Lateral gearbox	40-8
Disconnect electrical plug	25-10	Draining lateral gearbox	40-9
Disconnecting from three-point hitch	25-10	Refilling lateral gearbox	40-9
		Checking lateral gearbox oil level	40-10
		Every 10 years	40-10

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMCC49842 A9-19-15JAN99

COPYRIGHT© 1999
DEERE & COMPANY
European Office Mannheim
All rights reserved
A John Deere ILLUSTRATION® Manual

	Page
Troubleshooting	
Mower-conditioner operation	45-1
Locking system for PTO	45-5
End yokes	45-6
Inboard yokes	45-7
Profile tubes	45-8
Telescoping hook-up guards	45-9
Service	
Torque Values	50-1
Checking slip clutch	50-2
Adjusting belt tension	50-3
Replacing drive belts	50-4
Replacing rotor tines	50-5
Adjusting transport stop	50-5
Checking hydro-pneumatic accumulator	50-6
Adjusting hydraulic cylinders	50-7
Removing disks	50-8
Installing and synchronizing disks	50-9
Direction of knife rotation	50-10
Direction of disk rotation	50-10
Checking the knives	50-11
Removing knives	50-12
Installing knives	50-13
Checking knife wear	50-14
Checking knife fitting hole	50-15
Checking hardware torques	50-15
Checking knife hardware	50-16
Checking knife bolt wear	50-17
Checking knife lock nut wear	50-18
Storage	
After the season	55-1
Before the season	55-2
Specifications	
Specifications for 324 model	60-1
Specifications for 328 model	60-2
Serial Number	
Product identification number	65-1
Serial number plate description	65-1
Mower-conditioner serial number	65-1
Index	

Identification View



CC015030

328 Mower-Conditioner

CC015030 -JUN-22/JAN99

CC.324SM 004660-19-15JAN99

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98

T81389 -UN-07DEC68


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93

T5201 -UN-23AUG88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



▲ WARNING

▲ CAUTION

DX,SIGNAL -19-03MAR93

T5187 -19-30SEP88



OBSERVE ROAD TRAFFIC REGULATIONS

Always observe local road traffic regulations when using public roads.



FX,ROAD -19-01MAY91

H28930 -UN-30JUN89

STORE ATTACHMENTS SAFELY

Stored attachments such as dual wheels, cage wheels, and loaders can fall and cause serious injury or death.

Securely store attachments and implements to prevent falling. Keep playing children and bystanders away from storage area.



DX,STORE -19-03MAR93


TS219 -UN-23AUG88

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

TS291 -UN-23AUG88




WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



DX,WEAR -19-10SEP90

TS206 -UN-23AUG68

CHECK MACHINE SAFETY

Always check the road and general operating safety of the machine before using.

FX,READY -19-28FEB91

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.




DX,PTO -19-12SEP95

TS1644 -UN-22AUG95



OPERATE SAFELY

1. Keep all curtains and shields in place.
2. Never hand feed material into the machine.
3. Do not lean against or sit or stand on the cutterbar curtains or their supporting framework.
4. Do not operate mower-conditioner with cutterbar in raised position.
5. Regularly check that disk and knife bolts are tight; also verify that tines are securely mounted on rotor.
6. Always operate the machine at rated speed.
7. Drive slowly over rough ground.
8. Avoid holes when operating on hillsides. Tractor rollover could result. It is requested that the mower-conditioner be used only with tractors having an operator enclosure.
9. Provide sufficient weight to stabilize the tractor when operating on hilly land or under other adverse conditions. See your tractor operator's manual.
10. Lower mower-conditioner to the ground when leaving it and tractor unattended.
11. Always apply parking brake before detaching from tractor.



CC 9185

-UN-23AUG68

TS268

-UN-07FEB95

CC9185

CC.224SM 004146-19-01JAN98




AVOID INJURY FROM THROWN OBJECTS

Extreme care must be exercised to avoid injury from thrown objects. Do not, under any circumstances, operate the mower-conditioner when other people are in the vicinity. Stones and other objects can be thrown great distances by the rotating cutting blades.

The cutterbar curtains are very important to reduce the potential for thrown objects. Always keep these curtains down when operating the mower-conditioner. Replace the curtains if they should become worn or damaged.

For additional operator protection from thrown objects, it is requested that the mower-conditioner be used only with tractors having an operator enclosure.




TS265 -UN-23AUG68

CC.MOCOUS000605-19-05OCT92

USE SAFETY LIGHTS AND DEVICES

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use hand signals or turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible and in good working order. Replace or repair lighting and marking that has been damaged or lost.



TS951 -UN-12APR90

DX,FLASH -19-04FEB99



PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



DX,SERV -19-04FEB99

-UN-23AUG88

TSS218




AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




X9811 -UN-23AUG88

DX,FLUID -19-03MAR93

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228 -UN-23AUG88

DX,LOOSE -19-04JUN90

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com