

435 and 535 Round Balers

(Serial No. 800001-)

**John Deere Ottumwa Works
OME79133 Issue L8**

LITHO IN U.S.A.
ENGLISH

Introduction

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction the implement will travel when going forward.



THIS MACHINE is of metric design. Measurements in this manual are metric with the customary U.S. measurement following. Use only metric hardware and tools as specified.

WRITE PRODUCT IDENTIFICATION NUMBERS in the space provided in the Specifications section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. If this

manual is kept on the machine, also file the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your machine may not apply outside the U.S.



John Deere 435 and 535 Round Balers

E32229
-UN-16SEP88

Contents

	Page		Page
Safety	05-1	Crop Preparation	35-3
Preparing the Tractor		Breaking-In	35-3
Adjusting the Drawbar	10-1	Forming a Bale	35-4
Adjusting Tractor Wheels	10-1	Gate Lock Valve	35-8
Checking Ballast, Wheel Spacing, and		Using Manual Twine Trip Rope	35-8
Tire Inflation	10-2	Operating Twine Arm With Empty Baler	35-9
Setting Hydraulic Outlets	10-2	Rotating Baler By Hand	35-9
Tractor Electrical Hookup	10-2	Adjusting Bale Size	35-10
Install Convenience Outlet On:		Bale Density Gauge	35-11
Negative Ground Tractors Without		Adjusting:	
SOUND-GARD Bodies	10-2	Bale Density	35-12
Positive Ground Tractors Without		Pickup Height	35-12
SOUND-GARD Bodies	10-4	Converging Wheel Height	35-13
Tractors With SOUND-GARD Bodies	10-5	Unplugging Baler Under Power	35-14
Install BALE-TRAK Monitor Console	10-6	Unplugging Baler With Hydraulic Pickup	
Using Heavy-Duty Tractor Drawbar	10-8	Lift	35-15
Using Drawbar Shield	10-8	Compressor Rack Assembly:	
Making Drawbar Shield	10-8	Removing	35-15
		Installing	35-15
Preparing the Baler		Adjusting	35-16
Selecting Twine	15-1	Starting a Bale in Difficult Conditions	35-17
Loading Twine Boxes	15-1	Baling Short, Dry, Slick Crops	35-18
Tying Sheet Bend Knot—Plastic Twine	15-2	Baling Cornstalks	35-19
Tying Modified Square Knot—Sisal Twine	15-2	Baling Wet Hay	35-20
Routing Twine From Right-Hand Twine		Extinguishing a Fire	35-21
Box (Rear Arm)	15-2	Bale Push Bar Operation (Optional)	35-21
Routing Twine From Left-Hand Twine		Operating Baler With Push Bar (Optional) . . .	35-23
Box (Front Arm)	15-4	Engaging Bale Push Bar (Optional)	35-25
Adjusting Twine Spacing	15-7	Locking Out Bale Push Bar (Optional)	35-26
Tire Inflation	15-8		
Attaching and Detaching	20-1	Attachments	40-1
Transporting	25-1	Lubrication and Maintenance	
Handling Round Bales	30-1	Perform Lubrication and Maintenance	45-1
Operating the Baler		Alternative Lubricants	45-1
BALE-TRAK Monitor	35-1	Hydraulic Pump Oil	45-1
How the Baler Forms a Bale	35-2	Chains	45-2
		Extreme Pressure Grease	45-2
		Gear Oil	45-3

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OME79133 L8-19-13DEC89

COPYRIGHT© 1988
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

	Page		Page
Lubrication and Maintenance:		Adjusting:	
Every 10 Hours	45-4	Twine Cutter Tension (535)	55-23
Every 30 Hours	45-6	Number of Twine Wraps on R-H End	
Every 50 Hours	45-8	of Bale (535)	55-24
Every 100 Hours	45-9	Twine Arm Travel To Shift Valve (535) . . .	55-25
Annually	45-10	Twine Cylinder Installation Dimensions	
Troubleshooting		(535)	55-25
Automatic Twine Wrap	50-1	Adjusting Gate Latch Stop	55-26
BALE-TRAK Monitor Difficulties	50-7	Adjusting Gate Latch Linkage	55-27
Feeding Difficulties	50-10	Adjusting Twine Indicator Retaining Strap . . .	55-27
Pickup Difficulties	50-12	Checking Microswitches	55-28
Bale Quality	50-14	Adjusting:	
General Baler Difficulties	50-16	Gate Latch Switch (Green Light)	55-28
Silage Bundle Difficulties	50-20	Twine Arm Switch (Solid Yellow Light) . . .	55-29
Service		Flashing Yellow Light Switch	55-29
Practice Safety	55-1	Oversize Bale Switch (Red Light)	55-30
Mounting Tires	55-2	Bale Shape Senders	55-30
Tractor/Monitor Wiring Diagram	55-3	Pickup Float Springs	55-31
Baler Wiring Diagram	55-4	Pickup Belt Idler	55-32
Bale Tension and Gate Hydraulic System . . .	55-5	Removing Center and Rear Tension Arm	
Adjusting Chains	55-6	Rolls	55-33
Adjusting Upper Drive Roll Chain	55-6	Removing Front Tension Arm Roll	55-34
Servicing Upper Chain and Idler	55-6	Installing Orifice in Tractors With Low	
Adjusting Drive Slip Clutch	55-7	Hydraulic Flow	55-34
Checking Belt Tracking	55-8	Priming Twine Hydraulic Pump	55-35
Adjusting Belt Tracking	55-10	Raising Gate With Hoist	55-37
Adjusting Lower Feed Roll Scraper	55-12	Checking Belt Pins	55-37
Adjusting Bale Size Indicator	55-13	Removal of All Belts or Spring Rods	55-37
Replacing Tension Wear Channel	55-14	Installing Belts	55-38
Adjusting Twine Trip Rod and Valve		Repairing Belts	55-39
Latch Clearance	55-14	Belts Eligible for Warranty Replacement	55-43
Adjusting Twine Trip Rope	55-16	Belts Not Eligible for Warranty	
Checking Pump Drive Latch Adjustment . . .	55-16	Replacement	55-43
Adjusting Pump Idler Switch	55-17	Surface Wrap—Preparing the Baler	
Checking Knife Register	55-18	Selecting Surface Wrap Material	60-1
Adjusting Twine Cutter Anvil	55-18	Care of Surface Wrap Material	60-1
Twine Arm Timing (435)	55-19	Additional Surface Wrap Storage	60-1
Twine Arm Timing (535)	55-19	Opening Surface Wrap Box	60-2
Adjusting:		Installing Surface Wrap and Routing	
Twine Cutter Tension (435)	55-20	Through Rolls	60-3
Number of Twine Wraps on R-H End		Closing Surface Wrap Box	60-4
of Bale (435)	55-21	Surface Wrap—Operating the Baler	
Twine Distance From R-H End of Bale		General Information	65-1
(435)	55-22	How the Surface Wrapping Mechanism	
Twine Cylinder Installation Dimensions		Works	65-1
(435)	55-23	BALE-TRAK Monitor Operation With	
		Surface Wrap	65-2

Continued on next page

	Page
Discharging Bale With Surface Wrapping Mechanism	65-2
Changing From Twine Wrapping to Surface Wrapping	65-3
Adjusting Number of Surface Wraps	65-4
Changing From Surface Wrapping to Twine Wrapping	65-5
Operating Surface Wrap System With Empty Baler	65-6
Releasing Knife Arm Manually	65-7
Surface Wrap—Lubrication	
Every 30 Hours	70-1
Annually	70-1
Surface Wrap—Troubleshooting	75-1
Surface Wrap—Service	
Practice Safety	80-1
Adjusting Feed Roll Pressure	80-1
Checking Drive Belt Length	80-2
Removing and Installing Belt	80-2
Removing and Installing Knife	80-3
Checking Brake	80-4
Adjusting Microswitch	80-5
Removing Wrappage From Feed Rollers	80-5
Adjusting Knife Arm Stop	80-7
Servicing Lower Front Gate Roll	80-8
Surface Wrapping Hydraulic System	80-10
Storage	85-1
Crime Prevention Tips	90-1
Specifications	95-1
Index	

Contents

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



053,ALERT -19-16JUN87

T81389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



053,SIGNAL -19-07OCT85


TS187 -19-30SEP88

FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.




053,READ -19-23APR87

TS201 -UN-23AUG88



PROTECT BYSTANDERS

To prevent crushing injury be sure bystanders stand clear before operating gate and unloading bale.




EX,435C,A -19-01SEP88

E32162 -UN-12SEP88

OPERATE BALER SAFELY

To avoid injury or death by being pulled into the machine:

- DO NOT attempt to feed crop or twine into baler or unplug feed area WHILE BALER IS RUNNING. The baler feeds material faster than you can release it.
- Disengage PTO and shut off engine.
- Stand clear of baler at all times when machine is operating.



EX,435C,B -19-01SEP88

E32161 -UN-12SEP88

OPERATE SAFELY ON SLOPES

Be especially careful when operating on hillsides. The baler may tip sideways if it strikes a hole, ditch, or other irregularity.

To prevent injury or damage from a rolling bale, discharge bales on level ground or in such a manner that the bale will not roll.

EX,435C,C -19-01SEP88




HANDLE ROUND BALES SAFELY

To help prevent personal injury, do not handle round bales without approved John Deere Round Bale Handling attachments.

Improper use of loaders to handle round bales can result in serious injury or death to the tractor/loader operator. This could be caused by the bale rolling back down the loader into the operator's station.

To attain optimum stability and visibility:

- Do not handle bales that exceed the bale weight limitations of the loader.
- Carry the bale slowly and as low as possible to the ground.
- Operate the loader controls smoothly, avoiding jerky operation.
- When handling round bales on a slope, always approach the bale with the tractor facing uphill.
- Never use the tractor/loader to stop a rolling bale.




W7718 -UN-06OCT88

EX,435C,D -19-01SEP88

KEEP RIDERS OFF MACHINE

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.



TS290 -UN-23AUG88

O53,RIDER -19-03MAY88




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

1. Eject bale immediately.
2. Move tractor and baler upwind 9 m (30 ft) away from flammable material.
3. Raise gate and engage gate lock valve.
4. Use fire extinguisher or other water supply to put out fire.

Keep first aid kit handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291
-UN-23AUG88


EX,435C,J -19-01NOV88

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



TS206
-UN-23AUG88

O53,WEAR -19-23APR87

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



TS198
-UN-23AUG88

O53,PTO -19-16JUN87




USE SAFETY LIGHTS AND DEVICES

When transporting your machine on a road or highway at night or during the day, use necessary safety lights. Check local governmental regulations. A safety lighting kit is available from your John Deere dealer.

Keep safety items in good condition. Replace missing or damaged items.

- A—Lights
- B—SMV Emblem
- C—Reflector Tape
- D—Reflectors
- E—Mirror and Extension



EX,435C,E -19-01SEP88


E22683 -UN-15SEP88

USE A SAFETY CHAIN

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.

Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength rating equal to or greater than the gross weight of the towed machine. Do not use safety chain as a tow chain for towing.



EX,435C,L -19-21NOV88

TS217 -UN-23AUG88

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com