

435 and 535 Round Balers

(Serial No. 915001-)

John Deere Ottumwa Works
OME80985 Issue H1
**(Mark old manual OME79133 L8 for
machines up to Serial No. 915001-)**

LITHO IN U.S.A.
ENGLISH

Introduction

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction the implement will travel when going forward.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers

when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty applicable to your machine may not apply outside the U.S.



John Deere 435 and 535 Round Balers

E32229
-JUN-16SEP88

EX,435A,IFCOM -19-01MAY91

Contents

	Page		Page
Safety	05-1	How the Baler Forms a Bale	35-2
Preparing the Tractor		Crop Preparation	35-3
Adjusting the Drawbar	10-1	Breaking-In	35-3
Adjusting Tractor Wheels	10-1	Adjusting Bale Size	35-4
Checking Ballast, Wheel Spacing, and Tire Inflation	10-2	Bale Density Gauge	35-5
Setting Hydraulic Outlets	10-2	Adjusting:	
Tractor Electrical Hookup	10-3	Bale Density	35-6
Install Convenience Outlet On:		Pickup Height	35-6
Negative Ground Tractors Without SOUND-GARD Bodies	10-3	Converging Wheel Height	35-7
Positive Ground Tractors Without SOUND-GARD Bodies	10-4	Forming a Bale	35-8
Tractors With SOUND-GARD Bodies	10-5	Checking Baler Performance in the Field ...	35-12
Install BALE-TRAK Monitor Console	10-7	Gate Lock Valve	35-13
Using Heavy-Duty Tractor Drawbar	10-9	Using Manual Twine Trip Rope	35-13
Using Drawbar Shield	10-9	Operating Twine Arm With Empty Baler ...	35-14
Making Drawbar Shield	10-9	Rotating Baler By Hand	35-14
Preparing the Baler		Unplugging Baler Under Power	35-15
Selecting Twine	15-1	Unplugging Baler With Hydraulic Pickup Lift	35-16
Loading Twine Boxes	15-1	Compressor Rack Assembly:	
Tying Sheet Bend Knot—Plastic Twine	15-2	Removing	35-16
Tying Modified Square Knot—Sisal Twine ...	15-2	Installing	35-16
Routing Twine From Right-Hand Twine Box (Rear Arm)	15-2	Adjusting	35-17
Routing Twine From Left-Hand Twine Box (Front Arm)	15-5	Starting a Bale in Difficult Conditions	35-18
Adjusting Twine Spacing	15-8	Baling Short, Dry, Slick Crops	35-19
Tire Inflation	15-9	Baling Cornstalks	35-20
Attaching and Detaching	20-1	Baling Wet Hay	35-21
Transporting	25-1	Extinguishing a Fire	35-22
Handling Round Bales	30-1	Bale Push Bar Operation (Optional)	35-22
Operating the Baler		Operating Baler With Push Bar (Optional) ...	35-24
BALE-TRAK Monitor	35-1	Engaging Bale Push Bar (Optional)	35-26
		Locking Out Bale Push Bar (Optional)	35-27
		Attachments	40-1
		Lubrication and Maintenance	
		Perform Lubrication and Maintenance	45-1
		Alternative Lubricants	45-1
		Hydraulic Pump Oil	45-1
		Chains	45-2

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OME80985 H1-19-19JUL91

COPYRIGHT© 1990
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1988 Deere & Company

Contents

	Page		Page
Extreme Pressure Grease	45-2		
Gear Oil	45-3		
Lubrication and Maintenance:			
Every 10 Hours	45-4		
Every 30 Hours	45-6		
Every 50 Hours	45-8		
Every 100 Hours	45-9		
Annually	45-10		
Troubleshooting			
Automatic Twine Wrap	50-1		
BALE-TRAK Monitor Difficulties	50-9		
Feeding Difficulties	50-13		
Pickup Difficulties	50-15		
Bale Quality	50-17		
General Baler Difficulties	50-19		
Push Bar Difficulties	50-24		
Silage Bundle Difficulties	50-25		
Service			
Practice Safety	55-1		
Mounting Tires	55-2		
BALE-TRAK Monitor and Baler Wiring Diagram	55-3		
Bale Tension and Gate Hydraulic System	55-4		
Adjusting Chains	55-5		
Adjusting Upper Drive Roll Chain	55-5		
Servicing Upper Chain and Idler	55-5		
Adjusting Drive Slip Clutch	55-6		
Checking Belt Tracking	55-7		
Adjusting:			
Belt Tracking	55-9		
Lower Feed Roll Scraper	55-11		
Compression Spring Rod Stop Nuts	55-11		
Bale Size Indicator	55-12		
Replacing Tension Wear Channel	55-13		
Checking Twine Trip Rod and Valve Latch Clearance	55-13		
Checking Maximum Size Bale Adjustment	55-15		
Adjusting Twine Trip Rope	55-16		
Checking Knife Register	55-16		
Adjusting Twine Cutter Anvil	55-17		
Twine Arm Timing (435)	55-17		
Twine Arm Timing (535)	55-18		
Adjusting:			
Twine Cutter Tension (435)	55-18		
Number of Twine Wraps on R-H End of Bale (435)	55-20		
Twine Distance From R-H End of Bale (435)	55-20		
Twine Cylinder Installation Dimensions (435)	55-21		
Adjusting:			
Twine Cutter Tension (535)	55-22		
Number of Twine Wraps on R-H End of Bale (535)	55-23		
Twine Arm Travel To Shift Valve (535)	55-24		
Twine Cylinder Installation Dimensions (535)	55-24		
Adjusting:			
Gate Latch Stop	55-25		
Gate Latch Linkage	55-26		
Twine Indicator Retaining Strap	55-26		
Checking Microswitches	55-27		
Adjusting:			
Pump Idler Switch	55-27		
Gate Latch Switch (Green Light)	55-28		
Twine Arm Switch (Solid Yellow Light)	55-28		
Flashing Yellow Light Switch	55-29		
Oversize Bale Switch (Red Light)	55-30		
Bale Shape Senders	55-30		
Pickup Float Springs	55-31		
Pickup Belt Idler	55-32		
Removing Center and Rear Tension Arm Rolls	55-33		
Removing Front Tension Arm Roll	55-34		
Installing Orifice in Tractors With Low Hydraulic Flow	55-34		
Priming Twine Hydraulic Pump	55-35		
Raising Gate With Hoist	55-37		
Checking Belt Pins	55-37		
Removal of All Belts or Spring Rods	55-37		
Installing Belts	55-38		
Repairing Belts	55-39		
Belts Eligible for Warranty Replacement	55-43		
Belts Not Eligible for Warranty Replacement	55-43		
Storage	60-1		
Crime Prevention Tips	65-1		
Specifications	70-1		
Index			

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-04JUN90

T81389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-04JUN90

TS187 -19-30SEP88


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.




DX,READ -19-04JUN90

TS201 -UN-23AUG88



PROTECT BYSTANDERS

To prevent crushing injury be sure bystanders stand clear before operating gate and unloading bale.




EX,435C,A -19-01SEP88

E32162 -UN-12SEP88

OPERATE BALER SAFELY

To avoid injury or death by being pulled into the machine:

- DO NOT attempt to feed crop or twine into baler or unplug feed area WHILE BALER IS RUNNING. The baler feeds material faster than you can release it.
- Disengage PTO and shut off engine.
- Stand clear of baler at all times when machine is operating.



EX,435C,B -19-01SEP88

E32161 -UN-12SEP88

OPERATE SAFELY ON SLOPES

Be especially careful when operating on hillsides. The baler may tip sideways if it strikes a hole, ditch, or other irregularity.

To prevent injury or damage from a rolling bale, discharge bales on level ground or in such a manner that the bale will not roll.

EX,435C,C -19-01SEP88




HANDLE ROUND BALES SAFELY

To help prevent personal injury, do not handle round bales without approved John Deere Round Bale Handling attachments.

Improper use of loaders to handle round bales can result in serious injury or death to the tractor/loader operator. This could be caused by the bale rolling back down the loader into the operator's station.

To attain optimum stability and visibility:

- Do not handle bales that exceed the bale weight limitations of the loader.
- Carry the bale slowly and as low as possible to the ground.
- Operate the loader controls smoothly, avoiding jerky operation.
- When handling round bales on a slope, always approach the bale with the tractor facing uphill.
- Never use the tractor/loader to stop a rolling bale.




W7718 -UN-06OCT88

EX,435C,D -19-01SEP88

KEEP RIDERS OFF MACHINE

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.



TS290 -UN-23AUG88

DX,RIDER -19-04JUN90




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

1. Eject bale immediately.
2. Move tractor and baler upwind 9 m (30 ft) away from flammable material.
3. Raise gate and engage gate lock valve.
4. Use fire extinguisher or other water supply to put out fire.

Keep first aid kit handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



-UN-23AUG88

TS291

EX,435C,J -19-01NOV88


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



-UN-23AUG88

TS206

DX,WEAR -19-10SEP90




HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



DX,MSDS,NA -19-15MAR91

TS1132 -UN-26NOV90

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



DX,PTO -19-04JUN90


TS198 -UN-23AUG88

USE SAFETY LIGHTS AND DEVICES

Slow moving tractors, self-propelled equipment and towed implements or attachments can create a hazard when driven on public roads. They are difficult to see, especially at night. Avoid personal injury or death resulting from collision with a vehicle.

Flashing warning lights and turn signals are recommended whenever driving on public roads. To increase visibility, use the lights and devices provided with your machine. For some equipment, install extra flashing warning lights.

Keep safety items in good condition. Replace missing or damaged items. An implement safety lighting kit is available from your John Deere dealer.



DX,FLASH -19-04JUN90

TS951 -UN-12APR90




USE A SAFETY CHAIN

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.

Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength rating equal to or greater than the gross weight of the towed machine. Do not use safety chain for towing.



-UN-23AUG88

TS217


DX,CHAIN -19-04JUN90

REDUCE SPEED WHEN TOWING LOADS

Braking to stop towed loads from transport speeds can cause the towed load to swerve and upset. Reduce speed if towed load weighs more than the tractor and is not equipped with brakes.

Follow recommended speed-weight ratio guidelines:

- Maximum speed is 20 mph (32 km/h) when towing load equal to or less in weight than the tractor.
- Reduce speed to 10 mph (16 km/h) when towing load up to double the tractor weight.
- Do not tow loads exceeding double the tractor weight.
- Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.



-UN-23AUG88

TS216

DX,TOW -19-04JUN90

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com