

466,
(Serial No. 144301-)
466 Silage Special,
(Serial No. 144901-)
and 566
(Serial No. 145601-)
Round Balers

John Deere Ottumwa Works
OME97074 Issue A0
(Mark old manual OME92593 L7 and OME92599
A8 for
machines up to Serial No. listed above.)

LITHO IN U.S.A.
ENGLISH

Introduction

FORWARD



466 Round Baler with Net Wrap

E40014 -UN-28MAY96

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction the implement will travel when going forward.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification section. Accurately record all the numbers to help in tracing the machine should it

be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty applicable to your machine may not apply outside the U.S.

Introduction



466 Silage Special Round Baler

E41686 -UN-26OCT96



566 Round Baler with MEGATOOTH Pickup and Gathering Wheels

E47630 -UN-06JAN00

AG.OUO6017,1573 -19-25OCT99-2/2

Contents

	Page		Page
Safety	05-1	Additional Net Wrap Storage	25-1
Safety Signs	10-1	Opening and Closing Net Wrap Cover	25-2
Preparing the Tractor		Using Net Wrap After Extended Storage ¹	25-2
Adjusting Tractor Drawbar	15-1	Manually Releasing Net Wrap Brake	25-8
Using Heavy-Duty Tractor Drawbar	15-2	Threading Net Wrap and Routing Through Rolls	25-9
Using Drawbar Shield	15-3	Attaching and Detaching	
Making Drawbar Shield	15-3	Assembling Main PTO Driveline Splined Telescoping Members (If Necessary)	30-1
Three-Point Hitch Position	15-3	Attaching Baler to Tractor Drawbar	30-1
Adjusting Tractor Wheels	15-4	Connecting PTO Driveline	30-2
Checking Ballast, Wheel Spacing, and Tire Inflation	15-5	Attaching to Tractor Hydraulic System	30-4
Setting Tractor Hydraulic Outlets	15-5	Using Tractor Convenience Outlet	30-5
Tractor Convenience Outlet	15-5	Connecting Baler Wiring Harness to Tractor. . .	30-5
Installing BALETRAK PLUS		Connecting Tail/Warning Light Plug to Tractor	30-6
Monitor-Controller		Detaching Baler From Tractor	30-7
Open-Station Tractor	15-8	Transporting	
ComfortGard Cab	15-8	Preparing Baler for Transport	35-1
SOUND-GARD Cab	15-10	Follow Safe Transport Procedures	35-4
Using Extended Rear-View Mirror	15-11	Lighting Enhancement Module Operation	35-4
Preparing the Baler		Keep Riders Off Machine	35-5
Checking Oversize Bale Switch	20-1	Using Extended Rear-View Mirror	35-5
Selecting Twine	20-1	Handling Round Bales	
Loading Twine Boxes	20-2	With Bale Fork	40-1
Routing Twine from Boxes		With Grapple	40-2
Left-Hand Side (Front Twine Arm)	20-3	With Round Bale Hugger	40-3
Right-Hand Side (Rear Twine Arm)	20-7	With Net Wrap	40-3
Wheel Spindle Positions 11L-14 Tires (466/566)		Feeding Round Bales	40-4
Regular or MEGATOOTH Pickup	20-11	Operating the Baler	
Wide Pickup (466)	20-12	How the Baler Forms a Bale	45-1
Wheel Spindle Positions 31 x 13.5-15 Tires		Crop Preparation	45-2
Regular or MEGATOOTH Pickup	20-13	Breaking In Baler	45-2
Wide Pickup (466/466S)	20-14	Keep Riders Off Machine	45-3
Adjusting Wheel Spindles	20-15	BALETRAK PLUS Monitor-Controller	
Tire Inflation	20-15	Introduction	45-4
Checking Wheel Nut Torque	20-16	Description	45-6
Preparing Baler for Net Wrap			
Selecting Net Wrap Material	25-1		
Care of Net Wrap Material	25-1		

Continued on next page

Contents

	Page		Page
Keys and Switches	45-8	Compressor Rack Assembly	
Displays and Indicators	45-9	Removing	45-56
Setup Values and Initial Settings	45-10	Installing	45-57
Diagnostic and Setup Modes	45-11	Adjusting (Regular or MEGATOOTH)	45-58
Diagnostic and Setup Channels	45-12	Adjusting Compressor Rod Channel	
Operating	45-13	(MEGATOOTH™ Pickup)	45-59
Resetting to Initial Settings (Channel 01)	45-15	Setting Pickup Feeder Forks (Wide	
Activating Alarms	45-16	Pickup—466/466S)	45-60
Adjusting Audible Alarm Volume	45-17	Starting a Bale in Difficult Conditions	45-61
Setting Bale Diameter	45-17	Baling	
Adjusting Bale Diameter Display	45-18	Short, Dry, Slick Crops	45-62
Optional Variable (Soft) Core (If Equipped)		Cornstalks	45-64
Understanding	45-19	Long, Stiff, Cane-Type Crops	45-66
Adjusting	45-20	Wet Hay	45-68
Understanding Twine Wrap Terms and		Fire Prevention	45-69
Settings	45-23	Extinguishing a Fire	45-70
Setting		Bale Push Bar (If Equipped)	
Twine Spacing	45-25	Operation	45-71
Number of Twine End Wraps	45-26	Operating	45-73
Twine End Wrap Distance	45-27	Locking Out	45-75
Number of Net Wraps (If Equipped)	45-29	Engaging	45-76
Recommended Baling Guidelines	45-30	Attachments	
Interpreting Bale Shape Indicators	45-31	Hitch Conversion Kit	50-1
Weaving in the Windrow	45-33	Pickup Gauge Wheels	50-1
Viewing and Resetting Bale Counters	45-34	Gathering Wheels	50-1
Using Manual Actuator, Wrap, and Bypass		Hi-Flotation Tires	50-2
Switches	45-35	Bale Push Bar	50-2
Using Bypass Switch (Twine Wrap Only)	45-36	Surface Wrap Unit	50-3
Advanced Operational Information		High-Moisture Kit (466 and 566)	50-3
Using Dry Straw Twine Wrap		Hydraulic Pickup Lift	50-4
(Channel 17)	45-37	Variable Core Valve	50-4
Setting Bale Shape Sensitivity		Buildup Reduction Scraper Kit	50-5
(Channel 24)	45-38	Gate Deflectors (466 and 566)	50-5
Setting Near-Full Indicator Set Point		BALETRAK PLUS Monitor-Controller	50-6
(Channel 25)	45-39	Monitor-Controller Mounting Brackets	50-6
Adjusting Net Wrap Delay (Channel 26)	45-40	Mounting Kit For Open Station 6000 and	
Changing Monitor-Controller Display to		7000 Series Tractors	50-7
Metric or English Units	45-41	Belt Lacing Tool	50-7
Changing Baler Model Program	45-42	Skiving Tool	50-7
Bale Density Gauge	45-43	Drawbar Shield	50-7
Adjusting		Electrical Outlet Socket	50-8
Bale Density	45-44	Rear-View Mirror Extension	50-8
Twine Tension	45-45	Bale Accumulator	50-9
Pickup Height	45-48	PTO Conversion Parts	50-10
Gauge		Fire Extinguisher	50-11
Wheels--Regular/MEGATOOTH Pickup	45-49	Allied Equipment	50-13
Gauge Wheels--Wide (466/466S)	45-51	Lubrication and Maintenance	
Gathering Wheel Height (If Equipped)	45-51	Grease	55-1
Checking Baler Performance in the Field	45-52	Gear Case Oil	55-1
Locking the Gate	45-53		
Unplugging Baler With Hydraulic Pickup Lift			
(If Equipped)	45-54		
Unplugging Baler Under Power	45-55		

Continued on next page

Contents

	Page		Page
Alternative and Synthetic Lubricants	55-2	Lower Belt and Cleaning Auger Drive Roll	
Observe Lubrication Symbols	55-2	Chain (466S)	65-28
Perform Lubrication and Maintenance	55-3	Upper Drive Roll Chain	65-29
Fire Prevention	55-3	Servicing Upper Chain and Idler	65-29
Belt Pins	55-4	Replacing Chain Idler Bushing	65-30
Every 10 Hours	55-4	Main Drive Slip Clutch	
Every 30 Hours	55-8	Adjusting	65-31
Every 50 Hours	55-12	Slipping	65-32
Every 100 Hours	55-13	Checking Pickup Slip Clutch Torque (
Annually	55-13	MEGATOOTH™ or Wide—466/466S)	65-34
Troubleshooting		Belt Tracking	
PTO Driveline Difficulties	60-1	Checking	65-37
Main Drive Slip Clutch Difficulties	60-2	Adjusting	65-37
Drive Chain Difficulties	60-3	Adjusting Scraper(s)	
Gear Case Difficulties	60-4	Lower Feed Roll	65-40
Diagnosing Hydraulic Functions	60-5	Starter Roll (If Equipped)	65-42
Automatic Twine Wrap	60-9	Idler Roll	65-43
BALETRAK PLUS Monitor-Controller		Auger (Wide Pickup—466/466S)	65-43
Difficulties	60-19	Checking and Adjusting Clearance	
Feeding Difficulties	60-33	Between Cleaning Auger and Staggered Belt	
Pickup Difficulties	60-38	Roll	65-44
Bale Quality	60-43	Adjusting	
General Baler Difficulties	60-45	Take-Up Arm Compression Springs	65-46
Push Bar Difficulties	60-53	Twine Indicator Retaining Strap	65-47
High-Moisture Kit (Silage Baling) Difficulties	60-55	Twine Cutter Tension	65-48
Net Wrap Difficulties	60-58	Clearance Between Cutter Link	
Support and Twine Arm	65-53	Front Twine Arm	65-55
Service—Baler		Twine Cutter to Twine Arm	65-57
Detailed Service Information—Use TM1767	65-1	Twine Arm Timing (566)	65-59
Practice Safe Service Procedures	65-2	Checking Knife Adjustment	65-60
Fire Prevention	65-3	Twine Electric Actuator Installation	
Keep Service Area Clean	65-4	Adjustment	65-63
Service Tires Safely	65-5	Adjusting Twine Arm to Starter Roll,	
Rotating Output Shaft By Hand	65-5	Cutter Link Support, and Twine Arm Stop	65-69
BALETRAK PLUS Component Locations	65-6	Adjusting Pickup Float Springs	
Wiring Harness Diagrams		Regular Pickup (466 and 566)	65-75
BALETRAK PLUS	65-7	MEGATOOTH Pickup	65-76
Baler	65-11	Wide Pickup (466/466S)	65-77
Replacing Monitor Fuses and Relays	65-15	Adjusting Pickup Lift Crank Stop Nuts	
Hydraulic System Diagram	65-17	(Wide Pickup—466/466S)	65-78
Installing Orifice in Tractors With Low		Hydraulic Pickup Lift Cylinder Dimension (If	
Hydraulic Flow	65-19	Equipped)	65-79
Adjusting		Checking Pickup Tooth End Play	65-80
Pickup Idler Spring--Regular Pickup (466		Adjusting	
and 566)	65-22	Gate Latch Stop	65-81
Pickup Belt Idler-Regular Pickup (466		Gate Latch Linkage	65-82
and 566)	65-23	Replacing	
Pickup Drive Chains--MEGATOOTH		Twine Wrap Sensor	65-83
Pickup	65-24	Bale Diameter Sensor	65-84
Pickup Drive Chains--Wide Pickup		Bale Shape Sensor	65-84
(466/466S)	65-25		
Lower Drive Roll Chain	65-27		

Continued on next page

Contents


	Page		Page
Adjusting		Removing and Installing Net Wrap V-Belt V-Belt Idler Arm	70-35
Twine Wrap Sensor (Channel 3--With Sound)	65-85	Removing and Installing	70-37
Bale Diameter Sensor (Channel 05--With Sound)	65-88	Checking Adjustment	70-37
Bale Shape Bar Display (Channels 07 and 09)	65-90	Adjusting Net Wrap Roll Support Brackets	70-40
Adjusting Bale Shape Sensor (Channels 07 and 09—With Sound)	65-91	Checking and Adjusting Lower Net Wrap Guide	70-42
Testing		Storage	
Gate Latch and Oversize Bale Switches	65-93	Storing Baler (End of Season)	75-1
Twine Wrap Actuator Current	65-95	Removing Baler from Storage (Beginning of Season)	75-2
Tractor Convenience Outlet Voltage	65-97		
Liquid Crystal Display (LCD) Panel	65-98	Specifications	
Adjusting Switches		BALETRAK PLUS Monitor-Controller	80-1
Oversize Bale	65-99	Machine Specifications	80-2
Gate Latch	65-100	Record Product Identification Numbers	80-4
Checking Microswitches	65-101	Record Serial Numbers	
Raising Gate With Hoist	65-101	Baler	80-4
Checking Belt Pins	65-102	Net Wrap (If Equipped)	80-4
Correct Belt Lacing and Pin Installation	65-103	Bolt and Cap Screw Torque Values	
Incorrect Belt Lacing and Pin Installation	65-104	Metric	80-5
Installing Belts	65-105	Inified Inch	80-6
Repairing Belts	65-106	Crime Prevention Tips	
Belts Eligible For Warranty Replacement	65-114	Help Prevent Crime	85-1
Belts Not Eligible for Warranty Replacement	65-114	Record Ag Identification Numbers	85-1
Service—Net Wrap		Keep Proof of Ownership	85-1
Detailed Service Information—Use TM1767	70-1	Park Indoors Out of Sight	85-2
Practice Safe Service Procedures	70-1	When Parking Outdoors	85-2
Releasing Feed Roll Brake	70-2	Reduce Vandalism	85-3
Correcting Net Wrap Feeding Problems	70-3	Report Thefts Immediately	85-3
Repairing Cuts on Feed Roll	70-6	John Deere Service Literature Available	1
Brake Bar Tension		John Deere Service Keeps You On The Job	2
Decreasing	70-6		
Increasing	70-8		
Adjusting Knife Arm Stop	70-10		
Checking and Adjusting Feed Roll Brake	70-15		
Adjusting Feed Roll Pressure	70-17		
Net Wrap Switch			
Monitor-Controller Assisted Test (Channel 10)	70-18		
Checking and Adjusting	70-20		
Cutoff Indicator Channel			
Checking Travel	70-23		
Straighten	70-25		
Net Wrap Knife			
Removing and Installing	70-27		
Sharpening	70-29		
Actuator			
Removing	70-30		
Installing	70-32		

Safety

RECOGNIZE SAFETY INFORMATION

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98-1/1

T81389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.




TS201 -UN-23AUG88

DX,READ -19-03MAR93-1/1

PROTECT BYSTANDERS

To prevent crushing injury be sure bystanders stand clear before operating gate and unloading bale.




E32162 -UN-12SEP88

EX,435C,A -19-01SEP88-1/1

OPERATE BALER SAFELY

To avoid injury or death by being pulled into the machine:


- DO NOT attempt to feed crop or twine into baler or unplug feed area WHILE BALER IS RUNNING. The baler feeds material faster than you can release it.
- Disengage PTO and shut off engine.
- Stand clear of baler at all times when machine is operating.



E32161 -UN-12SEP88

EX,435C,B -19-01SEP88-1/2

If baler plugs during twine arm cycle, it is recommended that twine arms be manually positioned to release any "hold" they may have on the crop plug. Turn off power to twine arms. This will help to make the unplugging operation easier and prevent twine arms from moving unexpectedly while your hands may be in the path of the twine arms. Stay out of the path of twine arms at all times when power to the arms is ON.




E47598 -UN-07JAN00

EX,435C,B -19-01SEP88-2/2

OPERATE SAFELY ON SLOPES

Be especially careful when operating on hillsides. The baler may tip sideways if it strikes a hole, ditch, or other irregularity.

To prevent injury or damage from a rolling bale, discharge bales on level ground or in such a manner that the bale will not roll.



E36866 -UN-30APR92

EX,435C,C -19-14JUL92-1/1


HANDLE ROUND BALES SAFELY

To help prevent personal injury, do not handle round bales without approved John Deere Round Bale Handling attachments.

Improper use of loaders to handle round bales can result in serious injury or death to the tractor/loader operator. This could be caused by the bale rolling back down the loader into the operator's station.

To attain optimum stability and visibility:

- Do not handle bales that exceed the bale weight limitations of the loader.
- Carry the bale slowly and as low as possible to the ground.
- Operate the loader controls smoothly, avoiding jerky operation.
- When handling round bales on a slope, always approach the bale with the tractor facing uphill.
- Never use the tractor/loader to stop a rolling bale.



W7718 -UN-06OCT88

EX,435C,D -19-01SEP88-1/1

KEEP RIDERS OFF MACHINE

Keep riders off.

Riders are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.



TS249 -UN-23AUG88

EX,945IC,H -19-13FEB97-1/1

PREPARE FOR EMERGENCIES


Be prepared if a fire starts.

1. Eject bale immediately.
2. Move tractor and baler upwind 9 m (30 ft) away from flammable material.
3. Raise gate and engage gate lock valve.
4. Use fire extinguisher or other water supply to put out fire.

A 9.5 L (2-1/2 gal) pressurized-water fire extinguisher is recommended. See manufacturers recommendation for inspection and maintenance.

Keep first aid kit handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

EX,435C,J -19-25OCT96-1/1

FIRE PREVENTION

To reduce the risk of fire, follow these guidelines, especially in dry crop conditions:

- Equip the baler with a water-type fire extinguisher. Large capacity water fire extinguishers are recommended because application of water can cool hot parts to prevent a fire. (See Attachments section.)
- Keep foreign material (crop, chaff, twine, net wrap material, etc.) from building up on the machine near potentially hot areas, such as bearings on ends of baler rolls and slip clutch. Remove this buildup as part of the regular service operations.
- Avoid high pressure power-washing adjacent to the bearings on ends of baler rolls to prevent damaging seals.
- Check bearings on ends of baler rolls regularly for early signs of failure replace as necessary. (See Lubrication and Maintenance section or see your John Deere dealer.)
- If noticeable changes in machine performance occur which might indicate a part is beginning to fail, stop baling immediately and investigate the cause of any sounds, smells, or sights which are unusual.
- Promptly eject bales after they have been tied or wrapped. Do not use the baler to transport bales from the field. Do not bring a baler, with a bale inside it, into a building. Never leave a baler unattended with a bale inside the chamber.
- Use extreme care if it is necessary to park a baler in a field of dry crop or stubble. Whenever possible, park baler on bare ground or in an area surrounded by bare ground. Before leaving a baler which has been operating, verify there are no areas which are hot enough to start a fire. Do not leave the baler unattended near bales which have been baled wet, because spontaneous combustion can occur.
- If service operations require using a welder, cutting torch or grinder on the baler, refer to Fire Prevention in Service—Baler section for guidelines which may prove useful in preventing a fire.
- Use extreme care when smoking around the baler.



TS227 -UN-23AUG88

EX,566C.N -19-16DEC97-1/1

IN CASE OF FIRE

Stop baling immediately at the first sign of trouble. This may be a scorched smell, an unusual sound, or the sight of smoke or flame.

Do not risk personal injury. If a fire is too far advanced, do not try to extinguish it.

If you can safely extinguish the fire, proceed carefully and follow these guidelines:

- Position the tractor upwind from the baler to avoid the fire from overtaking the tractor.
- Open the baler gate to eject any crop material from the bale chamber, and drive away from this material.
- Use a fire extinguisher or other source to spray water at the base of the flame, and to cool adjacent parts. Do not position yourself under an open baler gate. It may fall if baler is on fire.



TS227 -UN-23AUG88

EX,566C,O -19-05SEP97-1/1


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1


HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.




TS1644 -UN-22AUG95

DX,PTO -19-12SEP95-1/1

USE SAFETY LIGHTS AND DEVICES

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use hand signals or turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible and in good working order. Replace or repair lighting and marking that has been damaged or lost.



TS951 -UN-12APR90


DX,FLASH -19-17FEB99-1/1

USE A SAFETY CHAIN

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.

Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength rating equal to or greater than the gross weight of the towed machine. Do not use safety chain for towing.



TS217 -UN-23AUG88

DX,CHAIN -19-03MAR93-1/1


TOW LOADS SAFELY

Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control. Consider the total weight of the equipment and its load.

Observe these recommended maximum road speeds, or local speed limits which may be lower:

- If towed equipment does not have brakes, do not travel more than 32 km/h (20 mph) and do not tow loads more than 1.5 times the tractor weight.
- If towed equipment has brakes, do not travel more than 40 km/h (25 mph) and do not tow loads more than 4.5 times the tractor weight.

Ensure the load does not exceed the recommended weight ratio. Add ballast to recommended maximum for tractor, lighten the load, or get a heavier towing unit. The tractor must be heavy and powerful enough with adequate braking power for the towed load. Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.



TS216 -UN-23AUG88

DX,TOW -19-02OCT95-1/1

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



TS218 -JUN-23AUG88

DX.SERV -19-17FEB99-1/1

REMOVE PAINT BEFORE WELDING OR HEATING

Avoid potentially toxic fumes and dust.


Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 76 mm (3 in.) from area to be affected by heating.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do all work in an area that is ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.



TS2220 -UN-23AUG88

DX,PAINT -19-22OCT99-1/1

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



TS953 -UN-15MAY90

DX,TORCH -19-03MAR93-1/1


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -UN-26NOV90

DX,DRAIN -19-03MAR93-1/1

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com