

OPERATOR'S MANUAL

OVERHEAD FRAME RAKE

| WR3414

| WR3416

| WR3417

| WR3419



HSMFG1008

5HPOMR8

TABLE OF CONTENTS

TABLE OF CONTENTS.....	INSIDE COVER
NOTES.....	1
DEALER PRE-DELIVERY & DELIVERY CHECKLIST.....	3
SPECIFICATIONS.....	5
BOLT TORQUE CHART.....	6
BE ALERT SYMBOL.....	7
SAFETY RULES.....	8-9
DANGER - WARNING DECALS.....	10
OPERATION WR3414, WR3416, WR3417 & WR3419.....	11-13
ADJUSTMENTS WR3414, WR3416, WR3417 & WR3419.....	14
LUBRICATION WR3414, WR3416, WR3417 & WR3419.....	15
DECAL LOCATION.....	16
OPTIONAL EQUIPMENT.....	17
TROUBLE SHOOTING.....	17
ORDERING PARTS - ABOUT IMPROVEMENTS.....	18
SERVICE AND PARTS NOTES.....	19
PARTS LISTS & DIAGRAMS WR3414, WR3416, WR3417 & WR3419.....	20-30

NOTES

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com