

# OPERATOR'S MANUAL

## MANURE SPREADER

**MS1231**

**MS1237**

**MS1243**



**FRONTIER**  
EQUIPMENT

# TABLE OF CONTENTS

TABLE OF CONTENTS.....	INSIDE COVER
WARRANTY & NOTES.....	1
DEALER PRE-DELIVERY & DELIVERY CHECKLIST.....	3
SPECIFICATIONS.....	5
BOLT TORQUE CHART.....	6
BE ALERT SYMBOL.....	7
SAFETY RULES.....	8-9
DANGER - WARNING DECALS.....	10-11
OPERATION MS1231, MS1237 & MS1243.....	12-13
ADJUSTMENTS.....	14-16
LUBRICATION GUIDE MS1231, MS1237 & MS1243.....	16-18
TROUBLE SHOOTING.....	19
OPTIONAL EQUIPMENT.....	20-21
DECAL LOCATION.....	22-23
ORDERING PARTS - ABOUT IMPROVEMENTS.....	24
SERVICE & PARTS NOTES.....	25
PARTS LISTS & DIAGRAMS MS1231, MS1237 & MS1243.....	26-49
OPTIONAL DOUBLE CYLINDER (MS1231 ONLY).....	39
OPTIONAL HYDRAULIC DRIVE.....	41
OPTIONAL PAN.....	27
OPTIONAL TOP BEATER.....	48
OPTIONAL ELECTRIC CONTROLS.....	49
SERVICE RECORDS.....	50

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)