


OPERATOR'S MANUAL

# SNOWBLOWER

SB1388

Serial #: 1XFSB13X\_E0140001 & plus



**FRONTIER.**

OM 0437SB1388-A  
09/14

---

# TABLE OF CONTENT

---

SPECIFICATIONS.....	3
INTRODUCTION – TO THE PURCHASER.....	4
SAFETY PRECAUTIONS .....	5-10
General Information.....	5
Notice .....	6
The Snowblower .....	6
Before Operation.....	6
Snowblower Operation .....	6
Stay Clear of Rotating Drivelines .....	8
The Tractor.....	9
General Information .....	9
Operating the Tractor.....	9
During Operation.....	9
Maintenance .....	9
Transportation.....	10
Storage .....	10
SAFETY DECALS .....	11-12
ASSEMBLY.....	13-28
Tractor Preparation.....	13
Snowblower Assembly .....	13
Installation of SMV Sign .....	13
Installation of Three Point Hitch.....	14
Installation of the <b>5RDF0072</b> or <b>5RDF0073</b> Chute, and the Hydraulic Rotation .....	15
Installation of the <b>5RDF0071</b> Hydraulic Deflector for 2 part Chute .....	16
Installation of the Hydraulic Hoses .....	17
A- Hoses of the chute rotation.....	17
B- Hoses of the chute deflector.....	17
Installation of Second Auger - <b>5RDF0063</b> .....	19
Installation of Serrated Auger <b>5RDF0067</b> .....	20
Installation of Drift Cutters - <b>5RDF0074</b> .....	21
Installation of Stainless Skid Shoes - <b>5RDF0062</b> .....	21
Installation of Lower Hitches for Quick Hitch - <b>5RDF0077</b> .....	22
Installation of Snowblower with Three Point Hitch.....	23
Installation of Snowblower with Quick Hitch.....	24
Preparation of the driveline.....	25
Recommendations for driveline angles .....	25
Angles at Each End of Driveline .....	25
Determining Driveline Length .....	26
Driveline Installation .....	28
Removing Snowblower from Tractor.....	28

---

## TABLE OF CONTENT

---

OPERATION .....	29-31
General Preparation .....	29
Operating Controls .....	29
Raising and Lowering the Snowblower.....	29
Work and Travel Speed .....	29
PTO Operation.....	29
Chute Rotation Orientation.....	29
Hydraulic Chute Deflector Orientation .....	30
Adjustments .....	29
Manual Deflector Adjustment.....	30
Skid Shoe Adjustment.....	30
Chute Door Adjustment.....	30
Snow Removal Methods .....	31
MAINTENANCE .....	32-37
Maintenance.....	32
Driveline.....	32
Shearbolts .....	32
Driveshaft .....	32
Driveline .....	32
Chain Idler Adjustment .....	33
Lubrication.....	34
Driveline – Troubleshooting.....	35-37
PARTS .....	38-55
Introduction .....	38
Manual Holder .....	38
Chain Idler .....	39
Snowblower Assembly – Front Part .....	40
Snowblower Assembly – Rear Part.....	42
Three Point Hitch.....	44
Hydraulic rotation .....	46
Gearbox .....	47
Driveline .....	48
<b>5RDF0072</b> - Two Part Chute .....	49
<b>5RDF0073</b> - Three Part Chute .....	50
<b>5RDF0071</b> - Hydraulic Deflector.....	51
<b>5RDF0077</b> - Lower hitches for quick hitch .....	52
<b>5RDF0063</b> - Second Auger .....	53
<u><b>Other Options: Drift Cutters - Stainless Skid Shoes -</b></u>	
<b>Cutting Edges</b> CHT400, Tivar, Stainless – <b>Serrated Auger</b> .....	54
TORQUE SPECIFICATION TABLE .....	55

# SPECIFICATIONS

Specifications	SB1388
<b>General</b>	
Type	2 phases
Direction of impeller rotation	CCW
PTO power requirements	55 - 85 Hp
Shipping weight (without chute)	1531 Lbs
Operating weight, incl. chute & hyd. deflect.	1607 Lbs
Set-up time	90 min
Working width	88 1/2"
Working height	41"
Overall width	88 1/2"
Overall height (without chute)	42 1/2"
Overall height (with three part chute closed)	81"
Overall length	59"
<b>Impeller</b>	
Impeller diameter	28"
Impeller width	12"
Number of impeller blade	4
Impeller shaft diameter	1 9/16"
Impeller RPM	540 RPM
<b>Auger</b>	
Auger - Single / dual	Single (dual in option)
Main auger diameter	23"
Auger driven system	Chain No.80
Second auger diameter	14"
Second auger driven system	Chain No.60
Auger RPM	185 RPM
<b>Drum</b>	
Rotating drum	No
Rotation of drum	N/A
Flow restrictor	N/A
<b>Housing</b>	
Housing thickness	10 Ga.
Side panel thickness	1/4"
Impeller housing thickness	1/4"
<b>Chute</b>	
Chute position	Right
Rotation of the chute	Hydraulic by motor
Flow restrictor (rotation)	Yes
Flow restrictor (deflector)	Yes
Hoses support	Yes
Deflector adjustment (2 part chute)	Manual (hydraulic in option)
Deflector adjustment (3 part chute)	Hydraulic
<b>Cutting edge</b>	
Replaceable and reversible cutting edge	Yes
Cutting edge material	Carb.steel (other mater.available)
Cutting edge dimension	1/2" x 4"
<b>Skid shoe</b>	
Replaceable and reversible skid shoe	Yes, 8 positions
Skid shoe material	Stand.steel (other mater.available)
<b>Drive and hitch</b>	
Main driving system	Driveline series 80
Chain idler	Twin sprokets w/compress.spring
Parking stand	Yes
Number of auger shear bolt	1 (on the driving shaft)
Number of impeller shear bolt	1 (on the driveline)
Type of hitch	3 pts, cat. 2
Compatibility with quick hitch	Requires kit 5RDF0077

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)