

1042/1052 Draper Headers Service Manual 7-90260 Table of Contents

Description	Section No.	Form No.
Hydraulics	Tab 8	
How It Works	8000	7-91550
Pump Drive Gearbox - Combine Adapter	8010	7-90250
Draper, Reel and Auger Drive Motor	8020	7-91350
Flow Control Valve - Combine Adapter	8030	7-91360
Sickle Drive Wobble Box	8040	7-91440
Feed Auger, Reel and Draper Drive Hydraulic Pump	8050	7-89640

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Rac 7-90260

© 1999 Case Corporation
Printed in U.S.A.
March, 1999

Section 8000

HOW IT WORKS

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Rac 7-91550EN

© 1999 Case Corporation
Printed in U.S.A.
March, 1999

8000

TABLE OF CONTENTS

OBJECTIVES	3
GENERAL INFORMATION	4
HYDRAULIC SYSTEM SPECIFICATIONS	5
HYDRAULIC RESERVOIR AND FILTERS	6
Hydraulic Reservoir	7
Filtration System	7
Hydraulic oil cooling system	7
HYDRAULIC PUMP AND DRIVE SYSTEM	8
Mounting Adapter Pump	9
MOTORS AND VALVES	10
Motors	11
Feed Auger Motor	11
Feeder Draper Motor	11
Left and Right Draper Motors	11
FLOW CONTROL VALVE	12
Flow Control Valve Components	14
Flow Control Valve Components	15
Relief Valve	15
Pressure-Compensating Spool	15
Check Valves	15
SYSTEM OPERATION	16
HYDRAULIC SYSTEM TESTING PROCEDURES	20
DIAGNOSTIC TEST EQUIPMENT	21
Hydraulic	21
Test Couplers and Hoses	21
DIAGNOSTIC TEST EQUIPMENT	22
Hydraulic	22
Digital Pressure & Temperature Analyzer	22
SYSTEM RELIEF VALVE TEST	24
SYSTEM RELIEF VALVE TEST	25
DRAPER DRIVE PUMP TEST	26
Draper Pump Flow and Pressure Test	27
CHECK VALVE TROUBLESHOOTING	28

NOTE: Case Corporation reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

OBJECTIVES

After completion of this section of the training manual, the learner will be able to accomplish the following:

Understand how to read hydraulic schematics.

1. Know the location of all hydraulic components.
2. Know how all hydraulic components function.
3. Know how each hydraulic circuit functions.
4. Be able to pressure test each hydraulic circuit.
5. Be able to properly disassemble and reassemble the main valve assembly.
6. Be able to diagnose and systematically troubleshoot defects in the hydraulic system.

GENERAL INFORMATION

This section addresses the hydraulic system of the 1042 and 1052 Draper Headers

There are two hydraulic systems that control the functions of the header as follows:

Combine Hydraulics: Same as with the 1010 and 1020 grain headers

- Operate the Reel Drive
- Raise and Lower the Reel
- Move the Reel Fore and Aft


Header Hydraulics: Totally self contained on the header

- Is used to operate the Feeder Auger and Feeder Draper
- Is used to operate and control the speed of the Right and Left Drapers

HYDRAULIC SYSTEM SPECIFICATIONS

Pump output (Max)	32 Litres (8.5 gpm)
Pump output (min)	24.5 Litres (6.5 gpm)
Relief Valve Setting	190 ± 3 bar (2750 ± 50 PSI)
Reservoir Capacity	System 25 Litres (6.6 US gal) Tank only 17 Litres (4.5 US gal)
Oil Type	SAE 15W40 Class SH or CH-4 engine oil
Change Interval	1000 hours or 3 years
Filter Change Interval	First 50 hours and every 250 hours after

HYDRAULIC RESERVOIR AND FILTERS



RR99E004

Right Front View Of Adapter Housing

- A. Reservoir Tank Fill Cap, Dipstick and Breather
- B. Reservoir Drain
- C. Filter

HYDRAULIC RESERVOIR AND FILTERS

Hydraulic Reservoir

The hydraulic reservoir is located on the left-side of the header. It has a capacity of 17 Litres (4.5 gals.) of SAE 15W40 engine oil. The reservoir contains a separate filtered breather assembly. The fill cap contains a dipstick for checking the oil level, add oil until the level is in the safe zone. Do not overfill.


Filtration System

The filtration system consists of one external spin-on filter. This element is 95% efficient at a 10 micron rating. The service interval is after the first 50 hours and every 250 hours or once a year thereafter. The spin-on hydraulic filter is in the return line to the reservoir, therefore it is important clean oil is added to the reservoir. The filter base contains a 1.1 bar (15 psi) bypass valve to protect the filter from rupturing. There is no warning light or alarm to tell the operator that the oil is bypassing, so it is important that the filter is serviced at the recommended intervals.

Hydraulic oil cooling system

Heat is generated as oil moves through the system. The reservoir tank and lines provide cooling for the system. The system will normally run $100 \pm 20^{\circ}$ F above ambient temperature.

HYDRAULIC PUMP AND DRIVE SYSTEM



RR99E005

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com