


John Deere > Agriculture > TRACTOR > SE6400 - TRACTOR > SE6100, SE6200, SE6300, SE6400 Tractors (Europe Edition) > 20 ENGINE > ST233984 - CYLINDER BLOCK, KIT

| REGGG97 | KEY | PART NO. | PART NAME | QTY | SE6200 | SE6300 | REMARKS |
|--|-----|----------|-----------------|-----|--------|--------|---|
| 1 | 1 | RE66497 | CYLINDER BLOCK | 1 | X | X | |
| 1 | 2 | 19H2676 | CAP SCREW | 2 | X | X | 3/8" X 1", (SAE 8) |
| CAMMAFT 1 | 3 | T20072 | PLATE | 1 | X | X | |
| CAMSHATE | 4 | T28041 | SHAFT KEY | 1 | X | X | 3.175 X 16.662 mm, (SUB FOR 26H72) |
| R48802 | 5 | | CAMSHAFT | 1 | X | X | |
| 8 R4868S DOWEL PIN 4 X X OD = 12.7 mm, (0.5"), UP, REAR 9 R26650 DOWEL PIN 2 X X OD = 9.5 mm, (0.37"), RRONT 10 19H1726 CAP SCREW 2 X X 3/8" X 2-1/4" 11 T25701 STUD 1 X X CGTH = 55.5 mm, 3/8"-16 UNC, (SUB FOR R108S88 AND R130883) 12 T18891 PLUG 1 X X OD = 16 mm, (0.63") 13 R26493 BUSHING 1 X X LGTH = 51 mm, (2"), (ORDER RE63674) 14 SPRING 1 X X LGTH = 51 mm, (2"), (ORDER RE63674) 15 SPRING 1 X X LGTH = 51 mm, (2"), (ORDER RE63674) 16 T23474 CAP SCREW 10 X X LGTH = 40.5 mm, (1.594"), (ORDER RE63674) 18 BEARING CAP AR X X (SUB FOR RE636497) 19 BEARING CAP AR | 6 | T20073 | CAM FOLLOWER | 8 | X | X | |
| 9 R26650 DOWEL PIN 2 X X OD = 9.5 mm, (0.37"), FRONT 10 19H1726 CAP SCREW 2 X X 3/8" X=21/4" CM 11 725701 STUD 1 X X LGTH = 55.5 mm, 3/8" -16 UN X 3/8" -17 UN X 3/8" -16 UN X 3/8" -17 UN | 7 | R54802 | ORIFICE | 4 | X | X | |
| 10 | 8 | R48685 | DOWEL PIN | 4 | X | X | OD = 12.7 mm, (0.5"), UP, .REAR |
| T25701 T25701 T25701 TUD T | 9 | R26650 | DOWEL PIN | 2 | X | X | OD = 9.5 mm, (0.37"), FRONT |
| T25701 | 10 | 19H1726 | CAP SCREW | 2 | X | X | 3/8" X 2-1/4" |
| 13 R26493 BUSHING 1 | 11 | T25701 | STUD | 1 | X | X | |
| 1 | 12 | T18891 | PLUG | 1 | X | X | OD = 16 mm, (0.63") |
| 15 | 13 | R26493 | BUSHING | 1 | X | X | |
| 16 T23474 CAP SCREW 10 X X (SUB FOR R32214, THIS APPLICATION) 17 T20168 WASHER 10 X X (GRDER RE66497) 18 BEARING CAP AR X X (GRDER RE66497) 19 BEARING CAP AR X X REAR, (ORDER RE66497) 20 R97185 O-RING 1 X X X 21 CYLINDER BLOCK 1 X X (MARKED R122820) (ORDER RE66497) 22 15H623 PIPE PLUG 1 X X 3/8" 23 15H690 PIPE PLUG 1 X X 3/4", (FOR 15H616 OR L62675) 24 15H616 PIPE BUSHING 1 X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X 1/8"-27 NPT, (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 U13639 O-RING | 14 | | SPRING | 1 | X | X | LGTH = 51 mm, (2"), (ORDER RE63674) |
| 17 T20168 WASHER 10 X X (SUB FOR R32214, THIS APPLICATION) 18 BEARING CAP AR X X (ORDER RE66497) 19 BEARING CAP AR X X REAR, (ORDER RE66497) 20 R97185 O-RING 1 X X X 21 CYLINDER BLOCK 1 X X (MARKED R122820) (ORDER RE66497) 22 15H623 PIPE PLUG 1 X X 3/8" 23 15H690 PIPE PLUG 1 X X 3/4", (FOR 15H616 OR L62675) 24 15H616 PIPE BUSHING 1 X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X X (INCLUDES R501377) (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 | 15 | | VALVE | 1 | X | X | LGTH = 40.5 mm, (1.594"), (ORDER RE63674) |
| 18 BEARING CAP AR X X (ORDER RE66497) 19 BEARING CAP AR X X REAR, (ORDER RE66497) 20 R97185 O-RING 1 X X X 21 CYLINDER BLOCK 1 X X (MARKED R122820) (ORDER RE66497) 22 15H623 PIPE PLUG 1 X X 3/8" 23 15H690 PIPE PLUG 1 X X 3/4", (FOR 15H616 OR L62675) 24 15H616 PIPE BUSHING 1 X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X 1/8"-27 NPT, (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 U13639 O-RING 1 X X (USE WITH RE508185 AND R39741) | 16 | T23474 | CAP SCREW | 10 | X | Х | |
| 19 | 17 | T20168 | WASHER | 10 | X | X | (SUB FOR R32214, THIS APPLICATION) |
| 20 | 18 | | BEARING CAP | AR | X | X | (ORDER RE66497) |
| 21 | 19 | | BEARING CAP | AR | X | X | REAR, (ORDER RE66497) |
| 22 15H623 PIPE PLUG 1 X X X 3/8" 23 15H690 PIPE PLUG 1 X X X 3/4", (FOR 15H616 OR L62675) 24 15H616 PIPE BUSHING 1 X X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X X X X X X X X | 20 | R97185 | O-RING | 1 | X | Х | |
| 23 15H690 PIPE PLUG 1 X X 3/4", (FOR 15H616 OR L62675) 24 15H616 PIPE BUSHING 1 X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X X X X X X X X | 21 | | CYLINDER BLOCK | 1 | X | Х | (MARKED R122820) (ORDER RE66497) |
| 24 15H616 PIPE BUSHING 1 X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X X 1/8"-27 NPT, (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 U13639 O-RING 1 X X X (USE WITH RE508185 AND R39741) | 22 | 15H623 | PIPE PLUG | 1 | X | X | 3/8" |
| 24 15H616 PIPE BUSHING 1 X X 3/4", (FOR 15H690) 24 L62675 ADAPTER FITTING 1 X X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X X 1/8"-27 NPT, (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 U13639 O-RING 1 X X X (USE WITH RE508185 AND R39741) | 23 | 15H690 | PIPE PLUG | 1 | X | X | 3/4", (FOR 15H616 OR L62675) |
| 24 L62675 ADAPTER FITTING 1 X X 1"-11.5 NPT X 3/4"-14 NPT, (FOR 15H690) 25 RE71255 PIPE PLUG 5 X X 1/8"-27 NPT, (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 U13639 O-RING 1 X X X (USE WITH RE508185 AND R39741) | 24 | 15H616 | PIPE BUSHING | 1 | X | X | |
| 25 RE71255 PIPE PLUG 5 X X X 1/8"-27 NPT, (SUB FOR R119392, R104592 OR RE42713) 26 RE508185 FITTING 1 X X X (INCLUDES R501377) (SUB FOR RE502422 AND R34741) 27 U13639 O-RING 1 X X X (USE WITH RE508185 AND R39741) | | L62675 | ADAPTER FITTING | 1 | | | |
| 26 RE508185 FITTING 1 X X R34741) 27 U13639 O-RING 1 X X (USE WITH RE508185 AND R39741) | 25 | RE71255 | PIPE PLUG | 5 | | | 1/8"-27 NPT, (SUB FOR R119392, R104592 OR |
| | 26 | RE508185 | FITTING | 1 | X | X | R34741) |
| 27 R501277 FILTER HEAD 1 X X (FOR RE502422) | 27 | U13639 | O-RING | 1 | X | X | (USE WITH RE508185 AND R39741) |
| | 27 | R501277 | FILTER HEAD | 1 | X | X | (FOR RE502422) |

| KEY | PART NO. | PART NAME | QTY | SE6200 | SE6300 | REMARKS |
|-----|----------|-----------------|-----|--------|--------|------------------------------------|
| 20 | DEC07007 | DIDE DI LIC | 1 | V | V | 1/4"-18 NPT, (SUB FOR R55233, THIS |
| 28 | RE507807 | PIPE PLUG | 1 | X | X | APPLICATION) |
| 29 | R119874 | BUSHING | 1 | X | X | |
| 30 | 15H584 | PIPE PLUG | 1 | X | X | 1/2" |
| 31 | T23435 | THREADED NIPPLE | 1 | X | X | |
| 32 | 15H562 | PIPE PLUG | AR | X | X | 1" |
| 33 | R119210 | BUSHING | 6 | X | X | OD STD |
| 34 | 14H1076 | NUT | 1 | X | X | 3/8" |
| 35 | 15H685 | PIPE PLUG | AR | X | X | 1/4" |
| 36 | 19H2038 | CAP SCREW | AR | X | X | 3/8" X 1/2" |
| 37 | R62107 | WASHER | AR | X | X | |
| 38 | RE63674 | VALVE | AR | X | X | KIT |
| 39 | AT13740 | DRAIN VALVE | AR | X | X | |






John Deere > Agriculture > TRACTOR > SE6400 - TRACTOR > SE6100, SE6200, SE6300, SE6400 Tractors (Europe Edition) > 20 ENGINE > ST233986 - CAMSHAFT


| KEY | PART NO. | PART NAME | QTY | ALL | REMARKS | |
|-----|----------|--------------|-----|-----|---|--|
| 1 | RE55901 | CAMSHAFT | 1 | Х | (INCLUDES INSTRUCTIONS) (MARKED R115335 OR RE522312) (ALSO ORDER TY6333) | |
| 2 | T28041 | SHAFT KEY | 1 | X | 3.175 X 16.662 mm, (SUB FOR 26H72) | |
| 3 | | CAMSHAFT | 1 | X | A = 40 mm, (1.57"), (ORDER RE55901) (MARKED R115335 OR RE522312) | |
| 4 | T20073 | CAM FOLLOWER | 8 | X | | |
| 5 | R119874 | BUSHING | AR | X | | |
| 6 | 19H2676 | CAP SCREW | 2 | X | 3/8" X 1", (SAE 8) | |
| 7 | T20070 | HELICAL GEAR | 1 | X | Z = 48 | |
| 8 | T20072 | PLATE | 1 | X | | |





John Deere > Agriculture > TRACTOR > SE6400 - TRACTOR > SE6100, SE6200, SE6300, SE6400 Tractors (Europe Edition) > 20 ENGINE > ST233987 - BALANCER SHAFT

| KEY | PART NO. | PART NAME | QTY | SE6100 | SE6400 | REMARKS |
|-----|----------|----------------|-----|--------|--------|--|
| 1 | RE53082 | BALANCER SHAFT | 1 | X | Х | (KIT, RH) |
| 1 | RE56351 | BALANCER SHAFT | 1 | X | Х | (KIT, LH) |
| 2 | R88112 | PLATE | 1 | X | Х | |
| 3 | T28041 | SHAFT KEY | 1 | X | Х | 3.175 X 16.662 mm, (SUB FOR 26H72) |
| 4 | | BALANCER SHAFT | 1 | x | X | MARKED "R", (MARKED R54634), (ORDER RE53082) |
| 4 | | BALANCER SHAFT | 1 | X | Х | MARKED "L", (MARKED R54634), (ORDER RE56351) |
| 5 | R119210 | BUSHING | 3 | X | Х | OD STD |
| 6 | T15634 | NUT | 2 | X | X | |
| 7 | R54635 | WEIGHT | 2 | X | X | |
| 8 | T28745 | BOLT | 2 | X | Х | |
| 9 | 19H2021 | CAP SCREW | 4 | X | Х | 3/8" X 5/8" |
| 10 | 12H304 | LOCK WASHER | 4 | X | Х | 3/8" |
| 11 | T20130 | GEAR | 1 | X | X | Z = 12, RH, (FOR RE53082) |
| 11 | T20133 | GEAR | 1 | X | Х | Z = 12, LH, (FOR RE56351) |



Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com