

Section: ENGINE


AIR DUCTING LOWER PART

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|---|----------|---|----------------------|
| 1 | 02101745 | 1 | air duct |
| 2 | 02101802 | 1 | rubber |
| 3 | 01112299 | 1 | screw m 8 x 12, d933 |
| 4 | 01102799 | 2 | washer 8, d128 |
| 5 | 01107101 | 2 | washer 8.4 |
| 6 | 01110548 | 1 | screw m 8x12 d912 |



Section: ENGINE


LUFTFÜHRUNGS-OBERTEIL

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|---|----------|---|------------|
| 1 | 02101739 | 1 | connection |
| 2 | 01212482 | 1 | plug |
| 3 | 01212483 | 1 | stop |



Section: ENGINE


COOLING AIR BAFFLE

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|---|----------|---|-----------------------------|
| 1 | 01112232 | 4 | screw m 6 p.1 x 10 |
| 2 | 01102797 | 4 | washer 6, d128 |
| 3 | 01215850 | 4 | washer |
| 4 | 01112307 | 3 | screw m 8 p.1.25 x 15, d933 |
| 5 | 01107101 | 3 | washer 8.4 |
| 6 | 01102799 | 3 | washer 8, d128 |
| 7 | 02231907 | 1 | division |




Section: ENGINE
STANDBLECH (VORNE)

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:
 [2004 INTRAC]

| | | | |
|----|----------|---|----------------------|
| 1 | 01112240 | 1 | screw m 6 x 12 |
| 2 | 01102797 | 1 | washer 6, d128 |
| 3 | 01215850 | 1 | washer |
| 4 | 01112299 | 1 | screw m 8 x 12, d933 |
| 5 | 01107283 | 1 | washer 8.2 |
| 6 | 01107101 | 1 | washer 8.4 |
| 7 | 01112813 | 1 | nut m 6 |
| 8 | 01107095 | 1 | washer 6.4 |
| 9 | 02101698 | 1 | plate |
| 10 | 01167425 | 1 | rubber bushing |
| 11 | 01112240 | 1 | screw m 6 x 12 |
| 12 | 01102797 | 1 | washer 6, d128 |




Section: ENGINE
COVER PLATE

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:
 [2004 INTRAC]

| | | | |
|---|----------|---|-----------------|
| 1 | 02232810 | 1 | plate RIGHTS |
| 2 | 02232816 | 1 | gasket |
| 3 | 02232811 | 1 | plate LEFT |
| 4 | 02232816 | 1 | gasket |
| 5 | 01215850 | 4 | washer |
| 6 | 01112240 | 4 | screw m 6 x 12 |
| 7 | 01171586 | 4 | oil seal |



Section: ENGINE


EXHAUST MANIFOLD

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|---|----------|---|------------------|
| 1 | 03371689 | 4 | gasket |
| 2 | 01126895 | 8 | small column |
| 3 | 03316466 | 8 | nut |
| 4 | 02238668 | 1 | exhaust manifold |
| 6 | 01125788 | 1 | plug |



Section: ENGINE


GENERATOR

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]


| | | | |
|---|----------|---|--|
| 1 | 01171617 | 1 | dynamo EINZELTEILE SIEHE BILDTAFEL 502 7044 |
| 2 | 01133976 | 1 | pin m14x1,5 d936 |
| 3 | 01102802 | 1 | washer 14.2 |
| 4 | 01118325 | 1 | key |
| 5 | 01173068 | 1 | regulator |



Section: ENGINE

GENERATOR COMPONENT PARTS

| Fig. | P/n | QTY | Name |
|---------------|----------|-----|-----------------------------------|
| Notes: | | | |
| [2004 INTRAC] | | | |
| 1 | 01308012 | 1 | bearing |
| 2 | 01136912 | 1 | ball bearing |
| 3 | 01308014 | 1 | support |
| 4 | 01308456 | 1 | impeller |
| 5 | 01308457 | 1 | ring |
| 6 | 01138500 | 1 | ball bearing |
| 7 | 01308096 | 1 | bearing |
| 8 | 01306533 | 1 | diode |
| 9 | 01107544 | 3 | washer 5,3x10x1,0 |
| 10 | 01306413 | 3 | screw |
| 11 | 01306557 | 1 | regulator |
| 12 | 01306411 | 2 | spring |
| 13 | 01307794 | 1 | brush |
| 14 | 01308455 | 1 | u bolt |
| 15 | 01102796 | 3 | ring 5 |
| 16 | 02985171 | 3 | screw |
| 17 | 01126724 | 2 | spring disc |
| 18 | 01123576 | 2 | screw |
| 19 | 01306556 | 1 | diode |
| 20 | 01126725 | 1 | spring disc |
| 21 | 01105522 | 1 | screw |
| 22 | 01306558 | 1 | chassis frame |
| 23 | 01169028 | 2 | tube |
| 24 | 01308019 | 1 | spare parts kit |
| 25 | 01308020 | 1 | spare parts kit FUER KLEMME B. |
| 26 | 01308021 | 1 | spare parts kit FOR CLAMP D+ |



Section: ENGINE


DRIVING PARTS

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|---|----------|---|--------|
| 1 | 01163984 | 1 | fan |
| 2 | 01171413 | 1 | pulley |



Section: ENGINE


FASTENINGS

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|----|----------|---|-----------------------|
| 1 | 02241732 | 1 | console |
| 2 | 01123718 | 1 | - |
| 3 | 01122477 | 2 | nut m 8 p.1.25 |
| 4 | 01102659 | 2 | nut m 10, d934 |
| 5 | 01107105 | 1 | washer 10.5 |
| 6 | 01107101 | 4 | washer 8.4 |
| 7 | 01112439 | 1 | screw m 10 x 35, d933 |
| 8 | 01122397 | 2 | screw |
| 9 | 01112850 | 1 | nut |
| 10 | 02381307 | 1 | nut |
| 11 | 02242264 | 2 | bushing |
| 12 | 03363990 | 1 | bushing |
| 13 | 02242265 | 1 | link |
| 14 | 02242259 | 1 | screw |
| 15 | 02242261 | 1 | screw |



Section: ENGINE


NARROW V-BELT

| Fig. | P/n | QTY | Name |
|------|-----|-----|------|
|------|-----|-----|------|

Notes:

[2004 INTRAC]

| | | | |
|---|----------|---|--------------------------|
| 1 | 02235255 | 1 | small belt AV 10x1450 mm |
|---|----------|---|--------------------------|



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com