

Ref: B0.01.0 (1)





Ref: B0.01.2 (1)


Section: B0 - ENGINE CYLINDER LINER O-RING

	Fig.	P/n	QTY	Name
_				

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001]

16 2.1539.259.0 6 special oil seal 107.62x2.62




Ref: B0.01.4 (1)

MONOBLOC ENGINE-GEARBOX CONNECTING FLANGE

Section: B0 - ENGINE

Fig.	P/n	QTY	Name
Notes: [DORADO) 90 2WD -> ZKDBD50100'	FS300 01]	[DORADO 90 4WD -> ZKDBD50200TS30001]
1		1	0
1	0.007.7752.0/30	1	flange
2	2.0112.511.2	8	screw m 14 p.2 x 30
3	2.1651.912.0	2	cylindrical plug 12x28
4	2.1651.917.0	1	cylindrical plug 12x40
5	2.0432.257.7	1	stud bolt m 12 p.1.75 - 1.25 x 30
6	2.0439.250.7	1	stud bolt m 12 / m 10 x 30
7	0.011.9294.0/10	1	bush




Ref: B0.01.5 (1)

SIDE PLUG FOR CYLINDER BLOCK

Section: B0 - ENGINE

Fig.	P/n	QTY	Name
Notes:			
[DORADO	90 2WD -> ZKDI	3D50100TS30001]	[DORADO 90 4WD -> ZKDBD50200TS30001]

12	2.1560.018.0	1	gasket 22.2 x 29
	2110 00101010	-	8401100 2212 11 25
13	2.3120.102.0	1	plug



I9_K7815_03_0-B-001

Ref: B0.01.6 (1)

FITTING FOR ENGINE OIL PRESSURE SWITCH

Section: B0 - ENGINE

Fig.	P/n	QTY	Name
Notes:			
[DORAD	O 90 2WD -> ZKDBD5010	0TS30001]	[DORADO 90 4WD -> ZKDBD50200TS30001]
1	2.3120.101.0	1	plug m 18 p.1.5
2	2.1560.014.0	1	washer 18.2 x 24
3	2.3249.697.2	1	pipe union
4	2.1560.008.0	3	gasket 12.2 x 18
-			





Fig.	P/n	QTY	Name
Notes: [DORADO	90 2WD -> ZKDBD50100*	FS300 01]	[DORADO 90 4WD -> ZKDBD50200TS30001]
1	0.019.2255.3/20	1	crankshaft
1.2	0.007.0855.0/10	1	gear
1.3	2.1651.915.0	1	pin 12x35
7	0.019.5455.0	4	main half bushing STANDARD
8	0.019.5456.0	4	main half bushing STANDARD
9	2.1599.524.7	1	washer 21x60x12
10	0.065.1218.0	4	shim STANDARD
11	2.1529.073.0	1	special oil seal 110x130x13
12	0.065.1254.0/20	1	gasket
13	0.007.0851.0/10	1	cover
14	2.1475.002.7	9	washer 8.4
15	2.0112.207.2	7	screw m 8 p 1.25 x 20
20	2.0432.003.7	2	stud bolt m 8 p.1.25 / p.1 x 20
21	2.1011.405.2	2	nut m 8 p.1
1001	0.065.1218.7		shim + mm 0.10
1002	0.065.1218.8		$shim + mm \ 0.15$



I9_K7712_00_0-A-001

Ref: B0.02.2 (1)


Section: B0 - ENGINE CRANKSHAFT GEAR


|--|

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001]

1	0.019.4145.0	1	gear $z = 33$
2	2.1720.006.0	1	key 4x6.5





Ref: B0.02.4 (1)


Section: B0 - ENGINE CRANKSHAFT PULLEY Fig. P/n

ig.	P/n	QTY	Name

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001]

1	0.019.9925.0	1	pulley	
2	0.019.6668.0	1	flange	
3	0.065.1256.0	2	ring 45x52	
4	2.1579.865.0	1	spacer 45.2x51.8x10	
5	2.0439.195.7	1	stud bolt m 20 p.1.5x80	
6	2.1019.094.7	1	nut m 20 p.1.5	
7	2.0112.320.2	6	screw m 10 p.1.5 x 55	
8	2.1470.006.2	6	lock washer 10	
9	2.1720.006.0	1	key 4x6.5	
10	0.019.6413.0	1	gear wheel	
11	2.1651.505.0	1	cylindrical plug 6x12	



Ref: B0.02.6 (1)


Section: B0 - ENGINE CRANKSHAFT - FLYWHEEL

Fig.	P/n	QTY	Name

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001]

1	0.014.2774.3	1	flywheel
1.2	0.069.1242.0	1	crown wheel $Z = 121$
2	2.0399.368.0	6	screw



Ref: B0.02.9 (1)

COMPRESSOR DRIVEBELT


Section: B0 - ENGINE

Fig.	,	P/n	QTY	Name

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001]

3 2.4119.220.0 1 belt



Ref: B0.02.10 (1)


Section: B0 - ENGINE BELT AND TENSIONER

Fig. P/n QTY Name

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] 30003 <- [DORADO 90 4WD -> ZKDBD50200TS30001] 30003 <-

1	2.4119.218.0/10	1	belt PK 10 L=2017
2	0.021.4446.4	1	tensioner
3	0.019.9869.4/10	3	pulley guide
4	2.0312.214.2	5	screw m 8 p.1.25 x 40
5	0.020.4604.0	1	support
7	2.0399.380.2	1	screw
8	2.0399.379.2	1	small column
9	2.1480.015.2	1	washer 10
10	2.1480.014.2	5	washer 8
11	2.1310.004.2	2	flat washer 8.4x17
12	2.0314.322.2	1	screw
13	2.0112.209.2	2	screw m 8 p 1.25 x 25
14	2.1310.006.2	1	flat washer 10.5x21



Ref: B0.02.10 (2)

9_K7917_09_0-A-002

Section:	B0 - ENGINE		Ref: B0.02.10 (2	2)
BELT .	AND TENSIO	NER		
Fig.	P/n	QTY	Name	
Notes: [DORAD(D 90 2WD -> ZKDBE)50100TS30001]	[DORADO 90 4WD -> ZKDBD50200TS30001] -> 30004	

1	2.4119.218.0/10	1	belt PK 10 L=2017
3	0.019.9869.4/10	3	pulley guide
4	2.0312.214.2	5	screw m 8 p.1.25 x 40
5	0.020.4604.0	1	support
7	2.0399.380.2	1	screw
8	2.0399.379.2	1	small column
9	2.1480.015.2	1	washer 10
10	2.1480.014.2	5	washer 8
11	2.1310.004.2	2	flat washer 8.4x17
13	2.0112.209.2	2	screw m 8 p 1.25 x 25

Ref: B0.02.11 (1)

	9
9_K7917_10_0-/	4-001

Section: B0 - ENGINE **BELT AND TENSIONER**

_			_		
Fig	. P/n	QTY	Name		

Notes:

1

2

3

4 5

7

8

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001] 2.4119.219.0 1 belt PK 10 L=1498 0.021.4446.4 1 tensioner 0.019.9869.4/10 2 pulley guide 2.0312.214.2 5 screw m 8 p.1.25 x 40 0.020.4604.0 support 1 2.0399.380.2 screw 1 2 0200 270 2 mall only 1

2.0399.3/9.2	1	small column
2.1480.015.2	1	washer 10
2.1480.014.2	5	washer 8
2.1310.004.2	2	flat washer 8.4x17
2.0314.322.2	1	screw
2.0112.209.2	2	screw m 8 p 1.25 x 25
2.1310.006.2	1	flat washer 10.5x21

belt PK 10 L=1498

screw m 8 p.1.25 x 40

pulley guide

small column

flat washer 8.4x17

screw m 8 p 1.25 x 25

washer 10

washer 8

support

screw

Name

ΟΤΥ

1

2

5

1

1

1

1

5

2

2

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001]

Section: B0 - ENGINE

Fig.

Notes:

1 3

4

5

7

8

9

10

11

13

BELT AND TENSIONER

P/n

2.4119.219.0

2.0312.214.2

0.020.4604.0

2.0399.380.2

2.0399.379.2

2.1480.015.2

2.1480.014.2

2.1310.004.2

2.0112.209.2

0.019.9869.4/10

Ref: B0.02.11 (2)

9_K7917_10_0-A-002

Ref: B0.02.13 (1)


Section: B0 - ENGINE TENSION ROLLER

Fig.	P/n	ΟΤΥ	Name

Notes:

[DORADO 90 2WD -> ZKDBD50100TS30001] [DORADO 90 4WD -> ZKDBD50200TS30001] -> 30004

1	0.021.4446.4	1	tensioner
2	2.1310.006.2	1	flat washer 10.5x21
3	2.0314.322.2	1	screw



9_IB017_10_0-A-001

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com